Change Log for Xoptfoil-JX

[1.70] - 2021-12

This is a major functional release with some enhancements and new features. Have a look in the following feature list and the updated reference guide.

Xoptfoil-JX

- Dynamic weighting during optimization The weighting of all operating points having target values and all geometry targets will be automatically adjusted to ensure that targets will be uniformly reached. Dynamic weighting eliminates the tedious task of fine tuning the weighting of each op point to get good results. The new parameter dynamic_weighting in namelist &operating_conditions is active by default. Dynamic weightings can be watched with show_details = .true.
- Auto curvature control when using 'Hicks-Henne' shape functions. Right before optimization the
 various curvature parameters and constraints are evaluated based on the curvature quality of the seed
 airfoil and the initial values in the input file. During optimization these parameters are constrained to
 achieve best possible quality for the optimized airfoil. The parameter auto_curvature in namelist
 &curvature is active by default for Hicks-Henne shape functions.
 (This feature was already introduced in version 1.60 but didn't show the desired functionality)
- Auto retry of a single particle if its shape design fails due to geometry or curvature constraints. With
 auto retry the particle will have a second chance to create a valid design. Auto retry highly improves
 optimization speed. The parameter auto_retry is active by default for Hicks-Henne shape functions.
- Bubble detect of possible laminar separation bubble at an operating point. The detection is based on
 Xfoils TAU value (sheer stress getting < 0). Bubble detection does not directly affect the objective
 function but bubbles will influence the aerodynamic results. Bubble information will be displayed with
 activated show_details.
- Preset of thickness and/or camber of the seed airfoil when geometry targets or thickness/camber constraints are defined. This improves the quality of the initial designs for the particle swarm and reduces optimization time.
- New screen output during particle swarm optimization to get more details about the ongoing optimization of each op point. Use show details to activate the details.
- A full Xfoil polar will be generated for each new design (parameter generate_polar in namelist &polar_generation). This polar is used by the visualizer as additional information in the polar plots during optimization. This intermediate polar file uses the Xfoil polar format, so it can be imported into Xflr5 or Flow5.
- The temporary files to display the ongoing optimization with the visualizer moved to a subdirectory. This helps to keep working directory tidily.
- Revision of the Xoptfoil-JX documentation including the visualizer and Xfoil_worker. You will now find not only the subset of parameters which extend the original Xoptfoil, but a complete listing of

all parameters supported by Xoptfoil-JX including a bunch of tips for usage. Please have a read...

- New or improved example cases
- ... plus a lot of minor things ...

Breaking Changes

- All curvature related constraints moved from namelist &constraints to the new namelist &curvature
- Depricated curvature constraints: highlow_threshold max_curv_highlow_top max_curv_highlow_top max_spikes_top max_spikes_bot
- Deprciated geometry target types: zTop and zBot including their extra parameter x_pos
- Polar generation with Xptfoil-JX will now generate a single intermediate polar for each new design during optimization. This intermediate polar is used as a reference polar in the Viualizer. To create a polar set for the final, optimized airfoil, use the Xfoil_Worker (it will work like before).

Xoptfoil_visualizer-JX

- General revision of the visualizer with an additional plot for curvature and 3rd derivative of airfoil surface, new window sizes, colors, ...
- If available a real polar of the seed airfoil and the current design will pe plotted in the polar window (Xopfoil-JX option generate_polar). The polar is helpful for an early estimation of optimization success.

Have Fun!

[1.60] - 2020-11-27

This is a consolitation release with a bunch of smaller but nice enhancements and some refactorings inside the programm

Xoptfoil-JX

- More robust xfoil driver which reduces the situations, xfoil doesn't get convergence at an operating
 point. Switching on show_details the xfoil driver will give some information about iterations and
 retries.
- Auto-detection of curvature constraints especially when using 'Hicks-Henne' shape functions. The
 various curvature parameters will be automatically set to achieve best possible quality for the optimized
 airfoil based on the quality of the seed airfoil. The new parameter auto_curvature is active by default.
- Smoothing of the seed airfoil surface is now done automatically if the auto-detection of curvature signals too many 'spikes' on the surface. Again show_details will give some more information. The new default value is now do smoothing .true.
- New screen output during particle swarm optimization to get more details about the success of each
 particle. This greatly improves an understanding of the overall optimization process based on particle
 swarm. Use show_details to get more information about single operating points especially when
 using target_drag
- Multi-threading is now always active also if show_details = .true.

• Experimental: Retry of a single particle shape design if this design fails due to geometry constraints to improve optimization speed

• A lot of minor things...

Xfoil_worker

- Added new option -w set which allows to modify the geometry parameters like thickness, camber and their positions of maximum
- Added new option "-w check" to check the surface (curvature) quality of an airfoil and tell about best
 optimization options for the curvature. This is the same information as auto_curvature = .true.
 when using the optimizer.
- Added new option -w blend to blend an airfoil with another airfoil by xx%.

[1.52.1] - 2020-06-25

This is just a bugfix and maintenance release

Xoptfoil-JX

- Fix: When smoothing an exception occured when the number of spikes became 0
- Fix: Typo 'highlow_treshold'.

breakin change: All occurences of highlow_treshold in input files have to be changed in highlow_threshold

Xoptfoil_visualizer-JX

• In polar view little markers will show the value changes during optimization

Xfoil_worker

• added new option "-w flap" to set flap at an airfoil and generate a new airfoil with flap set

[1.52] - 2020-06-10

Xoptfoil-JX

- Normalization of the airfoil the optimized airfoil will be repaneled, moved, scaled and rotated to have the leading edge at 0,0 and the trailing edge at 1,0
 - depending on the repaneling result a new airfoil will have 200 or 201 points (if an additional leading edge point was added)
 - o breaking change as the new airfoil can differ a little from previous runs
- Revision of smoothing and bump prevention for Hicks Henne shape functions
 - o improved smoothing algorithm for the seed airfoil which now also includes leading edge area
 - new constraints max_curv_highlow_top and max_curv_highlow_top to limit the number of "bumps" at top and bottom side (default = 0)
 - moved parameter highlow_threshold from smoothing options to constraints namelist breaking change
 - added examples for smoothing

- see updated documentation for further information on smoothing and bump prevention
- New shape functions type 'camb-thick-plus' where upper and lower side of the airfoil is treated sperately when modifying the surface. This broadens and improves the usecases for this fast lane optimization type.
- Updated example of a 'high end F3F airfoil' to feature the capabilties of Xoptfoil-JX
- New utility tool Xfoil_worker to execute little jobs also convinient for automizations
 - o generate polars of an airfoil in xfoil format which can be imported directly in xflr5 or flow5
 - o normalize, optionally smooth an airfoil. Generates a 7 decimals airfoil file.
 - see documentation of Xfoil worker
- For Windows the programs will be linked 'static' so no more additional libraries are needed to run Xoptfoil-JX or Xfoil_worker
- Fixes
 - Different methods were used to calculate thickness and camber. This is now consistent taking the more precise method

Xoptfoil_visualizer-JX

- Fixes
 - new plot objects were added at each refresh. This slowed down the visualizer more and more during long optimizations
 - o removed flicker of the three plot windows

Thanks to Tobias for testing and advices, Alexander for his hint regarding smoothing algorithm - and of course to my super developer mate Matthias.

[1.51.0] - 2020-05-24

Xoptfoil-JX

- Revision of match_foils mode. Added ready to run examples to demonstrate the theoretical precision of Hicks-Henne or Camb-Thick based optimizations.
- New geometric constraint 'max_te_curvature' to handle curvature problems at TE when using Hicks-Henne shape functions
- Re-activated multi threading for optimization runs. Multi threading is switched off when 'show_details =
 .true.' is set to avoid mixed up console output.
- The smoothing option now affects only the seed airfoil at the beginning of an optimization. During optimization smoothing is switched off. The assessment of the surface is still active to detect bumps (High-Lows of curvature) experimental.
- The default value for the number of panels ('npan') used for xfoil calculations is now set to 201 (previously 160). This avoids discrepancies between the xfoil results during optimization and the properties of the final airfoil (which has 201 panels)
- Fixed: When creating 'initial designs' the xfoil calculation isn't called anymore. This speeds up 'initial designs' heavily.
- Code cleanings and minor bugs

Xoptfoil_visualizer-JX

created short documentation (Xoptfoil_visualizer-JX Reference.pdf)

- show points of transition laminar-turbulent in geometric view
- some code revisions ease setting of additional plot options (see documentation)

[1.50.1] - 2020-04-24

- fixed a bug for LINUX colored output
- fixed LINUX built to handle environment variables properly (thanks John)
- fixed display of airfoil name when generating polar

[1.50.0] - 2020-04-22

- Initial release with a compiled version for Windows
- ready to run examples in ./examples