Magic VLSI Cheatsheet

Harald Pretl Institute for Integrated Circuits, Johannes Kepler University Linz

© 2021-2022

This cheat sheet compiles useful commands (to be entered in the Tcl console) and bind keys (in the layout window) as well as a summary of the mouse operations for the different tool modes. This compilation relates to Magic 8.3 (see https://github.com/RTimothyEdwards/magic).

A comprehensive Magic documentation and description of all macros can be found at http://opencircuitdesign.com/magic/userguide.html.

The command macro layout in the Magic Tcl console lists all defined macros.

Useful commands:	
addpath [path]	add search path of cells
antennacheck	run antenna check on cell
array $xsize \ ysize$	array the selection <i>xsize</i> -times in X, <i>ysize</i> -times in Y, spacing by box
box [options]	print information about the box like b, or manipulate it in various ways
cif [options]	powerful command with various options (like generating mask layers, calculate density, etc.). Consult online help.
$\verb"contact" type"$	create contact inside box of intersecting layers
$\mathtt{copy}\ [to\ x\ y]$	copy to current cursor position or to x/y -position
corner $dir1$ $dir2$	draws a corner inside box, first in dir1, then in dir2
	(cf. fill)
drc find	locate DRC error
drc why	explain DRC errors in box
$\mathtt{dump}\ cell$	copy given <i>cell</i> into current layout cell
${ t erase} \ layers$	erase comma-separated list of <i>layers</i> in box
erase *	all layers but not labels
erase \$	erase everything (like CTRL-D)
erase labels	erase selected label(s) in box
fill dir	extend layers from one side of box to the other in the given <i>direction</i> (cf. corner)
$\verb findlabel label $	center the box on the <i>label</i>
${\tt flatten} cell$	flatten the current edit cell incl. hierarchy into a new $cell$
flush	revert edit cell to last state on disk
get $cell$	instantiate cell into current edit cell
goto $nodename$	move box to net <i>nodename</i> , throw error if not existing
help [pattern]	shows help for various commands
identify $cell$ - id	name the selected cell as <i>cell-id</i>
iroute	interactive point-to-point router, from cursor to box
label string [position	create a point, line or box label
[layer]]	-
${ t load} \stackrel{\scriptstyle n}{cell}$	open the <i>cell</i> in the layout window
	open the cest in the layout window

macro [window type] new macro definition

[key [value]]

measure [hor|ver|auto] create a ruler in the box

move x y move the selection to the x,y coordinate, or relative

by specifying direction and distance; parameters are in

lambda or in um

paint layers paint the comma-separated list of layers in box

plow dir move layout structures incl. connectivity in direction,

see manual

port make create a port from selected label

port index number assign a port index (must match the number from

schematic)

quit [-nocheck] exit magic (using -nocheck discards unsaved changes)

see [no] layers show or hide comma-separated list of layers

see [no] * show or hide all layers

select save file Save selection as new file.mag

select short label1 Find the path that electrically connects (shorts) the

label2 nodes labeled label1 and label2.

straighten dir try to repair jogs by pulling in direction

tool changes the currently used tool to (box, wiring, netlist,

pick)

redraw redraws the window unmeasure remove all rulers in box

what print information about the current selection xload cell open the cell in the layout window unexpanded

xview full view, with unexpanded cells

Bind keys:	
a	select everything in box
A	select additional objects in box
CTRL-A	deselect objects in box
b	print information about the box
В	center window on the box
С	сору
d	delete selection
CTRL-D	delete all layers and labels in box selected by cursor
е	makes the selected cell the new edit cell
F	flip the selection upside-down
g	toggle grid
G	toggle grid 2
i	select instance under cursor
I	select additional instance under cursor
CTRL-I	deselect instance under cursor
m	move selection to cursor position
0	openwindow (with current selection)
r	rotate 90 degree
R	rotate -90 degree
s	select objects under cursor
S	select additional objects under cursor
CTRL-S	deselect objects under cursor
u	undo the last operation
U	redo the last undo
v	view, full view of layout
W	writeall changed cells to disk
х	expand cells (make visible) in box
X	unexpand cells (hide) inside the box
CTRL-X	toggle the visibility of cells in box
У	drc why
z	zoom out
Z	zoom in
CTRL-Z	zoom in on box
>	edit the selected cell in layout window (cf. <)
<	return from editing a cell (cf. >)
,	clear selection
:	directly jump to command window (like VI)
SPACE	change the tool
SHIFT + SPACE	change to the box tool
KEYPAD-2	move selection south, equivalent to 'move s 1'
SHIFT + KEYPAD-2	stretch selection south, equivalent to 'stretch s 1'
KEYPAD-4	move selection west, equivalent to 'move w 1'
SHIFT + KEYPAD-4	stretch selection west, equivalent to 'stretch w 1'
KEYPAD-6	move selection east, equivalent to 'move e 1'
SHIFT + KEYPAD-6	stretch selection east, equivalent to 'stretch e 1'
KEYPAD-8	move selection north, equivalent to 'move n 1'
SHIFT + KEYPAD-8	stretch selection north, equivalent to 'stretch n 1'

Bind keys (IIC add-on):	
f	full layout view
CTRL-F	flip the selection sideways
k	measure (ruler)
K	remove rulers
p	draw a wiring path
q	open poperty dialog of p-cell
?	show what is contained in box
=	find DRC error(s) and zoom to it (thanks M. Guthaus)
0	show locali
!	show metal-1
@	show metal-2
#	show metal-3
\$	show metal-4
%	show metal-5
9	show all layers

Mouse operations:	
Box tool: LEFT RIGHT MIDDLE SHIFT + MIDDLE	set lower-left corner of box set upper-right corner of box paint layer pointed with cursor in box erase layer pointed with cursor in box
Layer selection tool: LEFT RIGHT	show selected layer, cf. see hide selected layer, cf. see no
Wiring tool: LEFT MIDDLE RIGHT SHIFT + LEFT SHIFT + RIGHT SHIFT + MIDDLE	pick wire material and size from cursor place wire at cursor cancel wire change to higher layer (e.g. m1 to m2) change to lower layer (e.g. m2 to m1) place a contact at cursor and continue on higher layer
Pick tool: LEFT MIDDLE RIGHT SHIFT + MIDDLE	remove current selection and follow cursor place a copy and continue cancel make a copy of selection and follow cursor