MSP430X port - small memory model version

Jean-Luc Béchennec

October 18, 2019

This document describes the small version for the CPUX of the Trampoline port on MSP430, which assumes that the code is hosted in the first 64kB of memory and therefore the addresses are stored on 16-bit words. Instruction set of the MSP430X is available in [4] or [3].

1 ABI

In [2] a change has been made in GCC so that it conforms to the ABI defined in [1] and becomes compatible with the proprietary Texas Instruments compiler. So there are two GCC compilers for MSP430: the one that does not conform to the ABI defined by Texas Instruments, MSPGCC, and the one that does conform to the ABI, GCC compiler for MSP.

As it is difficult to support both ABIs simultaneously, it was decided to support both ABIs at compile time. A precompiled MSPGCC is available in the latest version of Energia¹. Energia can be downloaded at https://energia.nu. A precompiled GCC compiler for MSP is available at http://www.ti.com/tool/msp430-gcc-opensource.

In both ABIs the registers used to pass arguments to functions are r12, r13, r14 and r15. In the ABI of MSPGCC, r15 is the first argument, r14 the second and so on. If a function returns a value, it is placed in r15. In the ABI of GCC compiler for MSP r12 is the first argument, r13 the second and so on. If a function returns a value, it is placed in r12. No Trampoline service uses more than 3 arguments and therefore r12, for MSPGCC ABI, or r15, for GCC compiler for MSP ABI, is available to pass the service ID into the wrapper.

Adapting to both ABIs at compile time is not very complicated. This involves exchanging the use made of the registers r12, identifying the service, and r15, the return value of the service and the argument of tpl_run_elected. This can be done by defining an abstract register to pass the service identifier and an abstract register to return the return value of the service. The register selection can be made using the preprocessor and the macro __GXX_ABI_VERSION as shown at Figure 1. This macro is 1002 for MSPGCC and 1011 for GCC compiler for MSP. 2 abstract registers are defined: REG_SID which is r12 in MSPGCC ABI

 $^{^{1}}$ GCC 4.6.3.

and r15 in GCC compiler for MSP ABI, and REG_RETARG which is r15 in MSPGCC ABI and r12 in GCC compiler for MSP ABI.

Figure 1: ABI selection with C preprocessor macros

```
#if __GXX_ABI_VERSION == 1002
/* MSPGCC ABI */
#define MSPGCC_ABI
#define REG_SID r12
#define REG_RETARG r15
#define REG_RETARG_OFFSET 8
#elif __GXX_ABI_VERSION == 1011
/* GCC compiler for MSP ABI */
#define GCCFORMSP_ABI
#define REG_SID r15
#define REG_RETARG_OFFSET 2
#define REG_RETARG_OFFSET 2
#else
#error "Unsupported ABI"
#endif
```

The following table summarizes the use of the registers in both ABIs if we consider all arguments are small enough to be stored in one register. Although r11 is volatile in one of them, for simplification purposes later on, r11 is considered as non-volatile. A preserved register is noted P and a Volatile register is noted V.

Register	MSPGCC	GCC compiler for MSP	
r0	Program Counter, saved on stack by cpu		
r1	Stack Pointer		
r2	Status Register		
r3	Constants Generator		
r4-r10	Not preserved by the callee		
r11	V	P	
r12	V, argument 4	V, argument 1, return value	
r13	V, argument 3	V, argument 2	
r14	V, argument 2	V, argument 3	
r15	V, argument 1, return value	V, argument 4	

It can be noted that the arguments being passed through the low weight 16 bits of the registers, except perhaps for the far pointers, the arguments of the Trampoline services must fit on 16 bits. This limits the tick argument of the services related to alarms to 16 bits.

2 Stack

A service call is done using the br instruction in the service call wrapper to prevent 2 nested call and fold the ret instruction. The service identifier is passed to the service call handler through the REG_SID register. So a service call wrapper is as shown in listing at figure 2.

Figure 2: Service wrapper

```
mov #<service_id>, REG_SID /* put the service id in the ad-hoc reg */
br #tpl_sc_handler /* branch to the service call handler */
```


When in the tpl_sc_handler the stack is as shown at figure 3². PTOS stands for *Process Top Of Stack*.

Figure 3: Stack at beginning of tpl_sc_handler



When an interrupt is taken into account, the PC and the SR are pushed on the stack. To save space, the SR is stored in the same 16-bit word as bits 19..16 of PC. For an obscure reason, words are in reverse order and bits 19..16 of PC are in high bits. Since all the code is in the first 64kb of the memory, bits 19 to 16 of the PC are always 0. The stack is shown at figure 4.

Figure 4: Stack in an interrupt handler



Preemption cases

A preemption can be synchronous or asynchronous. A synchronous preemption (SP) happens when a service call is done, for instance when a task activates a higher priority task. An asynchronous preemption (AP) happens under interrupt, for instance when a higher

²stacks are drawn with the lower address up so they are growing upward, not downward. Each stack location is a 16 bits word.

priority task is activated by an alarm. A preempted task may resume its execution following a synchronous event (SR): the running task calls TerminateTask, ChainTask, WaitEvent or SetEvent or following an asynchronous event (AR): an alarm does a SetEvent. So there are 4 cases:.

- **SPSR** Synchronous Preemption, Synchronous Resume. τ_1 is running, τ_2 is ready. $P(\tau_1) > P(\tau_2)$. τ_1 calls WaitEvent and is preempted synchronously, τ_2 becomes running and calls SetEvent. τ_2 is preempted and τ_1 is resumed synchronously.
- **SPAR** Synchronous Preemption, Asynchronous Resume. τ_1 calls WaitEvent and is synchronously preempted, An alarm does a SetEvent on τ_1 which is asynchronously resumed.
- **APSR** Asynchronous Preemption, Synchronous Resume. τ_1 is running, τ_2 is suspended. $P(\tau_1) < P(\tau_2)$. An alarm activates τ_2 , τ_1 is asynchronously preempted, τ_2 calls TerminateTask, τ_1 is synchronously resumed.
- **APAR** Asynchronous Preemption, Asynchronous Resume. τ_1 is running, τ_2 is suspended. $P(\tau_1) < P(\tau_2)$. An alarm activates τ_2 , τ_1 is asynchronously preempted. τ_2 is terminated by the OS because of protection fault, for instance a timing protection interrupt and τ_1 is asynchronously resumed.

So the stack frame has to be normalized. The normalized stack frame is the asynchronous one shown at figure 4 because it contains the Status Register. Normalization is done at the beginning of the tpl_sc_handler. The end of the tpl_sc_handler done using the reti instruction, as at the end of an interrupt.

The normalized stack frame may be done only when a context is saved to prevent a normalization if there is no context switch. However, the load of the context is much complicated, as the restauration of r2 (aka status register) in the tpl_sc_handlerre-enable the interrupts before the end of the function.

3 The tpl_sc_handler

The background color of the code snippets depends on the current active stack:

green process stack

red kernel stack

yellow either kernel or process stack

The first thing to do is to compare the service id to the number of services to verify its validity.


Disable interrupts so that the kernel cannot be interrupted. Check the reentrancy flag. If it is not zero, it means the service is called from a hook and has to be processed differently.

```
dint
tst.b &tpl_reentrancy_flag
jnz tpl_sc_handler_from_hook
```

We need to have the same stack pattern for both the tpl_sc_handler and an interrupt handler which calls the operating system. So we push the SR and we reset the 4 higher bits (high weight of PC, not sure it is needed) and set GIE in the saved SR.

```
push sr
bic.b #0xF0, 1(sp) /* reset the 4 higher bits of saved SR */
bis.b #0x08, 0(sp) /* set the GIE bit in the saved SR */
```

The stack is then as follow:



Obviously volatile registers (r12 to r15 because we take into account both ABIs) are not saved in tpl_sc_handler since the caller does not expect their values to be preserved but we need to make room (8 bytes) on the stack for them because an interrupt handler will save these registers at this location. However register names appear in figures but are in italic. Either r12 if MSPGCC ABI is used or r15 if GCC for MSP ABI is used is for the REG_RETARG which is not saved yet.

```
sub #8, sp
```


The tpl_sc_handler needs one working register and we choose to use r11 which has to be saved on the process stack before using it.

```
push r11
```

At that stage the stack is shown in figure 5.


Before calling the service, we setup the kernel stack. The process stack pointer (PSP) is saved in r11, then SP is loaded to the kernel stack bottom and the PSP is saved on the kernel stack.

Figure 5: Stack shape before calling the service



```
mov r1,r11
mov #tpl_kern_stack_bottom, r1
push r11
```

The kernel stack is as follow (KTOS stands for Kernel Top Of Stack):



Init the NEED_SWITCH/SAVE in tpl_kern.

```
mov #tpl_kern, r11
mov.b #NO_NEED_SWITCH_NOR_SCHEDULE, TPL_KERN_OFFSET_NEED_SWITCH(r11)
mov.b #NO_NEED_SWITCH_NOR_SCHEDULE, TPL_KERN_OFFSET_NEED_SCHEDULE(r11)
```

Call the service. The reentrancy flag is incremented before and decremented after.

```
inc.b &tpl_reentrancy_flag /* surround the call by inc ... */
rla REG_SID /* index -> offset */
call tpl_dispatch_table(REG_SID)
dec.b &tpl_reentrancy_flag /* ... and dec of the flag. */
```

From there, REG_RETARG holds the return value. It is put at its location in the process stack. Also r13 and r14 become usable whatever is the ABI.

Check the context switch condition in tpl_kern.

```
mov #tpl_kern, r11
tst.b TPL_KERN_OFFSET_NEED_SWITCH(r11)
jz tpl_sc_handler_no_context_switch
```

3.1 Branch of context switching

Prepare the call to tpl_run_elected by setting REG_RETARG to 0, aka no save.

```
mov #0, REG_RETARG
```

Test the NEED_SAVE condition.

```
bit.b #NEED_SAVE, TPL_KERN_OFFSET_NEED_SWITCH(r11)
jz tpl_sc_handler_no_save_running_context
```

Save the context. The MSP430 have a "push multiple words", but no "move multiple word". So, we get back to process stack to benefit this instruction

```
mov r1, r14 /* get a copy of the KSP to restore it later */
mov r13, r1 /* change stack to process stack */
pushm.w #7, r10 /* Push r4 to r10 on process stack (save) */
```

The whole context is now saved on process stack and the kernel stack has been cleaned. The saved context structure is shown at figure 6.

Now the stack pointer is saved in the dedicated location.

```
mov &tpl_kern, r11 /* Get the s_running slot of tpl_kern in r11 */
mov @r11, r11 /* Get the pointer to the context (SP alone) */
mov r1, @r11 /* Save the stack pointer */
```

Prepare the argument of tpl_run_elected: 1 (aka save) and call it after switching back to the kernel stack.

```
mov r14, r1  /* get back to kernel stack */
mov #1, REG_RETARG
tpl_sc_handler_no_save_running_context:
    call tpl_run_elected
```

tpl_run_elected has copied the elected process slot of tpl_kern to the running slot. We load the stack pointer of the new running process.

```
mov &tpl_kern, r11 /* Get the s_running slot of tpl_kern in r11 */
mov @r11, r11 /* Get the pointer to the context (SP alone) */

mov @r11, r1 /* Get the stack pointer */
```

Now, the context of the new running process is loaded. At start it has the same pattern as the one shown at figure 6. Registers r4 to r15 are popped and we return.

Figure 6: Context saved on stack

$\mathrm{SP} \!\! o \!\!$	saved r4		PTOS+0
	saved r5		PTOS+2
	saved r6		PTOS+4
	saved r7		
	saved r8		
	saved r9		
	saved r10		PTOS+12
	saved r11		PTOS+14
	$saved\ r12$ - REG_RETARG in GCC for MSP ABI		
	saved r13		PTOS+18
	saved r14		PTOS+20
	$saved\ r15$ - will hold REG_RETARG in MSPGCC ABI		PTOS+22
	0 0 0 0	saved SR	PTOS+24
		saved PC	PTOS+26
			\neg

```
popm.w #12,r15 /* Pop r4 to r15 at once */ reti /* and return with interrupts enabled */
```

3.2 Branch of No context switching

In case of no context switch, we have to get to the process stack, stored in r13

```
tpl_sc_handler_no_context_switch:
    mov r13, r1  /* get back to process stack */
```

Here we have the stack shaped as shown at figure 5. REG_RETARG is restored, r11 is restored, the stack is cleaned and we return. Interrupts are enabled at that time.

```
mov REG_RETARG_OFFSET(r1), REG_RETARG /* get back REG_RETARG */
pop r11 /* get back r11 */
add #8, r1 /* clean the stack */
reti /* return with int enabled */
```

3.3 Branch when the sc handler is called from hook

Here we are on the kernel stack already and the pc has been pushed on the stack by the call. REG_SID contains the identifier of the service and the 3 other registers contain the arguments if any. We do not need to do complicated stuff here because we have no context switch to do. We only call the service then return and that's it.

3.4 Context initialisation

The context that should be set during the task's initialisation (tpl_init_context) is the one of the figure 6, but with a call to either CallTerminateTask or CallTerminateISR2 as return address of the task/ISR2 function, depending of the type of the process to init.

SP-PTOS+0 r4PTOS+2r5PTOS+4 r6r7PTOS+6 PTOS+8 r8 PTOS+10 r9PTOS+12 r10 PTOS+14 r11r12 - REG_RETARG in GCC for MSP ABI PTOS+16PTOS+18 r13PTOS+20r15 - REG_RETARG in MSPGCC ABI PTOS+22 PTOS+24 $0\ 0\ 0\ 0$ SRPTOS+26 PCCallTerminateISR2 PTOS+28

Figure 7: Context initialization

Beside that, registers from r4 to r15 may be initialized to 0 or left uninitialized to save both execution time and energy consumption. PC has to be initialized to the address of the task/ISR2 function. SR has to be initialized with:

- v at 0
- SCG1, SCG0, OSCOFF and CPUOFF control the low power mode and are all at 0. This correspond to the Active Mode.
- GIE at 1 so interrupts are enabled when the task runs.
- N, z and c at 0.

So the initialization value of SR is 0x0008.

4 Interrupt Handlers

Interrupt handlers are generated from the OIL description. There are 3 categories of interrupt handlers in Trampoline which are handlers that link an interrupt vector to:

- the increment of one or more counters
- the execution of a category 1 ISR
- the execution of a category 2 ISR

The incrementation of a counter or the execution of a category 2 ISR involves an interaction with the OS with possible rescheduling and context switch, while the execution of a category 1 ISR does not involve an interaction with the OS.

For ISR 1 the interrupt handler will only backup the volatile registers, call the function implementing ISR 1 and restore the volatile registers. For ISR2 and counters, the handler will be similar to the one of the service call.

In addition, the interrupt vectors related to the GPIO ports, one vector for each port, are shared among the I/O pins of the port.

Interrupt vectors are defined in templates/config/msp430x/small/msp430fr5969/config.oil file. The following vectors are available and can be used as SOURCE attribute is ISR and COUNTER objects:

- AES256_VECTOR,
- RTC_VECTOR,
- PORT4_VECTOR,
- PORT3_VECTOR,
- TIMER3_A1_VECTOR,
- TIMER3_AO_VECTOR,
- PORT2_VECTOR,
- TIMER2_A1_VECTOR,

- TIMER2_AO_VECTOR,
- PORT1_VECTOR,
- TIMER1_A1_VECTOR,
- TIMER1_AO_VECTOR,
- DMA_VECTOR,
- USCI_A1_VECTOR,
- TIMERO_A1_VECTOR,
- TIMERO_AO_VECTOR,
- ADC12_VECTOR,
- USCI_BO_VECTOR,
- USCI_AO_VECTOR,
- WDT_VECTOR,
- TIMERO_B1_VECTOR,
- TIMERO_BO_VECTOR,
- COMP_E_VECTOR,
- UNMI_VECTOR

Several ISR or COUNTER objects cannot share the same SOURCE.

The SystemCounter uses the TIMER3_AO_VECTOR and is defined as follow in templates/config/msp430x/small/msp430fr5969/config.oil file:

```
COUNTER SystemCounter {
   SOURCE = TIMER3_AO_VECTOR;
};
```

When a PORTx_VECTOR source is used, a bit sub-attribute can be added to select which bit is used as interrupt source. In this case several ISR or COUNTER may share the same vector but shall be of the same type. In other words 2 counters may share the same port vector, each on its bit or 2 ISR 1 or 2 ISR 2 but you can't have a counter and an ISR sharing the same port vector or an ISR 1 and an ISR 2.

Examples can be found in examples/msp430x/small/msp430fr5969/launchpad. In readbutton_isr1, an ISR 1 is linked to button S1 which is connected to bit 5 of PORT4:

```
ISR buttonS1 {
   CATEGORY = 1;
   PRIORITY = 1;
   SOURCE = PORT4_VECTOR {
    BIT = 5;
   }; /* Button S1 is on GPIO port 4, bit 5 */
};
```

readbutton_isr2 is the same example but with an ISR 2 instead of the ISR 1.

4.1 Vector table generation

The OIL compiler generates the vector table according to what SOURCE are used in the OIL file. For instance here is the vector table generated for readbutton_isr1 example:

```
_attribute__ ((section(".isr_vector")))
CONST(tpl_it_handler, AUTOMATIC) tpl_it_vectors[26] = {
  /* OxFFCC, AES256_VECTOR
                                   */ (tpl_it_handler)tpl_null_it,
  /* OxFFCE,
  /* OxFFCE, RTC_VECTOR
/* OxFFDO, PORT4_VECTOR
                                   */ (tpl_it_handler)tpl_null_it
                                      (tpl_it_handler)tpl_direct_irq_handler_PORT4_VECTOR,
  /* 0xFFD2, PORT3_VECTOR
                                      (tpl_it_handler)tpl_null_it,
  /* OxFFD4, TIMER3_A1_VECTOR */
/* OxFFD6, TIMER3_A0_VECTOR */
                                     (tpl_it_handler)tpl_null_it,
                                      (tpl_it_handler)tpl_primary_irq_handler_TIMER3_AO_VECTOR,
  /* OxFFD8, PORT2_VECTOR */
/* OxFFDA, TIMER2_A1_VECTOR */
/* OxFFDC, TIMER2_A0_VECTOR */
                                      (tpl_it_handler)tpl_null_it,
                                      (tpl_it_handler)tpl_null_it,
                                      (tpl_it_handler)tpl_null_it,
  /* OxFFDE,
              PORT1_VECTOR
                                      (tpl_it_handler)tpl_null_it
  /* OxFFEO, TIMER1_A1_VECTOR */
                                      (tpl_it_handler)tpl_null_it,
  /* OxFFE2, TIMER1_AO_VECTOR
                                      (tpl_it_handler)tpl_null_it,
  /* OxFFE4, DMA_VECTOR
                                      (tpl_it_handler)tpl_null_it
  /* OxFFE6, USCI_A1_VECTOR
                                      (tpl_it_handler)tpl_null_it,
                                      (tpl_it_handler)tpl_null_it,
  /* OxFFE8, TIMERO_A1_VECTOR */
  /* OxFFEA, TIMERO_AO_VECTOR
                                      (tpl_it_handler)tpl_null_it
  /* OxFFEC, ADC12_VECTOR
/* OxFFEE, USCI_BO_VECTOR
                                      (tpl_it_handler)tpl_null_it,
                                      (tpl_it_handler)tpl_null_it,
  /* OxFFFO, USCI_AO_VECTOR
                                      (tpl_it_handler)tpl_null_it
  /* OxFFF2, WDT_VECTOR
                                      (tpl_it_handler)tpl_null_it,
  /* OxFFF4, TIMERO_B1_VECTOR */
/* OxFFF6, TIMERO_BO_VECTOR */
/* OxFFF8, COMP_E_VECTOR */
                                      (tpl_it_handler)tpl_null_it,
                                      (tpl_it_handler)tpl_null_it,
                                      (tpl_it_handler)tpl_null_it,
  /* OxFFFA, UNMI_VECTOR
                                      (tpl_it_handler)tpl_null_it
     OxFFFC, SYSNMI_VECTOR
                                      (tpl_it_handler)tpl_MPU_violation,
  /* OxFFFE, RESET_VECTOR
                                   */ (tpl_it_handler)tpl_reset_handler
```

Obviously the last 2 vectors, SYSNMI_VECTOR and RESET_VECTOR, are not usable by the application and are reserved to Trampoline.

4.2 ISR 1 interrupt handler


An ISR 1 handler has a name formed from the concatenation of tpl_direct_irq_handler_ and the name of the source. For instance an ISR 1 handler for the PORT4_VECTOR has the name tpl_direct_irq_handler_PORT4_VECTOR.

When entering the ISR, the stack is as shown at figure 4 and PC (r0) and SR (r2) have been saved. Before doing anything we have to save the volatile registers, which are r11³ to r15.

```
tpl_direct_irq_handler_PORT4_VECTOR:
   pushm.w #5, r15 /* Push r11, r12, r13, r14 and r15 */
```

As a result the stack is as follow:

³r11 is not volatile in the *MSPGCC* ABI but is volatile in *GCC compiler for MSP* ABI. Anyway, in order to limit variabilility, r11 is saved for both ABIs.



If the vector is not a port vector, the code is straightforward.

```
call #buttonS1_function
```

If the vector is a port vector but no bit is specified, the ack of the interrupt is added.

```
call #buttonS1_function
mov #0,__P4IV
```

If the vector is a port vector and a bit is specified, the generated code follows the Texas Instruments recommendations as outlined in section 12.2.6.1 of [3].

```
add
            &__P4IV, pc
  jmp
            tpl_direct_irq_handler_exit_PORT4_VECTOR
            tpl_direct_irq_handler_exit_PORT4_VECTOR
                                                             /* bit 0 */
  jmp
            tpl_direct_irq_handler_exit_PORT4_VECTOR
                                                             /* bit 1 */
  jmp
            tpl_direct_irq_handler_exit_PORT4_VECTOR
                                                             /* bit 2 */
  jmp
                                                             /* bit 3 */
  jmp
            tpl_direct_irq_handler_exit_PORT4_VECTOR
  jmp
            tpl_direct_irq_handler_exit_PORT4_VECTOR
                                                             /* bit 4 */
            tpl_p4_5_handler
                                                             /* bit 5 */
  jmp
            tpl_direct_irq_handler_exit_PORT4_VECTOR
                                                             /* bit 6 */
  jmp
            tpl_direct_irq_handler_exit_PORT4_VECTOR
                                                             /* bit 7 */
  jmp
tpl_p4_5_handler:
            #buttonS1_function
 call
tpl_direct_irq_handler_exit_PORT4_VECTOR:
```

Then the volatile registers are restored and we return.

```
popm.w #5, r15
reti
```

4.3 ISR 2 interrupt handler

An ISR 2 handler has a name formed from the concatenation of tpl_primary_irq_handler_and the name of the source. For instance an ISR 2 handler for the PORT4_VECTOR has the name tpl_primary_irq_handler_PORT4_VECTOR.

When entering the ISR, the stack is as shown at figure 4 and PC (r0) and SR (r2) have been saved. Before doing anything we have to save the volatile registers, which are r11 to r15.

```
tpl_primary_irq_handler_PORT4_VECTOR:
   pushm.w #5, r15 /* Push r11, r12, r13, r14 and r15 */
```

Then we switch to the kernel stack and init tpl_kern.

```
mov r1, r11 /* Copy the PSP in r11 */
mov #tpl_kern_stack + TPL_KERNEL_STACK_SIZE, r1 /* kernel stack */
push r11 /* Save PSP to kernel stack */
mov #tpl_kern, r11
mov.b #NO_NEED_SWITCH_NOR_SCHEDULE, TPL_KERN_OFFSET_NEED_SWITCH(r11)
mov.b #NO_NEED_SWITCH_NOR_SCHEDULE, TPL_KERN_OFFSET_NEED_SCHEDULE(r11)
```

Activate the ISR 2. Here the #1 in mov #1, REG_RETARG is the identifier of the ISR 2. Only the most complex generated code is shown.

```
add
            &__P4IV, pc
            tpl_direct_irq_handler_exit_PORT4_VECTOR
  jmp
            tpl_direct_irq_handler_exit_PORT4_VECTOR
                                                              /* bit 0 */
  jmp
            tpl_direct_irq_handler_exit_PORT4_VECTOR
                                                              /* bit 1 */
  jmp
            \verb|tpl_direct_irq_handler_exit_PORT4_VECTOR||
                                                              /* bit 2 */
  jmp
                                                              /* bit 3 */
            tpl_direct_irq_handler_exit_PORT4_VECTOR
  jmp
                                                              /* bit 4 */
  jmp
            tpl_direct_irq_handler_exit_PORT4_VECTOR
  jmp
            tpl_p4_5_handler
                                                              /* bit 5 */
            tpl_direct_irq_handler_exit_PORT4_VECTOR
                                                              /* bit 6 */
 jmp
                                                              /* bit 7 */
            tpl_direct_irq_handler_exit_PORT4_VECTOR
 jmp
tpl_p4_5_handler:
            #1, REG_RETARG
 mov
            #tpl_fast_central_interrupt_handler
  call
```

The remaining code is similar to the one of the tpl_sc_handler.

```
tpl_direct_irg_handler_exit_PORT4_VECTOR:
            r1, r13 /* get a copy of the KSP to restore it later
 mov
                                                                          */
 add
            #2, r13 /* and forget the pushed PSP (not useful anymore).
                                                                          */
            r1
                    /* get the saved process stack pointer back
                                                                          */
 pop
 mov
            #tpl_kern, r11
 tst.b
            TPL_KERN_OFFSET_NEED_SWITCH(r11)
 įΖ
            tpl_PORT4_VECTOR_no_context_switch
            #7, r10 /* Push r4 to r10 */
 pushm.w
            &tpl_kern, r11 /* Get the s_running slot of tpl_kern in r11 */
 mov
            @r11, r11
                           /* Get the pointer to the context (SP alone) */
 mov
                           /* Save the stack pointer
            r1, @r11
                                                                          */
 mov
            r13, r1
                            /* Switch back to the kernel stack
                                                                          */
 mov
            #1, REG_RETARG
 mov
            #tpl_run_elected
 call
            &tpl_kern, r11 /* Get the s_running slot of tpl_kern in r11 */
 mov
            @r11, r11
                            /* Get the pointer to the context (SP alone) */
 mov
```

4.4 Counter interrupt handler

A counter interruption handler has the same structure as that of an ISR 2. The only difference is the function called. For instance for the SystemCounter the code is straightforward.

```
tpl_primary_irq_handler_TIMER3_AO_VECTOR:
* -1- Before doing anything we have to save the volatile registers, which
* are r11 (r11 is not volatile in the MSPGCC ABI but is volatile in GCC
* compiler for MSP ABI. Anyway, in order to limit variabilility, r11 is
* saved for both ABIs) to r15, because they will not be saved when we will
* call the underlying C function.
 pushm.w #5, r15 /* Push r11, r12, r13, r14 and r15 */
* -2- Switch to the kernel stack.
                                        /* Copy the PSP in r11
 mov
         r1, r11
         #tpl_kern_stack + TPL_KERNEL_STACK_SIZE, r1 /* kernel stack */
 mov
                           /* Save PSP to kernel stack */
         r11
 push
* -3- Init the NEED_SWITCH/SAVE in tpl_kern.
 mov
         #tpl_kern, r11
         #NO_NEED_SWITCH_NOR_SCHEDULE, TPL_KERN_OFFSET_NEED_SWITCH(r11)
 mov.b
         #NO_NEED_SWITCH_NOR_SCHEDULE, TPL_KERN_OFFSET_NEED_SCHEDULE(r11)
\ast -4- Call the underlying C function.
*/
        #tpl_tick_TIMER3_AO_VECTOR
 call
/*----
* -5- Switch back to the process stack
*/
tpl_direct_irq_handler_exit_TIMER3_A0_VECTOR:
         r1, r13 /* get a copy of the KSP to restore it later
                                                                  */
           \#2, r13 /* and forget the pushed PSP (not useful anymore). */
 pop
          r1 /* get the saved process stack pointer back
* -6- Check the context switch condition in tpl_kern.
*/
           #tpl_kern, r11
 mov
```

```
TPL_KERN_OFFSET_NEED_SWITCH(r11)
       tpl_TIMER3_AO_VECTOR_no_context_switch
 jz
* -7- Save the rest of the context.
 pushm.w #7, r10 /* Push r4 to r10 */
* -8- Now the stack pointer is saved in the dedicated location.
         &tpl_kern, r11 /* Get the s_running slot of tpl_kern in r11 */
 mov
 mov
         @r11, r11 /* Get the pointer to the context (SP alone) */
        r1, @r11 /* Save the stack pointer
/*-----
* -9- Call tpl_run_elected with argument 1 (aka save) after switching back
* to the kernel stack.
*/
       r13, r1
                    /* Switch back to the kernel stack
                                                       */
 mov
 mov
        #1, REG_RETARG
      #tpl_run_elected
 call
/*----
* -10- tpl_run_elected has copied the elected process slot of tpl_kern to
* the running slot. We load the stack pointer of the new running process.
*/
         &tpl_kern, r11 /\ast Get the s_running slot of tpl_kern in r11 \ast/
 mov
         Or11, r11 /* Get the pointer to the context (SP alone) */
        @r11, r1
                   /* Get the stack pointer
/*----
* -11- Now, the context of the new running process is loaded. All registers
* are popped.
       #12,r15 /* Pop r4 to r15 */
 popm.w
/*----
* -12- We get here from stage 6. Restore the volatile registers and return
* from the interrupt handler.
tpl_TIMER3_A0_VECTOR_no_context_switch:
popm.w #5, r15
 reti
```

5 MCU Clocks

The MCU clocks is set to 1MHz at startup (defined in tpl_startup.c). It uses the DCO as input clock, and a user fonction is provided to update the frequency in tpl_clocks.h:

```
/* configure the frequency in MHz: 1,2,4,6,8,12,16,(21,24 overclock)
 * set to 1MHz in case of bad input frequency.
 **/
```

```
FUNC(void,OS_CODE) tpl_set_mcu_clock(uint16_t freq);
```

When the CPU clock is updated, the Wait States for the FRAM access are set accordingly: 1 wait state above 8MHz, and 2 wait states above 16MHz.

Note that the $21\mathrm{MHz}$ and $24\mathrm{\ MHz}$ frequencies overclock the CPU capabilities and may not work.

References

- [1] Texas Instruments. MSP430 Embedded Application Binary Interface. Technical report, Texas Instruments incorporated, June 2013.
- [2] Texas Instruments. Calling Convention and ABI Changes in MSP GCC. Technical report, Texas Instruments Incorporated, February 2015.
- [3] Texas Instruments. MSP430FR58xx, MSP430FR59xx, and MSP430FR6xx Family User's Guide. Technical report, Texas Instruments Incorporated, December 2017.
- [4] Texas Instruments. MSP430x5xx and MSP430x6xx Family User's Guide. Technical report, Texas Instruments Incorporated, March 2018.