


Physical Layer



OSI Layer1: Physical Layer

- Type of Network
- LAN Media
- UTP for Ethernet
- Media and signal Problems
- Basic Knowledge of Data Communication

Type of Networks



Type of Networks

- ☐ Shared media environment
 - ■Multiple hosts can access the same medium.
 - □It means that they all share the same media even though the "wire" might be UTP, which has four pairs of wire
- □ Point-to-point network environment
 - □One device is connected to the other one via a link
 - ■Most widely used in dial-up network connections, and is the one with which you are most likely familiar.


OSI Layer1: Physical Layer

- Type of Network
- LAN Media
- UTP for Ethernet
- Media and signal Problems
- Basic Knowledge of Data Communication


LAN Media


- Function is to transmit data
- Transmission process is referred to as encoding
- Cable types include STP, UTP, coaxial, fiber-optics

Representations of Signals on the Physical Media




Sample electrical signals transmitted on copper cable





Microwave (wireless) signals


LAN Media--UTP



- ◆ Speed and throughput: 10 100 Mbps
- Average \$ per node: Least Expensive
- Media and connector size: Small
- Maximum cable length: 100m (short)

- □relies solely on the cancellation effect, produced by twisted wire pairs to limit signal degradation caused by EMI and RFI
- has four pairs of copper wire
- □has impedance of 100 Ohms

LAN Media—Advantages of UTP




- easy to install and is less expensive
- costs less per meter than any other type of LAN cabling
- □small external diameter does not fill up wiring ducts as rapidly as other types of cable
- ☐ is installed <u>using an RJ connector</u>
 so potential sources of network
 noise are greatly reduced and a
 good solid connection is practically
 guaranteed

LAN Media—Disadvantages of UTP


- Cable is more prone to electrical noise and interference than other types of networking media
- distance between signal boosts is shorter for twisted-pair than for coaxial and fiber-optics

LAN Media--Coaxial



- □ *Thinnet/thicknet*
- □longer network runs without using repeaters than twisted-pair
- □less expensive than fiber but more expensive than twisted-pair

LAN Media—Fiber-Optic



- ◆ Speed and throughput: 100+ Mbps
- Average \$ per node: Most Expensive
- Media and connector size: Small
- ◆ Single mode, maximum cable length: Up to 3000m
- Multimode mode, maximum cable length: Up to 2000m
- Single mode: One stream of laser-generated light
- ◆ Multimode: Multiple streams of LED-generated light

- conducts modulated light transmission
- □not susceptible to EMI or RFI and is capable of higher data rates than other networking media
- electromagneticwaves are guidedthrough optical fiber

Fiber-Optic Mode Types

□Single Mode


- also called axial: light travels down the axis of the cable
- faster than multimode (up to 10 Gbps) because of the dispersion in multimode
- typically used for WANS
- smaller in diameter than multimode (less dispersion)
- ■uses ILD most often but also LED

□Multimode

- light enters the glass pipe at different angles and travels nonaxially, which means it bounces back and forth off the walls of the glass tube
- larger than single mode, used most often in LANS
- susceptible to greater dispersion

Wireless Communication

Encoding Signals as Electromagnetic Waves



☐ The primary way of distinguishing between different electromagnetic waves is by their frequency.(frequency multiplexing)

Wireless Transmission Methods

Lasers

output a coherent electromagnetic field in which all waves are at the same frequency and are aligned in a phase

Infrared

- normally a line-of-sight technology but can be bounced or redirected
- cannot go through opaque objects

Radio

- carry data signals that can pass through walls
- both terrestrial and satellite radio technologies

OSI Layer1: Physical Layer

- Type of Network
- LAN Media
- UTP for Ethernet
- Media and signal Problems
- Basic Knowledge of Data Communication

Cable Specification and Termination

- ☐ The standards for networking media were developed and issued by the following groups:
 - ■IEEE—Institute of Electrical and Electronics Engineers
 - **■UL**—Underwriters Laboratories
 - ■EIA—Electronic Industries Alliance
 - ■TIA—Telecommunications Industry Association
 - ■ANSI—American National Standards Institute

TIA/EIA Standards

TIA/EIA-568A

Commercial Building Telecommunications Cabling Standard

TIA/EIA-569A

Commercial Building Standard for Telecommunications Pathways and Spaces

TIA/EIA-570A

Residential and Light Commercial Telecommunications Wiring Standard

TIA/EIA-606

Administration Standard for the Telecommunications Infrastructure of Commercial Buildings

TIA/EIA-607

Commercial Building Grounding and Bonding Requirements for Telecommunications

Category of UTP

- □ 一类线: 主要用于语音传输, 不用于数据传输
- □ 二类线: 传输频率1MHz,用于语音和最高4Mbps的数据传输,常见于令牌网
- □ **三类线**: EIA/TIA568标准指定电缆,传输频率16MHz,用于语音传输及最高传输速率为10Mbps的数据传输,主要用于10BASE-T
- □ 四类线: 传输频率为20MHz,用于语音传输和最高传输速率16Mbps的数据传输,主要用于令牌网和 10BASE-T/100BASE-T
- □ 五类线: 增加了绕线密度, 外套高质量绝缘材料, 用于语音和数据传输(主要为100/1000BASE-T), 是最常用的以太网电缆
- □ 超五类线: 衰减小, 串扰少, 具有更高的衰减/串扰比和信噪比、更小的时延误差, 主要用于1000BASE-T
- □ 六类线: 传输频率为1MHz~250MHz,性能远高于超五类标准,适用于高于1Gbps的应用
- □ 七类线: 带宽为600MHz, 可能用于今后的10G比特以太网。

Type of Cable

- ■Straight Cable
- ■Rollover Cable

Crossover Cable


Creating a Straight-Through Cable

Cut a Length of Cable


Strip off the Jacket




Separate the Wires



Untwist the Wires



Organize and Flatten Wires



Clip the Wires



Insert Wires into RJ-45 Plug



Push the Wires in



Inspect the Color Code



Crimp down the Wires



Inspect Both Ends





Test the Quality of Cable



Straight Cable

100-Ohm balanced twisted-pair telecommunication outlet/connector





W-G G W-O BI W-BI O W-Br Br

W-O O W-G BI W-BI G W-Br Br

Straight cable: use T568A on both ends or T568B on both ends

Rollover Cable

□Alias: console cable

- □ is used to connect a workstation or terminal to the console port of a router/switch to configure it
- □Pin 1 on one end connects to Pin 8 on the other end; then Pin 2 connects to Pin 7, Pin 3 to Pin 6 and so on

Configuring Devices with Console



- Connect the serial port (com) of computer by using RJ-45-to-DB-9 adapter
- Start up "super terminal"
- Use "default configurations"

Crossover Cable

- pairs 2 and 3 on one end of the cable will be reversed on the other end
 - □T568-A on one end and T568-B on the other
- is considered to be part of the "vertical" cabling/ backbone
- can be used to
 - connect two or more hubs or switches
 - connect two isolated workstations to create a mini-LAN

OSI Layer1: Physical Layer

- Type of Network
- LAN Media
- UTP for Ethernet
- Media and signal Problems
- Basic Knowledge of Data Communication

- Propagation
 - travel time; speed depends upon medium
 - As data transmission rates increase, you must sometimes take into account the amount of time it takes the signal to travel.
- Attenuation
 - loss of signal over distance due to surroundings
 - can affect a network because it limits the length of network cabling over which you can send a message

■ Reflection

- Caused by discontinuities in the medium
- Occurs in electrical signals; can be a result of kinks in cable or poorly terminated cables
- Networks should have a specific impedance to match the electrical components in the NICs
- The result of impedance mismatch is reflected energy.


■ Noise

- unwanted additions to optical/electromagnetic signals
- Crosstalk—electrical noise from other wires in a cable
- EMI (electromagnetic interference) can be caused by electric motors.
- Cancellation of signals can be avoided through the twisting of wire pairs to provide selfshielding within the network media.


- ☐ Timing problem
 - <u>Dispersion</u>—signal broadens in time
 - can be fixed by proper cable design, limiting cable lengths, and finding the proper impedance
 - <u>Jitter</u>—source and destination not synchronized
 - can be fixed through hardware and software including protocols
 - Latency—delay of network signal

Collisions and Collision Domains

- A collision occurs when two bits propagate at the same time on the same network.
- Collision domains are extended by adding repeaters and hubs.
- Networks can be segmented by adding intelligent devices such as bridges, switches, and routers.



Segmenting Collision Domains



OSI Layer1: Physical Layer

- Type of Network
- LAN Media
- UTP for Ethernet
- Media and signal Problems
- Basic Knowledge of Data Communication

数据通信基本知识

- □ 数据通信的理论基础
 - 基本术语
 - 信号处理
 - 波特率与比特率
- □ 数据通信技术
 - 数据通信系统基本结构
 - 数据表示和传输方式
 - 信号的传输
 - 数字信号编码
 - 多路复用
 - 通信方式

基本术语

- □ 信号(signal)——数据的电气的或电磁的表现。
 - "模拟的" (analogous)——消息的参数的取值是连续的
 - □ 模拟信号是随时间变化而平稳变化的连续波形式
 - "数字的" (digital)——消息的参数的取值是离散的
 - □ 数字信号是离散信号,可能包含有限的几个预定值
- □ 码元(code)——在使用时间域(或简称为时域)的波形表示数字信号时,代表不同离散数值的基本波形。

理论基础:信号处理

- 模拟信号可以被分为简单信号和复合信号
 - ■简单信号(正弦波)不能被分解为更简单的模拟信号
 - ■复合信号可以被分解为多个正弦波
- ■复合模拟信号的分解: 傅立叶分析
 - ■任何一个周期为T的有理周期性函数 g(t)可分解为若干项(可能无限多项)正弦和余弦函数之和:

$$g(t) = \frac{1}{2} c + \sum_{n=1}^{\infty} a_n \sin(2\pi n f t) + \sum_{n=1}^{\infty} b_n \cos(2\pi n f t)$$


f = 1/T 基本频率; a_n , b_n . n次谐波项的正弦和余弦振幅值


理论基础:信号处理

- □ 数字信号一般是非周期性的,通常在传输介质上表现为方波
- □ 一个数字信号可以分解为无穷多个被称为谐波的简单正弦波, 每个谐波都具有不同的频率与相位
- □ 在介质上发送数字信号时,其实质是在发送无穷多的简单谐波,如果某些分量未能忠实地通过介质传输,则在接收端将产生信号畸变
- □ 由于介质本身的限制,信号畸变是难以完全避免的
- □ 任何实际的信道都不是理想的,在传输信号时会产生各种失真以及带来多种干扰。
- □ 码元传输的速率越高,或信号传输的距离越远,在信道的输出端的波形的失真就越严重

数字信号通过实际的信道

□ 有失真,但可识别






发送信号波形

□ 失真大,无法识别



实际的信道 (带宽受限*、*有噪声*、*干扰和失真)

发送信号波形



接收信号波形

无噪声信道的最高传输速率

□ 1924 年,奈奎斯特(Nyquist) 指出在假定无噪声的信道上,为避免码间串扰,传输比特率的上限值为:

$C=W \log_2 L bps$

- W 为信道的带宽(以 Hz 为单位)
- L为表示数据的信号电平的数量
- □ 在任何信道中,码元传输的速率是有上限的,否则就会出现码间串扰的问题,使接收端对码元的判决(即识别)成为不可能。
- □ 如果信道的频带越宽,也就是能够通过的信号高频分量越 多,那么就可以用更高的速率传送码元而不出现码间串扰

噪声信道的最高传输速率

- □ 香农(Shannon)用信息论的理论推导出了带宽 受限且有高斯白噪声干扰的信道的极限、无差 错的信息传输速率
- □ 信道的极限信息传输速率 C 可表达为 $C = W \log_2(1+S/N)$ bps
 - W 为信道的带宽(以 Hz 为单位);
 - S为信道内所传信号的平均功率;
 - N 为信道内部的高斯噪声功率
 - S/N称为信噪比

香农公式的含义

- □ 信道带宽或信道的信噪比越大,极限传输速率越高
- □ 只要信息传输速率低于信道的极限信息传输速率,就 一定有办法实现无差错的传输
- □ 若信道的带宽 W 或信噪比 S/N 没有上限(实际不可能),则其极限信息传输速率 C 也没有上限
- □ 实际能够达到的传输速率比香农极限传输速率低不少
- □ 请注意:对于频带宽度已确定的信道,即使信噪比不能再提高,且码元速率已达上限,也有办法提高传输速率。这就是用编码的方法让每个码元携带更多比特


的信息量

理论基础:波特率和比特率

- 波特率(baud)和比特率(bit)
 - 波特率(调制速率):信号每秒钟变化的次数
 - 比特率: 每秒钟传送的二进制位数。
- 波特率与比特率的关系取决于信号值与比特位的关系
 - 例:每个信号值表示为3位,则比特率是波特率的3倍; 每个信号值表示为1位,则比特率和波特率相同
 - 对于比特率为a bps的信道,发送 8 位所需的时间为 8/a秒,若 8 位为一个周期 T ,则一次谐波的频率是:

f = a/8 Hz


数据通信系统的模型



数据通信技术: 数字数据编码

- □ 基带: 基本频带, 指传输变换前所占用的频带, 是原始信号所固有的频带
- 基带传输:在传输时直接使用基带数字信号(不转换为模拟信号,即不调制)
 - 基带传输是一种最简单最基本的传输方式,一般 用低电平表示"0",高电平表示"1"
 - 适用范围: 低速和高速的各种情况。
 - 限制: 因基带信号所带的频率成分很宽, 所以对 传输线有一定的要求

将数字数据转换到模拟信号:调制




将数字数据转换到数字信号:线路编码

Line coding means to convert the binary data into a form that can travel on a physical communications link such as an electrical pulse on a wire, a light pulse on an optical fiber, or an electromagnetic wave in space

数据通信技术:编码方式

- 编码方式可分为三类:
 - 单极性编码
 - 极化编码
 - NRZ(Non-Return to Zero, 不归零制码)
 - RZ(Return to Zero, 归零制码)
 - 双相位编码
 - 曼彻斯特码
 - 差分曼彻斯特码
 - 双极性编码
 - <u>传号交替反转码(AMI)</u>
 - 双极性8连0替换码(B8ZS)
 - 3阶高密度双极性码(HDB3)

单极性编码



- 原理:
 - 用0电平表示"0",正电平表示"1"
- 缺点:
 - 难以分辨一位的结束和另一位的开始
 - 发送方和接收方必须有时钟同步
 - 若信号中"0"或"1"连续出现,信号直流 分量将累加,单极性编码的直流分量问题严重
- 结论:容易产生传播错误

极化编码


——不归零制码(NRZ: Non-Return to Zero)

- 不归零电平编码
 - 原理: 用负电平表示"0",正电平表示"1" (或相反)
 - 缺点:
 - ■难以分辨一位的结束和另一位的开始
 - ■发送方和接收方必须有时钟同步
 - 尽管不会如单极性编码严重,但若信号中"0" 或"1"连续出现,信号直流分量仍将累加


极化编码

——不归零制码(NRZ: Non-Return to Zero)

- 不归零反相编码
 - 原理:信号电平的一次翻转代表比特1,无电 平变化代表0
 - 不归零反相编码优于不归零电平编码:由于每次遇到"1"(或"0")都要发生跃迁,因此可以根据电平跃迁进行有限的同步




- ——归零制码(RZ: Return to Zero)
- 原理:用负电平表示"0",正电平表示"1"(或相反),比特中位跳变到零电平,从而提供同步
- 优点:信号本身带有同步信息,经济性好,且不易出错
- 缺点:需要采用三个不同电平,两次信号变化来编码1比特,因此增加了占用的带宽



——曼彻斯特码(Manchester)


- 原理:每一位中间都有一个跳变,从低跳到高表示"**0**", 从高跳到低表示"**1**"
 - 请思考: "00" "01" 曼彻斯特编码下应怎样表示?
 - 优点:克服了NRZ码的不足。每位中间的跳变既可作为数据,又可作为时钟,能够自同步;同时只采用两个电平,跳变减少,比RZ码效率更高



——差分曼彻斯特码(Differential Manchester)

- 原理:
 - 每一位中间跳变:表示时钟
 - 每一位位前跳变:表示数据
 - 有跳变表示"0",无跳变表示"1"
- 优点: 时钟、数据分离, 便于提取


——差分曼彻斯特码(Differential Manchester)



双极性编码:

——双极性传号交替反转码(AMI)


- 与RZ相同的是: 采用三个电平: 正、负与零
- 与RZ不同的是:零电平表示"O",正负电平的跃迁表示"1",实现对"1"电平的交替反转。
- 优点:
 - 对每次出现的"1"交替反转,使直流分量为0
 - 尽管连续"0"不能同步,但连续"1"可以同步



数据通信技术:多路复用

■ 多路复用技术

■ 由于一条传输线路的能力远远超过传输一个用户信号所需的能力,为了提高线路利用率,经常让多个信号共用一条物理线路



多路复用

时分复用

TDM (Time Division Multiplexing)

频分复用

FDM (Frequency Division Multiplexing)

波分复用


WDM (Wavelength Division Multiplexing)

码分复用

CDM (Code Division Multiplexing)


时分复用TDM (Time Division Multiplexing)

- □ 时分复用是将时间划分为一段段等长的时分复用(TDM)帧,每个时分复用的用户在每个 TDM 帧中占用固定序号的时隙。
- □ 每一个用户所占用的时隙是周期性地出现
- □ TDM 信号也称为等时(isochronous)信号。
- □ 时分复用的所有用户在不同的时间占用同样的频带宽度




时分复用可能会造成线路资源的浪费

使用时分复用系统传送计算机数据时,由于计算机数据的突发性质,用户对分配到的子信道的利用率一般不高。



统计时分复用 STDM (Statistic TDM)




频分复用 FDM (Frequency Division Multiplexing)

- □ 用户在分配到一定的频带后,在通信过程中自始至终都占 用这个频带。
- □ 所有用户在同样的时间占用不同的带宽资源(请注意,这 里的"带宽"是频率带宽)

频率

频率 5 频率 4 频率 3 频率 2 频率 1

波分复用 WDM (Wavelength Division Multiplexing)



码分复用 CDM (Code Division Multiplexing)

- □ 常用的名词是码分多址 CDMA(Code Division Multiple Access)
- □ 各用户使用经过特殊挑选的不同码型,因此彼此不会造成干扰。
- □ 这种系统发送的信号有很强的抗干扰能力,其频谱类似于白噪声,不易被敌人发现

