# WiFiMCU Reference Book

Doit

2015-8-25

WiFiMCU Reference Book	1
Lua Basic Modules	5
MCU Module	5
Function List	5
Constant	5
mcu.ver()	5
mcu.info()	6
mcu.reboot()	6
mcu.mem()	7
mcu.chipid()	7
mcu.bootreason()	7
GPIO Moduls	9
Function List	9
Constant	9
GPIO Pin Table	
gpio.mode	
gpio.read()	11
gpio.write()	11
gpio.toggle()	
TIMER Module	
Function List	
Constant	
tmr.start()	
tmr.stop()	
tmr.stopall()	
tmr.tick()	
tmr.delayms()	
tmr.wdclr()	
WiFi Module	
Function list	
Constant	
wifi.startap()	
wifi.startsta()	
wifi.scan()	
wifi.stop()	
wifi.powersave()	
wifi.ap.getip()	
wifi.ap.getipadv()	
wifi.ap.stop()	
wifi.sta.getip()	
wifi.sta.getipadv()	
wifi.sta.getlink()	
wifi.sta.stop()	22

Net	Module	23
	Function list.	23
	Constant	23
	net.new()	23
	net.start()	23
	net.on()	24
	net.send()	25
	net.close()	25
	net.getip()	26
File	Module	27
	Function list.	27
	Constant	27
	file.format()	27
	file.open()	28
	file.close()	28
	file.write()	29
	file.writeline()	29
	file.read()	29
	file.readline()	30
	file.list()	31
	file.slist()	31
	file.remove()	31
	file.seek()	32
	file.flush()	32
	file.rename()	32
	file.info()	33
	file.state()	33
	file.compile()	34
	dofile()	34
PW	M Module	35
	Function list	35
	Constant	35
	Pin Table	35
	pwm.start()	35
	pwm.stop()	35
AD	C Module	37
	Function list.	37
	Constant	37
	Pin Table	37
	adc.read()	37
UA	RT Module	
	Function list.	
	Constant	
	uart.setup()	
	- ·	

38
39
39
39
39
39
40

# **Lua Basic Modules**

The Lua interpreter in WiFiMCU is based on Lua 5.1.4.

The following modules are supported:

luaopen_base	Supported
luaopen_package	Supported
luaopen_string	Supported
luaopen_table	Supported
luaopen_math	Supported

<sup>&#</sup>x27;io' and 'debug' modules are not supported.

The functions description in supported modules can be found at:

http://www.lua.org/manual/5.1/

# **MCU Module**

# **Function List**

mcu.ver()	Get the WiFiMCU firmware version
mcu.info()	Get the mxchipWNet library version, MAC address, WLAN driver version
mcu.reboot()	Reboot WiFiMCU
mcu.mem()	Get the memory status
mcu.chipid()	Get the stm32 chip ID (96 bits)
mcu.bootreason()	Get the WiFiMCU boot reason that cause its startup

# **Constant**

nil

# mcu.ver()

## Description

Get the WiFiMCU firmware version.

#### Syntax

nv,bd=mcu.ver()

#### **Parameters**

nil

```
Returns
```

```
nv: string type, WiFiMCU firmware version bd: string type, build date of the firmware
```

### **Examples**

```
>nv,bd=mcu.ver()
>print(nv,bd)
>WiFiMCU 0.9.3 build 20150818
```

# mcu.info()

### **Description**

Get the mxchipWNet library version, MAC address, WLAN driver version.

### **Syntax**

```
libv,mac,,drv=mcu.info()
```

#### **Parameters**

nil

#### Returns

libv: mxchipWNet library version mac: MAC address of the module drv: WLAN driver version

#### **Examples**

```
>libv,mac,drv=mcu.info()
>print(libv,mac,drv)
>31620002.031 C8:93:46:50:21:4C wl0: Dec 29 2014 14:07:06 version 5.90.230.10
FWID 01-9bdaad4d
```

# mcu.reboot()

### **Description**

Reboot WiFiMCU immediately.

#### **Syntax**

mcu.reboot()

#### **Parameters**

nil

### Returns

nil

### **Examples**

> mcu.reboot()

# mcu.mem()

### **Description**

Get the memory status.

### **Syntax**

fm,tas,mtas,fc=mcu.mem()

#### **Parameters**

nil

#### Returns

fm: Total free space

tas: Total allocated space

mtas: Maximum total allocated space

fc: Number of free chunks

### **Examples**

>fm,tas,mtas,fc=mcu.mem()

>print(fm,tas,mtas,fc)

> 35600 50416 86016 25

# mcu.chipid()

## Description

Get the stm32 chip ID (96 bits).

### **Syntax**

chipid= mcu.chipid()

#### **Parameters**

nil

### Returns

chipid: the stm32 chip product ID

### **Examples**

> chipid= mcu.chipid()

> print(chipid)

0200C000 FDFFFAE005DFF000

# mcu.bootreason()

## Description

Get the WiFiMCU boot reason that cause its startup.

### **Syntax**

bootreason= mcu. bootreason()

### **Parameters**

nil

#### Returns

bootreason: The boot reason should be one the followings:

"NONE": Fail to get the boot reason

"SOFT\_RST": Software reset
"PWRON\_RST": Power on reset

"EXPIN\_RST": Pin reset

"WDG\_RST": Independent Watchdog reset
"WWDG\_RST": Window Watchdog reset
"LOWPWR\_RST": Low Power reset
"BOR\_RST": POR/PDR or BOR reset

## **Examples**

> mcu.bootreason()

SOFT\_RST

# **GPIO Moduls**

# **Function List**

gpio.mode()	Define the GPIP Pin mode, set the pin to input output or interrupt mode
gpio.read()	Read the pin value
gpio.write()	Set the pin value
gpio.toggle()	Toggle the pin's output value

# Constant

	1
gpio.INPUT	Input with an internal pull-up resistor
gpio.INPUT_PULL_UP	Input with an internal pull-up resistor
gpio.INPUT_PULL_DOWN	Input with an internal pull-down resistor
gpio.INPUT_INPUT_HIGH_IMPEDANCE_DOWN	Input high impedance down
gpio.OUTPUT	Output actively driven high and actively
	driven low
gpio.OUTPUT_PUSH_PULL	Output actively driven high and actively
	driven low
gpio.OUTPUT_OPEN_DRAIN_NO_PULL	Output actively driven low but is
	high-impedance when set high
gpio.OUTPUT_OPEN_DRAIN_PULL_UP	Output actively driven low and is pulled
	high with an internal resistor when set
	high
gpio.INT	Interrupt
gpio.HIGH	High voltage level
gpio.LOW	Low voltage level

# **GPIO Pin Table**

WiFiMCU Index	Alternative	Discription
	Function	
D0	GPIO/BOOT	WiFiMCU would enter into Bootloader
		Mode, if D0 goes to LOW
D1	GPIO/PWM/ADC	
D2	GPIO	
D3	GPIO/PWM	

D4	GPIO	
D5	GPIO	SWD Flash Programming Pin: swclk
D6	GPIO	SWD Flash Programming Pin: swdio
D7	GPIO	
D8	GPIO/PWM	Uart1 rx pin: RX1
D9	GPIO/PWM	Uart1 tx pin: TX1
D10	GPIO/PWM	I2C interface: SCL
D11	GPIO/PWM	I2C interface: SDA
D12	GPIO/PWM	
D13	GPIO/PWM/ADC	
D14	GPIO/PWM	
D15	GPIO/PWM/ADC	
D16	GPIO/PWM/ADC	
D17	GPIO/ADC	A LED is connected on WiFiMCU board

# gpio.mode

### **Description**

Define the GPIP Pin mode, set the pin to input output or interrupt mode.

#### **Syntax**

```
gpio.mode(pin, mode)
gpio.mode(pin, gpio.INT, trigMode, func_cb)

Parameters
pin: gpio ID, 0~17
mode: Should be one of the followings:
gpio.INPUT
```

gpio.INPUT\_PULL\_UP
gpio.INPUT\_PULL\_DOWN
gpio.INPUT\_INPUT\_HIGH\_IMPEDANCE\_DOWN
gpio.OUTPUT
gpio.OUTPUT\_PUSH\_PULL
gpio.OUTPUT\_OPEN\_DRAIN\_NO\_PULL

gpio.OUTPUT\_OPEN\_DRAIN\_PULL\_UP

gpio.INT

trigMode: if mode is gpio.INT, trigMode should be:

'rising': Interrupt triggered at input signal's rising edge 'falling': Interrupt triggered at input signal's falling edge

'falling': Interrupt triggered at input signal's falling edge 'both': Interrupt triggered at both rising and falling edge

func\_cb: if mode is gpio.INT, the interrupt call back function

Note: It's recommend that DO NOT do too much time consumption operations in the func\_cb.

#### Returns

nil

### **Examples**

```
>gpio.mode(0, gpio.OUTPUT)
>gpio.write(0, gpio.HIGH)
>gpio.mode(1,gpio.INPUT)
>print(gpio.read(1))
>0
```

# gpio.read()

## Description

Read the pin value.

### **Syntax**

value=gpio.read(pin)

#### **Parameters**

pin: gpio ID, 0~17

### Returns

value: 0 - low, 1 - high

### **Examples**

```
>gpio.mode(0, gpio.INPUT)
>print(gpio.read(0))
>0
```

# gpio.write()

### **Description**

Set the pin value.

#### **Syntax**

gpio.write(pin, value)

### **Parameters**

pin: gpio ID, 0~17

value: 0 or 1 or gpio.HIGH or gpio.LOW

### Returns

nil

## **Examples**

```
>gpio.mode(0, gpio.OUTPUT)
>gpio.write(0,gpio.HIGH)
> gpio.write(0,0)
```

# gpio.toggle()

### **Description**

Toggle the pin's output value

```
Syntax
```

gpio.toggle(pin)

# **Parameters**

pin: gpio ID, 0~17

# Returns

nil

- >gpio.mode(17, gpio.OUTPUT)
- >gpio.toggle(17)
- >gpio.toggle(17)

# **TIMER Module**

# **Function List**

tmr.start()	Start a timer with call back function
tmr.stop()	Stop a timer
tmr.stopall()	Stop all the timer
tmr.tick()	Get the current time tick of the MCU (ms) since startup
tmr.delayms()	Delay for a assigned time in micro senconds
tmr.wdclr()	Clear the Independent watchdog counter

# **Constant**

nil

# tmr.start()

## **Description**

Start a timer with call back function.

## **Syntax**

tmr.start(tmrID, interval, func\_cb)

#### **Parameters**

tmrID: timer ID, 0~15. 16 timers are supported at present

interval: interval time for the timer

func\_cb: Callback function for the timer

#### Returns

nil

## **Examples**

> tmr.start(1,1000,function() print("tmr1 is called") end)

> tmr1 is called

tmr1 is called

tmr1 is called

# tmr.stop()

## Description

Stop a timer

### **Syntax**

```
tmr.stop(tmrID)
Parameters
    tmrID: timer ID, 0~15
Returns
    nil
Examples
    > tmr.start(1,1000,function() print("tmr1 is called") end)
    > tmr1 is called
    tmr1 is called
    tmr1 is called
    >tmr. stop(1)
tmr.stopall()
Description
    Stop all the timer.
Syntax
    tmr.stopall(tmrID)
Parameters
    nil
Returns
    nil
Examples
    >tmr. stopall()
tmr.tick()
Description
    Get the current time tick of the MCU (ms) since startup.
Syntax
    tick=tmr.tick()
Parameters
    nil
Returns
    nil
Examples
    >print(tmr.tick())
    1072237
```

# tmr.delayms()

## Description

Delay for a assigned time in micro seconds.

## **Syntax**

tmr.delayms(ms)

## **Parameters**

ms: The delay time in micro seconds

### Returns

nil

## **Examples**

> tmr.delayms(1000)

# tmr.wdclr()

## Description

Clear the independent watchdog counter. The default independent watchdog time is 10 senconds

Note: This function should be called if some operations cost over 10 seconds.

## **Syntax**

tmr. wdclr ()

### **Parameters**

nil

### Returns

nil

## **Examples**

> tmr.wdclr()

# WiFi Module

# **Function list**

wifi.startap()	Setup wifi in soft Access Point (AP) Mode, enable DHCP	
	function	
wifi.startsta()	Setup wifi in Station Mode (STA), begin to connect a AP	
wifi.scan()	Scan APs	
wifi.stop()	Close all the Wi-Fi connections, Both in station mode and soft ap	
	mode	
wifi.powersave()	Enable IEEE power save mode	
wifi.ap.getip()	Get ip address in soft AP mode	
wifi.ap.getipadv()	Get advanced net information in soft AP mode: DHCP mode, ip	
	address, gateway, netmask, dns, MAC, broad cast address	
wifi.ap.stop()	Close all the Wi-Fi connections in soft ap mode	
wifi.sta.getip()	Get ip address in STA mode	
wifi.sta.getipadv()	Get advanced net information in STA mode: DHCP mode, ip	
	address, gateway, netmask, dns, MAC, broad cast address	
wifi.sta.getlink()	Get the connected AP information in STA mode:Connect status,	
	WiFi signal strength, ssid, bssid.	
wifi.sta.stop()	Close all the Wi-Fi connections in STA mode	

# **Constant**

nil

# wifi.startap()

## Description

Setup wifi in soft Access Point (AP) Mode, enable DHCP function.

#### **Syntax**

```
wifi.startap(cfg)
wifi.startap(cfg,func_cb)
```

### **Parameters**

cfg: lua table, contains the configurations for soft AP mode.

cfg.ssid: soft AP's ssid

cfg.pwd: soft AP's password. It will be an open WiFi if cfg.pwd is empty cfg.ip: optional. The local ip address of the module, It's "11.11.11.1" in default.

cfg.netmask: optional. Netmask. It's "255.255.255.0" in default. cfg.gateway: optional. Gateway. It's "11.11.11.1" in default.

```
cfg.dnsSrv: optional. DNS server address. It's "11.11.11.1" in default.
```

cfg.retry interval: optional. retry interval in micro seconds. It's 1000ms in default.

func\_cb: The callback function when the soft AP is setup successfully or the soft AP is shut down. Function prototype is: func\_cb(info). "info" is the information indicates the event: "STATION\_UP", "STATION\_DOWN", "AP\_UP", "AP\_DOWN", "ERROR"

#### Returns

nil

#### **Examples**

```
>cfg={}
>cfg.ssid="WiFiMCU_Wireless"; cfg.pwd=""
>wifi.startap(cfg)
```

# wifi.startsta()

## **Description**

Setup wifi in Station Mode (STA), begin to connect a AP.

#### **Syntax**

```
wifi.startsta(cfg)
wifi.startsta(cfg, func cb)
```

#### **Parameters**

cfg: lua table, contains the configurations for soft AP mode.

cfg.ssid: AP's ssid

cfg.pwd: AP's password

cfg.dhcp: optional. Set dhcp function: 'enable' is to enable the dhcp client function. WiFiMCU will get ip automatically. 'disable' is to disable the dhcp client function. It's 'enable' in default.

cfg.ip: optional. The local ip address of the module. If cfg.dhcp is 'disable' this parameter must be assigned.

cfg.netmask: optional. Netmask. If cfg.dhcp is 'disable' this parameter must be assigned.

cfg.gateway: optional. Gateway. If cfg.dhcp is 'disable' this parameter must be assigned.

cfg.dnsSrv: optional. DNS server address. If cfg.dhcp is 'disable' this parameter must be assigned.

cfg.retry\_interval: optional. retry interval in micro seconds. If cfg.dhcp is 'disable' this parameter must be assigned.

func\_cb: The callback function when WiFiMCU had connected to the AP successfully, or WiFiMCU is disconnected to from the AP. Function prototype is: func\_cb(info). "info" is the information indicates the event: 'STATION\_UP', 'STATION\_DOWN', 'AP\_UP', 'AP\_DOWN', 'ERROR'

#### Returns

nil

```
>cfg={}
>cfg.ssid="Doit"; cfg.pwd="123456789"
```

# wifi.scan()

#### **Description**

Scan AP list and return a Lua table contains the results.

#### **Syntax**

```
wifi.scan(fun_cb(t))
```

#### **Parameters**

func\_cb(t): The callback function when scan is finished. 't' is a Lua table in which the keys are the APs' ssid and values are strings in format ("mac, signal strength, channel, authmode")

#### **Returns**

nil

### **Examples**

> function listap(t) if t then for k,v in pairs(t) do print(k.."\t"..v);end else print('no ap') end end

> wifi.scan(listap)

CMCC-WEB 00:23:89:22:98:B0,90,11,OPEN

MERCURY 44B6 C0:61:18:21:44:B6,75,6,WPA2 AES

Tomato 8C:28:06:1E:01:54,100,11,WPA2 AES

ChinaNet-mALi 8C:E0:81:30:C1:95,65,10,WPA2 AES

Wireless 00:25:12:62:A6:36,57,6,OPEN

CMCC 00:23:89:22:98:B1,87,11,WPA2 AES

CMCC-FREE 00:23:89:96:02:03,60,11,OPEN

Doit BC:D1:77:32:E7:2E,100,1,WPA2 AES

# wifi.stop()

### **Description**

Close all the Wi-Fi connections, Both in station mode and soft ap mode.

#### **Syntax**

wifi.stop()

#### **Parameters**

nil

### Returns

nil

#### See also

wifi.ap.stop()

wifi.sta.stop()

#### **Examples**

> wifi.stop()

# wifi.powersave()

### **Description**

Enable IEEE power save mode.

### **Syntax**

wifi. powersave ()

#### **Parameters**

nil

#### Returns

nil

### **Examples**

> wifi. powersave ()

# wifi.ap.getip()

### **Description**

Get ip address in AP mode

### **Syntax**

ip=wifi. ap.getip()

#### **Parameters**

nil

#### Returns

ip: The module ip in soft AP mode.

## Examples

```
> ip=wifi.ap.getip ()
> print(ip)
11.11.11.1
```

# wifi.ap.getipadv()

### **Description**

Get advanced net information in soft AP mode: DHCP mode, ip address, gate way, net mast, dns, MAC, broad cast address.

### **Syntax**

```
dhcp,ip,gw,nm,dns,mac,bip =wifi. ap.getipadv()
```

#### **Parameters**

nil

#### Returns

```
dhcp: DHCP mode. in soft AP mode, it will be always "DHCP_Server" ip: ip address.
gw: gateway address.
nm: netmask.
```

```
dns: dns address.
mac: MAC address.
bip: broadcast ip address.

Examples

> dhcp,ip,gw,nm,dns,mac,bip =wifi.ap.getipadv()

>print(dhcp,ip,gw,nm,dns,mac,bip)

DHCP_Server 11.11.11.1 11.11.11.1 255.255.255.0 208.67.222.222 c89346501a62
255.255.255.255
```

# wifi.ap.stop()

## Description

Close all the Wi-Fi connections in soft ap mode.

#### **Syntax**

wifi.ap.stop()

### **Parameters**

nil

### Returns

nil

#### See also

wifi.stop()
wifi.sta.stop()

### **Examples**

> wifi.ap.stop()

# wifi.sta.getip()

## Description

Get ip address in STA mode.

#### Syntax

ip=wifi. sta.getip()

## **Parameters**

nil

#### Returns

ip: The module ip in STA mode.

```
> ip=wifi.sta.getip ()
> print(ip)
192.168.1.108
```

# wifi.sta.getipadv()

### **Description**

Get advanced net information in STA mode: DHCP mode, ip address, gateway, netmask, dns, MAC, broad cast address.

#### **Syntax**

```
dhcp,ip,gw,nm,dns,mac,bip =wifi. sta.getipadv()
```

#### **Parameters**

nil

#### Returns

```
dhcp: DHCP mode. in STA mode, "DHCP_Server" or "DHCP_Client" or DHCP_Disable ip: ip address.
gw: gateway address.
nm: netmask.
dns: dns address.
mac: MAC address.
bip: broadcast ip address.
```

#### **Examples**

```
> dhcp,ip,gw,nm,dns,mac,bip =wifi.sta.getipadv()
>print(dhcp,ip,gw,nm,dns,mac,bip)
DHCP_Client 192.168.1.108 192.168.1.1 255.255.255.0 192.168.1.1 c89346501a62
255.255.255.255
```

# wifi.sta.getlink()

#### **Description**

Get the connected AP information in STA mode:Connect status, WiFi signal strength, ssid, bssid.

### **Syntax**

status, strength, ssid, bssid=wifi.sta.getlink()

#### **Parameters**

nil

#### **Returns**

status: The connecting status. if connected it's "connected" else it's "disconnected". It will be nil for strength/ssid/bssid if it's "disconnected".

```
strength: The signal strength.
ssid: The connected AP's ssid.
bssid: The connected AP's bssid.
```

```
> status,strength,ssid,bssid=wifi.sta.getlink()
>print(status,strength,ssid,bssid)
connected 62 Doit BC:D1:77:32:E7:2E
```

# wifi.sta.stop()

# Description

Close all the Wi-Fi connections in STA mode.

## **Syntax**

wifi.sta.stop()

## **Parameters**

nil

## Returns

nil

## See also

wifi.stop()
wifi.ap.stop()

# Examples

> wifi.sta.stop()

## **Net Module**

## **Function list**

net.new()	Create a new socket, set the socket and transmission protocol
net.start()	Start the socket, set remote port, remote ip address, or local port
	according to the socket and transmission protocol
net.on()	Register the callback functions for socket events
net.send()	Send data
net.close()	Close socket
net.getip()	Get the ip address and port of the client socket.

## **Constant**

net.TCP	TCP protocol
net.UDP	UDP protocol
net. SERVER	Server type
net.CLIENT	Client type

# net.new()

### **Description**

Create a new socket, set the socket and protocol type.

Max 4 server and Max 4 client can be setup in WiFiMCU. If the socket type is Server, max number of 5 clients are allowed to connect.

### **Syntax**

skt=net.new(protocol,type)

#### **Parameters**

protocol: The transmission protocol, must be one of the two: net.TCP, net.UDP type: socket type, must be one of the two: net.SERVER, net.CLIENT

### Returns

skt: the andle for this socket

## Examples

>skt = net.new(net.TCP,net.SERVER) >skt2 = net.new(net.UDP,net.CLIENT)

# net.start()

### **Description**

Start the socket, set remote port, remote ip address, or local port according to the socket and transmission protocol.

#### **Syntax**

```
net.start(socket, localport)
net.start(socket, remoteport, "domain", [local port])
```

#### **Parameters**

socket: The socket handle returned from net.new()

localport: If the socket type is net.SERVER, It's the local binded port for this socket.

remoteport: If the socket type is net.CLIENT, It's the remote server port.

"domain": If the socket type is net.CLIENT, it's the domain name string for remote server. The remote server's ip address can be used too.

[local port]: Optinal, if the socket type is net.CLIENT, [local port] set the local binded port for the socket. If ignored, a random port would be assigned.

#### Returns

nil

#### **Examples**

```
>skt = net.new(net.TCP,net.SERVER)
>skt2 = net.new(net.UDP,net.CLIENT)
>net.start(skt, 80)
>net.start(skt2,9000,'11.11.11.2', 8000)
```

# net.on()

### Description

Register the callback functions for socket events.

#### **Syntax**

```
net.on(socket,event,func_cb)
```

#### **Parameters**

socket: The socket handle returned from net.new()

event: If the socket type is net.SERVER, event should be one of the following:

"accept" (TCP server socket only), "receive", "sent", "disconnect".

If the socket type is net.CLIENT, event should be one of the following:

"connect(TCP client socket only)", "receive", "sent", "disconnect", "dnsfound".

func cb: Callback function for different events. The function parameters diff from events.

"accept": TCP server socket only. If the tcp server accept a tcp client connection request, the function will be called. Function prototype is: func\_cb(clt, ip, port). "clt" is the tcp client socket handle, "ip" is the client ip address, "port" is the client's port.

"receive": If data arrived on the assigned socket, the function will be called. Function prototype is: func cb(clt, data). "clt" is the socket handle, "data" is the received data.

"sent": When data had sent succeffuly on the assigned socket, the function will be called. Function prototype is: func cb(clt). "clt" is the socket handle.

"disconnect": If the client socket is disconnected from server or some errors happened, the function will be called. Function prototype is: func cb(clt). "clt" is the socket handle.

"connect": TCP Client socket only. When the client socket connects to the remote server

successfully, the function will be called. Function prototype is: func\_cb(clt). "clt" is the socket handle.

"dnsfound": TCP or UDP Client socket only. When the DNS operations has finished, the function will be called. Function prototype is: func\_cb(clt, ip). "clt" is the socket handle, "ip" is the ip address for the domain.

#### **Returns**

nil

#### **Examples**

```
>clt = net.new(net.TCP,net.CLIENT)
>net.on(clt,"dnsfound",function(clt,ip) print("dnsfound clt:"..clt.." ip:"..ip) end)
>net.on(clt,"connect",function(clt) print("connect:clt:"..clt) end)
>net.on(clt,"disconnect",function(clt) print("disconnect:clt:"..clt) end)
>net.on(clt,"receive",function(clt,d) print("receive:clt:"..clt.."data:"..d) end)
>net.start(clt,9003,"11.11.11.2")
```

# net.send()

### **Description**

Send data.

#### **Syntax**

```
net.send(socket, data, [func_cb])
```

#### **Parameters**

socket: The socket handle returned from net.new()

data: Data to be sent.

[func\_cb]: Optinal, "sent" eventcall back function. When data had sent succeffuly on the assigned socket, the function will be called. Function prototype is: func\_cb(clt). "clt" is the socket handle.

### Returns

nil

#### **Examples**

>net.send(clt,"hello")

# net.close()

#### **Description**

Close socket, release the resource of the socket.

## **Syntax**

net.close(socket)

#### **Parameters**

socket: The socket handle returned from net.new()

#### **Returns**

nil

```
>skt = net.new(net.TCP,net.SERVER)
>net.close(skt)
```

# net.getip()

## Description

Get the ip address and port of the client socket.

### **Syntax**

```
ip, port = net.getip(socket)
```

### **Parameters**

socket: The socket handle returned from net.new(). The socket handle should be a client socket.

### Returns

```
ip: the ip address for the socket. port: the port for the socket.
```

```
>ip, port = net.getip(clt)
```

# File Module

The file system is based on spi flash embeded in WiFiMCU. The totoal storage capacity is 1280k [(1024+256)\*1024] bytes.

# **Function list**

file.format()	Format file system, all stored data will be lost after format
file.open()	Open or create a file
file.close()	Close an opened file
file.write()	Write data to an opened file
file.writeline()	Write data to an opened file, with a '\n' added at the tailed of data
file.read()	Read data from an opened file
file.readline()	Read a line data from an opened file
file.list()	Get the file name and size list in file system
file.slist()	Print the file name and size list on terminal
file.remove()	Remove file
file.seek()	Set the position of file pointer
file.flush()	Clear file buffer
file.rename()	Rename the file
file.info()	Get the file system storage status
file.state()	Get the opened file's name and size
file.compile()	Compile a Lua scripts file to lc file.
dofile()	Run a file

# Constant

nil

# file.format()

## Description

Format file system, all stored data will be lost after format. It's recommended Do not do any things while formatting.

## **Syntax**

```
file.format()
Parameters
     nil
Returns
     nil
    If formatting is done successfully, "format done" will be printed, else "format error" will be
printed.
Examples
    >file.format()
     format done
file.open()
Description
     Open or create a file.
Syntax
     ret = file.open(filename,mode)
Parameters
     filename: filename string to be created or opened. Directories are not supported yet.
     mode: opened type:
          "r": read mode (the default parameter)
          "r+": update mode, all previous data is preserved
          "w": write mode
          "w+": update mode, all previous data is erased
          "a": append mode
          "a+": append update mode, previous data is preserved, writing is only allowed at the end
     of file
Returns
     ret: true if succeed, else nil.
Examples
    >file.open("test.lua","w+")
    >file.write("This is a test")
    >file.close()
```

# file.close()

### **Description**

Close an opened file.

## **Syntax**

file.close()

#### **Parameters**

nil

## Returns

```
nil
```

## **Examples**

```
>file.open("test.lua","w+")
>file.write("This is a test")
>file.close()
```

# file.write()

### **Description**

Write data to an opened file.

#### **Syntax**

ret=file.write(data)

#### **Parameters**

data: The data to be wrote.

#### **Returns**

ret: true if succeed, else nil.

### **Examples**

```
>file.open("test.lua","w+")
>file.write("This is a test")
>file.close()
```

# file.writeline()

#### **Description**

Write data to an opened file, with a '\n' added at the tailed of data.

## **Syntax**

```
ret=file.writeline(data)
```

#### **Parameters**

data: The data to be wrote. A char '\n' will be added at the end of data.

#### Returns

```
ret: true if succeed, else nil.
```

## **Examples**

```
>file.open("test.lua","w+")
>file.writeline("This is a test")
>file.close()
```

# file.read()

### **Description**

Read data from an opened file.

#### **Syntax**

```
ret=file.read()
```

```
ret=file.read(num)
     ret=file.read(endchar)
Parameters
     if the parameter is nil, read all byte in file.
     num: if a number is assigned, read the num bytes from file, or all rest data in case of end of
file.
     endchar: read until endchar or EOF is reached.
Returns
     ret: the file data if succeed, else nil.
Examples
     >file.open("test.lua","r")
     >data=file.read()
    >file.close()
    >print(data)
     This is a test
     >file.open("test.lua","r")
    >data=file.read(10)
    >file.close()
    >print(data)
     This is a
    >file.open("test.lua","r")
    >data=file.read('e')
    >file.close()
    >print(data)
     This is a te
file.readline()
Description
     Read a line data from an opened file.
Syntax
     ret=file.readline()
Parameters
     nil
Returns
     ret: the file data if succeed, else nil.
Examples
     >file.open ("test.lua","w+")
    >file.writeline("this is a test")
    >file.close()
    >file.open ("test.lua","r")
     >data=file.readline()
```

>print(data)
> This is a test

```
>file.close()
```

# file.list()

### **Description**

Get the file name and size list in file system.

#### **Syntax**

```
ft=file.list()
```

#### **Parameters**

nil

#### Returns

ft: a Lua table, in which the filename is the key, file size is the value.

### **Examples**

```
>for k,v in pairs(file.list()) do print("name:"..k.." size(bytes):"..v) end > name:test.lua size(bytes):15
```

# file.slist()

## Description

Print the file name and size list on terminal.

#### **Syntax**

file.slist()

#### **Parameters**

nil

## Returns

nil

### **Examples**

```
>file.slist()
test.lua size:15
```

# file.remove()

## Description

Remove file.

#### **Syntax**

file.remove(filename)

### **Parameters**

filename: filename string to be removed.

#### **Returns**

nil

```
>file.remove ("test.lua")
```

# file.seek()

```
Description
     Set the position of file pointer.
Syntax
     fi = file.seek(whence, offset)
Parameters
     whence: should be one of the following:
          "set": base is position 0 (beginning of the file);
          "cur": base is current position;(default value)
          "end": base is end of file;
     offset: default 0.
Returns
     fi: the file pointer final position if succeed, else nil.
Examples
    >>file.open ("test.lua","r")
     >file.seek("set",10)
    >data=file.read()
    >file.close()
     >print(data)
     test
file.flush()
Description
```

Clear file buffer.

### **Syntax**

ret = file.flush()

#### **Parameters**

nil

### Returns

ret: true if succeed, else nil.

### **Examples**

```
>file.open ("test.lua","r")
>file.flush ()
>file.close()
```

# file.rename()

## Description

Rename the file.

### **Syntax**

```
ret=file.rename(oldname,newname)
Parameters
     oldname: File name to be changed.
     newname: New file name.
Returns
     ret: true if succeed, else nil.
Examples
    > file.slist()
     test.lua size:14
    >file.rename ('test.lua', 'testNew.lua')
    >file.slist()
     testNew.lua size:14
file.info()
Description
     Get the file system storage status.
     last,used,total = file.info()
Parameters
     nil
Returns
     last: free storage left in bytes.
     used: used storage in bytes.
     total: all allocated storage for file system in bytes.
Examples
    > last,used,total = file.info()
    > print(last,used,total)
     1140500 2750 1143250
file.state()
Description
     Get the opened file's name and size
Syntax
     fn,sz = file.state()
Parameters
     nil
Returns
     fn: filename.
     sz: file size in bytes.
Examples
```

>file.open("testNew.lua","r")

```
>fn,sz = file.state()
>file.close()
>print(fn,sz)
testNew.lua 14
```

# file.compile()

### Description

Compile a Lua scripts file to lc file. The lc file will be named as the same name as the Lua file.

#### **Syntax**

```
file.compile('filename.lua')
```

#### **Parameters**

filename.lua: file name of the Lua scripts.

#### **Returns**

nil.

### **Examples**

```
>file.open("test.lua","w+")
>file.write("print('Hello world!')")
>file.close()
>file.compile("test.lua")
>file.slist()
test.lua size:21
test.lc size:100
```

# dofile()

### **Description**

Run a file. The file can be either a Lua scripts or a lc format file.

#### **Syntax**

```
dofile('filename.lua')
dofile('filename.lc')
```

#### **Parameters**

filename.lua: Lua scripts file. filename.lc: a lc file

### Returns

nil.

```
>dofile("test.lua")
Hello world!
>dofile("test.lc")
Hello world!
```

# **PWM Module**

# **Function list**

pwm.start()	Start pwm function at assigned gpio pin
pwm.stop()	Stop pwm

## **Constant**

nil

# Pin Table

Plaese refer: "GPIO Table" for detail.

# pwm.start()

### **Description**

Start pwm function at assigned gpio pin.

#### **Syntax**

```
pwm.start(pin, freq, duty)
```

#### **Parameters**

```
pin: gpio pin ID. There are 11 PWM ports supported in WiFiMCU: D1, D3, D4, D9, D10, D11, D12, D13, D14, D15, D16. freq: PWM output frequency in Hz, 0<freq<10KHz duty: Duty of PWM output, must be 0<=duty <=100
```

### Returns

nil.

## **Examples**

```
>i=1;pin=1;

>tmr.start(1,1000,function()

i=i+10;if i>=100 then i=1 end

pwm.start(pin,10000,i)

end)

>
```

# pwm.stop()

### **Description**

```
Stop pwm.
```

# Syntax

pwm.stop(pin)

## **Parameters**

pin: gpio pin ID. There are 11 PWM ports supported in WiFiMCU: D1, D3, D4, D9, D10, D11, D12, D13, D14, D15, D16.

## Returns

nil.

# Examples

>pwm.stop(1)

# **ADC Module**

# **Function list**

adc.read()	Read the ADC result at assigned pin
------------	-------------------------------------

## **Constant**

nil

# Pin Table

Plaese refer: "GPIO Table" for detail.

# adc.read()

## Description

Read the ADC result at assigned pin.

#### **Syntax**

data= adc.read(pin)

### **Parameters**

```
pin: gpio pin ID. There are 5 ADC ports supported in WiFiMCU: D1, D13, D15, D16, D17.
```

#### Returns

data: if succeed, data between  $0\sim4095$  is returned, else nil. Note that: 0 presents 0V, 4095 presents 3.3V.

```
>=adc.read(1)
>1
>=adc.read(1)
>4095
```

# **UART Module**

Only one uart is supported in WiFiMCU so far. The GPIO pin is D8(RX1), D9(TX1).

# **Function list**

uart.setup()	Setup uart parameters: buadrate, databits, parity, stopbits.
uart.on()	Register the callback functions for uart events
uart.send()	Send data via uart

## **Constant**

null

# uart.setup()

### **Description**

Setup uart parameters: buadrate, databits, parity, stopbits.

### **Syntax**

```
uart.setup(id, baud, parity, databits, stopbits)
```

### **Parameters**

```
id: uart ID, always 1 at present.
baud: baudrate, such as: 4800, 9600, 115200.
parity: 'n': no parity, 'o': odd parity, 'e': even parity.
databits: data bits, '5', '6', '7', '8', '9'.
stopbits: stop bits, '1', '2'
```

#### Returns

nil

#### **Examples**

```
>uart.setup(1,9600,'n','8','1')
```

# uart.on()

### **Description**

Register the callback functions for uart events.

### **Syntax**

```
uart.on(id, event ,func_cb)
```

### **Parameters**

id: uart ID, always 1 at present.

```
event: always "data".
```

func\_cb: Callback function for the event. When data arrived, the function will be called. Function prototype is: func\_cb(data). "data" is the data received.

#### Returns

nil

### **Examples**

```
>uart.on(1, 'data',function(t) len=string.len(t) print(len.." "..t) uart.send(1,t) end)
```

# uart.send()

### **Description**

Send data via uart.

#### **Syntax**

```
uart.send(1, string1,[number],...[stringn])
```

#### **Parameters**

```
id: uart ID, always 1 at present.
```

string1: string ready to send.

[number]: Optional, number ready to send.

[stringn]: Optional, The nth string ready to be send.

#### **Returns**

nil

### **Examples**

```
>uart.send(1,'hello wifimcu')
```

>uart.send(1,'hello wifimcu','hi',string.char(0x32,0x35))

>uart.send(1,string.char(0x01,0x02,0x03))

## **SPI Module**

To be continued.

### I2C Module

To be continued.

## **OW Module**

To be continued.

## **Bit Module**

To be continued.

# **MQTT Module**

To bo continued