CE394M: 1D-Finite Element Method

Krishna Kumar

University of Texas at Austin


January 19, 2019

Overview

FEM workflow

2 1D FEM

Finite Element Analysis




Finite Element Analysis

FEM is a systematic procedure for approximating differential equations. For any problem in any spatial dimension it follows the same steps:

- Identify the equation of interest
- Cast the equation of interest in a weak form
- Select a finite element type
- Construct the element matrix and vector
- Assemble the global matrix and vector and apply boundary conditions
- Solve the system of linear equations

1D Finite Element Analysis of a cantilever beam




1D cantilever beam

Assume L as unit length L = 1. Unit force f = 1.

1D Finite Element Analysis of a cantilever beam

What element should be used?





Linear elements

Qudrilateral element

1D discretization of a cantilever beam

1D FEM: Shape functions and derivatives

Shape function **N**:

$$N_1(x) = -\frac{x}{L} + 1$$

$$N_2(x) = \frac{x}{L}$$

$$N_1(x) = -x + 1$$

$$N_2(x) = x$$

B is the derivatives of the shape functions:

$$\mathbf{B} = \begin{bmatrix} \frac{dN_1(x)}{dx} & \frac{dN_2(x)}{dx} \end{bmatrix}$$

$$\mathbf{B} = \begin{bmatrix} -1 & 1 \\ L & L \end{bmatrix} = \begin{bmatrix} -1 & 1 \end{bmatrix}$$

1D FEM: Stiffness and force

Element stiffness k_e :

$$k_{e} = \int \mathbf{B}^{T} EAB \, \mathrm{d}x$$

$$k_{e} = \begin{bmatrix} 1 & -1 \\ -1 & 1 \end{bmatrix}$$

Right-hand side vector b_e is:

$$b_{e} = \int N^{T} f \, dx = \int_{0}^{L} \begin{bmatrix} -\frac{x}{L} + 1 \\ \frac{x}{L} \end{bmatrix}$$
$$b_{e} = \begin{bmatrix} -\frac{1}{2} \\ \frac{1}{2} \end{bmatrix}$$