# **Caveatron Hardware Version Code Description**

2018-08-01

Software Versions: 1.00 – Current

This is an 11 digit numeric code that defines the specific hardware components inside the Caveatron allowing for different hardware modules to be used with the same software. The table and list below describe what each digit of the code means and provides valid values for the Software versions listed above.

Character #	Value Range	Description
1	0-9	SD Card Data Storage
2	0-9	Display
3	0-9	Font/Graphics Storage
4	0-9	Laser Rangefinder
5	0-9	Compass
6	0-9	IMU/Gyro
7	0-9	Battery
8	0-9	Battery Gauge
9	0-9	Clock
10	0-9	Piezo Buzzer
11	0-9	Future Use

### **SD Card Data Storage**

1 = SPI Mode SD Card on Arduino Due

#### Display

- 1 = Original Coldtears 3.5" 480x320 LCD (With original Font IC. No longer produced legacy only)
- 2 = Updated Coldtears 3.5" 480x320 LCD (With new Font IC and using UTFT GHL library)
- 3 = Coldtears 4.0" 480x320 LCD (Uses UTFT\_CTE library)

#### **Font/Graphic Storage**

- 1 = UTFT\_CTE font library
- 2 = UTFT\_GHL font library

## **Laser Rangefinder**

- 1 = Uni-T UT390B early version with verbose output
- 2 = Uni-T UT390B normal version
- 3 = JRT 100 m Laser distance module

#### Compass

- 1 = LSM303DLM or LSM303DLHC
- 2 = LSM303D

#### IMU/Gyro

0 = None

## **Battery**

1 = 4400 mAh/5200 mAh 3.7V Li-Ion

# **Battery Gauge**

1 = MAX17043 LiPo Fuel Gauge

2 = Sparkfun LiPo Battery Manager

## Clock

1 = DS3231 RTC

## Piezo Buzzer

1 = 1-3V directly driven Piezo Buzzer