# Mesh Smoothing in Nek5000

#### Ketan Mittal\*

A mesh smoother has been deployed for smoothing meshes in Nek5000. This smoother is a combination of Laplacian smoothing and mesh optimization, which makes the mesh more uniform while preserving the boundary layer resolution of the original mesh. This document explains the parameters that are important for understanding the functionality of the smoother and using it effectively. The example here demonstrates how to use the mesh smoother on a 2D mesh for a turbine blade.

#### 1 Smoother Parameters

The user must follow the following steps to run the mesh smoother:

- 1. include smoothlx.f in the .usr file. The file smoothlx.f includes the subroutine smoothmesh and other dependencies.
- 2. Specify the metric type (mtyp) for optimization Currently only mtyp = 1, which optimizes based on the condition number of the Jacobian matrix, is available. More metrics will be added soon.
- 3. Specify the number of smoothing iterations:

nouter - The number of loops for Laplacian and optimization smoothing nlap - number of iterations of Laplacian smoothing in each loop

nopt - number of iterations of optimization based smoothing in each loop

noutput - The frequency of outputting a mesh in f0000 format for user to analyze in Postnek, Visit or another software of their choice.

By default nouter = 20, nlap = 30, nopt = 20 and noutput = 10, but the user can change these values based on their mesh.

4. Input parameters nbc, dcbc, idftyp,  $\alpha$ , and  $\beta$  required to calculate the weight function (w):

The weight function is used to preserve the boundary layer resolution during the mesh smoothing process. This function is based on the minimum distance (d) of all Gauss-Lobatto Legendre (GLL) points from the boundary conditions specified by the user.

The user starts by specifying the boundary conditions near which boundary layer resolution must be preserved using parameter nbc and character array dcbc. The parameter nbc is set to 2 by default to indicate two boundary conditions will be specified in dcbc, and dcbc is set to /'W ','P '/ to indicated that boundary layer resolution will be preserved near wall and periodic surfaces. The user can modify these values based on their case. For example, the user can set nbc = 1 and dcbc = /'W '/ to

<sup>\*</sup>Email: kmittal2@illinois.edu, Web: www.k10mittal.com

indicate that boundary layer resolution will be preserved only near the wall boundary condition.

Once d is calculated from the boundary conditions specified by the user, it is normalized using the maximum value of d over the computational domain and then the weight function is calculated as:

$$w = 1 - exp(-d/\beta) \text{ if } funtype = 0$$
 
$$w = 0.5(tanh(\alpha(d-\beta)) + 1) \text{ if } funtype = 1.$$


By default idftyp = 0,  $\alpha = 15$  and  $\beta = 0.2$  i.e. the exponential based function is used with  $\beta = 0.2$ . The user can modify these values of funtype,  $\alpha$ , and  $\beta$  or implement a function of their own choice by modifying the subroutine disfun.

w is used during and after the mesh smoothing process to weight the movement of the nodes. This has the effect of reducing the movement of GLL points near the specified boundary conditions, thus preserving boundary layer resolution, while allowing the GLL points in the far-field to move in order to maximize mesh quality.

5. call smoothmesh from usrdat2 or in userchk as: call smoothmesh(mtyp,nlap,nopt,nouter,noutput,nbc,dcbc,idftyp,alpha,beta)

#### 2 Additional notes

1. The values of  $\alpha$  and  $\beta$  can be changed depending on how much movement the user wants to allow near the boundary surfaces. By default  $\alpha = 15$  and  $\beta = 0.2$  for the exponential and tanh based function. Figure 1(a) and (b) shows how w changes for different values of  $\alpha$  and  $\beta$ .






Figure 1: Weight function with different parameters

- 2. Laplacian smoother is computationally cheaper than optimization based smoothing. However, optimization based smoothing is more effective for complicated geometries because it tries to ensure that the mesh stays valid during the smoothing process.
- 3. Negative Jacobians During the smoothing process, the mesh can become invalid. This can be troubleshot by decreasing nlap (because optimization based smoother is more effective for complicated geometries), modifying the parameters funtype,  $\alpha$  and  $\beta$  if the invalid elements are near the domain

boundaries, or reducing *nlap* and *nopt* while simultaneously increasing *nouter* (this is because midside nodes are interpolated to the center of their respective element edges after Laplacian and optimization based smoothers run in each loop).

- 4. The value of glob\_mesh\_sum printed out by the optimization based smoother is a good indicator of the effectiveness of the mesh smoother. This value should generally be decreasing as the smoother optimizes the mesh quality.
- 5. Future versions will incorporate surface smoothing.
- 6. Please send any comments or feedback to kmittal2@illinois.edu

## 3 Examples

#### 3.1 2D mesh - Low pressure turbine blade

For the 2D case, we take a look at the mesh of a low pressure turbine blade. The domain has *periodic* boundary condition in the pitchwise direction, and *wall* boundary condition at the blade surface. The mesh smoother parameters are set as:

```
С
C.
     ______
C.
     _____
     parameter(nbc=2)
                             !number of boundary conditions
     character*3 dcbc(nbc)
                 dcbc
     save
                 dcbc /'W ','P '/ !BCs listed here
     data
     idftyp = 0
                     !distance function - 0 -> exponential, 1-> tanh
     alpha = 15.
                     !Input for wall distance function
     beta = 0.2
                     !Input for wall distance function
     nouter = 20
                      !total loops around laplacian and optimizer smoothing
     nlap = 30
                      !number of laplacian iterations in each loop
     nopt = 20
                      !number of optimization iterations in each loop
     noutput = 10
                      !output a mesh in *f0000 format after these many loops
     mtyp = 1
                      !metric type
     call smoothmesh(mtyp,nlap,nopt,nouter,noutput,nbc,dcbc,
           idftyp,alpha,beta)
     _____
С
С
С
```

Figure 2 shows a comparison of the mesh before and after smoothing. As evident, mesh smoothing makes the mesh more uniform and transition between different mesh regions smoother.




Figure 2: LPT-106 mesh before and after smoothing

### 3.2 3D mesh - Internal combustion engine's cylinder

For the 3D mesh, we take a look at the mesh for an internal combustion engine's (ICE) cylinder. The mesh has *symmetry* and *wall* boundary conditions. The smoothing parameters are:

```
С
      ______
      ._____
С
      _____
     parameter(nbc=2)
                             !number of boundary conditions
     character*3 dcbc(nbc)
                dcbc
     save
     data
                dcbc /'W ','SYM'/ !BCs listed here
     idftyp = 0
                    !distance function - 0 -> exponential, 1-> tanh
     alpha = 15.
                    !Input for wall distance function
     beta = 0.2
                    !Input for wall distance function
     nouter = 35
                     !total loops around laplacian and optimizer smoothing
                     !number of laplacian iterations in each loop
     nlap = 10
                     !number of optimization iterations in each loop
     nopt = 20
     noutput = 0
                     !Do not output during the smoothing process
     mtyp = 1
                     !metric type
     call smoothmesh(mtyp,nlap,nopt,nouter,noutput,nbc,dcbc,
           idftyp,alpha,beta)
          _____
С
С
С
        _____
```

As evident in Fig. 3(a), the original mesh has very thin elements in the far-field because of boundary layer resolving elements below the valve stem. Mesh smoothing makes the mesh more uniform away from the boundary surfaces specified by the user.




Figure 3: ICE cylinder's mesh before and after smoothing

Figure 4 shows a close-up of how mesh smoothing helps make the mesh more uniform away from walls, and the weight function helps in restoring the original boundary layer resolution of the original mesh.




Figure 4: Mesh at the ICE cylinder's valve stem before and after smoothing