2015 Test beam Run Control

Generated by Doxygen 1.8.9.1

Fri Apr 24 2015 02:04:49

Contents

1	Mod	lule Ind	ex		1
	1.1	Module	es		1
2	Hier	archica	l Index		3
	2.1	Class	Hierarchy		3
3	Data	Struct	ure Index		5
	3.1	Data S	Structures		5
4	Mod	lule Dod	cumentatio	on	7
	4.1	Socket	t communic	cation objects	7
		4.1.1	Detailed	Description	7
		4.1.2	Enumera	tion Type Documentation	7
			4.1.2.1	SocketType	7
	4.2	HPTD	C chip cont	trol	9
		4.2.1	Detailed	Description	10
		4.2.2	Enumera	tion Type Documentation	10
			4.2.2.1	CoreClockSource	10
			4.2.2.2	DeadTime	10
			4.2.2.3	DLLClockSource	10
			4.2.2.4	DLLSpeedMode	10
			4.2.2.5	EdgeResolution	10
			4.2.2.6	EnabledError	11
			4.2.2.7	EventType	11
			4.2.2.8	IOClockSource	11
			4.2.2.9	ReadoutSingleCycleSpeed	11
			4.2.2.10	ReadoutSpeed	12
			4.2.2.11	SerialClockSource	12
			4.2.2.12	SerialStrobeType	12
			4.2.2.13	WidthResolution	12
5	Data	a Struct	ure Docun	nentation	13
	5.1	Client	Class Refe	orence	19

iv CONTENTS

	5.1.1	Detailed Description				
	5.1.2	Construc	ctor & Destructor Documentation	15		
		5.1.2.1	Client	15		
		5.1.2.2	Client	15		
		5.1.2.3	~Client	15		
	5.1.3	Member	Function Documentation	15		
		5.1.3.1	Announce	15		
		5.1.3.2	Connect	16		
		5.1.3.3	Disconnect	16		
		5.1.3.4	GetType	17		
		5.1.3.5	ParseMessage	17		
		5.1.3.6	Receive	17		
		5.1.3.7	Send	18		
	5.1.4	Field Do	cumentation	18		
		5.1.4.1	fClientId	18		
		5.1.4.2	flsConnected	18		
5.2	Except	ion Class	Reference	18		
	5.2.1	Detailed	Description	19		
	5.2.2	Construc	ctor & Destructor Documentation	19		
		5.2.2.1	Exception	19		
		5.2.2.2	Exception	19		
		5.2.2.3	~Exception	19		
	5.2.3	Member	Function Documentation	19		
		5.2.3.1	Description	19		
		5.2.3.2	Dump	20		
		5.2.3.3	ErrorNumber	20		
		5.2.3.4	From	20		
		5.2.3.5	Type	20		
		5.2.3.6	TypeString	20		
	5.2.4	Field Do	cumentation	20		
		5.2.4.1	fDescription	20		
		5.2.4.2	fErrorNumber	20		
		5.2.4.3	fFrom	20		
		5.2.4.4	fType	20		
5.3	file_he	ader_t Str	uct Reference	21		
	5.3.1	Detailed	Description	21		
	5.3.2	Field Do	cumentation	21		
		5.3.2.1	config	21		
		5.3.2.2	magic	21		
		5.3.2.3	run_id	22		

CONTENTS

		5.3.2.4	spill_id	22			
5.4	FPGA	Handler Class Reference					
	5.4.1	Detailed I	Description	23			
	5.4.2	Construc	tor & Destructor Documentation	24			
		5.4.2.1	FPGAHandler	24			
		5.4.2.2	~FPGAHandler	24			
	5.4.3	Member I	Function Documentation	24			
		5.4.3.1	CloseFile	24			
		5.4.3.2	GetConfiguration	24			
		5.4.3.3	GetFilename	25			
		5.4.3.4	GetType	25			
		5.4.3.5	OpenFile	25			
		5.4.3.6	ReadBoundaryScanRegister	25			
		5.4.3.7	ReadBuffer	25			
		5.4.3.8	ReadConfiguration	25			
		5.4.3.9	SendConfiguration	25			
		5.4.3.10	SetConfiguration	26			
	5.4.4	Field Doo	cumentation	26			
		5.4.4.1	fFilename	26			
		5.4.4.2	flsFileOpen	26			
		5.4.4.3	flsTDCInReadout	26			
		5.4.4.4	fOutput	26			
		5.4.4.5	fTDCBSR	26			
		5.4.4.6	fTDCSetup	26			
5.5	HTTPN	Message C	class Reference	27			
	5.5.1	Detailed I	Description	28			
	5.5.2	Construc	tor & Destructor Documentation	28			
		5.5.2.1	HTTPMessage	28			
		5.5.2.2	HTTPMessage	28			
	5.5.3	Member I	Function Documentation	29			
		5.5.3.1	Decode	29			
		5.5.3.2	Dump	29			
		5.5.3.3	Encode	29			
		5.5.3.4	GetKey	29			
	5.5.4	Field Doo	cumentation	29			
		5.5.4.1	fOriginalString	29			
		5.5.4.2	fWS	29			
5.6	Listene	erInfo Struc	ct Reference	29			
	5.6.1	Detailed I	Description	29			
	5.6.2	Field Doo	cumentation	29			

vi CONTENTS

		5.6.2.1	name	29			
		5.6.2.2	type	29			
5.7	Messa	age Class Reference					
	5.7.1	Detailed Description					
	5.7.2	Construc	tor & Destructor Documentation	31			
		5.7.2.1	Message	31			
		5.7.2.2	Message	31			
		5.7.2.3	Message	31			
		5.7.2.4	~Message	31			
	5.7.3	Member	Function Documentation	31			
		5.7.3.1	Dump	31			
		5.7.3.2	GetKey	31			
		5.7.3.3	GetString	31			
		5.7.3.4	IsFromWeb	31			
	5.7.4	Field Doo	cumentation	31			
		5.7.4.1	fString	31			
5.8	Messe	nger Class	Reference	31			
	5.8.1	Detailed	Description	33			
	5.8.2	Construc	tor & Destructor Documentation	33			
		5.8.2.1	Messenger	33			
		5.8.2.2	Messenger	33			
		5.8.2.3	~Messenger	34			
	5.8.3	Member	Function Documentation	34			
		5.8.3.1	AddClient	34			
		5.8.3.2	Broadcast	34			
		5.8.3.3	Connect	35			
		5.8.3.4	Disconnect	35			
		5.8.3.5	DisconnectClient	36			
		5.8.3.6	GetType	36			
		5.8.3.7	ProcessMessage	36			
		5.8.3.8	Receive	37			
		5.8.3.9	Send	37			
		5.8.3.10	SwitchClientType	38			
	5.8.4	Field Doo	cumentation	38			
		5.8.4.1	fListenersInfo	38			
		5.8.4.2	fNumAttempts	38			
		5.8.4.3	fWS	38			
5.9	Socket	Class Ref	ference	39			
	5.9.1	Detailed	Description	40			
	5.9.2	Member	Typedef Documentation	41			

CONTENTS vii

		5.9.2.1	SocketCollection	. 41
	5.9.3	Construc	tor & Destructor Documentation	. 41
		5.9.3.1	Socket	. 41
		5.9.3.2	Socket	. 41
		5.9.3.3	~Socket	. 41
	5.9.4	Member	Function Documentation	. 41
		5.9.4.1	AcceptConnections	. 41
		5.9.4.2	Bind	. 41
		5.9.4.3	Configure	. 42
		5.9.4.4	Create	. 42
		5.9.4.5	DumpConnected	. 42
		5.9.4.6	FetchMessage	. 42
		5.9.4.7	GetPort	. 42
		5.9.4.8	GetSocketId	. 42
		5.9.4.9	GetSocketType	. 42
		5.9.4.10	IsWebSocket	. 42
		5.9.4.11	Listen	. 42
		5.9.4.12	PrepareConnection	. 43
		5.9.4.13	SelectConnections	. 43
		5.9.4.14	SendMessage	. 43
		5.9.4.15	SetPort	. 43
		5.9.4.16	SetSocketId	. 43
		5.9.4.17	Start	. 44
		5.9.4.18	Stop	. 44
	5.9.5	Field Doo	cumentation	. 44
		5.9.5.1	fAddress	. 44
		5.9.5.2	fBuffer	. 44
		5.9.5.3	fMaster	. 44
		5.9.5.4	fPort	. 44
		5.9.5.5	fReadFds	. 44
		5.9.5.6	fSocketId	. 44
		5.9.5.7	fSocketsConnected	. 44
5.10	Socket	Message (Class Reference	. 45
	5.10.1	Detailed	Description	. 46
	5.10.2	Construc	tor & Destructor Documentation	. 47
		5.10.2.1	SocketMessage	. 47
		5.10.2.2	SocketMessage	. 47
		5.10.2.3	SocketMessage	. 47
		5.10.2.4	SocketMessage	. 47
		5.10.2.5	SocketMessage	. 47

viii CONTENTS

		5.10.2.6 SocketMessage	48
		5.10.2.7 SocketMessage	48
		5.10.2.8 SocketMessage	48
		5.10.2.9 SocketMessage	48
		5.10.2.10 SocketMessage	49
		5.10.2.11 SocketMessage	49
		5.10.2.12 ~SocketMessage	49
	5.10.3	Member Function Documentation	49
		5.10.3.1 Dump	49
		5.10.3.2 GetIntValue	49
		5.10.3.3 GetKey	50
		5.10.3.4 GetString	50
		5.10.3.5 GetValue	50
		5.10.3.6 GetVectorValue	50
		5.10.3.7 Object	50
		5.10.3.8 SetKeyValue	50
		5.10.3.9 SetKeyValue	50
		5.10.3.10 SetKeyValue	51
		5.10.3.11 SetKeyValue	51
		5.10.3.12 String	51
	5.10.4		51
		5.10.4.1 fMessage	51
5.11	TDCBo	undaryScanRegister Class Reference	51
	5.11.1	Detailed Description	52
	5.11.2	Constructor & Destructor Documentation	52
		5.11.2.1 TDCBoundaryScanRegister	52
		5.11.2.2 ~TDCBoundaryScanRegister	53
5.12	TDCCo	entrol Class Reference	53
	5.12.1	Member Enumeration Documentation	54
			54
	5.12.2		54
			54
			54
			54
	5.12.3		54
		•	54
			55
			55
			55
		5.12.3.5 SetGlobalReset	55

CONTENTS

		5.12.3.6	SetPLLReset	. 56
	5.12.4	Field Doc	umentation	. 56
		5.12.4.1	kControlParity	. 56
		5.12.4.2	kDLLReset	. 56
		5.12.4.3	kEnableChannel	. 56
		5.12.4.4	kEnablePattern	. 56
		5.12.4.5	kGlobalReset	. 56
		5.12.4.6	kPLLReset	. 56
5.13	TDCEv	ent Class F	Reference	. 56
	5.13.1	Detailed D	Description	. 57
	5.13.2	Construct	or & Destructor Documentation	. 57
		5.13.2.1	TDCEvent	. 57
		5.13.2.2	~TDCEvent	. 57
	5.13.3	Member F	Function Documentation	. 57
		5.13.3.1	GetBunchld	. 57
		5.13.3.2	GetErrorFlags	. 58
			GetEventId	
			GetLeadingTime	
		5.13.3.5	GetTDCld	. 58
			GetTrailingTime	
			GetType	
			GetWidth	
			GetWordCount	
	5.13.4		umentation	
			fWord	
5.14			ss Reference	
			Description	
	5.14.2		Typedef Documentation	
			bit	
			word_t	
	5.14.3		or & Destructor Documentation	
			TDCRegister	
			~TDCRegister	
	5.14.4		Function Documentation	
			DumpRegister	
			GetBits	
			GetNumWords	
			GetWord	
			SetBits	
		5.14.4.6	SetWord	. 62

CONTENTS

	5.14.5	Field Documentation	62
		5.14.5.1 fNumWords	62
		5.14.5.2 fWord	62
5.15	TDCSe	up Class Reference	62
	5.15.1	Detailed Description	69
	5.15.2	Constructor & Destructor Documentation	70
		5.15.2.1 TDCSetup	70
		5.15.2.2 TDCSetup	71
		5.15.2.3 ~TDCSetup	71
	5.15.3	Member Function Documentation	71
		5.15.3.1 Dump	72
		5.15.3.2 GetChannelOffset	72
		5.15.3.3 GetCoarseCountOffset	72
		5.15.3.4 GetDeadTime	73
		5.15.3.5 GetDLLAdjustment	73
		5.15.3.6 GetEdgeResolution	74
		5.15.3.7 GetEdgesPairing	74
		5.15.3.8 GetEnableError	74
		5.15.3.9 GetEnableErrorBypass	75
		5.15.3.10 GetEnableErrorMark	75
		5.15.3.11 GetEnableJTAGReadout	75
		5.15.3.12 GetEnableReadoutOccupancy	76
		5.15.3.13 GetEnableReadoutSeparator	76
		5.15.3.14 GetEnableSerial	76
		5.15.3.15 GetLeadingMode	76
		5.15.3.16 GetMatchWindow	77
		5.15.3.17 GetMaxEventSize	77
		5.15.3.18 GetRCAdjustment	77
		5.15.3.19 GetReadoutFIFOSize	78
		5.15.3.20 GetRejectCountOffset	78
		5.15.3.21 GetRejectFIFOFull	78
		5.15.3.22 GetSearchWindow	79
		5.15.3.23 GetSetupParity	79
		5.15.3.24 GetTestInvert	80
		5.15.3.25 GetTestMode	80
		5.15.3.26 GetTrailingMode	80
		5.15.3.27 GetTriggerCountOffset	80
		5.15.3.28 GetTriggerLatency	81
		5.15.3.29 GetTriggerMatchingMode	81
		5.15.3.30 GetVernierOffset	81

CONTENTS xi

5.15.3.31 GetWidthResolution
5.15.3.32 SetAllChannelsOffset
5.15.3.33 SetAllTapsDLLAdjustment
5.15.3.34 SetBypassInputs
5.15.3.35 SetChannelOffset
5.15.3.36 SetCoarseCountOffset
5.15.3.37 SetConstantValues
5.15.3.38 SetCoreClockDelay
5.15.3.39 SetCoreClockSource
5.15.3.40 SetDeadTime
5.15.3.41 SetDLLAdjustment
5.15.3.42 SetDLLClockDelay
5.15.3.43 SetDLLClockSource
5.15.3.44 SetDLLControl
5.15.3.45 SetDLLMode
5.15.3.46 SetEdgeResolution
5.15.3.47 SetEdgesPairing
5.15.3.48 SetEnableAutomaticReject
5.15.3.49 SetEnableBytewise
5.15.3.50 SetEnableDirectBunchReset
5.15.3.51 SetEnableDirectEventReset
5.15.3.52 SetEnableDirectTrigger
5.15.3.53 SetEnableError
5.15.3.54 SetEnableErrorBypass
5.15.3.55 SetEnableErrorMark
5.15.3.56 SetEnableGlobalHeader
5.15.3.57 SetEnableGlobalTrailer
5.15.3.58 SetEnableJTAGReadout
5.15.3.59 SetEnableLocalHeader
5.15.3.60 SetEnableLocalTrailer
5.15.3.61 SetEnableMasterResetCode
5.15.3.62 SetEnableMasterResetOnEventReset
5.15.3.63 SetEnableOverflowDetect
5.15.3.64 SetEnableReadoutOccupancy
5.15.3.65 SetEnableReadoutSeparator
5.15.3.66 SetEnableRelative
5.15.3.67 SetEnableResetChannelBufferWhenSeparator
5.15.3.68 SetEnableSeparatorOnBunchReset
5.15.3.69 SetEnableSeparatorOnEventReset
5.15.3.70 SetEnableSerial

xii CONTENTS

	5.15.3.71 SetEnableSetCountersOnBunchReset	5
	5.15.3.72 SetEnableTTLClock	6
	5.15.3.73 SetEnableTTLControl	6
	5.15.3.74 SetEnableTTLHit	7
	5.15.3.75 SetEnableTTLReset	7
	5.15.3.76 SetEnableTTLSerial	7
	5.15.3.77 SetEventCountOffset	8
	5.15.3.78 SetIOClockDelay	8
	5.15.3.79 SetIOClockSource	8
	5.15.3.80 SetKeepToken	9
	5.15.3.81 SetLeadingMode	9
	5.15.3.82 SetLowPowerMode	9
	5.15.3.83 SetMaster	0
	5.15.3.84 SetMatchWindow	0
	5.15.3.85 SetMaxEventSize	0
	5.15.3.86 SetModeRC	1
	5.15.3.87 SetModeRCCompression	1
	5.15.3.88 SetPLLControl	1
	5.15.3.89 SetRCAdjustment	2
	5.15.3.90 SetReadoutFIFOSize	2
	5.15.3.91 SetReadoutSingleCycleSpeed	2
	5.15.3.92 SetReadoutSpeedSelect	3
	5.15.3.93 SetRejectCountOffset	3
	5.15.3.94 SetRejectFIFOFull	4
	5.15.3.95 SetRollOver	4
	5.15.3.96 SetSearchWindow	4
	5.15.3.97 SetSerialClockDelay	4
	5.15.3.98 SetSerialClockSource	5
	5.15.3.99 SetSerialDelay	5
	5.15.3.100SetSetupParity	5
	5.15.3.101SetStrobeSelect	6
	5.15.3.102SetTestInvert	6
	5.15.3.103SetTestMode	6
	5.15.3.104SetTokenDelay	7
	5.15.3.105SetTrailingMode	7
	5.15.3.106SetTriggerCountOffset	7
	5.15.3.107SetTriggerMatchingMode	8
	5.15.3.108SetVernierOffset	8
	5.15.3.109SetWidthResolution	8
5.15.4	Field Documentation	9

CONTENTS xiii

5.15.4.1 kCoarseCountOffset
5.15.4.2 kCoreClockDelay
5.15.4.3 kCoreClockSource
5.15.4.4 kDeadTime
5.15.4.5 kDLLClockDelay
5.15.4.6 kDLLClockSource
5.15.4.7 kDLLControl
5.15.4.8 kDLLMode
5.15.4.9 kDLLTapAdjust0
5.15.4.10 kEnableAutomaticReject
5.15.4.11 kEnableBytewise
5.15.4.12 kEnableDirectBunchReset
5.15.4.13 kEnableDirectEventReset
5.15.4.14 kEnableDirectTrigger
5.15.4.15 kEnableError
5.15.4.16 kEnableErrorBypass
5.15.4.17 kEnableErrorMark
5.15.4.18 kEnableGlobalHeader
5.15.4.19 kEnableGlobalTrailer
5.15.4.20 kEnableJTAGReadout
5.15.4.21 kEnableLocalHeader
5.15.4.22 kEnableLocalTrailer
5.15.4.23 kEnableMasterResetCode
5.15.4.24 kEnableMasterResetOnEventReset
5.15.4.25 kEnableMatching
5.15.4.26 kEnableOverflowDetect
5.15.4.27 kEnablePair
5.15.4.28 kEnableReadoutOccupancy
5.15.4.29 kEnableReadoutSeparator
5.15.4.30 kEnableRelative
5.15.4.31 kEnableResetChannelBufferWhenSeparator
5.15.4.32 kEnableSeparatorOnBunchReset
5.15.4.33 kEnableSeparatorOnEventReset
5.15.4.34 kEnableSerial
5.15.4.35 kEnableSetCountersOnBunchReset
5.15.4.36 kEnableTTLClock
5.15.4.37 kEnableTTLControl
5.15.4.38 kEnableTTLHit
5.15.4.39 kEnableTTLReset
5.15.4.40 kEnableTTLSerial

XIV

		5.15.4.41 kEventCountOffset
		5.15.4.42 kIOClockDelay
		5.15.4.43 kIOClockSource
		5.15.4.44 kKeepToken
		5.15.4.45 kLeading
		5.15.4.46 kLeadingResolution
		5.15.4.47 kLowPowerMode
		5.15.4.48 kMaster
		5.15.4.49 kMatchWindow
		5.15.4.50 kMaxEventSize
		5.15.4.51 kModeRC
		5.15.4.52 kModeRCCompression
		5.15.4.53 kOffset0
		5.15.4.54 kPLLControl
		5.15.4.55 kRCAdjust0
		5.15.4.56 kReadoutFIFOSize
		5.15.4.57 kReadoutSingleCycleSpeed
		5.15.4.58 kReadoutSpeedSelect
		5.15.4.59 kRejectCountOffset
		5.15.4.60 kRejectFIFOFull
		5.15.4.61 kRollOver
		5.15.4.62 kSearchWindow
		5.15.4.63 kSelectBypassInputs
		5.15.4.64 kSerialClockDelay
		5.15.4.65 kSerialClockSource
		5.15.4.66 kSerialDelay
		5.15.4.67 kSetupParity
		5.15.4.68 kStrobeSelect
		5.15.4.69 kTDCld
		5.15.4.70 kTestInvert
		5.15.4.71 kTestMode
		5.15.4.72 kTestSelect
		5.15.4.73 kTokenDelay
		5.15.4.74 kTrailing
		5.15.4.75 kTriggerCountOffset
		5.15.4.76 kVernierOffset
		5.15.4.77 kWidthSelect
5.16		ndler Class Reference
		Detailed Description
	5.16.2	Constructor & Destructor Documentation

CONTENTS xv

Index				115
		5.16.4.2	fHandle	113
			fDevice	
	5.16.4	Field Doo	sumentation	113
		5.16.3.4	Write	113
		5.16.3.3	Init	113
		5.16.3.2	Fetch	113
		5.16.3.1	DumpDevice	113
	5.16.3	Member I	Function Documentation	113
		5.16.2.2	~USBHandler	113
		5.16.2.1	USBHandler	113

Chapter 1

Module Index

				_	
4	-4	- N	ᄾ	ules	
		IV	16 16 1	111126	

Here is a list of all modules:	
Socket communication objects	
HPTDC chip control	,

2 **Module Index**

Chapter 2

Hierarchical Index

2.1 Class Hierarchy

This inheritance list is sorted roughly, but not completely, alphabetically:

Exception
file_header_t
ListenerInfo
Message
HTTPMessage
SocketMessage
Socket
Client
FPGAHandler
Messenger
TDCEvent
TDCRegister
TDCBoundaryScanRegister
TDCControl
TDCSetup
USBHandler
FPGAHandler

Hierarchical Index

Chapter 3

Data Structure Index

3.1 Data Structures

Here are the data structures with brief descriptions:

Client
Base client object for the socket
Exception
A simple exception handler
file_header_t
Header to the output files
FPGAHandler FPGAHandler
Driver for timing detectors' FPGA readout
HTTPMessage
Message to be transmitted through a WebSocket protocol
ListenerInfo
Information on a socket's listener
Message
Base socket message type
Messenger
Base master object for the socket
Socket
Base socket object from which clients/master from a socket inherit
SocketMessage
Socket-passed message type
TDCBoundaryScanRegister
TDCControl
TDCEvent
HPTDC event parser
TDCRegister
General register object to interact with a HPTDC chip
TDCSetup
Setup word to be sent to the HPTDC chip
USBHandler
Generic USB communication handler

6 **Data Structure Index**

Chapter 4

Module Documentation

4.1 Socket communication objects

Data Structures

· class Client

Base client object for the socket.

class HTTPMessage

Message to be transmitted through a WebSocket protocol.

struct ListenerInfo

Information on a socket's listener.

· class Messenger

Base master object for the socket.

· class Socket

Base socket object from which clients/master from a socket inherit.

class SocketMessage

Socket-passed message type.

Enumerations

enum Socket::SocketType {
 Socket::INVALID =-1, Socket::MASTER =0, Socket::WEBSOCKET_CLIENT, Socket::CLIENT,
 Socket::DETECTOR }

Type of actor playing a role on the socket.

- 4.1.1 Detailed Description
- 4.1.2 Enumeration Type Documentation
- 4.1.2.1 enum Socket::SocketType

Type of actor playing a role on the socket.

Enumerator

INVALID MASTER WEBSOCKET_CLIENT 8 Module Documentation

CLIENT DETECTOR 4.2 HPTDC chip control 9

4.2 HPTDC chip control

Data Structures

```
    class TDCBoundaryScanRegister
```

class TDCEvent

HPTDC event parser.

class TDCRegister

General register object to interact with a HPTDC chip.

class TDCSetup

Setup word to be sent to the HPTDC chip.

Enumerations

```
enum TDCEvent::EventType {
 TDCEvent::Invalid =-1, TDCEvent::GroupHeader =0, TDCEvent::GroupTrailer, TDCEvent::TDCHeader,
 TDCEvent::TDCTrailer, TDCEvent::LeadingEdge, TDCEvent::TrailingEdge, TDCEvent::Error,
 TDCEvent::Debug }

    enum TDCSetup::EdgeResolution {

 TDCSetup::E 100ps =0, TDCSetup::E 200ps, TDCSetup::E 400ps, TDCSetup::E 800ps,
 TDCSetup::E 1p6ns, TDCSetup::E 3p12ns, TDCSetup::E 6p25ns, TDCSetup::E 12p5ns }

    enum TDCSetup::DeadTime { TDCSetup::DT 5ns =0, TDCSetup::DT 10ns, TDCSetup::DT 30ns, TDC

 Setup::DT 100ns }

    enum TDCSetup::WidthResolution {

 TDCSetup::W 100ps =0, TDCSetup::W 200ps, TDCSetup::W 400ps, TDCSetup::W 800ps,
 TDCSetup::W 1p6ns, TDCSetup::W 3p2ns, TDCSetup::W 6p25ns, TDCSetup::W 12p5ns,
 TDCSetup::W 25ns, TDCSetup::W 50ns, TDCSetup::W 100ns, TDCSetup::W 200ns,
 TDCSetup::W 400ns, TDCSetup::W 800ns }
 enum TDCSetup::EnabledError {
 TDCSetup::VernierError =0x1, TDCSetup::CoarseError =0x2, TDCSetup::ChannelSelectError =0x4, TDC↔
 Setup::L1BufferParityError =0x8,
 TDCSetup::TriggerFIFOParityError =0x10, TDCSetup::TriggerMatchingError =0x20, TDCSetup::ReadoutF ←
 IFOParityError =0x40, TDCSetup::ReadoutStateError =0x80,
 TDCSetup::SetupParityError =0x100, TDCSetup::ControlParityError =0x200, TDCSetup::JTAGInstruction ←
 ParityError =0x400 }

    enum TDCSetup::DLL SpeedMode { TDCSetup::DLL 40MHz =0x0, TDCSetup::DLL 160MHz =0x1, TDC

 Setup::DLL 320MHz =0x2, TDCSetup::DLL Illegal =0x3 }
• enum TDCSetup::SerialClockSource { TDCSetup::Serial pll clock 80 =0x0, TDCSetup::Serial pll clock ←
  160 =0x1, TDCSetup::Serial pll clock 40 =0x2, TDCSetup::Serial aux clock =0x3 }

    enum TDCSetup::IOClockSource { TDCSetup::IO_clock_40 =0x0, TDCSetup::IO_pll_clock_80 =0x1, TDC

 Setup::IO_pll_clock_160 =0x2, TDCSetup::IO_aux_clock =0x3 }
• enum TDCSetup::CoreClockSource { TDCSetup::Core clock 40 =0x0, TDCSetup::Core pll clock 80 =0x1,
 TDCSetup::Core pll clock 160 =0x2, TDCSetup::Core aux clock =0x3 }

    enum TDCSetup::DLLClockSource {

 TDCSetup::DLL clock 40 =0x0, TDCSetup::DLL pll clock 40 =0x1, TDCSetup::DLL pll clock 160 =0x2,
 TDCSetup::DLL pll clock 320 =0x3,
 TDCSetup::DLL_aux_clock =0x4 }

    enum TDCSetup::ReadoutSpeed { TDCSetup::RO Fixed =0x0, TDCSetup::RO pll 80Mbits s =0x1 }

• enum TDCSetup::SerialStrobeType { TDCSetup::SS_NoStrobe =0x0, TDCSetup::SS_DSStrobe =0x1, TD←
  CSetup::SS LeadingTrailingStrobe =0x2, TDCSetup::SS LeadingEdge =0x3 }

    enum TDCSetup::ReadoutSingleCycleSpeed {

 TDCSetup::RSC 40Mbits s =0x0, TDCSetup::RSC 20Mbits s =0x1, TDCSetup::RSC 10Mbits s =0x2, T↔
 DCSetup::RSC 5Mbits s =0x3,
```

TDCSetup::RSC_2p5Mbits_s =0x4, TDCSetup::RSC_1p25Mbits_s =0x5, TDCSetup::RSC_625kbits_s =0x6,

TDCSetup::RSC_312p5kbits_s =0x7 }

10 Module Documentation

4.2.1 Detailed Description

4.2.2 Enumeration Type Documentation

4.2.2.1 enum TDCSetup::CoreClockSource

Enumerator

```
Core_clock_40
Core_pll_clock_80
Core_pll_clock_160
Core_aux_clock
```

4.2.2.2 enum TDCSetup::DeadTime

Enumerator

```
DT_5ns
DT_10ns
DT_30ns
DT_100ns
```

4.2.2.3 enum TDCSetup::DLLClockSource

Enumerator

```
DLL_clock_40
DLL_pll_clock_40
DLL_pll_clock_160
DLL_pll_clock_320
DLL_aux_clock
```

4.2.2.4 enum TDCSetup::DLLSpeedMode

Enumerator

```
DLL_40MHz
DLL_160MHz
DLL_320MHz
DLL_IIIegal
```

4.2.2.5 enum TDCSetup::EdgeResolution

Enumerator

```
E_100ps
E_200ps
E_400ps
E_800ps
E_1p6ns
E_3p12ns
E_6p25ns
```

E_12p5ns

4.2 HPTDC chip control 11

4.2.2.6 enum TDCSetup::EnabledError

Enumerator

VernierError

CoarseError

ChannelSelectError

L1BufferParityError

TriggerFIFOParityError

TriggerMatchingError

ReadoutFIFOParityError

ReadoutStateError

SetupParityError

ControlParityError

JTAGInstructionParityError

4.2.2.7 enum TDCEvent::EventType

Enumerator

Invalid

GroupHeader

GroupTrailer

TDCHeader

TDCTrailer

LeadingEdge

TrailingEdge

Error

Debug

4.2.2.8 enum TDCSetup::IOClockSource

Enumerator

IO_clock_40

IO_pll_clock_80

IO_pll_clock_160

IO_aux_clock

4.2.2.9 enum TDCSetup::ReadoutSingleCycleSpeed

Enumerator

RSC_40Mbits_s

RSC_20Mbits_s

RSC_10Mbits_s

RSC_5Mbits_s

RSC_2p5Mbits_s

RSC_1p25Mbits_s

RSC_625kbits_s

RSC_312p5kbits_s

12 Module Documentation

4.2.2.10 enum TDCSetup::ReadoutSpeed

Enumerator

RO Fixed

RO_pll_80Mbits_s

4.2.2.11 enum TDCSetup::SerialClockSource

Enumerator

Serial_pll_clock_80

Serial_pll_clock_160

Serial_pll_clock_40

Serial_aux_clock

4.2.2.12 enum TDCSetup::SerialStrobeType

Enumerator

SS_NoStrobe

SS_DSStrobe

SS_LeadingTrailingStrobe

SS_LeadingEdge

4.2.2.13 enum TDCSetup::WidthResolution

Enumerator

W_100ps

W_200ps

W_400ps

W_800ps

W_1p6ns

W_3p2ns

W_6p25ns

W_12p5ns

W_25ns

W_50ns

W_100ns

W_200ns

W_400ns

W_800ns

Chapter 5


Data Structure Documentation

5.1 Client Class Reference


Base client object for the socket.

#include <Client.h>

Inheritance diagram for Client:



Collaboration diagram for Client:



Public Member Functions

• Client ()

General void client constructor.

· Client (int port)

Bind a socket client to a given port.

- virtual ∼Client ()
- bool Connect ()

Bind this client to the socket.

· void Disconnect ()

Unbind this client from the socket.

• void Send (const Message &m) const

Send a message to the master through the socket.

• void Receive ()

Receive a socket message from the master.

virtual void ParseMessage (const SocketMessage &m)

Parse a SocketMessage received from the master.

virtual SocketType GetType () const

Socket actor type retrieval method.

Private Member Functions

• void Announce ()

Announce our entry on the socket to its master.

Private Attributes

- · int fClientId
- bool flsConnected

Additional Inherited Members

5.1.1 Detailed Description

Base client object for the socket.

Client object used by the server to send/receive commands from the messenger/broadcaster.

5.1 Client Class Reference 15

Author

Laurent Forthomme laurent.forthomme@cern.ch

Date

24 Mar 2015

5.1.2 Constructor & Destructor Documentation

5.1.2.1 Client::Client() [inline]


General void client constructor.

5.1.2.2 Client::Client (int port)

Bind a socket client to a given port.

5.1.2.3 Client::~Client() [virtual]

Here is the call graph for this function:




5.1.3 Member Function Documentation

5.1.3.1 void Client::Announce() [private]

Announce our entry on the socket to its master.


Here is the call graph for this function:



5.1.3.2 bool Client::Connect ()

Bind this client to the socket.

Here is the call graph for this function:




5.1.3.3 void Client::Disconnect ()

Unbind this client from the socket.

5.1 Client Class Reference 17

Here is the call graph for this function:



5.1.3.4 virtual SocketType Client::GetType () const [inline], [virtual]

Socket actor type retrieval method.

Reimplemented in FPGAHandler.


5.1.3.5 virtual void Client::ParseMessage (const SocketMessage & m) [inline], [virtual]

Parse a SocketMessage received from the master.

5.1.3.6 void Client::Receive ()

Receive a socket message from the master.

Here is the call graph for this function:



5.1.3.7 void Client::Send (const Message & m) const [inline]

Send a message to the master through the socket.

Here is the call graph for this function:



5.1.4 Field Documentation

5.1.4.1 int Client::fClientId [private]

5.1.4.2 bool Client::flsConnected [private]

The documentation for this class was generated from the following files:

- · include/Client.h
- · src/Client.cpp

5.2 Exception Class Reference

A simple exception handler.

#include <Exception.h>

Public Member Functions

- Exception (const char *from, std::string desc, ExceptionType type=Undefined, const int id=0)
- Exception (const char *from, const char *desc, ExceptionType type=Undefined, const int id=0)
- ∼Exception ()
- std::string From () const
- int ErrorNumber () const
- · std::string Description () const
- ExceptionType Type () const
- std::string TypeString () const
- void Dump (std::ostream &os=std::cerr) const

Private Attributes

- std::string fFrom
- std::string fDescription
- ExceptionType fType
- int fErrorNumber

5.2.1 Detailed Description

A simple exception handler.

Author

Laurent Forthomme laurent.forthomme@cern.ch

Date

24 Mar 2015

5.2.2 Constructor & Destructor Documentation

- **5.2.2.1** Exception::Exception (const char * from, std::string desc, ExceptionType type = Undefined, const int id = 0) [inline]
- **5.2.2.2** Exception::Exception (const char * *from*, const char * *desc*, ExceptionType *type =* Undefined, const int *id =* 0) [inline]
- 5.2.2.3 Exception:: \sim Exception() [inline]

Here is the call graph for this function:




5.2.3 Member Function Documentation

5.2.3.1 std::string Exception::Description () const [inline]

5.2.3.2 void Exception::Dump (std::ostream & os = std::cerr) const [inline]

Here is the call graph for this function:



- **5.2.3.3** int Exception::ErrorNumber() const [inline]
- **5.2.3.4** std::string Exception::From () const [inline]
- 5.2.3.5 ExceptionType Exception::Type () const [inline]
- **5.2.3.6** std::string Exception::TypeString() const [inline]

Here is the call graph for this function:



5.2.4 Field Documentation

- **5.2.4.1 std::string Exception::fDescription** [private]
- **5.2.4.2 int Exception::fErrorNumber** [private]
- **5.2.4.3 std::string Exception::fFrom** [private]
- 5.2.4.4 ExceptionType Exception::fType [private]

The documentation for this class was generated from the following file:


• include/Exception.h

5.3 file_header_t Struct Reference

Header to the output files.

#include <FPGAHandler.h>

Collaboration diagram for file_header_t:



Data Fields

- · uint32 t magic
- uint32_t run_id
- uint32_t spill_id
- TDCSetup config

5.3.1 Detailed Description

Header to the output files.

General header to store in each collected data file for offline readout. It enable any reader to retrieve the run/spill number, as well as the HPTDC configuration during data collection.

Author

Laurent Forthomme laurent.forthomme@cern.ch

Date

14 Apr 2015

5.3.2 Field Documentation

5.3.2.1 TDCSetup file_header_t::config

5.3.2.2 uint32_t file_header_t::magic

5.3.2.3 uint32_t file_header_t::run_id

5.3.2.4 uint32_t file_header_t::spill_id

The documentation for this struct was generated from the following file:


• include/FPGAHandler.h

5.4 FPGAHandler Class Reference


Driver for timing detectors' FPGA readout.

#include <FPGAHandler.h>

Inheritance diagram for FPGAHandler:



Collaboration diagram for FPGAHandler:



Public Member Functions

• FPGAHandler (int port, const char *dev)

Bind to a FPGA through the USB protocol, and to the socket.

- virtual ∼FPGAHandler ()
- void OpenFile ()

Open an output file to store header/HPTDC events.

• void CloseFile ()

Close a previously opened output file used to store header/HPTDC events.

• std::string GetFilename () const

Retrieve the file name used to store data collected from the FPGA.

void SetConfiguration (const TDCSetup &c)

Submit the HPTDC setup word as a TDCSetup object.

• TDCSetup GetConfiguration ()

Retrieve the HPTDC setup word as a TDCSetup object.

- void ReadBuffer ()
- SocketType GetType () const

Socket actor type retrieval method.

Private Member Functions

· void SendConfiguration ()

Set the setup word to the HPTDC internal setup register.

• void ReadConfiguration ()

Read the setup word from the HPTDC internal setup register.

• void ReadBoundaryScanRegister ()

Private Attributes

- · std::string fFilename
- std::ofstream fOutput
- TDCSetup fTDCSetup
- TDCBoundaryScanRegister fTDCBSR
- bool flsFileOpen
- bool flsTDCInReadout

Additional Inherited Members

5.4.1 Detailed Description

Driver for timing detectors' FPGA readout.

Main driver for a homebrew FPGA designed for the timing detectors' HPTDC chip readout.

Author

Laurent Forthomme laurent.forthomme@cern.ch

Date


14 Apr 2015

5.4.2 Constructor & Destructor Documentation

5.4.2.1 FPGAHandler::FPGAHandler (int port, const char * dev)

Bind to a FPGA through the USB protocol, and to the socket.

Here is the call graph for this function:



5.4.2.2 FPGAHandler::~**FPGAHandler()** [virtual]

Here is the call graph for this function:



5.4.3 Member Function Documentation


5.4.3.1 void FPGAHandler::CloseFile ()

Close a previously opened output file used to store header/HPTDC events.

5.4.3.2 TDCSetup FPGAHandler::GetConfiguration() [inline]

Retrieve the HPTDC setup word as a TDCSetup object.

Here is the call graph for this function:



5.4.3.3 std::string FPGAHandler::GetFilename () const [inline]

Retrieve the file name used to store data collected from the FPGA.

5.4.3.4 SocketType FPGAHandler::GetType() const [inline], [virtual]

Socket actor type retrieval method.

Reimplemented from Client.

5.4.3.5 void FPGAHandler::OpenFile ()

Open an output file to store header/HPTDC events.


5.4.3.6 void FPGAHandler::ReadBoundaryScanRegister() [private]

5.4.3.7 void FPGAHandler::ReadBuffer ()

5.4.3.8 void FPGAHandler::ReadConfiguration() [private]

Read the setup word from the HPTDC internal setup register.


Here is the call graph for this function:



5.4.3.9 void FPGAHandler::SendConfiguration() [private]

Set the setup word to the HPTDC internal setup register.

Here is the call graph for this function:



5.4.3.10 void FPGAHandler::SetConfiguration (const TDCSetup & c) [inline]

Submit the HPTDC setup word as a TDCSetup object.

Here is the call graph for this function:



- 5.4.4 Field Documentation
- **5.4.4.1 std::string FPGAHandler::fFilename** [private]
- **5.4.4.2 bool FPGAHandler::flsFileOpen** [private]
- **5.4.4.3 bool FPGAHandler::flsTDClnReadout** [private]
- **5.4.4.4 std::ofstream FPGAHandler::fOutput** [private]
- **5.4.4.5 TDCBoundaryScanRegister FPGAHandler::fTDCBSR** [private]
- **5.4.4.6 TDCSetup FPGAHandler::fTDCSetup** [private]

The documentation for this class was generated from the following files:


- · include/FPGAHandler.h
- src/FPGAHandler.cpp

5.5 HTTPMessage Class Reference


Message to be transmitted through a WebSocket protocol.

#include <HTTPMessage.h>

Inheritance diagram for HTTPMessage:



Collaboration diagram for HTTPMessage:



Public Member Functions

- HTTPMessage (WebSocket *ws, Message m, MessageAction a)
- HTTPMessage (WebSocket *ws, const char *msg, MessageAction a)
- void Decode ()
- void Encode ()
- MessageKey GetKey () const
- void Dump (std::ostream &os=std::cout) const

Private Attributes

- WebSocket * fWS
- std::string fOriginalString

Additional Inherited Members

5.5.1 Detailed Description

Message to be transmitted through a WebSocket protocol.

Type of message compatible to the transmission through a WebSocket protocol. It enables a direct conversion of standards from any socket message format used elsewhere in this code using the *MessageAction* statement.

Author

Laurent Forthomme laurent.forthomme@cern.ch


Date

1 Apr 2015

5.5.2 Constructor & Destructor Documentation


5.5.2.1 HTTPMessage::HTTPMessage (WebSocket * ws, Message m, MessageAction a) [inline]

Here is the call graph for this function:



5.5.2.2 HTTPMessage::HTTPMessage (WebSocket * ws, const char * msg, MessageAction a) [inline]

Here is the call graph for this function:



5.5.3 Member Function Documentation

```
5.5.3.1 void HTTPMessage::Decode( ) [inline]
5.5.3.2 void HTTPMessage::Dump( std::ostream & os = std::cout ) const [inline]
5.5.3.3 void HTTPMessage::Encode( ) [inline]
5.5.3.4 MessageKey HTTPMessage::GetKey( ) const [inline]
5.5.4 Field Documentation
5.5.4.1 std::string HTTPMessage::fOriginalString [private]
```

5.5.4.2 WebSocket* HTTPMessage::fWS [private]

The documentation for this class was generated from the following file:

• include/HTTPMessage.h

5.6 ListenerInfo Struct Reference

Information on a socket's listener.

```
#include <Messenger.h>
```

Data Fields

- std::string name
- Socket::SocketType type

5.6.1 Detailed Description

Information on a socket's listener.

Structure handling its name and type for any listener/client to be used in the socket management parts of this code.

5.6.2 Field Documentation

5.6.2.1 std::string ListenerInfo::name

5.6.2.2 Socket::SocketType ListenerInfo::type

The documentation for this struct was generated from the following file:


· include/Messenger.h

5.7 Message Class Reference

Base socket message type.

```
#include <Message.h>
```

Inheritance diagram for Message:



Public Member Functions

• Message ()

Void message constructor.

Message (const char *msg)

Construct a message from a string.

Message (std::string msg)

Construct a message from a string.

- virtual ∼Message ()
- MessageKey GetKey () const

Placeholder for the MessageKey retrieval method.

• std::string GetString () const

Retrieve the string carried by this message as a whole.

• bool IsFromWeb () const

Extract from any message its potential arrival from a WebSocket protocol.

• void Dump (std::ostream &os=std::cout) const

Protected Attributes

· std::string fString

5.7.1 Detailed Description

Base socket message type.

Base handler for messages to be transmitted through the socket

Author

Laurent Forthomme laurent.forthomme@cern.ch

Date

6 Apr 2015

5.7.2 Constructor & Destructor Documentation

```
5.7.2.1 Message::Message() [inline]
```

Void message constructor.

```
5.7.2.2 Message::Message (const char * msg ) [inline]
```

Construct a message from a string.

```
5.7.2.3 Message::Message ( std::string msg ) [inline]
```

Construct a message from a string.

```
5.7.2.4 virtual Message::~Message() [inline], [virtual]
```

5.7.3 Member Function Documentation

```
5.7.3.1 void Message::Dump ( std::ostream & os = std::cout ) const [inline]
```

```
5.7.3.2 MessageKey Message::GetKey ( ) const [inline]
```

Placeholder for the MessageKey retrieval method.

```
5.7.3.3 std::string Message::GetString()const [inline]
```

Retrieve the string carried by this message as a whole.

```
5.7.3.4 bool Message::lsFromWeb() const [inline]
```

Extract from any message its potential arrival from a WebSocket protocol.

5.7.4 Field Documentation

```
5.7.4.1 std::string Message::fString [protected]
```

The documentation for this class was generated from the following file:


· include/Message.h

5.8 Messenger Class Reference


Base master object for the socket.

```
#include <Messenger.h>
```

Inheritance diagram for Messenger:



Collaboration diagram for Messenger:



Public Member Functions

• Messenger ()

Build a void master object or socket actor.

• Messenger (int port)

Build a master object to control the socket.

- ∼Messenger ()
- bool Connect ()

Connect the master to the socket.

• void Disconnect ()

Remove the master and destroy the socket.

• void Send (const Message &m, int sid) const

Send any type of message to any client.

• void Receive ()

Handle a message reception from a client.

• void Broadcast (const Message &m) const

Emit a message to all clients connected through the socket.

• SocketType GetType () const

Socket actor type retrieval method.

Private Member Functions

• void AddClient ()

Add a client to listen to.

void DisconnectClient (int sid, MessageKey key, bool force=false)

Disconnect a client.

- void SwitchClientType (int sid, Socket::SocketType type)
- void ProcessMessage (SocketMessage m, int sid)

Process a message received from the socket.

Private Attributes

- WebSocket * fWS
- · int fNumAttempts
- std::vector< ListenerInfo > fListenersInfo

Additional Inherited Members

5.8.1 Detailed Description

Base master object for the socket.

Messenger/broadcaster object used by the server to send/receive commands from the clients/listeners.

Author

Laurent Forthomme laurent.forthomme@cern.ch

Date

23 Mar 2015

5.8.2 Constructor & Destructor Documentation

5.8.2.1 Messenger::Messenger()

Build a void master object or socket actor.

5.8.2.2 Messenger::Messenger (int port)


Build a master object to control the socket.

Here is the call graph for this function:



5.8.2.3 Messenger::~Messenger()

Here is the call graph for this function:




5.8.3 Member Function Documentation

5.8.3.1 void Messenger::AddClient() [private]

Add a client to listen to.

Add one client to the list of socket actors to monitor for message retrieval/submission.

Here is the call graph for this function:




5.8.3.2 void Messenger::Broadcast (const Message & m) const

Emit a message to all clients connected through the socket.

Parameters

in	m	Message to transmit

Here is the call graph for this function:




5.8.3.3 bool Messenger::Connect ()

Connect the master to the socket.

Connect this master to the socket for clients to be able to bind.

Here is the call graph for this function:




5.8.3.4 void Messenger::Disconnect ()

Remove the master and destroy the socket.

Remove this master from the socket, thus disconnecting automatically the clients connected.

Here is the call graph for this function:



5.8.3.5 void Messenger::DisconnectClient (int sid, MessageKey key, bool force = false) [private]


Disconnect a client.

Ask to a client to disconnect from this socket.

Parameters

in	sid	Unique identifier of the client to disconnect
in	key	Key to the message to transmit for disconnection
in	force	Do we need to force the client out of this socket?

Here is the call graph for this function:



5.8.3.6 SocketType Messenger::GetType () const [inline]

Socket actor type retrieval method.


5.8.3.7 void Messenger::ProcessMessage (**SocketMessage** *m*, int *sid*) [private]

Process a message received from the socket.

Parameters

_			
	in	Unique	identifier of the client sending the message


Here is the call graph for this function:



5.8.3.8 void Messenger::Receive ()

Handle a message reception from a client.

Here is the call graph for this function:




5.8.3.9 void Messenger::Send (const Message & m, int sid) const [inline]

Send any type of message to any client.

Parameters


in	m	Message to transmit
in	sid	Unique identifier of the client on this socket

Here is the call graph for this function:



5.8.3.10 void Messenger::SwitchClientType (int sid, Socket::SocketType type) [private]

Here is the call graph for this function:



- 5.8.4 Field Documentation
- **5.8.4.1** std::vector<ListenerInfo> Messenger::fListenersInfo [private]
- **5.8.4.2** int Messenger::fNumAttempts [private]
- **5.8.4.3 WebSocket*** Messenger::fWS [private]

The documentation for this class was generated from the following files:

- · include/Messenger.h
- src/Messenger.cpp


5.9 Socket Class Reference 39

5.9 Socket Class Reference

Base socket object from which clients/master from a socket inherit.

```
#include <Socket.h>
```

Inheritance diagram for Socket:



Public Types

enum SocketType {
 INVALID =-1, MASTER =0, WEBSOCKET_CLIENT, CLIENT,
 DETECTOR }

Type of actor playing a role on the socket.

typedef std::set< std::pair< int, SocketType > > SocketCollection

Public Member Functions

- Socket ()
- Socket (int port)
- virtual ∼Socket ()
- void Stop ()

Terminates the socket and all attached communications.

- void SetPort (int port)
- int GetPort () const

Retrieve the port used for this socket.

void AcceptConnections (Socket &socket)

Accept connection from a client.

- void SelectConnections ()
- void SetSocketId (int sid)
- int GetSocketId () const
- SocketType GetSocketType (int sid) const
- · bool IsWebSocket (int sid) const
- void DumpConnected () const

Protected Member Functions

· bool Start ()

Start the socket.

• void Bind ()

Bind a name to a socket.

- void PrepareConnection ()
- void Listen (int maxconn)

Listen to incoming messages.

• void SendMessage (Message message, int id=-1) const

Send a message on a socket.

• Message FetchMessage (int id=-1) const

Receive a message from a socket.

Protected Attributes

- int fPort
- char fBuffer [MAX_WORD_LENGTH]
- · SocketCollection fSocketsConnected
- · fd_set fMaster

Master file descriptor list.

• fd_set fReadFds

Temp file descriptor list for select()

Private Member Functions

• void Create ()

Create an endpoint for communication.

• void Configure ()

Configure the socket object for communication.

Private Attributes

- · int fSocketId
- · struct sockaddr_in fAddress

5.9.1 Detailed Description

Base socket object from which clients/master from a socket inherit.

General object providing all useful method to connect/bind/send/receive information through system sockets.

Author

Laurent Forthomme laurent.forthomme@cern.ch

Date

23 Mar 2015

5.9 Socket Class Reference 41

5.9.2 Member Typedef Documentation

 $\textbf{5.9.2.1} \quad \textbf{typedef std::set} < \textbf{std::pair} < \textbf{int,SocketType} > \textbf{Socket::SocketCollection}$

5.9.3 Constructor & Destructor Documentation

```
5.9.3.1 Socket::Socket() [inline]
```

5.9.3.2 Socket::Socket (int port)

5.9.3.3 Socket::~Socket() [virtual]

5.9.4 Member Function Documentation

5.9.4.1 void Socket::AcceptConnections (Socket & socket)


Accept connection from a client.

Set the socket to accept connections any client transmitting through the socket

Parameters

in,out	socket	Master/client object to enable on the socket
--------	--------	--

Here is the call graph for this function:



5.9.4.2 void Socket::Bind() [protected]

Bind a name to a socket.

Returns

Success of the operation

Here is the call graph for this function:



```
5.9.4.3 void Socket::Configure() [private]
Configure the socket object for communication.
5.9.4.4 void Socket::Create() [private]
Create an endpoint for communication.
5.9.4.5 void Socket::DumpConnected() const
5.9.4.6 Message Socket::FetchMessage(int id = -1) const [protected]
Receive a message from a socket.
Returns
    Received message as a std::string
```

 $\textbf{5.9.4.7} \quad \textbf{int Socket::GetPort () const} \quad \texttt{[inline]}$

Retrieve the port used for this socket.

5.9.4.8 int Socket::GetSocketId () const [inline]

5.9.4.9 SocketType Socket::GetSocketType (int sid) const [inline]

5.9.4.10 bool Socket::IsWebSocket (int sid) const [inline]

Here is the call graph for this function:



5.9.4.11 void Socket::Listen (int maxconn) [protected]

Listen to incoming messages.

Set the socket to listen to any message coming from outside

5.9 Socket Class Reference 43

Here is the call graph for this function:



5.9.4.12 void Socket::PrepareConnection() [protected]

Here is the call graph for this function:



5.9.4.13 void Socket::SelectConnections ()

Register all open file descriptors to read their communication through the socket

5.9.4.14 void Socket::SendMessage (Message message, int id = -1) const [protected]

Send a message on a socket.

Here is the call graph for this function:



5.9.4.15 void Socket::SetPort (int port) [inline]

5.9.4.16 void Socket::SetSocketId (int sid) [inline]

5.9.4.17 bool Socket::Start() [protected]


Start the socket.

Launch all mandatory operations to set the socket to be used

Returns

Success of the operation

Here is the call graph for this function:



5.9.4.18 void Socket::Stop ()

Terminates the socket and all attached communications.

- 5.9.5 Field Documentation
- **5.9.5.1 struct sockaddr_in Socket::fAddress** [private]
- **5.9.5.2 char Socket::fBuffer[MAX_WORD_LENGTH]** [protected]
- **5.9.5.3 fd_set Socket::fMaster** [protected]

Master file descriptor list.

5.9.5.4 int Socket::fPort [protected]

5.9.5.5 fd_set Socket::fReadFds [protected]

Temp file descriptor list for select()

5.9.5.6 int Socket::fSocketId [private]

A file descriptor for this socket, if *Create* was performed beforehand.

5.9.5.7 SocketCollection Socket::fSocketsConnected [protected]

The documentation for this class was generated from the following files:


- · include/Socket.h
- src/Socket.cpp

5.10 SocketMessage Class Reference


Socket-passed message type.

#include <SocketMessage.h>

Inheritance diagram for SocketMessage:



Collaboration diagram for SocketMessage:



Public Member Functions

- SocketMessage ()
- SocketMessage (const Message &msg)
- SocketMessage (const char *msg_s)
- SocketMessage (std::string msg_s)
- SocketMessage (const MessageKey &key)

Construct a socket message out of a key.

- SocketMessage (const MessageKey &key, const char *value)
 - Construct a socket message out of a key and a string-type value.
- SocketMessage (const MessageKey &key, std::string value)

Construct a socket message out of a key and a string-type value.

• SocketMessage (const MessageKey &key, const int value)

Construct a socket message out of a key and an integer-type value.

SocketMessage (const MessageKey &key, const float value)

Construct a socket message out of a key and a float-type value.

SocketMessage (const MessageKey &key, const double value)

Construct a socket message out of a key and a double precision-type value.

SocketMessage (MessageMap msg_m)

Construct a socket message out of a map of key/string-type value.

- ∼SocketMessage ()
- void SetKeyValue (const MessageKey &key, const char *value)

String-valued message.

void SetKeyValue (const MessageKey &key, int int_value)

Send an integer-valued message.

• void SetKeyValue (const MessageKey &key, float float_value)

Float-valued message.

• void SetKeyValue (const MessageKey &key, double double_value)

Double-valued message.

• std::string GetString () const

Extract the whole key:value message.

· MessageKey GetKey () const

Extract the message's key.

· std::string GetValue () const

Extract the message's string value.

• int GetIntValue () const

Extract the message's integer value.

VectorValue GetVectorValue () const

Extract the message's vector of string value.

void Dump (std::ostream &os=std::cout) const

Private Member Functions

- MessageMap Object () const
- std::string String () const

Private Attributes

MessageMap fMessage

Additional Inherited Members

5.10.1 Detailed Description

Socket-passed message type.

Author

Laurent Forthomme laurent.forthomme@cern.ch

Date

26 Mar 2015

5.10.2 Constructor & Destructor Documentation

5.10.2.1 SocketMessage::SocketMessage() [inline]

5.10.2.2 SocketMessage::SocketMessage (const Message & msg) [inline]

Here is the call graph for this function:



5.10.2.3 SocketMessage::SocketMessage (const char * msg_s) [inline]

Here is the call graph for this function:



5.10.2.4 SocketMessage::SocketMessage (std::string *msg_s*) [inline]


Here is the call graph for this function:



5.10.2.5 SocketMessage::SocketMessage (const MessageKey & key) [inline]

Construct a socket message out of a key.


Here is the call graph for this function:



5.10.2.6 SocketMessage::SocketMessage (const MessageKey & key, const char * value) [inline]

Construct a socket message out of a key and a string-type value.

Here is the call graph for this function:



5.10.2.7 SocketMessage::SocketMessage (const MessageKey & key, std::string value) [inline]

Construct a socket message out of a key and a string-type value.

Here is the call graph for this function:



5.10.2.8 SocketMessage::SocketMessage (const MessageKey & key, const int value) [inline]

Construct a socket message out of a key and an integer-type value.


Here is the call graph for this function:



5.10.2.9 SocketMessage::SocketMessage(const MessageKey & key, const float value) [inline]

Construct a socket message out of a key and a float-type value.

Here is the call graph for this function:



5.10.2.10 SocketMessage::SocketMessage (const MessageKey & key, const double value) [inline]

Construct a socket message out of a key and a double precision-type value.

Here is the call graph for this function:



5.10.2.11 SocketMessage::SocketMessage (MessageMap *msg_m*) [inline]


Construct a socket message out of a map of key/string-type value.

5.10.2.12 SocketMessage:: \sim SocketMessage() [inline]

5.10.3 Member Function Documentation

5.10.3.1 void SocketMessage::Dump (std::ostream & os = std::cout) const [inline]

Here is the call graph for this function:



5.10.3.2 int SocketMessage::GetIntValue() const [inline]

Extract the message's integer value.

5.10.3.3 MessageKey SocketMessage::GetKey () const [inline]

Extract the message's key.

5.10.3.4 std::string SocketMessage::GetString () const [inline]

Extract the whole key:value message.

5.10.3.5 std::string SocketMessage::GetValue() const [inline]

Extract the message's string value.

5.10.3.6 VectorValue SocketMessage::GetVectorValue () const [inline]

Extract the message's vector of string value.

Here is the call graph for this function:



5.10.3.7 MessageMap SocketMessage::Object() const [inline], [private]

5.10.3.8 void SocketMessage::SetKeyValue (const MessageKey & key, const char * value) [inline]

String-valued message.

Here is the call graph for this function:



5.10.3.9 void SocketMessage::SetKeyValue (const MessageKey & key, int int_value) [inline]

Send an integer-valued message.

Here is the call graph for this function:



5.10.3.10 void SocketMessage::SetKeyValue (const MessageKey & key, float float_value) [inline]

Float-valued message.

Here is the call graph for this function:



5.10.3.11 void SocketMessage::SetKeyValue (const MessageKey & key, double double_value) [inline]

Double-valued message.

Here is the call graph for this function:



5.10.3.12 std::string SocketMessage::String () const [inline], [private]

5.10.4 Field Documentation

5.10.4.1 MessageMap SocketMessage::fMessage [private]


The documentation for this class was generated from the following file:

• include/SocketMessage.h


5.11 TDCBoundaryScanRegister Class Reference

#include <TDCBoundaryScan.h>

Inheritance diagram for TDCBoundaryScanRegister:



Collaboration diagram for TDCBoundaryScanRegister:



Public Member Functions

- TDCBoundaryScanRegister ()
- virtual ~TDCBoundaryScanRegister ()

Additional Inherited Members

5.11.1 Detailed Description

Author

Laurent Forthomme laurent.forthomme@cern.ch

Date

24 Apr 2015

5.11.2 Constructor & Destructor Documentation

5.11.2.1 TDCBoundaryScanRegister::TDCBoundaryScanRegister() [inline]

5.11.2.2 virtual TDCBoundaryScanRegister::~TDCBoundaryScanRegister() [inline], [virtual]


The documentation for this class was generated from the following file:

• include/TDCBoundaryScan.h


5.12 TDCControl Class Reference

#include <TDCControl.h>

Inheritance diagram for TDCControl:



Collaboration diagram for TDCControl:



Public Types

• enum EnablePattern

Public Member Functions

- TDCControl ()
- TDCControl (const TDCControl &c)
- virtual ∼TDCControl ()
- void SetEnablePattern (const EnablePattern &ep)
- void SetGlobalReset (const bool gr=true)

- void SetDLLReset (const bool dr=true)
- void SetPLLReset (const bool pr=true)
- void SetControlParity (const bool cp=true)
- void Dump (int verb=1, std::ostream &os=std::cout) const

Static Private Attributes

- static const bit kEnablePattern = 0
- static const bit kGlobalReset = 4
- static const bit kEnableChannel = 5
- static const bit kDLLReset = 37
- static const bit kPLLReset = 38
- static const bit kControlParity = 39

Additional Inherited Members

- 5.12.1 Member Enumeration Documentation
- 5.12.1.1 enum TDCControl::EnablePattern
- 5.12.2 Constructor & Destructor Documentation
- **5.12.2.1 TDCControl::TDCControl()** [inline]
- 5.12.2.2 TDCControl::TDCControl (const TDCControl & c) [inline]

Here is the call graph for this function:



- 5.12.2.3 virtual TDCControl::~TDCControl() [inline], [virtual]
- 5.12.3 Member Function Documentation
- 5.12.3.1 void TDCControl::Dump (int verb = 1, std::ostream & os = std::cout) const [inline]

Here is the call graph for this function:



5.12.3.2 void TDCControl::SetControlParity (const bool cp = true) [inline]

Here is the call graph for this function:



5.12.3.3 void TDCControl::SetDLLReset (const bool dr = true) [inline]

Here is the call graph for this function:



5.12.3.4 void TDCControl::SetEnablePattern (const EnablePattern & ep) [inline]

Here is the call graph for this function:



5.12.3.5 void TDCControl::SetGlobalReset (const bool gr = true) [inline]

Here is the call graph for this function:



```
5.12.3.6 void TDCControl::SetPLLReset (const bool pr = true ) [inline]
```

Here is the call graph for this function:

```
TDCControl::SetPLLReset TDCRegister::SetBits
```

5.12.4 Field Documentation

```
5.12.4.1 const bit TDCControl::kControlParity = 39  [static], [private]
5.12.4.2 const bit TDCControl::kDLLReset = 37  [static], [private]
5.12.4.3 const bit TDCControl::kEnableChannel = 5  [static], [private]
5.12.4.4 const bit TDCControl::kEnablePattern = 0  [static], [private]
5.12.4.5 const bit TDCControl::kGlobalReset = 4  [static], [private]
5.12.4.6 const bit TDCControl::kPLLReset = 38  [static], [private]
```

The documentation for this class was generated from the following file:

· include/TDCControl.h

5.13 TDCEvent Class Reference

HPTDC event parser.

```
#include <TDCEvent.h>
```

Public Types

```
    enum EventType {
        Invalid =-1, GroupHeader =0, GroupTrailer, TDCHeader,
        TDCTrailer, LeadingEdge, TrailingEdge, Error,
        Debug }
```

Public Member Functions

- TDCEvent (const uint32_t &word)
- virtual ~TDCEvent ()
- EventType GetType () const

Type of packet read out from the TDC.

• unsigned int GetTDCld () const

Programmed identifier of master TDC.

• uint16_t GetEventId () const

Event identifier from event counter.

• uint16_t GetWordCount () const

Total number of words in event (including headers and trailers)

· uint16_t GetBunchld () const

Bunch identifier of trigger (or trigger time tag)

uint32_t GetLeadingTime (bool pair=false) const

Leading edge measurement in programmed time resolution.

• uint8_t GetWidth () const

Width of pulse in programmed time resolution.

uint32 t GetTrailingTime () const

Trailing edge measurement in programmed time resolution.

• uint16_t GetErrorFlags () const

Return error flags if an error condition has been detected.

Private Attributes

· uint32 t fWord

5.13.1 Detailed Description

HPTDC event parser.

Object enabling to decipher any measurement/error/debug event returned by the HPTDC chip

Author

Laurent Forthomme laurent.forthomme@cern.ch

Date

20 Apr 2015

5.13.2 Constructor & Destructor Documentation

```
5.13.2.1 TDCEvent::TDCEvent (const uint32_t & word) [inline]
```

```
5.13.2.2 virtual TDCEvent::~TDCEvent() [inline], [virtual]
```

5.13.3 Member Function Documentation

```
5.13.3.1 uint16_t TDCEvent::GetBunchld() const [inline]
```

Bunch identifier of trigger (or trigger time tag)



5.13.3.2 uint16_t TDCEvent::GetErrorFlags () const [inline]

Return error flags if an error condition has been detected.

Here is the call graph for this function:



5.13.3.3 uint16_t TDCEvent::GetEventId() const [inline]

Event identifier from event counter.

Here is the call graph for this function:



5.13.3.4 uint32_t TDCEvent::GetLeadingTime (bool pair = false) const [inline]

Leading edge measurement in programmed time resolution.

Here is the call graph for this function:



5.13.3.5 unsigned int TDCEvent::GetTDCld() const [inline]

Programmed identifier of master TDC.

5.13.3.6 uint32_t TDCEvent::GetTrailingTime () const [inline]

Trailing edge measurement in programmed time resolution.

Here is the call graph for this function:



5.13.3.7 EventType TDCEvent::GetType () const [inline]

Type of packet read out from the TDC.

5.13.3.8 uint8_t TDCEvent::GetWidth() const [inline]

Width of pulse in programmed time resolution.

Here is the call graph for this function:



5.13.3.9 uint16_t TDCEvent::GetWordCount() const [inline]

Total number of words in event (including headers and trailers)

Here is the call graph for this function:



5.13.4 Field Documentation

5.13.4.1 uint32_t TDCEvent::fWord [private]

The documentation for this class was generated from the following file:


• include/TDCEvent.h

5.14 TDCRegister Class Reference

General register object to interact with a HPTDC chip.

#include <TDCRegister.h>

Inheritance diagram for TDCRegister:



Public Types

• typedef uint16_t bit

LSB index.

typedef uint32_t word_t

Unit of the TDC register word to be successfully contained on any machine.

Public Member Functions

- TDCRegister (const size_t size)
- virtual ∼TDCRegister ()
- void SetWord (const unsigned int i, const word_t word)

Set one bit(s) subset in the register word.

word_t GetWord (const unsigned int i) const

Retrieve one subset from the register word.

• uint8_t GetNumWords () const

Number of words in the register.

• void DumpRegister (bit max_bits=-1, std::ostream &os=std::cout) const

Protected Member Functions

• void SetBits (uint16_t lsb, uint16_t word, uint8_t size)

Set bits in the register word.

• uint16_t GetBits (uint16_t lsb, uint8_t size) const

Extract bits from the register word.

Protected Attributes

- word_t * fWord
- size t fNumWords

5.14.1 Detailed Description

General register object to interact with a HPTDC chip.

Author

Laurent Forthomme laurent.forthomme@cern.ch

Date

24 Apr 2015

5.14.2 Member Typedef Documentation

5.14.2.1 typedef uint16_t TDCRegister::bit

LSB index.

5.14.2.2 typedef uint32_t TDCRegister::word_t

Unit of the TDC register word to be successfully contained on any machine.

5.14.3 Constructor & Destructor Documentation

```
5.14.3.1 TDCRegister::TDCRegister ( const size_t size ) [inline]
```

5.14.3.2 virtual TDCRegister::~TDCRegister() [inline], [virtual]

5.14.4 Member Function Documentation

5.14.4.1 void TDCRegister::DumpRegister (bit max_bits = -1, std::ostream & os = std::cout) const [inline]

5.14.4.2 uint16_t TDCRegister::GetBits (uint16_t lsb, uint8_t size) const [inline], [protected]

Extract bits from the register word.

Extract a fixed amount of bits from the full register word

Parameters

in	Isb	Least significant bit of the word to retrieve
in	size	Size of the word to retrieve

5.14.4.3 uint8_t TDCRegister::GetNumWords () const [inline]

Number of words in the register.

Return the number of words making up the full register word.

5.14.4.4 word_t TDCRegister::GetWord (const unsigned int *i*) const [inline]

Retrieve one subset from the register word.

5.14.4.5 void TDCRegister::SetBits (uint16_t lsb, uint16_t word, uint8_t size) [inline], [protected]

Set bits in the register word.

Set a fixed amount of bits in the full register word

Parameters

in	Isb	Least significant bit of the word to set
in	word	Word to set
in	size	Size of the word to set

5.14.4.6 void TDCRegister::SetWord (const unsigned int i, const word_t word) [inline]

Set one bit(s) subset in the register word.

5.14.5 Field Documentation

5.14.5.1 size_t TDCRegister::fNumWords [protected]

5.14.5.2 word_t* TDCRegister::fWord [protected]

The documentation for this class was generated from the following file:


• include/TDCRegister.h

5.15 TDCSetup Class Reference


Setup word to be sent to the HPTDC chip.

#include <TDCSetup.h>

Inheritance diagram for TDCSetup:



Collaboration diagram for TDCSetup:



Public Types

```
enum EdgeResolution {
 E_100ps =0, E_200ps, E_400ps, E_800ps,
 E_1p6ns, E_3p12ns, E_6p25ns, E_12p5ns }

    enum DeadTime { DT_5ns =0, DT_10ns, DT_30ns, DT_100ns }

enum WidthResolution {
 W_100ps =0, W_200ps, W_400ps, W_800ps,
 W_1p6ns, W_3p2ns, W_6p25ns, W_12p5ns,
 W 25ns, W 50ns, W 100ns, W 200ns,
 W_400ns, W_800ns }
enum EnabledError {
 VernierError =0x1, CoarseError =0x2, ChannelSelectError =0x4, L1BufferParityError =0x8,
 TriggerFIFOParityError =0x10, TriggerMatchingError =0x20, ReadoutFIFOParityError =0x40, ReadoutState ←
 Error =0x80,
 SetupParityError =0x100, ControlParityError =0x200, JTAGInstructionParityError =0x400 }
enum DLLSpeedMode { DLL_40MHz =0x0, DLL_160MHz =0x1, DLL_320MHz =0x2, DLL_Illegal =0x3 }
• enum SerialClockSource { Serial pll clock 80 =0x0, Serial pll clock 160 =0x1, Serial pll clock 40 =0x2,
 Serial aux clock =0x3 }

    enum IOClockSource { IO_clock_40 =0x0, IO_pll_clock_80 =0x1, IO_pll_clock_160 =0x2, IO_aux_clock =0x3

    enum CoreClockSource { Core_clock_40 =0x0, Core_pll_clock_80 =0x1, Core_pll_clock_160 =0x2, Core_
        ←

 aux_clock =0x3 }
• enum DLLClockSource {
 DLL_clock_40 =0x0, DLL_pll_clock_40 =0x1, DLL_pll_clock_160 =0x2, DLL_pll_clock_320 =0x3,
 DLL aux clock =0x4 }

    enum ReadoutSpeed { RO_Fixed =0x0, RO_pll_80Mbits_s =0x1 }

    enum SerialStrobeType { SS_NoStrobe =0x0, SS_DSStrobe =0x1, SS_LeadingTrailingStrobe =0x2, SS_←

 LeadingEdge =0x3 }

    enum ReadoutSingleCycleSpeed {

 RSC_40Mbits_s =0x0, RSC_20Mbits_s =0x1, RSC_10Mbits_s =0x2, RSC_5Mbits_s =0x3,
 RSC\_2p5Mbits\_s = 0x4, RSC\_1p25Mbits\_s = 0x5, RSC\_625kbits\_s = 0x6, RSC\_312p5kbits\_s = 0x7 \}
```

Public Member Functions

- TDCSetup ()
- TDCSetup (const TDCSetup &c)
- virtual ∼TDCSetup ()
- void SetEnableErrorMark (const bool em)

Mark events with error if global error signal is set.

- bool GetEnableErrorMark () const
- void SetEnableErrorBypass (const bool eb)

Bypass TDC chip if global error signal is set.

- bool GetEnableErrorBypass () const
- void SetEnableError (const uint16_t &err)

Enable internal error types for generation of global error signals.

- uint16_t GetEnableError () const
- void SetEnableSerial (const bool es)

Enable of serial read-out (otherwise parallel read-out)

- bool GetEnableSerial () const
- void SetEnableJTAGReadout (const bool jr)

Enable of read-out via JTAG.

- bool GetEnableJTAGReadout () const
- void SetReadoutFIFOSize (int rfs)

Effective size of readout FIFO.

- · int GetReadoutFIFOSize () const
- void SetRejectCountOffset (uint16_t rco)

Set the offset in reject counter (defines reject latency together with coarse count offset)

• uint16 t GetRejectCountOffset () const

Extract the offset in reject counter.

void SetSearchWindow (uint16_t sw)

Set the search window (in multiples of clock cycles: 0=25 ns, 1=50 ns, ...)

• uint16_t GetSearchWindow () const

Extract the search window (in multiples of clock cycles: 0=25 ns, 1=50 ns, ...)

void SetMatchWindow (uint16_t mw)

Set the matching window (in multiples of clock cycles: 0=25 ns, 1=50 ns, ...)

· uint16 t GetMatchWindow () const

Extract the matching window (in multiples of clock cycles: 0=25 ns, 1=50 ns, ...)

- void SetEdgeResolution (const EdgeResolution r)
- EdgeResolution GetEdgeResolution () const
- void SetMaxEventSize (int sz=-1)

Set the maximum number of hits per event.

uint8_t GetMaxEventSize () const

Extract the maximum number of hits per event.

void SetRejectFIFOFull (const bool rej=true)

Reject hits when readout FIFO full.

· bool GetRejectFIFOFull () const

Are hits rejected when readout FIFO is full?

void SetEnableReadoutOccupancy (const bool ro=true)

Enable the readout of buffer occupancies for each event (for debugging purposes)

- bool GetEnableReadoutOccupancy () const
- void SetEnableReadoutSeparator (const bool ro=true)

Enable the readout of separators for each event (for debugging purposes, valid if readout of occupancies is enabled)

- bool GetEnableReadoutSeparator () const
- void SetEventCountOffset (uint16 t eco)

Set offset for the event counter.

void SetTriggerCountOffset (uint16_t tco)

Set offset for the trigger time tag counter to set effective trigger latency.

• uint16_t GetTriggerCountOffset () const

Extract trigger time tag count offset.

void SetChannelOffset (int channel, uint16_t offset)

Set the time offset for one single channel.

uint16 t GetChannelOffset (int channel) const

Return the offset for one single channel.

void SetAllChannelsOffset (uint16_t offset)

Set the time offset for all channels.

void SetCoarseCountOffset (uint16 t cco)

Set offset for the coarse time counter.

uint16 t GetCoarseCountOffset () const

Extract offset for the coarse time counter.

void SetDLLAdjustment (int tap, uint8 t adj)

Set the DLL taps adjustments with a resolution of \sim 10 ps.

uint8_t GetDLLAdjustment (int tap) const

Set the adjustment of DLL taps.

void SetAllTapsDLLAdjustment (uint8 t adj)

Extract the adjustment of DLL taps.

• void SetRCAdjustment (int tap, uint8_t adj)

Set the adjustment of the RC delay line.

• uint8_t GetRCAdjustment (int tap)

Extract the adjustment of the RC delay line.

void SetWidthResolution (const WidthResolution r)

Set the pulse width resolution when paired measurements are performed.

WidthResolution GetWidthResolution () const

Extract the pulse width resolution when paired measurements are performed.

void SetVernierOffset (const uint8_t vo)

Set the offset in vernier decoding.

uint8_t GetVernierOffset () const

Extract the offset in vernier decoding.

void SetDeadTime (const DeadTime dt)

Channel dead time between hits.

- DeadTime GetDeadTime () const
- void SetTestInvert (const bool ti=true)

Automatic inversion of test pattern. Only used during production testing.

- bool GetTestInvert () const
- void SetTestMode (const bool tm=true)

Test mode where hit data are taken from coretest. Only used during production testing.

- bool GetTestMode () const
- void SetTrailingMode (const bool trail=true)

Enable/disable the detection of trailing edges.

• bool GetTrailingMode () const

Extract the status for the detection of trailing edges.

void SetLeadingMode (const bool lead=true)

Enable the detection of leading edges.

• bool GetLeadingMode () const

Extract the status for the detection of leading edges.

void SetTriggerMatchingMode (const bool trig=true)

Set the enable status of trigger matching mode.

bool GetTriggerMatchingMode () const

Extract the enable status of trigger matching mode.

void SetEdgesPairing (const bool pair=true)

Enable the pairing of leading and trailing edges (overrides individual enable of leading/trailing edges)

- · bool GetEdgesPairing () const
- void SetSetupParity (const bool sp=true)

Set the parity of setup data (should be an even parity)

· bool GetSetupParity () const

Extract the parity of setup data (should be an even parity)

void SetConstantValues ()

Ensure that the critical constant values are properly set in the setup word.

uint16 t GetTriggerLatency () const

Effective trigger latency in number of clock cycles (when no counter roll-over is used)

void Dump (int verb=1, std::ostream &os=std::cout) const

Private Member Functions

void SetReadoutSingleCycleSpeed (const ReadoutSingleCycleSpeed rscs=RSC_40Mbits_s)

Serial transmission speed in single cycle mode.

void SetSerialDelay (const uint8_t sd=0x0)

Programmable delay of serial input, in time unit \sim 1 ns.

- void SetStrobeSelect (const SerialStrobeType ss=SS NoStrobe)
- void SetReadoutSpeedSelect (const ReadoutSpeed rss=RO Fixed)

Selection of serial read-out speed.

void SetTokenDelay (const uint8_t td=0x0)

Programmable delay of token input, in time unit \sim 1 ns.

void SetEnableLocalTrailer (const bool elt=true)

Enable of local trailers in read-out.

void SetEnableLocalHeader (const bool elh=true)

Enable of local headers in read-out.

void SetEnableGlobalTrailer (const bool egt=true)

Enable of global trailers in read-out (only valid for master TDC)

void SetEnableGlobalHeader (const bool egh=true)

Enable of global headers in read-out (only valid for master TDC)

- void SetKeepToken (const bool kt=true)
- void SetMaster (const bool m=true)
- void SetEnableBytewise (const bool seb=true)
- void SetBypassInputs (const bool sbi=true)

Select serial in and token in from bypass inputs.

void SetEnableOverflowDetect (const bool eod=true)

Enable overflow detection of L1 buffers (should always be enabled!)

- void SetEnableRelative (const bool er=true)
- void SetEnableAutomaticReject (const bool ear=true)

Enable of automatic rejection (should always be enabled if trigger matching mode!)

void SetEnableSetCountersOnBunchReset (const bool escobr=true)

Enable all counters to be set on bunch count reset.

void SetEnableMasterResetCode (const bool emrc=true)

Enable master reset code on encoded_control.

void SetEnableMasterResetOnEventReset (const bool emroer=true)

Enable master reset of whole TDC on event reset.

void SetEnableResetChannelBufferWhenSeparator (const bool ercbws=true)

Enable reset channel buffers when separator.

void SetEnableSeparatorOnEventReset (const bool esoer=true)

Enable generation of separator on event reset.

• void SetEnableSeparatorOnBunchReset (const bool esobr=true)

Enable generation of separator on bunch reset.

void SetEnableDirectEventReset (const bool eder=true)

Enable of direct event reset input pin (1), otherwise taken from encoded control.

void SetEnableDirectBunchReset (const bool edbr=true)

Enable of direct bunch reset input pin (1), otherwise taken from encoded control.

void SetEnableDirectTrigger (const bool edt=true)

Enable of direct trigger input pin.

void SetLowPowerMode (const bool lpm=true)

Low power mode of channel buffers.

void SetDLLControl (const uint8_t dc)

Control of DLL (DLL charge pump levels)

void SetModeRCCompression (const bool mrc=true)

Perform RC interpolation on-chip (only valid in very high resolution mode)

void SetModeRC (const bool mr=true)

Enable of RR delay lines mode (in very high resolution mode); only for channels 0-4-8-12-16-20-24-28 active.

void SetDLLMode (const DLLSpeedMode dsm)

Selection of DLL speed mode.

 void SetPLLControl (const uint8_t charge_pump_current=0x4, const bool power_down_mode=false, const bool enable_test_outputs=false, const bool invert_connection_to_status=false)

Control of PLL.

void SetSerialClockDelay (const bool delay_clock, const uint8_t delay)

Delay of internal serial clock.

void SetIOClockDelay (const bool delay_clock, const uint8_t delay)

Delay of internal I/O clock.

void SetCoreClockDelay (const bool delay_clock, const uint8_t delay)

Delay of internal core clock.

void SetDLLClockDelay (const bool delay_clock, const uint8_t delay)

Delay of internal DLL clock.

void SetSerialClockSource (const SerialClockSource scs)

Selection of source for serial clock.

void SetIOClockSource (const IOClockSource ics)

Selection of clock source for I/O signals.

void SetCoreClockSource (const CoreClockSource ccs)

Selection of clock source for internal logic.

void SetDLLClockSource (const DLLClockSource dcs)

Selection of clock source for DLL.

void SetRollOver (const uint16_t ro=0xFFF)

Counter roll over value, defining maximal count value from where counters will be reset to 0.

void SetEnableTTLSerial (const bool ts=true)

Enable LV TTL inputs on serial registers, and disable their drivers.

void SetEnableTTLControl (const bool tc=true)

Enable LV TTL inputs on control registers.

void SetEnableTTLReset (const bool tr=true)

Enable LV TTL input on reset, otherwise uses LVDS input levels.

void SetEnableTTLClock (const bool tc=true)

Enable LV TTL inputs on: clk, aux_clock, otherwise uses LVDS input levels.

void SetEnableTTLHit (const bool th=true)

Enable LV TTL input on hit[31:0], otherwise uses LVDS input levels.

Static Private Attributes

- static const bit kTestSelect = 0
- static const bit kEnableErrorMark = 4
- static const bit kEnableErrorBypass = 5
- static const bit kEnableError = 6
- static const bit kReadoutSingleCycleSpeed = 17
- static const bit kSerialDelay = 20
- static const bit kStrobeSelect = 24
- static const bit kReadoutSpeedSelect = 26
- static const bit kTokenDelay = 27
- static const bit kEnableLocalTrailer = 31
- static const bit kEnableLocalHeader = 32
- static const bit kEnableGlobalTrailer = 33
- static const bit kEnableGlobalHeader = 34
- static const bit kKeepToken = 35
- static const bit kMaster = 36
- static const bit kEnableBytewise = 37
- static const bit kEnableSerial = 38
- static const bit kEnableJTAGReadout = 39
- static const bit kTDCld = 40
- static const bit kSelectBypassInputs = 44
- static const bit kReadoutFIFOSize = 45
- static const bit kRejectCountOffset = 48
- static const bit kSearchWindow = 60
- static const bit kMatchWindow = 72
- static const bit kLeadingResolution = 84
- static const bit kMaxEventSize = 116
- static const bit kRejectFIFOFull = 120
- static const bit kEnableReadoutOccupancy = 121
- static const bit kEnableReadoutSeparator = 122
- static const bit kEnableOverflowDetect = 123
- static const bit kEnableRelative = 124
- static const bit kEnableAutomaticReject = 125
- static const bit kEventCountOffset = 126
- static const bit kTriggerCountOffset = 138
- static const bit kEnableSetCountersOnBunchReset = 150
- static const bit kEnableMasterResetCode = 151
- static const bit kEnableMasterResetOnEventReset = 152
- static const bit kEnableResetChannelBufferWhenSeparator = 153
- static const bit kEnableSeparatorOnEventReset = 154
- static const bit kEnableSeparatorOnBunchReset = 155
- static const bit kEnableDirectEventReset = 156
- static const bit kEnableDirectBunchReset = 157
- static const bit kEnableDirectTrigger = 158
- static const bit kOffset0 = 438
- static const bit kCoarseCountOffset = 447
- static const bit kDLLTapAdjust0 = 459
- static const bit kRCAdjust0 = 555
- static const bit kLowPowerMode = 570
- static const bit kWidthSelect = 571
- static const bit kVernierOffset = 575
- static const bit kDLLControl = 580
- static const bit kDeadTime = 584
- static const bit kTestInvert = 586

- static const bit kTestMode = 587
- static const bit kTrailing = 588
- static const bit kLeading = 589
- static const bit kModeRCCompression = 590
- static const bit kModeRC = 591
- static const bit kDLLMode = 592
- static const bit kPLLControl = 594
- static const bit kSerialClockDelay = 602
- static const bit kIOClockDelay = 606
- static const bit kCoreClockDelay = 610
- static const bit kDLLClockDelay = 614
- static const bit kSerialClockSource = 618
- static const bit kIOClockSource = 620
- static const bit kCoreClockSource = 622
- static const bit kDLLClockSource = 624
- static const bit kRollOver = 627
- static const bit kEnableMatching = 639
- static const bit kEnablePair = 640
- static const bit kEnableTTLSerial = 641
- static const bit kEnableTTLControl = 642
- static const bit kEnableTTLReset = 643
- static const bit kEnableTTLClock = 644
- static const bit kEnableTTLHit = 645
- static const bit kSetupParity = 646

Additional Inherited Members

5.15.1 Detailed Description

Setup word to be sent to the HPTDC chip.

Object handling the configuration word provided by/to the HPTDC chip

Author


Laurent Forthomme laurent.forthomme@cern.ch

Date

16 Apr 2015


5.15.2 Constructor & Destructor Documentation

5.15.2.1 TDCSetup::TDCSetup()



5.15.2.2 TDCSetup::TDCSetup (const TDCSetup & c)

Here is the call graph for this function:




5.15.2.3 TDCSetup:: \sim TDCSetup() [virtual]

5.15.3 Member Function Documentation

5.15.3.1 void TDCSetup::Dump (int verb = 1, std::ostream & os = std::cout) const

Here is the call graph for this function:



5.15.3.2 uint16_t TDCSetup::GetChannelOffset(int channel)const [inline]

Return the offset for one single channel.

Here is the call graph for this function:



5.15.3.3 uint16_t TDCSetup::GetCoarseCountOffset() const [inline]

Extract offset for the coarse time counter.



5.15.3.4 DeadTime TDCSetup::GetDeadTime () const [inline]

Here is the call graph for this function:




5.15.3.5 uint8_t TDCSetup::GetDLLAdjustment (int tap) const [inline]

Set the adjustment of DLL taps.



5.15.3.6 EdgeResolution TDCSetup::GetEdgeResolution () const [inline]

Here is the call graph for this function:



5.15.3.7 bool TDCSetup::GetEdgesPairing () const [inline]

Here is the call graph for this function:




5.15.3.8 uint16_t TDCSetup::GetEnableError() const [inline]



5.15.3.9 bool TDCSetup::GetEnableErrorBypass () const [inline]

Here is the call graph for this function:



5.15.3.10 bool TDCSetup::GetEnableErrorMark() const [inline]

Here is the call graph for this function:




5.15.3.11 bool TDCSetup::GetEnableJTAGReadout () const [inline]



5.15.3.12 bool TDCSetup::GetEnableReadoutOccupancy() const [inline]

Here is the call graph for this function:




 $\textbf{5.15.3.13} \quad \textbf{bool TDCSetup::GetEnableReadoutSeparator () const} \quad \texttt{[inline]}$

Here is the call graph for this function:



5.15.3.14 bool TDCSetup::GetEnableSerial () const [inline]

Here is the call graph for this function:



5.15.3.15 bool TDCSetup::GetLeadingMode() const [inline]

Extract the status for the detection of leading edges.



5.15.3.16 uint16_t TDCSetup::GetMatchWindow() const [inline]

Extract the matching window (in multiples of clock cycles: 0=25 ns, 1=50 ns, ...)

Here is the call graph for this function:



5.15.3.17 uint8_t TDCSetup::GetMaxEventSize() const [inline]

Extract the maximum number of hits per event.

Here is the call graph for this function:



5.15.3.18 uint8_t TDCSetup::GetRCAdjustment(int tap) [inline]

Extract the adjustment of the RC delay line.



5.15.3.19 int TDCSetup::GetReadoutFIFOSize () const [inline]

Here is the call graph for this function:



5.15.3.20 uint16_t TDCSetup::GetRejectCountOffset() const [inline]

Extract the offset in reject counter.

Here is the call graph for this function:



5.15.3.21 bool TDCSetup::GetRejectFIFOFull () const [inline]

Are hits rejected when readout FIFO is full?

Extract whether or not hits are rejected once FIFO is full.



5.15.3.22 uint16_t TDCSetup::GetSearchWindow() const [inline]

Extract the search window (in multiples of clock cycles: 0=25 ns, 1=50 ns, ...)

Here is the call graph for this function:



5.15.3.23 bool TDCSetup::GetSetupParity () const [inline]

Extract the parity of setup data (should be an even parity)



5.15.3.24 bool TDCSetup::GetTestInvert() const [inline]

Here is the call graph for this function:



5.15.3.25 bool TDCSetup::GetTestMode() const [inline]

Here is the call graph for this function:



5.15.3.26 bool TDCSetup::GetTrailingMode () const [inline]

Extract the status for the detection of trailing edges.

Here is the call graph for this function:



5.15.3.27 uint16_t TDCSetup::GetTriggerCountOffset() const [inline]


Extract trigger time tag count offset.



5.15.3.28 uint16_t TDCSetup::GetTriggerLatency() const [inline]

Effective trigger latency in number of clock cycles (when no counter roll-over is used)

Here is the call graph for this function:



5.15.3.29 bool TDCSetup::GetTriggerMatchingMode () const [inline]

Extract the enable status of trigger matching mode.

Here is the call graph for this function:



5.15.3.30 uint8_t TDCSetup::GetVernierOffset() const [inline]


Extract the offset in vernier decoding.



5.15.3.31 WidthResolution TDCSetup::GetWidthResolution () const [inline]

Extract the pulse width resolution when paired measurements are performed.

Here is the call graph for this function:



5.15.3.32 void TDCSetup::SetAllChannelsOffset (uint16_t offset) [inline]


Set the time offset for all channels.

Here is the call graph for this function:



5.15.3.33 void TDCSetup::SetAllTapsDLLAdjustment (uint8_t adj) [inline]

Extract the adjustment of DLL taps.



5.15.3.34 void TDCSetup::SetBypassInputs (const bool *sbi* = true) [inline], [private]

Select serial in and token in from bypass inputs.

Here is the call graph for this function:



5.15.3.35 void TDCSetup::SetChannelOffset (int channel, uint16_t offset) [inline]

Set the time offset for one single channel.

Here is the call graph for this function:



5.15.3.36 void TDCSetup::SetCoarseCountOffset (uint16_t cco) [inline]


Set offset for the coarse time counter.

Here is the call graph for this function:



5.15.3.37 void TDCSetup::SetConstantValues ()

Ensure that the critical constant values are properly set in the setup word.



5.15.3.38 void TDCSetup::SetCoreClockDelay (const bool delay_clock, const uint8_t delay) [inline], [private]

Delay of internal core clock.

Parameters

in	delay_clock	Use of direct clock (0) or delayed clock (1)
in	delay	Delay in steps of (typically) 0.13 ns


Here is the call graph for this function:



5.15.3.39 void TDCSetup::SetCoreClockSource (const CoreClockSource ccs) [inline], [private]

Selection of clock source for internal logic.

Here is the call graph for this function:



5.15.3.40 void TDCSetup::SetDeadTime (const DeadTime dt) [inline]

Channel dead time between hits.

Here is the call graph for this function:



5.15.3.41 void TDCSetup::SetDLLAdjustment (int tap, uint8_t adj) [inline]

Set the DLL taps adjustments with a resolution of $\sim\!10$ ps.



5.15.3.42 void TDCSetup::SetDLLClockDelay (const bool delay_clock, const uint8_t delay) [inline], [private]

Delay of internal DLL clock.

Parameters

in	delay_clock	Use of direct clock (0) or delayed clock (1)
in	delay	Delay in steps of (typically) 0.13 ns

Here is the call graph for this function:



5.15.3.43 void TDCSetup::SetDLLClockSource (const DLLClockSource dcs) [inline], [private]

Selection of clock source for DLL.

Here is the call graph for this function:



5.15.3.44 void TDCSetup::SetDLLControl(const uint8_t dc) [inline], [private]

Control of DLL (DLL charge pump levels)



5.15.3.45 void TDCSetup::SetDLLMode (const DLLSpeedMode dsm) [inline], [private]

Selection of DLL speed mode.

Here is the call graph for this function:



5.15.3.46 void TDCSetup::SetEdgeResolution (const EdgeResolution r) [inline]

Here is the call graph for this function:




5.15.3.47 void TDCSetup::SetEdgesPairing (const bool pair = true) [inline]

Enable the pairing of leading and trailing edges (overrides individual enable of leading/trailing edges)



5.15.3.48 void TDCSetup::SetEnableAutomaticReject (const bool ear = true) [inline], [private]

Enable of automatic rejection (should always be enabled if trigger matching mode!)
Here is the call graph for this function:



5.15.3.49 void TDCSetup::SetEnableBytewise (const bool seb = true) [inline], [private]

Here is the call graph for this function:



5.15.3.50 void TDCSetup::SetEnableDirectBunchReset (const bool edbr = true) [inline], [private]

Enable of direct bunch reset input pin (1), otherwise taken from encoded control.



5.15.3.51 void TDCSetup::SetEnableDirectEventReset (const bool eder = true) [inline], [private]

Enable of direct event reset input pin (1), otherwise taken from encoded control.

Here is the call graph for this function:



5.15.3.52 void TDCSetup::SetEnableDirectTrigger(const bool edt = true) [inline], [private]

Enable of direct trigger input pin.

Here is the call graph for this function:



5.15.3.53 void TDCSetup::SetEnableError (const uint16_t & err) [inline]

Enable internal error types for generation of global error signals.



5.15.3.54 void TDCSetup::SetEnableErrorBypass (const bool *eb***)** [inline]

Bypass TDC chip if global error signal is set.

Here is the call graph for this function:



5.15.3.55 void TDCSetup::SetEnableErrorMark (const bool em) [inline]


Mark events with error if global error signal is set.

Here is the call graph for this function:



5.15.3.56 void TDCSetup::SetEnableGlobalHeader(const bool egh = true) [inline], [private]


Enable of global headers in read-out (only valid for master TDC)



5.15.3.57 void TDCSetup::SetEnableGlobalTrailer (const bool egt = true) [inline], [private]

Enable of global trailers in read-out (only valid for master TDC)

Here is the call graph for this function:



5.15.3.58 void TDCSetup::SetEnableJTAGReadout (const bool jr) [inline]


Enable of read-out via JTAG.

Here is the call graph for this function:



5.15.3.59 void TDCSetup::SetEnableLocalHeader(const bool elh = true) [inline], [private]

Enable of local headers in read-out.



5.15.3.60 void TDCSetup::SetEnableLocalTrailer (const bool elt = true) [inline], [private]

Enable of local trailers in read-out.


Here is the call graph for this function:



5.15.3.61 void TDCSetup::SetEnableMasterResetCode (const bool emrc = true) [inline], [private]

Enable master reset code on encoded control.

Here is the call graph for this function:



5.15.3.62 void TDCSetup::SetEnableMasterResetOnEventReset(const bool emroer = true) [inline], [private]


Enable master reset of whole TDC on event reset.



5.15.3.63 void TDCSetup::SetEnableOverflowDetect (const bool eod = true) [inline], [private]

Enable overflow detection of L1 buffers (should always be enabled!)

Here is the call graph for this function:




5.15.3.64 void TDCSetup::SetEnableReadoutOccupancy (const bool ro = true) [inline]

Enable the readout of buffer occupancies for each event (for debugging purposes)
Here is the call graph for this function:



5.15.3.65 void TDCSetup::SetEnableReadoutSeparator (const bool ro = true) [inline]

Enable the readout of separators for each event (for debugging purposes, valid if readout of occupancies is enabled)



5.15.3.66 void TDCSetup::SetEnableRelative (const bool *er* = true) [inline], [private]

Enable read-out of relative time to trigger time tag. Only valid when using trigger matching mode.

Here is the call graph for this function:



5.15.3.67 void TDCSetup::SetEnableResetChannelBufferWhenSeparator (const bool ercbws = true) [inline], [private]

Enable reset channel buffers when separator.

Here is the call graph for this function:



5.15.3.68 void TDCSetup::SetEnableSeparatorOnBunchReset (const bool esobr = true) [inline], [private]

Enable generation of separator on bunch reset.



5.15.3.69 void TDCSetup::SetEnableSeparatorOnEventReset (const bool esoer = true) [inline], [private]

Enable generation of separator on event reset.


Here is the call graph for this function:



5.15.3.70 void TDCSetup::SetEnableSerial (const bool es) [inline]


Enable of serial read-out (otherwise parallel read-out)

Here is the call graph for this function:



5.15.3.71 void TDCSetup::SetEnableSetCountersOnBunchReset (const bool escobr = true) [inline], [private]

Enable all counters to be set on bunch count reset.



5.15.3.72 void TDCSetup::SetEnableTTLClock (const bool tc = true) [inline], [private]

Enable LV TTL inputs on: clk, aux_clock, otherwise uses LVDS input levels.

Here is the call graph for this function:




5.15.3.73 void TDCSetup::SetEnableTTLControl(const bool tc = true) [inline], [private]

Enable LV TTL inputs on control registers.

Enable LV TTL input on:

- trigger,
- · bunch_reset,
- · event reset,
- encoded_control, otherwise uses LVDS input levels.

Here is the call graph for this function:



5.15.3.74 void TDCSetup::SetEnableTTLHit (const bool th = true) [inline], [private]

Enable LV TTL input on hit[31:0], otherwise uses LVDS input levels.

Here is the call graph for this function:



5.15.3.75 void TDCSetup::SetEnableTTLReset (const bool tr = true) [inline], [private]

Enable LV TTL input on reset, otherwise uses LVDS input levels.

Here is the call graph for this function:



5.15.3.76 void TDCSetup::SetEnableTTLSerial (const bool ts = true) [inline], [private]

Enable LV TTL inputs on serial registers, and disable their drivers.

Enable LV TTL input on:

- · serial_in,
- · serial_bypass_in,
- · token_in,
- token_bypass_in, otherwise uses LVDS input levels. Disable LVDS drivers on:
- · serial_out,
- · strobe_out,
- token_out.



5.15.3.77 void TDCSetup::SetEventCountOffset (uint16_t eco) [inline]

Set offset for the event counter.

Here is the call graph for this function:



5.15.3.78 void TDCSetup::SetlOClockDelay (const bool delay_clock, const uint8_t delay) [inline], [private]

Delay of internal I/O clock.

Parameters


in	delay_clock	Use of direct clock (0) or delayed clock (1)
in	delay	Delay in steps of (typically) 0.13 ns

Here is the call graph for this function:



5.15.3.79 void TDCSetup::SetlOClockSource (const IOClockSource ics) [inline], [private]

Selection of clock source for I/O signals.



5.15.3.80 void TDCSetup::SetKeepToken (const bool kt = true) [inline], [private]

Keep token until end of event or no more data, otherwise pass token after each word read. Must be enabled when using trigger matching.

Here is the call graph for this function:



5.15.3.81 void TDCSetup::SetLeadingMode (const bool lead = true) [inline]


Enable the detection of leading edges.

Here is the call graph for this function:



5.15.3.82 void TDCSetup::SetLowPowerMode (const bool *lpm* = true) [inline], [private]

Low power mode of channel buffers.



5.15.3.83 void TDCSetup::SetMaster (const bool m = true) [inline], [private]

Here is the call graph for this function:



5.15.3.84 void TDCSetup::SetMatchWindow (uint16_t mw) [inline]

Set the matching window (in multiples of clock cycles: 0=25 ns, 1=50 ns, ...)

Here is the call graph for this function:



5.15.3.85 void TDCSetup::SetMaxEventSize (int sz = -1) [inline]

Set the maximum number of hits per event.

Set the maximum number of hits that can be recorded for each event. It is always rounded to the next power of 2 (in the range 0-128), and if lower than 0 or bigger than 128 then set to unimited.



5.15.3.86 void TDCSetup::SetModeRC (const bool mr = true) [inline], [private]

Enable of RR delay lines mode (in very high resolution mode); only for channels 0-4-8-12-16-20-24-28 active. Here is the call graph for this function:



5.15.3.87 void TDCSetup::SetModeRCCompression (const bool mrc = true) [inline], [private]

Perform RC interpolation on-chip (only valid in very high resolution mode) Here is the call graph for this function:



5.15.3.88 void TDCSetup::SetPLLControl (const uint8_t charge_pump_current = 0×4 , const bool power_down_mode = false, const bool enable_test_outputs = false, const bool invert_connection_to_status = false) [inline], [private]

Control of PLL.



5.15.3.89 void TDCSetup::SetRCAdjustment (int tap, uint8_t adj) [inline]

Set the adjustment of the RC delay line.

Here is the call graph for this function:



5.15.3.90 void TDCSetup::SetReadoutFIFOSize (int rfs) [inline]

Effective size of readout FIFO.

Here is the call graph for this function:



5.15.3.91 void TDCSetup::SetReadoutSingleCycleSpeed (const ReadoutSingleCycleSpeed rscs = RSC_40Mbits_s)
[inline], [private]

Serial transmission speed in single cycle mode.



5.15.3.92 void TDCSetup::SetReadoutSpeedSelect (const ReadoutSpeed rss = RO_Fixed) [inline], [private]

Selection of serial read-out speed.

Parameters

in	rss	
		 0: Selection of serial read-out speed (as defined by setup[19:17], Set — ReadoutSingleCycleSpeed)
		• 1: 80 Mbits/s (PLL lock required)

Here is the call graph for this function:



5.15.3.93 void TDCSetup::SetRejectCountOffset (uint16_t rco) [inline]

Set the offset in reject counter (defines reject latency together with coarse count offset) Here is the call graph for this function:



5.15.3.94 void TDCSetup::SetRejectFIFOFull (const bool rej = true) [inline]

Reject hits when readout FIFO full.

Set whether or not hits are rejected once FIFO is full.

Here is the call graph for this function:



5.15.3.95 void TDCSetup::SetRollOver(const uint16_t ro = 0xFFF) [inline], [private]

Counter roll over value, defining maximal count value from where counters will be reset to 0. Here is the call graph for this function:



5.15.3.96 void TDCSetup::SetSearchWindow(uint16_t sw) [inline]

Set the search window (in multiples of clock cycles: 0=25 ns, 1=50 ns, ...)

Here is the call graph for this function:




5.15.3.97 void TDCSetup::SetSerialClockDelay (const bool delay_clock, const uint8_t delay) [inline], [private]

Delay of internal serial clock.

Parameters

in	delay_clock	Use of direct clock (0) or delayed clock (1)
in	delay	Delay in steps of (typically) 0.13 ns

Here is the call graph for this function:



5.15.3.98 void TDCSetup::SetSerialClockSource (const SerialClockSource scs) [inline], [private]

Selection of source for serial clock.


Here is the call graph for this function:



5.15.3.99 void TDCSetup::SetSerialDelay (const uint8_t sd = 0x0) [inline], [private]

Programmable delay of serial input, in time unit \sim 1 ns.

Here is the call graph for this function:



5.15.3.100 void TDCSetup::SetSetupParity (const bool sp = true) [inline]

Set the parity of setup data (should be an even parity)



5.15.3.101 void TDCSetup::SetStrobeSelect (const SerialStrobeType ss = SS_NoStrobe) [inline], [private]

Here is the call graph for this function:



5.15.3.102 void TDCSetup::SetTestInvert (const bool ti = true) [inline]

Automatic inversion of test pattern. Only used during production testing.

Here is the call graph for this function:



5.15.3.103 void TDCSetup::SetTestMode (const bool tm = true) [inline]

Test mode where hit data are taken from coretest. Only used during production testing.



5.15.3.104 void TDCSetup::SetTokenDelay (const uint8_t $td = 0 \times 0$) [inline], [private]

Programmable delay of token input, in time unit \sim 1 ns.


Here is the call graph for this function:



5.15.3.105 void TDCSetup::SetTrailingMode (const bool trail = true) [inline]

Enable/disable the detection of trailing edges.

Here is the call graph for this function:



5.15.3.106 void TDCSetup::SetTriggerCountOffset(uint16_t tco) [inline]

Set offset for the trigger time tag counter to set effective trigger latency.



5.15.3.107 void TDCSetup::SetTriggerMatchingMode (const bool trig = true) [inline]

Set the enable status of trigger matching mode.

Here is the call graph for this function:



5.15.3.108 void TDCSetup::SetVernierOffset (const uint8_t vo) [inline]

Set the offset in vernier decoding.

Here is the call graph for this function:



5.15.3.109 void TDCSetup::SetWidthResolution (const WidthResolution r) [inline]

Set the pulse width resolution when paired measurements are performed.



5.15.4 Field Documentation **5.15.4.1 const bit TDCSetup::kCoarseCountOffset = 447** [static], [private] **5.15.4.2** const bit TDCSetup::kCoreClockDelay = 610 [static], [private] **5.15.4.3** const bit TDCSetup::kCoreClockSource = 622 [static], [private] **5.15.4.4 const bit TDCSetup::kDeadTime = 584** [static], [private] **5.15.4.5** const bit TDCSetup::kDLLClockDelay = 614 [static], [private] **5.15.4.6** const bit TDCSetup::kDLLClockSource = 624 [static], [private] **5.15.4.7 const bit TDCSetup::kDLLControl = 580** [static], [private] 5.15.4.8 const bit TDCSetup::kDLLMode = 592 [static], [private] **5.15.4.9 const bit TDCSetup::kDLLTapAdjust0 = 459** [static], [private] **5.15.4.10** const bit TDCSetup::kEnableAutomaticReject = 125 [static], [private] **5.15.4.11** const bit TDCSetup::kEnableBytewise = 37 [static], [private] **5.15.4.12** const bit TDCSetup::kEnableDirectBunchReset = 157 [static], [private] **5.15.4.13** const bit TDCSetup::kEnableDirectEventReset = 156 [static], [private] **5.15.4.14** const bit TDCSetup::kEnableDirectTrigger = 158 [static], [private] **5.15.4.15** const bit TDCSetup::kEnableError = 6 [static], [private] **5.15.4.16** const bit TDCSetup::kEnableErrorBypass = 5 [static], [private] 5.15.4.17 const bit TDCSetup::kEnableErrorMark = 4 [static], [private] **5.15.4.18** const bit TDCSetup::kEnableGlobalHeader = **34** [static], [private] **5.15.4.19** const bit TDCSetup::kEnableGlobalTrailer = 33 [static], [private] **5.15.4.20** const bit TDCSetup::kEnableJTAGReadout = 39 [static], [private] **5.15.4.21** const bit TDCSetup::kEnableLocalHeader = **32** [static], [private]

```
5.15.4.22 const bit TDCSetup::kEnableLocalTrailer = 31 [static], [private]
5.15.4.23 const bit TDCSetup::kEnableMasterResetCode = 151 [static], [private]
5.15.4.24 const bit TDCSetup::kEnableMasterResetOnEventReset = 152 [static], [private]
5.15.4.25 const bit TDCSetup::kEnableMatching = 639 [static], [private]
5.15.4.26 const bit TDCSetup::kEnableOverflowDetect = 123 [static], [private]
5.15.4.27 const bit TDCSetup::kEnablePair = 640 [static], [private]
5.15.4.28 const bit TDCSetup::kEnableReadoutOccupancy = 121 [static], [private]
5.15.4.29 const bit TDCSetup::kEnableReadoutSeparator = 122 [static], [private]
5.15.4.30 const bit TDCSetup::kEnableRelative = 124 [static], [private]
5.15.4.31 const bit TDCSetup::kEnableResetChannelBufferWhenSeparator = 153 [static], [private]
5.15.4.32 const bit TDCSetup::kEnableSeparatorOnBunchReset = 155 [static], [private]
5.15.4.33 const bit TDCSetup::kEnableSeparatorOnEventReset = 154 [static], [private]
5.15.4.34 const bit TDCSetup::kEnableSerial = 38 [static], [private]
5.15.4.35 const bit TDCSetup::kEnableSetCountersOnBunchReset = 150 [static], [private]
5.15.4.36 const bit TDCSetup::kEnableTTLClock = 644 [static], [private]
5.15.4.37 const bit TDCSetup::kEnableTTLControl = 642 [static], [private]
5.15.4.38 const bit TDCSetup::kEnableTTLHit = 645 [static], [private]
5.15.4.39 const bit TDCSetup::kEnableTTLReset = 643 [static], [private]
5.15.4.40 const bit TDCSetup::kEnableTTLSerial = 641 [static], [private]
5.15.4.41 const bit TDCSetup::kEventCountOffset = 126 [static], [private]
5.15.4.42 const bit TDCSetup::klOClockDelay = 606 [static], [private]
5.15.4.43 const bit TDCSetup::klOClockSource = 620 [static], [private]
5.15.4.44 const bit TDCSetup::kKeepToken = 35 [static], [private]
5.15.4.45 const bit TDCSetup::kLeading = 589 [static], [private]
5.15.4.46 const bit TDCSetup::kLeadingResolution = 84 [static], [private]
5.15.4.47 const bit TDCSetup::kLowPowerMode = 570 [static], [private]
5.15.4.48 const bit TDCSetup::kMaster = 36 [static], [private]
5.15.4.49 const bit TDCSetup::kMatchWindow = 72 [static], [private]
```

```
5.15.4.50 const bit TDCSetup::kMaxEventSize = 116 [static], [private]
5.15.4.51 const bit TDCSetup::kModeRC = 591 [static], [private]
5.15.4.52 const bit TDCSetup::kModeRCCompression = 590 [static], [private]
5.15.4.53 const bit TDCSetup::kOffset0 = 438 [static], [private]
5.15.4.54 const bit TDCSetup::kPLLControl = 594 [static], [private]
5.15.4.55 const bit TDCSetup::kRCAdjust0 = 555 [static], [private]
5.15.4.56 const bit TDCSetup::kReadoutFIFOSize = 45 [static], [private]
5.15.4.57 const bit TDCSetup::kReadoutSingleCycleSpeed = 17 [static], [private]
5.15.4.58 const bit TDCSetup::kReadoutSpeedSelect = 26 [static], [private]
5.15.4.59 const bit TDCSetup::kRejectCountOffset = 48 [static], [private]
5.15.4.60 const bit TDCSetup::kRejectFlFOFull = 120 [static], [private]
5.15.4.61 const bit TDCSetup::kRollOver = 627 [static], [private]
5.15.4.62 const bit TDCSetup::kSearchWindow = 60 [static], [private]
5.15.4.63 const bit TDCSetup::kSelectBypassInputs = 44 [static], [private]
5.15.4.64 const bit TDCSetup::kSerialClockDelay = 602 [static], [private]
5.15.4.65 const bit TDCSetup::kSerialClockSource = 618 [static], [private]
5.15.4.66 const bit TDCSetup::kSerialDelay = 20 [static], [private]
5.15.4.67 const bit TDCSetup::kSetupParity = 646 [static], [private]
5.15.4.68 const bit TDCSetup::kStrobeSelect = 24 [static], [private]
5.15.4.69 const bit TDCSetup::kTDCld = 40 [static], [private]
5.15.4.70 const bit TDCSetup::kTestInvert = 586 [static], [private]
5.15.4.71 const bit TDCSetup::kTestMode = 587 [static], [private]
5.15.4.72 const bit TDCSetup::kTestSelect = 0 [static], [private]
5.15.4.73 const bit TDCSetup::kTokenDelay = 27 [static], [private]
5.15.4.74 const bit TDCSetup::kTrailing = 588 [static], [private]
5.15.4.75 const bit TDCSetup::kTriggerCountOffset = 138 [static], [private]
5.15.4.76 const bit TDCSetup::kVernierOffset = 575 [static], [private]
```

5.15.4.77 const bit TDCSetup::kWidthSelect = 571 [static], [private]

The documentation for this class was generated from the following files:


- · include/TDCSetup.h
- src/TDCSetup.cpp

5.16 USBHandler Class Reference

Generic USB communication handler.

#include <USBHandler.h>

Inheritance diagram for USBHandler:



Public Member Functions

- USBHandler (const char *dev)
- virtual ∼USBHandler ()
- void Init ()
- void DumpDevice (libusb_device *dev, int verb=1, std::ostream &out=std::cout)

Protected Member Functions

• void Write (uint32_t word, uint8_t size) const

Write a word to the USB device.

• uint32_t Fetch (uint8_t size) const

Receive a word from the USB device.

Private Attributes

- · std::string fDevice
- libusb_device_handle * fHandle

5.16.1 Detailed Description

Generic USB communication handler.

Date

21 Apr 2015

Author

Laurent Forthomme laurent.forthomme@cern.ch

5.16.2 Constructor & Destructor Documentation

5.16.2.1 USBHandler::USBHandler (const char * dev)

5.16.2.2 virtual USBHandler::~USBHandler() [inline], [virtual]

5.16.3 Member Function Documentation

5.16.3.1 void USBHandler::DumpDevice (libusb_device * dev, int verb = 1, std::ostream & out = std::cout)

5.16.3.2 uint32_t USBHandler::Fetch (uint8_t size) const [inline], [protected]

Receive a word from the USB device.

5.16.3.3 void USBHandler::Init ()

Pointer to a pointer of devices used to retrieve a list of them

A libusb session

Here is the call graph for this function:



5.16.3.4 void USBHandler::Write (uint32_t word, uint8_t size) const [inline], [protected]

Write a word to the USB device.

5.16.4 Field Documentation

5.16.4.1 std::string USBHandler::fDevice [private]

5.16.4.2 libusb_device_handle* USBHandler::fHandle [private]

The documentation for this class was generated from the following files:

- · include/USBHandler.h
- · src/USBHandler.cpp



Index

~Client	Disconnect, 16
Client, 15	fClientId, 18
\sim Exception	flsConnected, 18
Exception, 19	GetType, 17
~FPGAHandler	ParseMessage, 17
FPGAHandler, 24	Receive, 17
~Message	Send, 17
Message, 31	CloseFile
~Messenger	FPGAHandler, 24
Messenger, 33	CoarseError
~Socket	HPTDC chip control, 11
Socket, 41	config
~SocketMessage	file_header_t, 21
SocketMessage, 49	Configure
~TDCBoundaryScanRegister	Socket, 41
TDCBoundaryScanRegister, 52	Connect
~TDCControl	Client, 16
TDCControl, 54	Messenger, 35
~TDCEvent	ControlParityError
TDCEvent, 57	HPTDC chip control, 11
~TDCRegister	Core_aux_clock
TDCRegister, 61	HPTDC chip control, 10
~TDCSetup	Core_clock_40
TDCSetup, 71	HPTDC chip control, 10
~USBHandler	Core_pll_clock_160
USBHandler, 113	HPTDC chip control, 10
COBHANGO, TTO	Core_pll_clock_80
AcceptConnections	HPTDC chip control, 10
Socket, 41	CoreClockSource
AddClient	HPTDC chip control, 10
Messenger, 34	Create
Announce	Socket, 42
Client, 15	33.131, 12
	DETECTOR
Bind	Socket communication objects, 8
Socket, 41	DLL 160MHz
bit	HPTDC chip control, 10
TDCRegister, 61	DLL_320MHz
Broadcast	HPTDC chip control, 10
Messenger, 34	DLL 40MHz
	HPTDC chip control, 10
CLIENT	DLL Illegal
Socket communication objects, 7	HPTDC chip control, 10
ChannelSelectError	DLL_aux_clock
HPTDC chip control, 11	HPTDC chip control, 10
Client, 13	DLL clock 40
∼Client, 15	HPTDC chip control, 10
Announce, 15	DLL_pll_clock_160
Client, 15	HPTDC chip control, 10
Connect, 16	DLL pll clock 320

HPTDC chip control, 10	HPTDC chip control, 10
DLL_pll_clock_40	EnablePattern
HPTDC chip control, 10	TDCControl, 54
DLLClockSource	EnabledError
HPTDC chip control, 10	HPTDC chip control, 10
DLLSpeedMode	Encode
HPTDC chip control, 10	HTTPMessage, 29 Error
DT_100ns HPTDC chip control, 10	HPTDC chip control, 11
DT 10ns	ErrorNumber
HPTDC chip control, 10	Exception, 20
DT 30ns	EventType
HPTDC chip control, 10	HPTDC chip control, 11
DT 5ns	Exception, 18
HPTDC chip control, 10	∼Exception, 19
DeadTime	Description, 19
HPTDC chip control, 10	Dump, 19
Debug	ErrorNumber, 20
HPTDC chip control, 11	Exception, 19
Decode	fDescription, 20
HTTPMessage, 29	fErrorNumber, 20
Description	fFrom, 20
Exception, 19	fType, 20
Disconnect	From, 20
Client, 16	Type, 20
Messenger, 35	TypeString, 20
DisconnectClient	fAddress
Messenger, 36	Socket, 44
Dump	fBuffer
Exception, 19 HTTPMessage, 29	Socket, 44
Message, 31	fClientId
SocketMessage, 49	Client, 18
TDCControl, 54	fDescription
TDCSetup, 71	Exception, 20
DumpConnected	fDevice
Socket, 42	USBHandler, 113
DumpDevice	fErrorNumber
USBHandler, 113	Exception, 20
DumpRegister	fFilename
TDCRegister, 61	FPGAHandler, 26
	fFrom
E_100ps	Exception, 20
HPTDC chip control, 10	fHandle
E_12p5ns	USBHandler, 113
HPTDC chip control, 10	flsConnected
E_1p6ns HPTDC chip control, 10	Client, 18
E_200ps	flsFileOpen FPGAHandler, 26
HPTDC chip control, 10	flsTDCInReadout
E_3p12ns	FPGAHandler, 26
HPTDC chip control, 10	fListenersInfo
E_400ps	Messenger, 38
HPTDC chip control, 10	fMaster
E_6p25ns	Socket, 44
HPTDC chip control, 10	fMessage
E_800ps	SocketMessage, 51
HPTDC chip control, 10	fNumAttempts
EdgeResolution	Messenger, 38

fNumWords	GetBits
TDCRegister, 62	TDCRegister, 61
fOriginalString	GetBunchld
HTTPMessage, 29	TDCEvent, 57
fOutput	GetChannelOffset
FPGAHandler, 26	TDCSetup, 72
FPGAHandler, 22	GetCoarseCountOffset
∼FPGAHandler, 24	TDCSetup, 72
CloseFile, 24	GetConfiguration
fFilename, 26	FPGAHandler, 24
flsFileOpen, 26	GetDLLAdjustment
flsTDCInReadout, 26	TDCSetup, 73
fOutput, 26	GetDeadTime
FPGAHandler, 24	TDCSetup, 73
fTDCBSR, 26	GetEdgeResolution
	_
fTDCSetup, 26	TDCSetup, 73
GetConfiguration, 24	GetEdgesPairing
GetFilename, 24	TDCSetup, 74
GetType, 25	GetEnableError
OpenFile, 25	TDCSetup, 74
ReadBoundaryScanRegister, 25	GetEnableErrorBypass
ReadBuffer, 25	TDCSetup, 74
ReadConfiguration, 25	GetEnableErrorMark
SendConfiguration, 25	TDCSetup, 75
SetConfiguration, 26	GetEnableJTAGReadout
fPort	TDCSetup, 75
Socket, 44	GetEnableReadoutOccupancy
fReadFds	TDCSetup, 75
Socket, 44	GetEnableReadoutSeparator
fSocketId	TDCSetup, 76
Socket, 44	GetEnableSerial
fSocketsConnected	TDCSetup, 76
Socket, 44	GetErrorFlags
fString	TDCEvent, 57
Message, 31	GetEventId
fTDCBSR	TDCEvent, 58
FPGAHandler, 26	GetFilename
fTDCSetup	FPGAHandler, 24
FPGAHandler, 26	GetIntValue
fType	SocketMessage, 49
Exception, 20	GetKey
fWS	HTTPMessage, 29
HTTPMessage, 29	Message, 31
Messenger, 38	SocketMessage, 49
fWord	GetLeadingMode
TDCEvent, 59	TDCSetup, 76
TDCRegister, 62	GetLeadingTime
Fetch	TDCEvent, 58
	GetMatchWindow
USBHandler, 113	
FetchMessage	TDCSetup, 77
Socket, 42	GetMaxEventSize
file_header_t, 21	TDCSetup, 77
config, 21	GetNumWords
magic, 21	TDCRegister, 61
run_id, 21	GetPort
spill_id, 22	Socket, 42
From	GetRCAdjustment
Exception, 20	TDCSetup, 77

GerReadoulFiFOSize TDCSetup, 78 GerRejectCounlOffset TDCSetup, 78 GerRejectFiFOFull TDCSetup, 78 GerRejectFiFOFull TDCSetup, 78 GerRejectFiFOFull TDCSetup, 79 GerSearpWindow TDCSetup, 70 GerSearpWindow TDCSetup, 70 GerSearpWindow TDCSetup, 70 GerTestMode TDCSetup, 70 GerTestMode TDCSetup, 70 GerTestMode TDCSetup, 80 GerTestInyor TDCSetup, 80 GerTailingMode TDCSetup, 80 GerTailingMode TDCSetup, 80 GerTinggerCounlOffset TDCSetup, 80 GerTinggerCounlOffset TDCSetup, 80 GerTinggerCounlOffset TDCSetup, 81 GerTinggerCounlOffset TDCSetup, 81 GerTinggerMatchingMode TDCSetup, 81 GerTinggerTailer, 11 Gertype Client, 17 FPGAHandler, 25 Messenger, 36 TDCSetup, 81 GertWordowale SocketMessage, 50 GertVerorValue SocketMessage, 50 G		
GerRejectCountOffset		
TDCSetup. 78 GetRejectFIPOFull TDCSetup, 78 GetSearchWindow Core pll_clock, 80, 10 Core pll_clock, 10 DLL_slock, 10 DLL_slock, 10 DLL_gll_clock, 10 DLL_gll_clock, 10, 10 DLL_pll_clock, 10, 10 DLL_pll_clock, 10, 10 DLL_pll_clock, 220, 10 DLL_pll_clock, 40, 10 DLL_pll_clock, 320, 10 DLL_pll_clock, 40, 11 DCSetup, 81 GetTraiggerCounlOffset TDCSetup, 81 GetTriggerMatchingMode TDCSetup, 81 GetTriggerMatchingMode TDCSetup, 81 GetType Client, 17 FPGAHandler, 25 Messenger, 36 TDCEvent, 59 GetValue SocketMessage, 50 GetVernierOffset TDCSetup, 81 GetWord TDCSetup, 81 GetWord TDCSetup, 82 GetWord TDCSetup, 81 GetWord TDCSetup, 82 GetWord TDCSetup, 82 GetWord TDCSetup, 83 GetWord TDCSetup, 84 GetWord TDCSetup, 85 GetWord TDCSetup, 85 GetWord TDCSetup, 81 GetWord TDCChepister, 61 RSC_20Mbits_s, 11 RSC_215Mbits_s, 11 HPTDC chip control, 11 RSC_25Mbits_s, 11 HPTDC chip control, 9 RSC_20Mbits_s, 11 HPTDC chip control, 9 RSC_20Mbits_s, 11	·	_
GelRejectFIFOFull Core_pll_clock_80,10 TDCSetup, 78 Core_pll_clock_80,10 DLL_160MHz,10 DLL_320MHz,10 DLL_320MHz,1	•	
TDCSetup, 78 GetSearchWindow TDCSetup, 79 GetSetupParity TDCSetup, 79 GetSetupParity TDCSetup, 79 GetSecketId Socket, 42 GetSocketType DtL_pll_clock, 160, 10 DtL_pll_clock, 20, 10 DtL_pll_clock, 40, 10 DtL_pll_clock, 20, 10 Debug, 11 DtCSetup, 80 GetTrailingMode Debug, 11 DtCSetup, 80 GetTriggerCountOffset DtCSetup, 81 GetTiggerMatchingMode DtCSetup, 81 GetTigup, 81 DtCSetup, 81 DtcTigup, 81 DtcTigup, 81 DtcTigup, 81 DtcTigu	•	Core_clock_40, 10
GetSearchWindow TDCSetup, 79 GetSetupParity TDCSetup, 79 GetSetupParity TDCSetup, 79 GetSocketId Socket, 42 GetSocketId GetString Mossage, 31 SocketMessage, 50 GetTDCId TDCEvent, 58 GetTestInvert TDCSetup, 59 GetTestIndode TDCSetup, 80 GetTrailingMode TDCSetup, 80 GetTrailingTime TDCEvent, 58 GetTiggerCountOffset TDCSetup, 80 GetTiggerLatency TDCSetup, 80 GetTiggerLatency TDCSetup, 81 GetTiggerMatchingMode TDCSetup, 80 GetTiggerMatchingMode TDCSetup, 80 GetTiggerMatchingMode TDCSetup, 80 GetTiggerMatchingMode TDCSetup, 80 GetTiggerCountOffset TDCSetup, 81 GetTiggerCountOffset TDCSetup, 80 GetTiggerCountOffset TDCSetup, 81 GetTiggerCountOffset TDCSetup, 82 GetWord TDCRegister, 61 GetWordCount TDCSetup, 82 GetWord TDCRegister, 61 GetWordCount TDCSetup, 82 GetWord TDCRegister, 61 GetWordCount TDCSetup, 82 GetWordCount TDCSetup, 83 GetCabbits, 8, 11 HPTDC chip control, 9 HPTDC chip control, 9	•	Core_pll_clock_160, 10
TDCSetup, 79 GetSetupParity TDCSetup, 79 GetSocketId Socket, 42 GetSocketId DLL_lllegal, 10 DLL_aux_clock, 10 DLL_aux_clock, 10 DLL_aux_clock, 10 DLL_pll_clock_160, 10 Socket, 42 GetSocketType DLL_clock_40, 10 Socket, 42 DLL_pll_clock_320, 10 Message, 31 SocketMessage, 50 DLL_pll_clock_40, 10 DLLSpeedMode, 10 DLCSetup, 58 GetTDCId DDCSetup, 58 GetTestInwert DDCSetup, 80 GetTestMode TDCSetup, 80 GetTrailingTime TDCSetup, 80 GetTrailingMode Debug, 11 TDCSetup, 80 GetTrailingTime E12p5ns, 10 TDCSetup, 80 GetTriggerCountOffset TDCSetup, 80 GetTriggerCountOffset TDCSetup, 80 GetTriggerCountOffset TDCSetup, 80 GetTriggerAlachingMode TDCSetup, 81 GetTriggerMatchingMode TDCSetup, 81 GetTrype Client, 17 FPGAHandler, 25 Messenger, 36 TDCEvent, 59 GetValue SocketMessage, 50 GetVetrotValue SocketMessage, 50 GetVetrotOcount TDCSetup, 81 GetWord TDCSetup, 82 GetWord TDCSetup, 82 GetWord TDCSetup, 83 GetWord TDCSetup	·	Core_pll_clock_80, 10
GetSetupParity TDCSetup, 79 CetSocketId Socket, 42 GetSocketType Socket, 42 GetSocketType Socket, 42 GetSocketType DLL_aux_clock, 10 DLL_pll_clock_40, 10 Socket, 42 DLL_pll_clock_40, 10 Socket, 42 GetString Message, 31 DLL_pll_clock_40, 10 DT_10ns, 10 DT_10ns, 10 DT_10ns, 10 DT_10ns, 10 DT_5ns, 10 DT_30ns, 10 DT_5ns, 10 DT_5ns, 10 DD_30ns, 10 DEstup, 80 DeadTime, 10 Debug, 11 E_100ps, 10 E_12p5ns, 10 E_200ps, 10 E_3p12ns, 10 E_200ps, 10 E_3p12ns, 10 E_6p25ns, 10 E_6p25ns	GetSearchWindow	CoreClockSource, 10
DLL_40MHz, 10	TDCSetup, 79	DLL 160MHz, 10
GetSocketId	GetSetupParity	DLL 320MHz, 10
GetSocketId	TDCSetup, 79	DLL 40MHz, 10
Socket, 42 GetSocketType Socket, 42 GetString Message, 31 SocketMessage, 50 GetTDCld TDCEvent, 58 GetTestInde TDCSetup, 80 GetTillingTime TDCSetup, 80 GetTrailingTime TDCSetup, 80 GetTriggerCountOffset TDCSetup, 80 GetTriggerAutchingMode TDCSetup, 80 GetTillingGrine TDCSetup, 80 GetTillingGrine TDCSetup, 80 GetTillingGrine TDCSetup, 80 GetTillingTime TDCSetup, 80 GetVernierOffset TDCSetup, 80 GetVernierOffset TDCSetup, 81 GetVidthResolution TDCSetup, 81 GetVidthResolution TDCSetup, 82 GetWord TDCSetup, 82 GetWord TDCSetup, 83 GetWordCount TDCSetup, 82 GetWord TDCSetup, 83 GetWordCount TDCSetup, 83 GetWordCount TDCSetup, 84 GetWordCount TDCSetup, 85 GetWordCount TDCSetup, 86 GetWordCount TDCSetup, 87 GetWordCount TDCSetup, 81 GetWordCount TDCSetup, 82 GetWordCount TDCSetup, 83 GroupHeader HPTDC chip control, 11 RSC_312p5kbits_s, 11 HPTDC chip control, 11 RSC_312p5kbits_s, 11 HPTDC chip control, 11 RSC_5Mbits_s, 11 HPTDC chip control, 9 RSC_625kbits_s, 11	GetSocketId	-
GetSocketType	Socket, 42	-
Socket, 42	GetSocketType	
Description	• •	
Message, 31 SocketMessage, 50 BottDCld TDCEvent, 58 GetTestInvert TDCSetup, 79 GetTestMode TDCSetup, 80 GetTrailingMode TDCSetup, 80 GetTrailingTime TDCSetup, 80 GetTriggerCountOffset TDCSetup, 80 GetTriggerAlatchingMode TDCSetup, 81 GetTriggerMatchingMode TDCSetup, 81 GetType Client, 17 FPGAHandler, 25 Messenger, 36 TDCEvent, 59 GetVectorValue SocketMessage, 50 GetVectorValue SocketMessage, 50 GetVectorValue TDCSetup, 81 GetWord TDCSetup, 81 GetWord TDCSetup, 81 GetWord TDCSetup, 81 GetWord TDCSetup, 81 GetVectorValue SocketMessage, 50 GetVectorValue TDCSetup, 81 GetWord TDCSetup, 82 GetWord TDCSetup, 82 GetWord TDCSetup, 83 GetWord TDCSetup, 84 GetWord TDCSetup, 84 GetWord TDCSetup, 84 GetWord TDCSetup,		
SocketMessage, 50 GetTDCld TDCEvent, 58 GetTestInvert TDCSetup, 79 GetTestMode TDCSetup, 80 GetTraillingMode TDCSetup, 80 GetTraillingTime TDCSetup, 80 GetTriggerCountOffset TDCSetup, 80 GetTriggerAlatency TDCSetup, 81 GetTriggerMatchingMode TDCSetup, 81 GetTrype Client, 17 FPGAHandler, 25 Messenger, 36 TDCEvent, 59 GetVectorValue SocketMessage, 50 GetVectorValue SocketMessage, 50 GetVernierOffset TDCSetup, 81 GetWord TDCSetup, 82 GetWord TDCRegister, 61 GetWordCount TDCSevent, 59 GroupTrailer TDCCevent, 59 GroupTrailer TDCCevent, 59 GroupTrailer TDCSetup, 82 GetWord TDCRegister, 61 GetWordCount TDCSetup, 82 GroupTrailer TDCCevent, 59 GroupTrailer TDCSetup, 82 GroupTrailer TDCCevent, 59 GroupTrailer TDCSetup, 82 GroupTrailer TDCCevent, 59 GroupTraile	•	
CetTDCld		
TDCEvent, 58 GetTestInvert TDCSetup, 79 GetTestMode TDCSetup, 80 GetTrailingMode TDCSetup, 80 GetTrailingTime TDCSetup, 80 GetTriggerCountOffset TDCSetup, 80 GetTriggerLatency TDCSetup, 81 GetTriggerMatchingMode TDCSetup, 81 GetTriggerMatchingMode TDCSetup, 81 GetTrype Client, 17 FPGAHandler, 25 Messenger, 36 TDCEvent, 59 GetVerierOffset TDCSetup, 81 GetVereireOffset TDCSetup, 81 GetVereireOffset TDCSetup, 81 GetVereireOffset TDCSetup, 81 GetVereireOffset TDCSetup, 81 GetWord TDCSetup, 82 GetWord TDCSetup, 82 GetWord TDCRegister, 61 GetWordCount TDCSevent, 59 GroupHeader HPTDC chip control, 11 RSC_2p5Mbits_s, 11 RSC_2p5Mbits_s, 11 RSC_40Mbits_s, 11 RSC_40Mbits_s, 11 RSC_5Mbits_s, 11		
GetTestInvert		•
TDCSetup, 79 GetTestMode	,	
GetTestMode		_
TDCSetup, 80 GetTrailingMode	•	_
GetTrailingMode		_ ·
TDCSetup, 80 GetTrailingTime TDCEvent, 58 GetTriggerCountOffset TDCSetup, 80 GetTriggerLatency TDCSetup, 81 GetTriggerMatchingMode TDCSetup, 81 GetType Client, 17 FPGAHandler, 25 Messenger, 36 TDCEvent, 59 GetValue SocketMessage, 50 GetVectorValue SocketMessage, 50 GetVectorValue SocketMessage, 50 GetVernierOffset TDCSetup, 81 GetWidth TDCEvent, 59 GetWidth TDCEvent, 59 GetWidth TDCEvent, 59 GetWidthResolution TDCSetup, 82 GetWord TDCRegister, 61 GetWordCount TDCRegister, 61 GetWordCount TDCSetup, 59 GroupHeader HPTDC chip control, 11 GroupTrailer HPTDC chip control, 11 RSC_30Mbits_s, 11 RSC_30Mbits_s, 11 RSC_5Mbits_s, 11 RSC_5Mbits_s, 11 RSC_5Mbits_s, 11 RSC_5Mbits_s, 11 RSC_5Mbits_s, 11 RSC_5Mbits_s, 11	•	DeadTime, 10
GetTrailingTime	•	Debug, 11
TDCEvent, 58 GetTriggerCountOffset TDCSetup, 80 GetTriggerLatency TDCSetup, 81 GetTriggerMatchingMode TDCSetup, 81 GetTriggerMatchingMode TDCSetup, 81 GetTriggerMatchingMode TDCSetup, 81 GetTriggerMatchingMode TDCSetup, 81 GetType Client, 17 FPGAHandler, 25 Messenger, 36 TDCEvent, 59 GetValue SocketMessage, 50 GetVectorValue SocketMessage, 50 GetVernierOffset TDCSetup, 81 GetWidth TDCSetup, 81 GetWidth TDCSetup, 81 GetWidth TDCEvent, 59 GetWidthResolution TDCSetup, 82 GetWord TDCRegister, 61 GetWordCount TDCEvent, 59 GroupTealler HPTDC chip control, 11 GroupTrailer HPTDC chip control, 11 HPTDC chip control, 9 RSC_625kbits_s, 11 RSC_5Mbits_s, 11	•	E_100ps, 10
GetTriggerCountOffset E_200ps, 10 TDCSetup, 80 E_3p12ns, 10 GetTriggerLatency E_400ps, 10 TDCSetup, 81 E_6p25ns, 10 GetTriggerMatchingMode E_800ps, 10 TDCSetup, 81 EdgeResolution, 10 GetType EnabledError, 10 Client, 17 Ernor, 11 FPGAHandler, 25 EventType, 11 Messenger, 36 GroupHeader, 11 TDCEvent, 59 GroupHeader, 11 GetValue IO_aux_clock, 11 SocketMessage, 50 IO_pll_clock_40, 11 GetVerorierOffset IO_pll_clock_80, 11 TDCSetup, 81 IOClockSource, 11 GetWidth Invalid, 11 TDCEvent, 59 JTAGInstructionParityError, 11 GetWord LeadingEdge, 11 TDCSetup, 82 RO_Fixed, 12 GetWord RO_Fixed, 12 TDCRegister, 61 RO_Fixed, 12 GetWord RO_Fixed, 12 TDCEvent, 59 RSC_10Mbits_s, 11 GroupHeader RSC_20Mbits_s, 11 HPTDC chip control, 11 RSC_20Mbits_s	-	E_12p5ns, 10
TDCSetup, 80 GetTriggerLatency TDCSetup, 81 GetTriggerMatchingMode TDCSetup, 81 GetTriggerMatchingMode TDCSetup, 81 GetType Client, 17 FPGAHandler, 25 Messenger, 36 TDCEvent, 59 GetValue SocketMessage, 50 GetVectorValue SocketMessage, 50 GetVernierOffset TDCSetup, 81 GetWidth TDCSetup, 81 GetWidth TDCSetup, 82 GetWord TDCSetup, 82 GetWordCount TDCSevent, 59 GroupHeader HPTDC chip control, 11 GroupTrailer HPTDC chip control, 11 HPTDC chip control, 9 E 3912ns, 10 E 400ps, 10 E 400ps, 10 E 6p25ns, 10 E 800ps, 10 E a00ps, 10 E 6p25ns, 10 E a00ps, 10 E 6p25ns, 10 E 6p25ns, 10 E copytheader, 11 Colock 40, 11 Colock 40, 11 Invalid, 11 Inval		E_1p6ns, 10
GetTriggerLatency		E_200ps, 10
TDCSetup, 81 GetTriggerMatchingMode TDCSetup, 81 GetType Client, 17 FPGAHandler, 25 Messenger, 36 TDCEvent, 59 GetValue SocketMessage, 50 GetVectorValue SocketMessage, 50 GetVernierOffset TDCSetup, 81 GetWidth TDCSetup, 81 GetWidth TDCSetup, 81 GetWidthResolution TDCSetup, 82 GetWordCount TDCRegister, 61 GetWordCount TDCEvent, 59 GroupHeader HPTDC chip control, 11 GroupTrailer HPTDC chip control, 11 HPTDC chip control, 9 E_6025s, 10 E_8025s, 10 E_800ps, 10 E_802ps, 10 E_800ps, 10 E_800ps, 10 E_802ps, 10 EdgeResolution, 10 EdgeResolution EdgeResolution, 10 EdgeResolution EdgeResolute, 10 EdgeResolute, 10 EdgeResolue, 20 EdgeResclue, 20 EdgeResolue, 20 EdgeResolue, 20 EdgeResclue, 20 EdgeResclue, 20 EdgeR	•	E_3p12ns, 10
TDCSetup, 81		_ ·
Set TriggerMatchingMode E 800ps, 10 TDCSetup, 81 EdgeResolution, 10 EdgeResolution, 10 EnabledError, 10 Enror, 11 Error, 11 Error, 11 EventType, 11 EventType, 11 GroupTrailer, 11 IO_aux_clock, 11 IO_aux_clock, 11 IO_aux_clock, 11 IO_pll_clock_40, 11 IO_pll_clock_40, 11 IO_pll_clock_80, 11	•	
EdgeResolution, 10		
Get lype Client, 17 FPGAHandler, 25 Messenger, 36 TDCEvent, 59 GetValue SocketMessage, 50 GetVectorValue SocketMessage, 50 GetVernierOffset TDCSetup, 81 GetWidth TDCEvent, 59 GetWidthResolution TDCSetup, 82 GetWord TDCRegister, 61 GetWordCount TDCEvent, 59 GroupHeader IO_aux_clock, 11 IO_clock_40, 11 IO_clock_40, 11 IO_pll_clock_160, 11 IO_pll_clock_80, 11 IO_pll_clock_80, 11 Invalid, 11	TDCSetup, 81	
Client, 17 FPGAHandler, 25 Messenger, 36 TDCEvent, 59 GetValue SocketMessage, 50 GetVectorValue SocketMessage, 50 GetVernierOffset TDCSetup, 81 GetWidth TDCEvent, 59 GetWidthResolution TDCSetup, 82 GetWord TDCRegister, 61 GetWordCount TDCEvent, 59 GetWordCount TDCEvent, 59 GroupHeader IO_aux_clock, 11 IO_aux_clock, 11 IO_clock_40, 11 IO_pll_clock_160, 11 IO_pll_clock_80, 11 IOClockSource, 11 Invalid, 11 Invalid	GetType	-
FPGAHandler, 25 Messenger, 36 TDCEvent, 59 GetValue SocketMessage, 50 GetVectorValue SocketMessage, 50 GetVernierOffset TDCSetup, 81 GetWidth TDCEvent, 59 GetWidthResolution TDCSetup, 82 GetWord TDCRegister, 61 GetWordCount TDCEvent, 59 GroupTrailer, 11 GetWordCount TDCEvent, 59 GroupHeader IO_aux_clock, 11 IO_aux_clock, 11 IO_clock_40, 11 IO_pll_clock_160, 11 IO_pll_clock_80, 11 IOClockSource, 11 Invalid, 11 I	Client, 17	
Messenger, 36 TDCEvent, 59 GetValue SocketMessage, 50 GetVectorValue SocketMessage, 50 GetVernierOffset TDCSetup, 81 GetWidth TDCEvent, 59 GetWidthResolution TDCSetup, 82 GetWord TDCRegister, 61 GetWordCount TDCEvent, 59 GroupHeader HPTDC chip control, 11 GroupTrailer, 11 GroupTrailer, 11 IO_aux_clock, 11 IO_clock_40, 11 IO_pll_clock_160, 11 IO_pll_clock_80, 11 IOClockSource, 11 Invalid, 11 JTAGInstructionParityError, 11 LeadingEdge, 11 RO_Fixed, 12 RO_pll_80Mbits_s, 12 RSC_10Mbits_s, 11 RSC_20Mbits_s, 11 RSC_20Mbits_s, 11 RSC_312p5kbits_s, 11 RSC_5Mbits_s, 11 RSC_5Mbits_s, 11 RSC_5Mbits_s, 11 RSC_5Mbits_s, 11 RSC_5Mbits_s, 11 RSC_625kbits_s, 11 RSC_625kbits_s, 11	FPGAHandler, 25	
GetValue SocketMessage, 50 GetVectorValue SocketMessage, 50 GetVernierOffset TDCSetup, 81 GetWidth TDCEvent, 59 GetWord TDCSetup, 82 GetWord TDCRegister, 61 GetWordCount TDCEvent, 59 GroupTrailer TDCEvent, 59 GroupTrailer TDCEvent, 59 GetWord TDCRegister, 61 GetWordCount TDCEvent, 59 GroupHeader HPTDC chip control, 11 GroupTrailer HPTDC chip control, 9 GroupTrailer HPTDC chip control, 9 GroupTrailer IDCaux_clock, 11 IDC_aux_clock, 11 ID_aux_clock, 12 ID_aux_clock, 11 ID_clock_40, 11 ID_pll_clock_40, 11 ID_pll_clock_40	Messenger, 36	
GetValue SocketMessage, 50 GetVectorValue SocketMessage, 50 GetVernierOffset TDCSetup, 81 GetWidth TDCEvent, 59 GetWord TDCRegister, 61 GetWordCount TDCEvent, 59 GroupHeader HPTDC chip control, 11 GroupTrailer HPTDC chip control, 9 GetValue SocketMessage, 50 IO_clock_40, 11 IO_clock_160, 11 IO_pll_clock_80, 11 IOClockSource, 11 IDClockSource, 11 Invalid, 11 JTAGInstructionParityError, 11 LeadingEdge, 11 LeadingEdge, 11 RO_Fixed, 12 RO_pll_80Mbits_s, 12 RSC_10Mbits_s, 11 RSC_20Mbits_s, 11 RSC_20Mbits_s, 11 RSC_312p5kbits_s, 11 RSC_312p5kbits_s, 11 RSC_5Mbits_s, 11	TDCEvent, 59	-
GetVectorValue SocketMessage, 50 GetVernierOffset TDCSetup, 81 GetWidth TDCEvent, 59 GetWord TDCRegister, 61 GetWordCount TDCEvent, 59 GroupHeader HPTDC chip control, 11 GroupTrailer HPTDC chip control, 9 GetVectnierOffset TDCsetup, 80 IO_clock_40, 11 IO_pll_clock_80, 11 IO_pll_clock_80, 11 IOClockSource, 11 INvalid, 11 JTAGInstructionParityError, 11 LeadingEdge, 11 LeadingEdge, 11 RO_Fixed, 12 RO_pll_80Mbits_s, 12 RSC_10Mbits_s, 11 RSC_20Mbits_s, 11 RSC_2p5Mbits_s, 11 RSC_312p5kbits_s, 11 RSC_312p5kbits_s, 11 RSC_5Mbits_s, 11 RSC_5Mbits_s, 11 RSC_5Mbits_s, 11 RSC_5Mbits_s, 11 RSC_625kbits_s, 11	GetValue	-
GetVernierOffset TDCSetup, 81 GetWidth TDCEvent, 59 GetWord TDCSetup, 82 GetWord TDCRegister, 61 GetWordCount TDCEvent, 59 GroupHeader HPTDC chip control, 11 GroupTrailer HPTDC chip control, 9 GetVernierOffset ID_pll_clock_80, 11 IOClockSource, 11 Invalid, 11 Invalid, 11 JTAGInstructionParityError, 11 LeadingEdge, 11 LeadingEdge, 11 RO_pixed, 12 RO_pll_80Mbits_s, 12 RSC_10Mbits_s, 11 RSC_1p25Mbits_s, 11 RSC_2p5Mbits_s, 11 RSC_312p5kbits_s, 11 RSC_40Mbits_s, 11 RSC_5Mbits_s, 11 RSC_5Mbits_s, 11 RSC_5Mbits_s, 11 RSC_5Mbits_s, 11 RSC_5Mbits_s, 11 RSC_5Mbits_s, 11 RSC_625kbits_s, 11	SocketMessage, 50	
GetVernierOffset TDCSetup, 81 GetWidth TDCEvent, 59 GetWidthResolution TDCSetup, 82 GetWord TDCRegister, 61 GetWordCount TDCEvent, 59 GroupHeader HPTDC chip control, 11 GroupTrailer HPTDC chip control, 11 HPTDC chip control, 9 ID_pll_clock_80, 11 IDClockSource, 11 Invalid, 10 Invalid, 11 Invalid,	GetVectorValue	
TDCSetup, 81 GetWidth TDCEvent, 59 GetWidthResolution TDCSetup, 82 GetWord TDCRegister, 61 GetWordCount TDCEvent, 59 GroupHeader HPTDC chip control, 11 GroupTrailer HPTDC chip control, 11 HPTDC chip control, 9 IDClockSource, 11 Invalid, 10 Invalid, 11 Invalid, 11 Inval	SocketMessage, 50	- -
TDCSetup, 81 GetWidth TDCEvent, 59 GetWidthResolution TDCSetup, 82 GetWord TDCRegister, 61 GetWordCount TDCEvent, 59 GroupHeader HPTDC chip control, 11 GroupTrailer HPTDC chip control, 11 HPTDC chip control, 9 Invalid, 11 Invalid, 11 JTAGInstructionParityError, 11 LeadingEdge, 11 RO_Fixed, 12 RO_pll_80Mbits_s, 12 RSC_10Mbits_s, 11 RSC_10Mbits_s, 11 RSC_20Mbits_s, 11 RSC_220Mbits_s, 11 RSC_312p5kbits_s, 11 RSC_40Mbits_s, 11 RSC_5Mbits_s, 11 RSC_5Mbits_s, 11 RSC_5Mbits_s, 11 RSC_5Mbits_s, 11	GetVernierOffset	- -
GetWidth TDCEvent, 59 GetWidthResolution TDCSetup, 82 GetWord TDCRegister, 61 GetWordCount TDCEvent, 59 GroupHeader HPTDC chip control, 11 GroupTrailer HPTDC chip control, 11 HPTDC chip control, 9 TDCEvent, 59 GroupHeader HPTDC chip control, 9 TNZIII T		
TDCEvent, 59 GetWidthResolution TDCSetup, 82 GetWord TDCRegister, 61 GetWordCount TDCEvent, 59 GroupHeader HPTDC chip control, 11 GroupTrailer HPTDC chip control, 11 HPTDC chip control, 9 TTDCEvent, 59 TROGINSTRUCTIOnParityError, 11 LadingEdge, 11 RO_Fixed, 12 RO_pll_80Mbits_s, 12 RSC_10Mbits_s, 11 RSC_10Mbits_s, 11 RSC_20Mbits_s, 11 RSC_20Mbits_s, 11 RSC_312p5kbits_s, 11 RSC_40Mbits_s, 11 RSC_5Mbits_s, 11 RSC_5Mbits_s, 11 RSC_5Mbits_s, 11 RSC_5Mbits_s, 11		
GetWidthResolution L1BufferParityError, 11 TDCSetup, 82 LeadingEdge, 11 GetWord RO_Fixed, 12 TDCRegister, 61 RO_pll_80Mbits_s, 12 GetWordCount RSC_10Mbits_s, 11 TDCEvent, 59 RSC_1p25Mbits_s, 11 GroupHeader RSC_20Mbits_s, 11 HPTDC chip control, 11 RSC_312p5kbits_s, 11 GroupTrailer RSC_40Mbits_s, 11 HPTDC chip control, 11 RSC_5Mbits_s, 11 HPTDC chip control, 9 RSC_625kbits_s, 11		-
TDCSetup, 82 LeadingEdge, 11 GetWord RO_Fixed, 12 TDCRegister, 61 RO_pll_80Mbits_s, 12 GetWordCount RSC_10Mbits_s, 11 TDCEvent, 59 RSC_1p25Mbits_s, 11 GroupHeader RSC_20Mbits_s, 11 HPTDC chip control, 11 RSC_2p5Mbits_s, 11 GroupTrailer RSC_312p5kbits_s, 11 HPTDC chip control, 11 RSC_40Mbits_s, 11 HPTDC chip control, 9 RSC_625kbits_s, 11	,	-
GetWord RO_Fixed, 12 TDCRegister, 61 RO_pll_80Mbits_s, 12 GetWordCount RSC_10Mbits_s, 11 TDCEvent, 59 RSC_1p25Mbits_s, 11 GroupHeader RSC_20Mbits_s, 11 HPTDC chip control, 11 RSC_2p5Mbits_s, 11 GroupTrailer RSC_312p5kbits_s, 11 HPTDC chip control, 11 RSC_40Mbits_s, 11 HPTDC chip control, 9 RSC_625kbits_s, 11		LeadingEdge, 11
TDCRegister, 61 RO_pll_80Mbits_s, 12 GetWordCount RSC_10Mbits_s, 11 TDCEvent, 59 RSC_1p25Mbits_s, 11 GroupHeader RSC_20Mbits_s, 11 HPTDC chip control, 11 RSC_2p5Mbits_s, 11 GroupTrailer RSC_312p5kbits_s, 11 HPTDC chip control, 11 RSC_40Mbits_s, 11 HPTDC chip control, 9 RSC_625kbits_s, 11	• •	RO_Fixed, 12
GetWordCount RSC_10Mbits_s, 11 TDCEvent, 59 RSC_1p25Mbits_s, 11 GroupHeader RSC_20Mbits_s, 11 HPTDC chip control, 11 RSC_2p5Mbits_s, 11 GroupTrailer RSC_312p5kbits_s, 11 HPTDC chip control, 11 RSC_40Mbits_s, 11 HPTDC chip control, 9 RSC_625kbits_s, 11		RO_pll_80Mbits_s, 12
TDCEvent, 59 GroupHeader HPTDC chip control, 11 GroupTrailer HPTDC chip control, 11 HPTDC chip control, 11 RSC_312p5kbits_s, 11 RSC_40Mbits_s, 11 RSC_5Mbits_s, 11 RSC_5Mbits_s, 11 RSC_5Mbits_s, 11 RSC_625kbits_s, 11	· · · · · · · · · · · · · · · · · · ·	RSC_10Mbits_s, 11
GroupHeader HPTDC chip control, 11 GroupTrailer HPTDC chip control, 11 HPTDC chip control, 11 RSC_312p5kbits_s, 11 RSC_40Mbits_s, 11 RSC_5Mbits_s, 11 HPTDC chip control, 9 RSC_625kbits_s, 11		
HPTDC chip control, 11 GroupTrailer HPTDC chip control, 11 HPTDC chip control, 11 HPTDC chip control, 9 RSC_2p5Mbits_s, 11 RSC_312p5kbits_s, 11 RSC_40Mbits_s, 11 RSC_5Mbits_s, 11 RSC_5Mbits_s, 11		_ ·
## Table Chip Control, 11 GroupTrailer HPTDC chip control, 11 HPTDC chip control, 11 HPTDC chip control, 9 RSC_312p5kbits_s, 11 RSC_40Mbits_s, 11 RSC_5Mbits_s, 11 RSC_625kbits_s, 11	•	
HPTDC chip control, 11 RSC_40Mbits_s, 11 RSC_5Mbits_s, 11 HPTDC chip control, 9 RSC_625kbits_s, 11	•	_ ·
HPTDC chip control, 9 RSC_5Mbits_s, 11 HSC_625kbits_s, 11	•	
HPTDC chip control, 9 RSC_625kbits_s, 11	HPTUC cnip control, 11	
·	HPTDC chin control 9	
Treadouti ii Or antychol, 11	•	
	Shamolooistelloi, 11	noudout if Of unity LITOI, TT

ReadoutSingleCycleSpeed, 11	HPTDC chip control, 11
ReadoutSpeed, 11	IsFromWeb
ReadoutStateError, 11	Message, 31
SS_DSStrobe, 12	IsWebSocket
SS_LeadingEdge, 12	Socket, 42
SS_LeadingTrailingStrobe, 12	
SS_NoStrobe, 12	JTAGInstructionParityError
Serial_aux_clock, 12	HPTDC chip control, 11
Serial_pll_clock_160, 12	
Serial_pll_clock_40, 12	kCoarseCountOffset
Serial pll clock 80, 12	TDCSetup, 109
SerialClockSource, 12	kControlParity
SerialStrobeType, 12	TDCControl, 56
SetupParityError, 11	kCoreClockDelay
TDCHeader, 11	TDCSetup, 109
TDCTrailer, 11	kCoreClockSource
TrailingEdge, 11	TDCSetup, 109
TriggerFIFOParityError, 11	kDLLClockDelay
TriggerMatchingError, 11	TDCSetup, 109
	kDLLClockSource
VernierError, 11	TDCSetup, 109
W_100ns, 12	kDLLControl
W_100ps, 12	TDCSetup, 109
W_12p5ns, 12	kDLLMode
W_1p6ns, 12	TDCSetup, 109
W_200ns, 12	kDLLReset
W_200ps, 12	TDCControl, 56
W_25ns, 12	kDLLTapAdjust0
W_3p2ns, 12	
W_400ns, 12	TDCSetup, 109
W_400ps, 12	kDeadTime
W_50ns, 12	TDCSetup, 109
W_6p25ns, 12	kEnableAutomaticReject
W_800ns, 12	TDCSetup, 109
W_800ps, 12	kEnableBytewise
WidthResolution, 12	TDCSetup, 109
HTTPMessage, 27	kEnableChannel
Decode, 29	TDCControl, 56
Dump, 29	kEnableDirectBunchReset
Encode, 29	TDCSetup, 109
fOriginalString, 29	kEnableDirectEventReset
fWS, 29	TDCSetup, 109
GetKey, 29	kEnableDirectTrigger
HTTPMessage, 28	TDCSetup, 109
3 ,	kEnableError
INVALID	TDCSetup, 109
Socket communication objects, 7	kEnableErrorBypass
IO_aux_clock	TDCSetup, 109
HPTDC chip control, 11	kEnableErrorMark
IO_clock_40	TDCSetup, 109
HPTDC chip control, 11	kEnableGlobalHeader
IO_pll_clock_160	TDCSetup, 109
HPTDC chip control, 11	kEnableGlobalTrailer
IO_pll_clock_80	TDCSetup, 109
HPTDC chip control, 11	kEnableJTAGReadout
IOClockSource	TDCSetup, 109
HPTDC chip control, 11	kEnableLocalHeader
Init	TDCSetup, 109
USBHandler, 113	kEnableLocalTrailer
Invalid	TDCSetup, 109
	. 2000.00

kEnableMasterResetCode	kMaxEventSize
TDCSetup, 110	TDCSetup, 110
kEnableMasterResetOnEventReset	kModeRC
TDCSetup, 110	TDCSetup, 111
kEnableMatching	kModeRCCompression
TDCSetup, 110	TDCSetup, 111
kEnableOverflowDetect	kOffset0
TDCSetup, 110	TDCSetup, 111
kEnablePair	kPLLControl
TDCSetup, 110	TDCSetup, 111
kEnablePattern	kPLLReset
TDCControl, 56	TDCControl, 56
kEnableReadoutOccupancy	kRCAdjust0
• •	-
TDCSetup, 110	TDCSetup, 111
kEnableReadoutSeparator	kReadoutFIFOSize
TDCSetup, 110	TDCSetup, 111
kEnableRelative	kReadoutSingleCycleSpeed
TDCSetup, 110	TDCSetup, 111
kEnableResetChannelBufferWhenSeparator	kReadoutSpeedSelect
TDCSetup, 110	TDCSetup, 111
kEnableSeparatorOnBunchReset	kRejectCountOffset
TDCSetup, 110	TDCSetup, 111
kEnableSeparatorOnEventReset	kRejectFIFOFull
TDCSetup, 110	TDCSetup, 111
kEnableSerial	kRollOver
TDCSetup, 110	TDCSetup, 111
kEnableSetCountersOnBunchReset	kSearchWindow
TDCSetup, 110	TDCSetup, 111
kEnableTTLClock	kSelectBypassInputs
TDCSetup, 110	TDCSetup, 111
kEnableTTLControl	kSerialClockDelay
TDCSetup, 110	TDCSetup, 111
kEnableTTLHit	kSerialClockSource
TDCSetup, 110	TDCSetup, 111
kEnableTTLReset	kSerialDelay
TDCSetup, 110	TDCSetup, 111
kEnableTTLSerial	kSetupParity
TDCSetup, 110	TDCSetup, 111
kEventCountOffset	kStrobeSelect
TDCSetup, 110	TDCSetup, 111
kGlobalReset	kTDCld
TDCControl, 56	TDCSetup, 111
kIOClockDelay	kTestInvert
TDCSetup, 110	TDCSetup, 111
klOClockSource	kTestMode
TDCSetup, 110	TDCSetup, 111
kKeepToken	kTestSelect
TDCSetup, 110	TDCSetup, 111
kLeading	kTokenDelay
TDCSetup, 110	TDCSetup, 111
kLeadingResolution	kTrailing
TDCSetup, 110	TDCSetup, 111
kLowPowerMode	kTriggerCountOffset
TDCSetup, 110	TDCSetup, 111
kMaster	kVernierOffset
TDCSetup, 110	TDCSetup, 111
kMatchWindow	kWidthSelect
TDCSetup, 110	TDCSetup, 111
1500Gtup, 110	1000etup, 111

L1BufferParityError	HPTDC chip control, 11
HPTDC chip control, 11	RSC_1p25Mbits_s
LeadingEdge	HPTDC chip control, 11
HPTDC chip control, 11	RSC_20Mbits_s
Listen	HPTDC chip control, 11
Socket, 42	RSC_2p5Mbits_s
ListenerInfo, 29	HPTDC chip control, 11
name, 29	RSC_312p5kbits_s
type, 29	HPTDC chip control, 11
	RSC_40Mbits_s
MASTER	HPTDC chip control, 11
Socket communication objects, 7	RSC_5Mbits_s
magic	HPTDC chip control, 11
file_header_t, 21	RSC_625kbits_s
Message, 29	HPTDC chip control, 11
\sim Message, 31	ReadBoundaryScanRegister
Dump, 31	FPGAHandler, 25
fString, 31	ReadBuffer
GetKey, 31	FPGAHandler, 25
GetString, 31	ReadConfiguration
IsFromWeb, 31	FPGAHandler, 25
Message, 31	ReadoutFIFOParityError
Messenger, 31	HPTDC chip control, 11
\sim Messenger, 33	ReadoutSingleCycleSpeed
AddClient, 34	HPTDC chip control, 11
Broadcast, 34	ReadoutSpeed
Connect, 35	HPTDC chip control, 11
Disconnect, 35	ReadoutStateError
DisconnectClient, 36	HPTDC chip control, 11
fListenersInfo, 38	Receive
fNumAttempts, 38	Client, 17
fWS, 38	Messenger, 37
GetType, 36	run_id
Messenger, 33	file_header_t, 21
ProcessMessage, 36	
Receive, 37	SS_DSStrobe
Send, 37	HPTDC chip control, 12
SwitchClientType, 38	SS_LeadingEdge
	HPTDC chip control, 12
name	SS_LeadingTrailingStrobe
ListenerInfo, 29	HPTDC chip control, 12
	SS_NoStrobe
Object	HPTDC chip control, 12
SocketMessage, 50	SelectConnections
OpenFile	Socket, 43
FPGAHandler, 25	Send
	Client, 17
ParseMessage	Messenger, 37
Client, 17	SendConfiguration
PrepareConnection	FPGAHandler, 25
Socket, 43	SendMessage
ProcessMessage	Socket, 43
Messenger, 36	Serial_aux_clock
	HPTDC chip control, 12
RO_Fixed	Serial_pll_clock_160
HPTDC chip control, 12	HPTDC chip control, 12
RO_pll_80Mbits_s	Serial_pll_clock_40
HPTDC chip control, 12	HPTDC chip control, 12
RSC_10Mbits_s	Serial_pll_clock_80

HPTDC chip control, 12	TDCSetup, 90
SerialClockSource	SetEnableErrorMark
HPTDC chip control, 12	TDCSetup, 90
SerialStrobeType	SetEnableGlobalHeader
HPTDC chip control, 12	TDCSetup, 90
SetAllChannelsOffset	SetEnableGlobalTrailer
TDCSetup, 82	TDCSetup, 91
SetAllTapsDLLAdjustment	SetEnableJTAGReadout
TDCSetup, 82	TDCSetup, 91
SetBits	SetEnableLocalHeader
TDCRegister, 62	TDCSetup, 91
SetBypassInputs	SetEnableLocalTrailer
TDCSetup, 82	TDCSetup, 92
SetChannelOffset	SetEnableMasterResetCode
TDCSetup, 83	TDCSetup, 92
SetCoarseCountOffset	SetEnableMasterResetOnEventReset
TDCSetup, 83	TDCSetup, 92
SetConfiguration	SetEnableOverflowDetect
FPGAHandler, 26	TDCSetup, 93
SetConstantValues	SetEnablePattern
TDCSetup, 83	TDCControl, 55
SetControlParity	SetEnableReadoutOccupancy
TDCControl, 55	TDCSetup, 93
SetCoreClockDelay	SetEnableReadoutSeparator
TDCSetup, 84	TDCSetup, 93
SetCoreClockSource	SetEnableRelative
TDCSetup, 85	TDCSetup, 94
SetDLLAdjustment	SetEnableResetChannelBufferWhenSeparator
TDCSetup, 85	TDCSetup, 94
SetDLLClockDelay	SetEnableSeparatorOnBunchReset
TDCSetup, 86	TDCSetup, 94
SetDLLClockSource	SetEnableSeparatorOnEventReset
TDCSetup, 86	TDCSetup, 95
SetDLLControl	SetEnableSerial
TDCSetup, 86	TDCSetup, 95
SetDLLMode	SetEnableSetCountersOnBunchReset
TDCSetup, 87	TDCSetup, 95
SetDLLReset	SetEnableTTLClock
TDCControl, 55	TDCSetup, 96
SetDeadTime	SetEnableTTLControl
TDCSetup, 85	TDCSetup, 96
SetEdgeResolution	SetEnableTTLHit
TDCSetup, 87	TDCSetup, 96
SetEdgesPairing	SetEnableTTLReset
TDCSetup, 87	TDCSetup, 97
SetEnableAutomaticReject	SetEnableTTLSerial
TDCSetup, 88	TDCSetup, 97
SetEnableBytewise	SetEventCountOffset
TDCSetup, 88	TDCSetup, 98
SetEnableDirectBunchReset	SetGlobalReset
TDCSetup, 88	TDCControl, 55
SetEnableDirectEventReset	SetIOClockDelay
TDCSetup, 89	TDCSetup, 98
SetEnableDirectTrigger	SetIOClockSource
TDCSetup, 89	TDCSetup, 98
SetEnableError	SetKeepToken
TDCSetup, 89	TDCSetup, 99
SetEnableErrorBypass	SetKeyValue

CooketMennage FO F1	TDCSature 107
SocketMessage, 50, 51 SetLeadingMode	TDCSetup, 107 SetTriggerMatchingMode
	-
TDCSetup, 99	TDCSetup, 108
SetLowPowerMode	SetVernierOffset
TDCSetup, 99	TDCSetup, 108
SetMaster	SetWidthResolution
TDCSetup, 100	TDCSetup, 108
SetMatchWindow	SetWord
TDCSetup, 100	TDCRegister, 62
SetMaxEventSize	SetupParityError
TDCSetup, 100	HPTDC chip control, 11
SetModeRC	Socket, 39
TDCSetup, 101	~Socket, 41
SetModeRCCompression	AcceptConnections, 41
TDCSetup, 101	Bind, 41
SetPLLControl	Configure, 41
TDCSetup, 101	Create, 42
SetPLLReset	DumpConnected, 42
TDCControl, 56	fAddress, 44
SetPort	fBuffer, 44
Socket, 43	fMaster, 44
SetRCAdjustment	fPort, 44
TDCSetup, 102	fReadFds, 44
SetReadoutFIFOSize	fSocketId, 44
TDCSetup, 102	fSocketsConnected, 44
SetReadoutSingleCycleSpeed	FetchMessage, 42
TDCSetup, 102	GetPort, 42
SetReadoutSpeedSelect	GetSocketId, 42
TDCSetup, 103	GetSocketType, 42
SetRejectCountOffset	IsWebSocket, 42
TDCSetup, 103	Listen, 42
SetRejectFIFOFull	PrepareConnection, 43
TDCSetup, 103	SelectConnections, 43
SetRollOver	SendMessage, 43
TDCSetup, 104	SetPort, 43
SetSearchWindow	SetSocketId, 43
TDCSetup, 104	Socket, 41
SetSerialClockDelay	SocketCollection, 41
TDCSetup, 104	Start, 43
SetSerialClockSource	Stop, 44
TDCSetup, 105	Socket communication objects, 7
SetSerialDelay	CLIENT, 7
TDCSetup, 105	DETECTOR, 8
SetSetupParity	INVALID, 7
TDCSetup, 105	MASTER, 7
SetSocketId	SocketType, 7
Socket, 43	WEBSOCKET_CLIENT, 7
SetStrobeSelect	SocketCollection
TDCSetup, 106	Socket, 41
SetTestInvert	SocketMessage, 45
TDCSetup, 106	~SocketMessage, 49
SetTestMode	Dump, 49
TDCSetup, 106	fMessage, 51
SetTokenDelay	GetIntValue, 49
TDCSetup, 107	GetKey, 49
SetTrailingMode	GetString, 50
TDCSetup, 107	GetValue, 50
SetTriggerCountOffset	GetVectorValue, 50

Object, 50	GetWord, 61
SetKeyValue, 50, 51	SetBits, 62
SocketMessage, 47-49	SetWord, 62
String, 51	TDCRegister, 61
SocketType	word_t, 61
Socket communication objects, 7	TDCSetup, 62
spill_id	∼TDCSetup, 71
file_header_t, 22	Dump, 71
Start	GetChannelOffset, 72
Socket, 43	GetCoarseCountOffset, 72
Stop	GetDLLAdjustment, 73
Socket, 44	GetDeadTime, 73
String	
SocketMessage, 51	GetEdgeResolution, 73
SwitchClientType	GetEdgesPairing, 74
Messenger, 38	GetEnableError, 74
wessenger, so	GetEnableErrorBypass, 74
TDCBoundaryScanRegister, 51	GetEnableErrorMark, 75
~TDCBoundaryScanRegister, 52	GetEnableJTAGReadout, 75
TDCBoundaryScanRegister, 52	GetEnableReadoutOccupancy, 75
TDCControl, 53	GetEnableReadoutSeparator, 76
	GetEnableSerial, 76
~TDCControl, 54	GetLeadingMode, 76
Dump, 54	GetMatchWindow, 77
EnablePattern, 54	GetMaxEventSize, 77
kControlParity, 56	GetRCAdjustment, 77
kDLLReset, 56	GetReadoutFIFOSize, 78
kEnableChannel, 56	GetRejectCountOffset, 78
kEnablePattern, 56	GetRejectFIFOFull, 78
kGlobalReset, 56	GetSearchWindow, 79
kPLLReset, 56	
SetControlParity, 55	GetSetupParity, 79
SetDLLReset, 55	GetTestInvert, 79
SetEnablePattern, 55	GetTestMode, 80
SetGlobalReset, 55	GetTrailingMode, 80
SetPLLReset, 56	GetTriggerCountOffset, 80
TDCControl, 54	GetTriggerLatency, 81
TDCEvent, 56	GetTriggerMatchingMode, 81
∼TDCEvent, 57	GetVernierOffset, 81
fWord, 59	GetWidthResolution, 82
GetBunchld, 57	kCoarseCountOffset, 109
GetErrorFlags, 57	kCoreClockDelay, 109
GetEventId, 58	kCoreClockSource, 109
GetLeadingTime, 58	kDLLClockDelay, 109
GetTDCId, 58	kDLLClockSource, 109
GetTrailingTime, 58	kDLLControl, 109
GetType, 59	kDLLMode, 109
	kDLLTapAdjust0, 109
GetWidth, 59	kDeadTime, 109
GetWordCount, 59	kEnableAutomaticReject, 109
TDCEvent, 57	•
TDCHeader	kEnableBytewise, 109
HPTDC chip control, 11	kEnableDirectBunchReset, 109
TDCRegister, 60	kEnableDirectEventReset, 109
\sim TDCRegister, 61	kEnableDirectTrigger, 109
bit, 61	kEnableError, 109
DumpRegister, 61	kEnableErrorBypass, 109
fNumWords, 62	kEnableErrorMark, 109
fWord, 62	kEnableGlobalHeader, 109
GetBits, 61	kEnableGlobalTrailer, 109
GetNumWords, 61	kEnableJTAGReadout, 109

LEnglish and University 400	OstAllTens Did Ashretmant 00
kEnableLocalHeader, 109	SetAllTapsDLLAdjustment, 82
kEnableLocalTrailer, 109	SetBypassInputs, 82
kEnableMasterResetCode, 110	SetChannelOffset, 83
kEnableMasterResetOnEventReset, 110	SetCoarseCountOffset, 83
kEnableMatching, 110	SetConstantValues, 83
kEnableOverflowDetect, 110	SetCoreClockDelay, 84
kEnablePair, 110	SetCoreClockSource, 85
kEnableReadoutOccupancy, 110	SetDLLAdjustment, 85
kEnableReadoutSeparator, 110	SetDLLClockDelay, 86
kEnableRelative, 110	SetDLLClockSource, 86
kEnableResetChannelBufferWhenSeparator, 110	SetDLLControl, 86
kEnableSeparatorOnBunchReset, 110	SetDLLMode, 87
kEnableSeparatorOnEventReset, 110	SetDeadTime, 85
kEnableSerial, 110	SetEdgeResolution, 87
kEnableSetCountersOnBunchReset, 110	SetEdgesPairing, 87
kEnableTTLClock, 110	SetEnableAutomaticReject, 88
kEnableTTLControl, 110	SetEnableBytewise, 88
kEnableTTLHit, 110	SetEnableDirectBunchReset, 88
kEnableTTLReset, 110	SetEnableDirectEventReset, 89
kEnableTTLSerial, 110	SetEnableDirectTrigger, 89
kEventCountOffset, 110	SetEnableError, 89
klOClockDelay, 110	SetEnableErrorBypass, 90
·	
kIOClockSource, 110	SetEnableErrorMark, 90
kKeepToken, 110	SetEnableGlobalHeader, 90
kLeading, 110	SetEnableGlobalTrailer, 91
kLeadingResolution, 110	SetEnableJTAGReadout, 91
kLowPowerMode, 110	SetEnableLocalHeader, 91
kMaster, 110	SetEnableLocalTrailer, 92
kMatchWindow, 110	SetEnableMasterResetCode, 92
kMaxEventSize, 110	SetEnableMasterResetOnEventReset, 92
kModeRC, 111	SetEnableOverflowDetect, 93
kModeRCCompression, 111	SetEnableReadoutOccupancy, 93
kOffset0, 111	SetEnableReadoutSeparator, 93
kPLLControl, 111	SetEnableRelative, 94
kRCAdjust0, 111	SetEnableResetChannelBufferWhenSeparator, 94
kReadoutFIFOSize, 111	SetEnableSeparatorOnBunchReset, 94
kReadoutSingleCycleSpeed, 111	SetEnableSeparatorOnEventReset, 95
kReadoutSpeedSelect, 111	SetEnableSerial, 95
kRejectCountOffset, 111	SetEnableSetCountersOnBunchReset, 95
kRejectFIFOFull, 111	SetEnableTTLClock, 96
kRollOver, 111	SetEnableTTLControl, 96
kSearchWindow, 111	SetEnableTTLHit, 96
kSelectBypassInputs, 111	SetEnableTTLReset, 97
kSerialClockDelay, 111	SetEnableTTLSerial, 97
kSerialClockSource, 111	SetEventCountOffset, 98
kSerialDelay, 111	SetIOClockDelay, 98
kSetupParity, 111	SetIOClockSource, 98
kStrobeSelect, 111	SetKeepToken, 99
kTDCld, 111	SetLeadingMode, 99
kTestInvert, 111	SetLowPowerMode, 99
kTestMode, 111	SetMaster, 100
kTestSelect, 111	SetMatchWindow, 100
kTokenDelay, 111	SetMaxEventSize, 100
kTrailing, 111	
G.	SetModeRC, 101
kTriggerCountOffset, 111	SetModeRCCompression, 101
kVernierOffset, 111	SetPLLControl, 101
kWidthSelect, 111	SetRCAdjustment, 102
SetAllChannelsOffset, 82	SetReadoutFIFOSize, 102

SetReadoutSingleCycleSpeed, 102	HPTDC chip control, 12
SetReadoutSpeedSelect, 103	W 25ns
SetRejectCountOffset, 103	HPTDC chip control, 12
SetRejectFIFOFull, 103	W_3p2ns
SetRollOver, 104	HPTDC chip control, 12
SetSearchWindow, 104	W 400ns
SetSerialClockDelay, 104	HPTDC chip control, 12
SetSerialClockSource, 105	W_400ps
SetSerialDelay, 105	HPTDC chip control, 12
SetSetupParity, 105	W_50ns
SetStrobeSelect, 106	HPTDC chip control, 12
SetTestInvert, 106	W_6p25ns
SetTestMode, 106	HPTDC chip control, 12
SetTokenDelay, 107	W_800ns
SetTrailingMode, 107	HPTDC chip control, 12
SetTriggerCountOffset, 107	W_800ps
SetTriggerOdditiOnset, 107 SetTriggerMatchingMode, 108	HPTDC chip control, 12
SetVernierOffset, 108	WEBSOCKET_CLIENT
SetWeitherOnset, 108	Socket communication objects, 7
TDCSetup, 70	WidthResolution
TDCTrailer	HPTDC chip control, 12
	word t
HPTDC chip control, 11 TrailingEdge	TDCRegister, 61
HPTDC chip control, 11	Write
TriggerFIFOParityError	USBHandler, 113
HPTDC chip control, 11	OODI landler, 110
TriggerMatchingError	
HPTDC chip control, 11	
_	
Type Evention 20	
Exception, 20	
type	
ListenerInfo, 29	
TypeString Exception, 20	
Exception, 20	
USBHandler, 112	
~USBHandler, 113	
DumpDevice, 113	
fDevice, 113	
fHandle, 113	
Fetch, 113	
Init, 113	
USBHandler, 113	
Write, 113	
write, 113	
VernierError	
HPTDC chip control, 11	
The TBO chip control, Th	
W 100ns	
HPTDC chip control, 12	
W 100ps	
HPTDC chip control, 12	
W_12p5ns	
HPTDC chip control, 12	
W_1p6ns	
HPTDC chip control, 12	
W 200ns	
HPTDC chip control, 12	
W 200ps	
- ·	