# **GamePad**

#### From Free60

### **Contents**

- 1 Gamepad
  - 1.1 General information
  - 1.2 The gamepad HID device
  - 1.3 Input report
- 2 Output report
  - 2.1 LED Control
  - 2.2 Rumbler Control
  - 2.3 The headset-port
  - 2.4 The headset data protocol
  - 2.5 Isusb output
  - 2.6 Speculation

# Gamepad

#### **General information**

The gamepads have 11 buttons, 2 triggers, 2 sticks and 1 D-Pad. The wired gamepad has a regular USB connector, the wireless uses the RF Module in the Xbox360. Both talk the same USB protocol.

The Play and Charge Kit for the wireless controller only provides power and a trickle charge. It does not change the wireless controller to a wired controller. The USB data lines are not active on the play and charge kit. It will not charge AA rechargeable batteries. The trickle charge is only available at the four prong jack at the bottom of the battery compartment. The play and charge can be plugged into any USB port, it does not have to be one on the 360.

## The gamepad HID device

The gamepad is a regular USB HID device, but it has been crippled in a slight way:

The device uses the 0xff DeviceClass ('Vendor Specific') while normal HID devices use 0x03. Therefore normal HID drivers won't attach to it automatically. The device has no USB Report Descriptor, making the operating system unable to determine its device layout. Both problems

are not hard to overcome; some operating systems (the BSDs for example) already override the USB Report Descriptors for some devices because they were shipped with broken ones.

A replacement report descriptor is available from the Free60 CVS repository. The layout of this descriptor is the same as the Windows driver, except that the big X button has been mapped to button 11. On Windows, it's unmapped.

### Input report

Once in a while, a USB HID device sends back a so-called input report which contains all information about its current state. The length of the input report is the same as the original Xbox gamepad; 20 bytes.

Its button/trigger/pad/stick alignment is as listed below:

```
Offset Length (bits)
                                  Description
                                                        Windows driver
0x00.0 8 Message type
0x01.0 8
                     Packet size (20 bytes = 0x14)
0x02.0 1
                     D-Pad up D-Pad up
                     D-Pad down
0x02.1 1
                                             D-Pad down
                     D-Pad left
                                           D-Pad left
0x02.2 1
0x02.2 1
0x02.3 1
0x02.4 1
0x02.5 1
0x02.6 1
0x02.7 1
0x03.0 1
0x03.1 1
                     D-pad right D-Pad right
                     Start button Button 8
                      Back button Button 7
                                                 Button 9
                       Left stick press
                       Right stick press
                                                       Button 10
                       Button LB Button 5
                       Button RB
                                             Button 6
0x03.2 1
                       Xbox logo button
0x03.3 1
                     Unused
0x03.4 1
                     Button A
                                             Button 1
0x03.5 1
                    Button B
                                          Button 2
0x03.6 1
                    Button X
                                          Button 3

        0x03.6
        1
        Button X
        Button 3

        0x03.7
        1
        Button Y
        Button 4

        0x04.0
        8
        Left trigger Z-axis down

        0x05.0
        8
        Right trigger Z-axis up

        0x06.0
        16
        Left stick X-axis X-axis X-axis

        0x08.0
        16
        Left stick Y-axis Y-axis

0x0a.0 16
                     Right stick X-axis X-turn
0x0c.0 16
                       Right stick Y-axis
                                                       Y-turn
0x0e.0 48
                       Unused
```

All eight-bit values are unsigned. The 16-bit values are signed little-endian. The first byte (Message type) will be 0x01 for a LED status message and 0x00 for a normal input report message.

# **Output report**

#### **LED Control**

Some control over the LEDs surrounding the XBox button is provided, corresponding to the markings 1, 2, 3 and 4. This is controlled using message type 0x01.

To select a new pattern for the LEDs, send a 3-byte packet of the following form:

#### 0103XX

0x01 is the message type, 0x03 is the message length, and 0xXX is the desired pattern:

```
Pattern Description
0x00
       All off
0x01
       All blinking
0x02
       1 flashes, then on
0x03
       2 flashes, then on
0x04
       3 flashes, then on
0x05
        4 flashes, then on
0x06
        1 on
0x07
        2 on
0x08
        3 on
       4 on
0x09
0x0A
      Rotating (e.g. 1-2-4-3)
0x0B
        Blinking*
0x0C
        Slow blinking*
0x0D
        Alternating (e.g. 1+4-2+3), then back to previous*
```

The previous setting will be used for any itmes with \* (all blinking, or 1, 2, 3 or 4 on).

#### **Rumbler Control**

Rumbling is also similar to on the original controller. Rumble commands take the following 8-byte form:

#### 000800bbl1000000

Where b is the speed to set the motor with the big weight, and l is the speed to set the small weight (0x00 to 0xFF in both cases).

# The headset-port

Headset Port File:Headset port pinout.jpg Pinout for the headset port on the wired and wireless Xbox 360 controller Baud Rate: Unknown, Data 1: RX or TX, Data 2: RX or TX

A chatpad (mini-keyboard) for text entry can be plugged into this port.

## The headset data protocol

FreeBSD ships with a driver called ugen(4) which is just a fallback driver for USB devices that do not have a matching driver. It allows you to read and write to the descriptors of the device. Descriptor 3 is used for the microphone. Descriptor 4 is the earpiece.

At this moment there isn't a lot of information available about the transfer protocol. The protocol for the microphone and the earpiece are the same, but the latter one uses half the sample rate of the first one. The following test shows this:

```
$ cat /dev/ugen0.3 > myvoice
# tell a funny joke to the microphone and press ^C
$ cat myvoice > /dev/ugen0.4
Playback will take twice as long.
```

The microphone emits 8000 bytes per second of 4 bits signed PCM, thus it's 16 KHz. The earpiece only consumes 4000 bytes, so it can only emit 8 KHz PCM (4 KHz sound at best).

## **Isusb** output

Linux's Isusb utility tells us the following about the gamepad.

```
Bus 002 Device 003: ID 045e:028e Microsoft Corp.
Device Descriptor:
  bLength
                            18
  bDescriptorType
                            1
 bcdUSB 2.00
bDeviceClass 255 Vendor Specific Class
bDeviceSubClass 255 Vendor Specific Subclass
bDeviceProtocol 255 Vendor Specific Protocol
bMaxPacketSize0 8
idVendor 0x045e Microsoft Corp.
idProduct 0x028e
  bcdDevice
                        1.10
  iManufacturer
                              1
  iProduct
  iSerial
  bNumConfigurations
                              1
  Configuration Descriptor:
    bLength
                                2
    bDescriptorType
    wTotalLength
                              153
    bNumInterfaces
                                4
    bConfigurationValue
                                1
    iConfiguration
    bmAttributes
                             0xa0
       (Bus Powered)
       Remote Wakeup
    MaxPower
                              500mA
    Interface Descriptor:
       bLength
       bDescriptorType
                                  4
                                  0
      bInterfaceNumber
                                  0
       bAlternateSetting
       bNumEndpoints
                                  2
       bInterfaceClass
                               255 Vendor Specific Class
       bInterfaceSubClass 93
       bInterfaceProtocol
                                1
       iInterface
       Endpoint Descriptor:
         bLength
                                     7
         bDescriptorType
                                    5
         bEndpointAddress
                                 0x81 EP 1 IN
         bmAttributes
           Transfer Type
                                        Interrupt
```

```
Synch Type
                                None
      Usage Type
                                Data
    wMaxPacketSize
                       0x0020
                                1x 32 bytes
    bInterval
                             4
  Endpoint Descriptor:
                            7
    bLength
    bDescriptorType
                             5
                               EP 2 OUT
    bEndpointAddress
                          0x02
    bmAttributes
                            3
      Transfer Type
                                Interrupt
      Synch Type
                                None
                                Data
      Usage Type
    wMaxPacketSize
                       0x0020
                                1x 32 bytes
    bInterval
                             8
Interface Descriptor:
  bLength
                           9
  bDescriptorType
                           4
  bInterfaceNumber
                           1
  bAlternateSetting
                           0
  bNumEndpoints
                           4
                         255 Vendor Specific Class
  bInterfaceClass
  bInterfaceSubClass
                         93
  bInterfaceProtocol
                           3
                           0
  iInterface
  Endpoint Descriptor:
                            7
    bLength
    bDescriptorType
                            5
    bEndpointAddress
                                EP 3 IN
                          0x83
    bmAttributes
                            3
      Transfer Type
                                Interrupt
      Synch Type
                                None
      Usage Type
                                Data
    wMaxPacketSize
                       0x0020
                                1x 32 bytes
    bInterval
  Endpoint Descriptor:
                             7
    bLength
    bDescriptorType
    bEndpointAddress
                          0x04
                               EP 4 OUT
    bmAttributes
      Transfer Type
                                Interrupt
      Synch Type
                                None
      Usage Type
                                Data
    wMaxPacketSize
                       0x0020
                                1x 32 bytes
    bInterval
  Endpoint Descriptor:
                             7
    bLength
    bDescriptorType
                             5
    bEndpointAddress
                          0x85
                                EP 5 IN
    bmAttributes
      Transfer Type
                                Interrupt
      Synch Type
                                None
      Usage Type
                                Data
    wMaxPacketSize
                       0x0020
                                1x 32 bytes
    bInterval
                            64
  Endpoint Descriptor:
    bLength
                             7
    bDescriptorType
                             5
                                EP 5 OUT
    bEndpointAddress
                          0x05
    bmAttributes
      Transfer Type
                                Interrupt
      Synch Type
                                None
      Usage Type
                                Data
    wMaxPacketSize
                       0x0020
                                1x 32 bytes
    bInterval
                            16
Interface Descriptor:
  bLength
                           9
                           4
  bDescriptorType
  bInterfaceNumber
                           2
  bAlternateSetting
                           0
                           1
  bNumEndpoints
```

```
bInterfaceClass
                       255 Vendor Specific Class
  bInterfaceSubClass
                        93
  bInterfaceProtocol
                         2
  iInterface
                         0
  Endpoint Descriptor:
                           7
   bLength
   bDescriptorType
                           5
                        0x86 EP 6 IN
   bEndpointAddress
   bmAttributes
                          3
     Transfer Type
                              Interrupt
     Synch Type
                              None
     Usage Type
                              Data
   wMaxPacketSize
                      0x0020 1x 32 bytes
   bInterval
                         16
Interface Descriptor:
 bLength
                         9
  bDescriptorType
                         4
  bInterfaceNumber
                         3
                         0
  bAlternateSetting
  bNumEndpoints
  bInterfaceClass
                       255 Vendor Specific Class
  bInterfaceSubClass
                       253
  bInterfaceProtocol
                        19
  iInterface
  UNRECOGNIZED: 06 41 00 01 01 03
```

### **Speculation**

Rumors that both the wired gamepad and wireless dongle share the same interface, but probably won't have the same USB device IDs. The last six bytes of the input descriptor are for analog face buttons. The information on the web is contradictory. I know that the controller did have pressure sensitive face buttons originally. Some web sites now say that it does not, so they must have been scrapped. Others say that it still does have them. If it does not the bytes are just a relic, but if the controler does have the analog buttons then there must be some form of toggle mechanism.

Retrieved from "http://free60.org/w/index.php? title=GamePad&oldid=2856" Category: Xbox360 Hardware

- This page was last modified on 7 January 2014, at 00:24.
- This page has been accessed 14,965 times.
- Content is available under GNU Free Documentation License 1.3 or later unless otherwise noted.