
The PMCs of EC2: Measuring IPC

04 May 2017

Performance Monitoring
Counters (PMCs) are now
publicly available from
dedicated host types in the AWS
EC2 cloud. PMC nerds
worldwide rejoice! (All six of us.)
There should be more of us in
the future, as with the increasing
scale of processors and speed of
storage devices, the common
bottleneck is moving from disks
to the memory subsystem. CPU



IPC and LLC loads with a scaling workload

caches, the MMU, memory busses, and CPU interconnects. These can only be analyzed with PMCs.

Memory is the new disk.

If PMCs are new to you, then in a nutshell they are special hardware counters that can be accessed via processor registers, and enabled and read via certain instructions. PMCs provide low-level CPU performance statistics that aren't available anywhere else.

In this post I'll summarize the PMCs available in EC2, which are for dedicated hosts only (eg, m4.16xl, i3.16xl), and I'll demonstrate measuring IPC. Note that PMCs are also known as HPCs (hardware performance counters), and other names as well.

EC2 Dedicated Host PMCs

The PMCs available are the architectural PMCs listed in the Intel-64 and IA-32
Architectures Developer's Manual: vol. 3B, in section 18.2.1.2 "Pre-defined Architectural Performance Events", Table 18-1 "UMask and Event Select Encodings for Pre-Defined Architectural Performance Events". I've drawn my own table of them below with example event mnemonics.

Architectural PMCs

Event Name	UMask	Event Select	Example Event Mask Mnemonic
UnHalted Core Cycles	00H	3СН	CPU_CLK_UNHALTED.THREAD_P
Instruction Retired	00H	СОН	INST_RETIRED.ANY_P
UnHalted Reference Cycles	01H	3СН	CPU_CLK_THREAD_UNHALTED.REF_XCLK
LLC Reference	4FH	2EH	LONGEST_LAT_CACHE.REFERENCE
LLC Misses	41H	2EH	LONGEST_LAT_CACHE.MISS

Branch Instruction	00H	C4H	BR_INST_RETIRED.ALL_BRANCHES
Retired			
Branch Misses	00H	C5H	BR MISP RETIRED.ALL BRANCHES
Retired		СЭП	DK_WIISF_KETIKED.ALL_BRAINCHES

What's so special about these seven architectural PMCs?

They give you a good overview of key CPU behavior, sure. But Intel have also chosen them as a golden set, to be highlighted first in the PMC manual and their presence exposed via the CPUID instruction.

Note that the Intel mnemonic for LLC here is "longest latency cache", but this is also known as "last level cache" or "level 3 cache" (assuming it's L3).

PMC Usage

Before I demonstrate PMCs, it's important to know that there's two very different ways they can be used:

- **Counting**: where they provide a count over an interval.
- **Sampling**: where based on a number of events, an interrupt can be triggered to sample the program counter or stack trace.

Counting is cheap. Sampling costs more overhead based on the rate of the interrupts (which can be tuned by changing the event trigger threshold), and whether you're reading the PC or the whole stack trace.

I'll demonstrate PMCs by using counting to measure IPC.

Measuring IPC

Instructions-per-cycle (IPC) is a good starting point for PMC analysis, and is measured by counting the instruction count and cycle count PMCs. (On some systems it is shown as its invert, cycles-per-instruction, CPI.)

IPC is like miles-per-gallon for CPUs: how much bang for your buck. The resource here isn't gallons of gasoline but CPU cycles, and the result isn't miles traveled but instructions retired (ie, completed). The more instructions you can complete with your fixed cycles resource, the better.

In the interest of keeping this short, I'll gloss over IPC caveats. There are situations where it can be misleading, like an increase of IPC because your program suffers more spin lock contention, and those spin instructions happen to be very fast. Just like MPG can be misleading, as it can be influenced by the route driven, not just the car's own characteristics.

I'll use the Linux <u>perf</u> command to measure IPC of a program, noploop, which loops over a series of NOP instructions (no op):

```
# perf stat ./noploop
^C./noploop: Interrupt
Performance counter stats for './noploop':
       2418.149339
                        task-clock (msec)
                                                       1.000 CPUs utilized
                       context-switches
                                                       0.001 K/sec
                 0
                       cpu-migrations
                                                       0.000 K/sec
                                                       0.016 K/sec
                39
                        page-faults
    6,245,387,593
                       cycles
                                                       2.583 GHz
                                                                                        (75.03%)
  <not supported>
                        stalled-cycles-frontend
   <not supported>
                       stalled-cycles-backend
   24,766,697,057
                                                       3.97
                                                             insns per cycle
                                                                                        (75.02%)
                        instructions
                                                        6.095 M/sec
                                                                                        (75.02%)
       14,738,991
                        branches
                                                       0.17% of all branches
           24,744
                        branch-misses
                                                                                        (75.04%)
       2.418826663 seconds time elapsed
```

I've highlighted IPC ("insns per cycle") in the output. I like noploop as a sanity test. Because this processor is 4-wide (instruction prefetch/decode width), it can process a maximum of 4 instructions with every CPU cycle. Since NOPs are the fastest possible instruction (they do nothing), they can be retired at an IPC rate of 4.0. This goes down to 3.97 with a little loop logic (the program is looping over a block of NOPs).

The "<not supported>" metrics are cases where the PMC is not currently available (they are outside of the architectural set, in this case).

You can also measure the entire system, using perf with -a. This time I'm measuring a software build:

```
# perf stat -a -- sleep 10
Performance counter stats for 'system wide':
                                                                                         (100.00%)
     641398.723351
                        task-clock (msec)
                                                        64.116 CPUs utilized
           379,651
                        context-switches
                                                        0.592 K/sec
                                                                                         (100.00%)
            51,546
                        cpu-migrations
                                                   #
                                                        0.080 K/sec
                                                                                         (100.00%)
        13,423,039
                        page-faults
                                                        0.021 M/sec
1,433,972,173,374
                                                        2.236 GHz
                        cycles
                                                                                         (75.02%)
   <not supported>
                        stalled-cycles-frontend
   <not supported>
                        stalled-cycles-backend
 1,118,336,816,068
                        instructions
                                                        0.78 insns per cycle
                                                                                         (75.01%)
                                                      389.218 M/sec
   249,644,142,804
                        branches
                                                                                         (75.01%)
     7,791,449,769
                                                        3.12% of all branches
                                                                                         (75.01\%)
                        branch-misses
      10.003794539 seconds time elapsed
```

That's reporting an IPC of 0.78.

perf can also print statistics over time (-I), but the output becomes verbose. I've written a quick wrapper to clean this up and summaize the architectural PMCs on a single line. It's <u>pmcarch</u> (first version):

```
# pmcarch 1
                                 IPC BR RETIRED
CYCLES
               INSTRUCTIONS
                                                   BR MISPRED
                                                                BMR% LLCREF
                                                                                   LLCMISS
                                                                                                LLC%
90755342002
               64236243785
                                0.71 11\overline{7}60496978
                                                   17\overline{4}052359
                                                                1.48 1542464817
                                                                                   360223840
                                                                                               76.65
75815614312
                               0.78 10665897008
                                                                                   286800304
               59253317973
                                                   158100874
                                                                1.48 1361315177
                                                                                               78.93
65164313496
               53307631673
                               0.82 9538082731
                                                   137444723
                                                                1.44 1272163733
                                                                                   268851404
                                                                                               78.87
90820303023
               70649824946
                                0.78 12672090735
                                                   181324730
                                                                1.43 1685112288
                                                                                   343977678
                                                                                               79.59
76341787799
               50830491037
                               0.67 10542795714
                                                   143936677
                                                                1.37 1204703117
                                                                                   279162683
                                                                                               76.83
[ \cdots ]
```

This is from a production instance on EC2, and each line of output is a one second summary.

Interpreting IPC

For real-world applications, here's how I'd interpret the IPC:


- IPC < 1: likely stall cycle bound, also likely memory bound (more PMCs can confirm). Stall cycles are when the CPU isn't making forward progress, likely because it's waiting on memory I/O. In this case, look to tune memory usage: allocate fewer or smaller objects, do zero copy, look at NUMA and memory placement tuning. A <u>CPU flame graph</u> will show which code is on-CPU during these stall cycles, and should be clues for were to look for memory usage.
- IPC > 1: likely instruction bound. Look to tune instructions: a <u>CPU flame graph</u> will show which code is on-CPU doing instructions: find ways to reduce executed code.

You can combine IPC and flame graphs to show everything at once: <u>CPI flame graphs</u> (CPI is IPC inverted). This requires using the sampling mode of PMCs to capture stack traces on overflow events. There are, however, caveats with doing this which I'll get to in another post.

Note that I'm using these on a modern Linux kernel, 4.4+. There was a problem on older kernels (3.x) where PMCs would be measured incorrectly, leading to a bogus IPC measurement.

RxNetty Study

In 2015 I found PMCs crucial in fully understanding the performance differences between RxNetty and Tomcat as they scaled with client load. Tomcat serves requests using threads for each connection, whereas RxNetty uses event loop threads. Between low and high client counts, Tomcat's CPU cycles per request was largely unchanged, whereas RxNetty became *more* efficient and consumed *less* CPU per request as clients increased. Can you guess why?



IPC and CPU/reg as load scales

Click for a slide deck where I explain why on <u>slides 25-27</u> (these slides are from the <u>WSPerfLab</u> repository, summarizing a study by myself, Nitesh Kant, and Ben Christensen.)

We knew that we had a 46% higher request rate, and so we began a study to identify and quantify the reasons why. There was 5% caused by X, and 3% caused by Y, and so on. But after weeks of study, we fell short: over 10% of that 46% remained unexplained. I checked and rechecked our numbers, but fell short every time. It was driving me nuts, and casting doubt on everything we'd found so far.

With PMCs I was able to identify this last performance difference, and the numbers finally added up! We could break down the 46% difference and explain every percentage point. It was very satisfying. It also emphasized the importance of PMCs: understanding CPU differences is a common task in our industry, and without PMCs you're always missing an important part of the puzzle.

This study was done on a physical machine, not EC2, where I'd measured and studied dozens of PMCs. But the crucial PMCs I included in that slide deck summary were the measurements of IPC and the LLC, which are possible with the architectural PMCs now available in EC2.

How is this even possible in the cloud?

You might be wondering how cloud guests can read PMCs at all. It works like this: PMCs are managed via the privileged instructions RDMSR and WRMSR for configuration (which I wrote about in <u>The MSRs of EC2</u>), and RDPMC for reading. A privileged instruction causes a guest exit, which is handled by the hypervisor. The hypervisor can then run its own code, and configure PMCs if the actual hardware allows, and save and restore their state whenever it context switches between guests.

Mainstream Xen supported this years ago, with its virtual Performance Monitoring Unit (vPMU). It is configured using vpmu=on in the Xen boot line. However, it is rarely turned on. Why?

There are hundreds of PMCs, and they are all exposed with vpmu=on. Could some pose a security risk? A number of papers have been published showing PMC side-channel attacks, whereby measuring certain PMCs while sending input to a known target program can eventually leak bits of the target's state. While these are unlikely in practice, and such attacks aren't limited to PMCs (eg, there's also timing attacks), you can understand a paranoid security policy not wanting to enable all PMCs by default.

In the cloud it's even harder to do these attacks, as when Xen context switches between guests it switches out the PMCs as well. But still, why enable all the PMCs if they aren't all needed? Imagine if we could create a whitelist of allowed PMCs for secure environments. This is a question I pondered in late 2015, and I ended up contributing the x86/VPMU: implement ipc and arch filter flags patch to Xen to provide two whitelist sets as options, chosen with the vpmu boot flag:

- **ipc**: Enough PMCs to measure IPC only. Minimum set.
- arch: The seven architectural PMCs (see table above). Includes IPC.

More sets can be added. For example, I can imagine an extended set to allow some Intel vTune analysis.

AWS just enabled architectural PMCs. My patch set might be a useful example of how such a whitelist can be implemented, although, how EC2 implemented it might be different to this.

Conclusion

PMCs are crucial for analyzing a (if not *the*) modern system bottleneck: memory I/O. A set of PMCs are now available on dedicated hosts in the EC2 cloud, enough for high-level analysis of memory I/O issues. I used them in this post to measure IPC, which can identify if your applications are likely memory bound or instruction bound, directing further tuning efforts.

I've worked with PMCs before, and the sort of wins they help you find can range from small single digit percentages to as much as 2x. The net result for companies like Netflix is that our workloads will run faster on EC2 because we can use PMCs to find these performance wins. Consider that, next time someone is comparing clouds by microbenchmarking alone. It's not just out-of-the-box performance that matters, it's also your ability to observe and tune your applications.

A cloud you can't analyze is a slower cloud.

Thanks to those at Netflix for supporting my work on this, the Xen community for their vpmu work, and everyone at Amazon and Intel who made this happen! (Thanks Joe, Matt, Subathra, Rosana, Uwe, Laurie, Coburn, Ed, Mauricio, Steve, Artyom, Valery, Jan, Boris, and more.) (Yes, I'm happy.)

Comments for this thread are now closed

×

8 Comments

Brendan Gregg's Blog



○ Recommend 4





Sort by Best

Behram Mistree • a year ago

I had some trouble getting this to work. Whenever I issued the `perf stat Is`, cycles, stalled-cycles-frontend, stalled-cycles-backend, instructions, branches, and branch-misses would show up as unsupported. Explicitly running with the umask+event select bytes for some of the entries labeled in the architectural pmcs table above also showed unsupported (e.g., running the command with `-e r4F2E`).

I've been running on a c4.8xlarge box running on a dedicated host, with kernel 4.4.0-21 installed. The post at the top says that performance counters are publicly available on aws, but this is the only real documentation I've been able to find about it. Has anyone else been successful with this?

1 ^ | V • Share •

Meng Xu • a year ago

This is a great post! It's good to know AWS enabled parts of the vpmu functionality. However, according to XSA-163 [1], vpmu should be disabled in production environment.

At the high level, I understand that you (and Amazon AWS) whitelist a set of PMC events; however, I'm not sure why this could fix the issue?

In other words, is there any known attack that uses XSA-163? By figuring out how attack may be possible with vpmu, I think it may be clear why whielisting a set of PMC events can fix the problem.

Thank you very much for your time and help on this question!

Best,

[1] https://vanhite.van.org/yea

Note : N

Sayak • a year ago

HI Brendan,

Can you tell me how long a single sample takes?

Thank You,

Sayak

hackworks • 2 years ago

Hello Brendan,

Very nice post (no surprise coming from you). I am not very familiar with the underlying virtualization techniques in different hypervisor implementations. If there is CPU emulation like bochs, would it make it possible to get PMC data for virtual instances?

```
∧ ∨ · Share ›
```

Kevin Closson • 2 years ago

Hi Brendan,

Which AWS AMI do you do this IPC testing with?

```
    ∧ Share >
```

Tomer Morad • 2 years ago

Thanks for the excellent post! Is there any official announcement from Amazon about this or any official documentation?

```
∧ ∨ · Share ›
```

brendangregg Mod → Tomer Morad • 2 years ago

Glad you liked it. As for your questions, currently no and no. I'll add a link if/when something official gets posted.

```
1 ^ V · Share ›
```

Michael Smith • 2 years ago

Thanks for writing this - as more and more systems are cloud systems, we'll need good metrics for them. But if I understand correctly, this only applies to dedicated host types. Is there no way to get PMCs at all for non-dedicated ec2 instances?

You can comment here, but I can't guarantee your comment will remain here forever: I might switch comment systems at some point (eg, if disqus add advertisements).