Harcom

Hardware complexity model for microarchitecture exploration

Pierre Michaud

June 27, 2025

Contents

1	Intr	oduction	5
2	Ove	rview of Harcom	7
3	The	Harcom language	11
	3.1	Harcom data types	11
		3.1.1 The val type	11
		3.1.2 The reg type	12
		3.1.3 The arr type	13
		3.1.4 The hard type	15
	3.2	The ram type	15
	3.3	The rom type	16
	3.4	Arithmetic and logical operators	16
	3.5	Free functions	17
	3.6	The hardware cost of reading values	19
		3.6.1 The fanout function	19
		3.6.2 The fo1 function	19
		3.6.3 The split type	20
	3.7	The no-hidden-cost (NHC) rule	20
4	Usin	ng the Harcom library	23
	4.1	The panel	23
	4.2	The superuser	23
	4.3	The next_cycle function	26
	4.4	Tips and suggestions	26
		4.4.1 Compiler options	26
		4.4.2 Fanouts	27
		4.4.3 Isolation	27
		4.4.4 Templates	27
5	Har	dware complexity model	29
			29

4 CONTENTS

Introduction

Microarchitecture exploration is generally conducted with performance simulators written in general-purpose programming languages such as C or C++. For example, gem5 [5, 3] and ChampSim [6, 2] are two popular open-source performance simulators. A performance simulation outputs various statistics, such as execution time, number of cache misses, number of branch mispredictions, etc. A performance simulator does not need to simulate all the details of the hardware implementation. It is often sufficient to simulate the events that can impact performance significantly, such as cache misses, branch mispredictions, data dependences, etc. Performance simulators often use approximations and abstractions. This is what allows them to simulate the execution of many instructions in a short amount of time, which is important for estimating millisecond-scale performance and for design space exploration.

People using performance simulators are generally engineers, researchers or students, hereafter referred to collectively as *microarchitects*. In a typical situation, a microarchitect needs to study the effects of modifying a part of the microarchitecture. Performance simulators are easily modifiable to conduct such study. The constraints for modifying the simulator are generally few besides those of the programming language itself (e.g., C++). Microarchitects generally try to achieve their goal with minimal modifications to the simulator, so they are practically constrained by how the simulator is structured and how the part they want to modify communicates with the rest of the simulator. Otherwise, microarchitects can use whatever approximation or abstraction they like. Such flexibility comes with a drawback: there is no guarantee that a modification corresponds to realistic hardware.

In general, microarchitects are aware of hardware constraints and try to simulate realistic mechanisms. Nevertheless, assessing the hardware complexity of a mechanism which only exists as a piece of C++ code in a performance simulator can be difficult. Hardware complexity is a multidimensional quantity including silicon area, energy consumption and delay. A simple, oft-used estimate of hardware complexity is the amount of storage (typically, SRAM capacity) used by a mechanism. Indeed, the silicon area, energy and access latency of an SRAM increases with its size, and a substantial part of the hardware complexity of processors comes from on-chip SRAMs. Still, there is more to hardware complexity than storage. For instance, the delay of a branch predictor depends not only on the size of its SRAMs but also on the logic circuits processing the information retrieved from the SRAMs.

Microarchitects, especially in academia, often use high-level complexity models such as CACTI [10, 1] and McPAT [7, 4]. These tools are distinct from the performance simulator: the microarchitect must manually configure CACTI/McPAT to reflect the hardware modification. Moreover, these tools have limited configurability. For instance, the branch predictor modeled in McPAT is the one implemented in the Alpha 21264. Modeling a different predictor requires



Figure 1.1: Hardware complexity estimation is off the main microarchitecture exploration loop.

to hack McPAT's source code.

The most general solution for estimating the hardware complexity of a microarchitectural part is to use a hardware description language (HDL) such as SystemVerilog, write a RTL (Register Transfer Level) description of the part and run EDA (Electronic Design Automation) tools to assess the hardware complexity. However, this is a time-consuming process, and hardware complexity estimation is generally off the main microarchitecture exploration loop (Figure 1.1).

Harcom is <u>not</u> a HDL. The goal is not to synthesize hardware. The purpose of Harcom is to provide a hardware complexity model directly inside the performance simulator. The hope is that Harcom improves the process of selecting solutions to implement in HDL and reduces the burden of designers.

Harcom tries to find a useful middle ground between several contradictory objectives: hardware complexity model accuracy, simulation speed, flexibility and ease of use. This implies tradeoffs that make Harcom's complexity model a very rough approximation of what a designer can obtain with RTL/EDA. Nevertheless, an approximate model can still be useful if it provides sufficient qualitative accuracy and if the microarchitect understands the sources of error and the model's limitations.

Overview of Harcom

Harcom is a C++20 library consisting of a single header file ("harcom.hpp"). Most performance simulators today are written in C++, so incorporating Harcom in existing simulators should be straightforward.

Harcom's basic data type is called val. A val object is declared with a parameter N and represents an N-bit integer value¹ which can also be viewed merely as a bundle of N bits. Listing 2.1 shows a simple C++ program using Harcom's vals. Each val has a value and a timing in picoseconds which are both printed with the method print(). Vals x and y both have a null timing, as they are initialized from hardwired values, i.e., values known when designing the hardware. However, operations on vals generally increase the timing: val z, the sum of x and y, has a timing corresponding to the latency of an 8-bit adder. In the general case, the timing of the result of a two-input operation is the maximum of the timing of the two inputs plus the latency of the hardware operator, as illustrated in Figure 2.1. The function panel.print() prints the total number of transistors used and the total energy consumption.

Figure 2.2 illustrates a typical usage of Harcom, where only the part of the performance simulator modeling the processor component that we want to study is rewritten to use Harcom vals in place of C++ integers. The rest of the simulator remains unchanged. The outputs of the component are vals, whose timing, along with the total number of transistors and total energy consumption, is a measure of the hardware complexity of the component.

Performance simulators sometimes use abstractions that do not correspond to an actual hardware implementation. In order to estimate hardware complexity, Harcom restricts what users can do with vals. These constraints can be called the *Harcom language*.

In particular, the actual value of a val is a private member of the val C++ class: trying to read or write this value directly triggers a compilation error. While C++ makes it possible to circumvent the *private* access specifier if that is the user's intention, this is, hopefully, unlikely

¹Future versions of Harcom might provide floating-point values.




Figure 2.1: The timing of the result of a two-input operation is the maximum of the timing of the two inputs plus the latency of the hardware operator.

Listing 2.1: A simple C++ program using Harcom's vals

```
#include "harcom.hpp"
using namespace hcm; // Harcom namespace
int main()
  val < 8 > x = 1; // 8-bit unsigned integer
  val < 4 > y = 2; // 4-bit unsigned integer
  auto z = x + y; // 9-bit unsigned integer
  z.print("sum=");
  panel.print();
}
// prints on the standard output:
    sum=3 (t=42 ps)
     storage (bits): 0
//
     transistors: 406
//
     dynamic energy (fJ): 9.04
     static power (mW): 0.000152
//
```




Figure 2.2: Harcom's typical usage: only the part of the performance simulator modeling the processor component that we want to study is rewritten.

to happen accidentally.

Nevertheless, the outputs of a component modeled with Harcom must be communicated to the rest of the performance simulator as normal C++ integers. Harcom distinguishes the *user* from the *superuser*. The superuser is whoever owns (i.e., can modify) the class called harcom_superuser. While the user is constrained by the Harcom language, the superuser can access private members and is responsible for implementing the interface between the component modeled with Harcom and the rest of the simulator. For example, in the context of a branch prediction championship, the superuser would be the championship's organizers and the user would be a contestant. Otherwise, the user and superuser might be a single person or a group of people willing to use Harcom the way it was intended to be used, as explained in this document.

The Harcom language

The Harcom language is not a proper programming language, it is just C++ programming with Harcom vals. However, there are strong constraints associated with vals, and programming with them can be viewed as a distinct language.

Throughout this document, *rightmost* bits refers to the least significant bits of an integer and *leftmost* bits refers to the most significant bits.

3.1 Harcom data types

3.1.1 The val type

The val type represents a **transient** value, i.e., a value existing at a certain time, and with a limited lifetime. A val takes two template parameters N and T, where N is the number of bits and T is the underlying C++ **integer** type. For example:

```
val<10,u64> x = 1; // 10 bits; underlying type is std::uint64\_t; val<6,i64> y = -1; // 6 bits; underlying type is std::int64\_t; val<8> z = 1; // equivalent to val<8,u64>
```

Note that u64 and i64 are convenient aliases for std::uint64_t and std::int64_t that we use throughout this document. While it is possible to use smaller integer types (int, short,...) to save a little memory, u64 and i64 are sufficient most of the time. If type T is omitted in the declaration, the underlying type is u64 by default (see the example above). The value of N must not exceed type T's number of bits. In any case, N must not exceed 64.

A val must be initialized with a value, which can be a C++ integer literal, a C++ integer variable, another val or a reg (see section 3.1.2). When initializing from another val (or reg), the destination and source vals do not need to have the same size:² the value is truncated if the source val is longer than the destination val, it is sign extended if shorter:

```
val <8> x = 0b111111111; // 255
val <4> y = x; // truncated: 0b1111 (15)
val <8> z = y; // sign extended: 0b00001111 (15)
```

The Harcom user cannot change the value of a val.³

¹They are actually defined in the "harcom.hpp" header file.

²They do not need to have the same type either: Harcom uses the same implicit conversions as C++.

³Attempting to change the value of a val triggers a compilation error.

name	type	description	example
size	C++ int	number of bits	
maxval	maxval C++ int maximum value		val<4> x = val<4>::maxval
minval	C++ int	minimum value	val<4,i64> x = val<4,i64>::minval;
print	function	print value	see Section 3.1.1
printb	function	binary printing	see Section 3.1.1
fanout	function	set fanout	val<1> x = 1;
Tanout			<pre>x.fanout(hard<4>{});</pre>
fo1	function	function set fanout of 1	val<3> x = 1;
101	Tunction		val<3> y = x.fo1() + 1;
make_array	function	make an array	val<12> x = 0b1010111110011;
make_array		from the value bits	<pre>auto A = x.make_array(val<4>{});</pre>
reverse	function	reverse bits	<pre>val<8>{43}.reverse().printb();</pre>
rotate_left	function	rotate bits	<pre>val<8>{43}.rotate_left(-1).printb();</pre>
ones	function	bit count	val<8>{43}.ones().print();
one_hot	function	reset all bits but the	<pre>val<8>{44}.one_hot().printb();</pre>
		rightmost 1	
replicate	function	replicate the value	val<1> x = 1;
_		(generate an array)	<pre>x.replicate(hard<4>{}).print();</pre>

Table 3.1: Public members of class val besides constructors. The functions highlighted in red have a non-null hardware cost. Class reg inherits the same members.

While the value of a val is a private member that the Harcom user should not try to access directly, it is possible to print the value to the standard output, in decimal or binary representation:

```
x.print(); // prints "255 (t=3 ps)"
y.printb(); // prints "1111 (t=6 ps)"
```

Functions print and printb have default parameters that can be overridden:

```
z.print("z=","\n",false,std::cerr);
// prints "z=15" to the error stream
```

Table 3.1 lists the public members of class val that the Harcom user can access (constructors are omitted). Functions with a non-null hardware cost are highlighted in red.

3.1.2 The reg type

The reg type is derived (in the C++ sense) from the val type. A reg (for *register*) represents a **persistent** value, i.e., a value that is associated with storage. Unlike a val, a reg can be modified:

```
reg<4> x = -1; // 4-bit unsigned register, initialized with 15 reg<4,i64> y = x; // 4-bit signed register, initialized with -1 x = 0; // a reg can be modified
```

If a reg is not initialized explicitly, it is initialized implicitly with zero. Regs must obey the following two rules:

• All regs must have the same lifetime. That is, a reg cannot be created after another reg has been destroyed.⁴

⁴To make sure that this rule is not violated, it is sufficient to declare regs as static variables.

• A reg can be modified at most once per clock cycle.

Violating these rules triggers an exception at execution. Besides the properties mentioned above, a reg is akin to a val, as illustrated by the example below:

```
auto increment = [](val<2> &x) -> val<2>
{
    return x+1;
};
reg<2> y = 1;
y = increment(y); // equivalent to y=y+1
y.print();
```

In this document, the term **valtype** refers to both vals and regs.⁵ The public members of class val, listed in Table 3.1, are also public members of class reg.

3.1.3 The arr type

The arr type represents an array of valtype objects. An arr takes two template parameters T and N, where T is a valtype and N is an unsigned integer:

```
arr < val < 3 > ,4 > A = {1,2,3,4};
A[2].print(); // print the third element
arr < val < 3 > ,4 > B = [](u64 i){return i+1;};
arr < reg < 1 > ,4 > C = B;
C.print(); // print all the elements
```

The subscript operator [] returns a reference to a particular element (second line). The first element has index 0 (like C arrays).

In the example above, array B is initialized from a C++ lambda (third line). It is sometimes necessary to use a lambda or a function to initialize an array of vals, as vals, unlike regs, cannot be changed after their creation. An arr can also be initialized from a C array or from an std::array:

```
val <4> AA[3] = {1,2,3};
arr < val <4>,3> A = AA;
std::array < val <4>,3> BB = {4,5,6};
arr < val <4>,3> B = BB;
```

Table 3.2 lists the public members of class arr that the Harcom user can access (constructors and operators are omitted). Functions with a non-null hardware cost are highlighted in red. The functions concat, make_array, shift_left, shift_right treat array elements as consecutive chunks of a bit vector. The first array element (index 0) corresponds to the rightmost bits of this bit vector.

The array assignment operator is public. However, if the Harcom user tries to modify an array of vals, this triggers a compilation error. The subscript operator [] already mentioned in Section 3.1.3 takes C++ integers as argument. An array with a single element is implicitly convertible to a val:

```
arr < val < 4 > , 1 > A = {10};
val < 4 > x = A;
```

⁵The "harcom.hpp" header file defines a C++ concept of that name (static_assert(valtype<reg<8>>);)

name	type	description	example	
size	C++ int	number of elements		
print			same syntax as valtype	
printb	function	binary printing	same syntax as valtype	
select	function	read a selected	arr <val<2>,4> A = {1,3,0,2};</val<2>	
Select		element	A.select(A[1]).print();	
concat	function	concatenate all bits	arr <val<3>,3> A = {0b000,0b111,0b010};</val<3>	
Concat		into single val	A.concat().printb();	
fanout	function	set fanout	A.fanout(hard<16>{});	
fo1	function	set fanout of 1	A.fo1().concat().printb();	
append	function	generate array with one extra element	A.append(7).print();	
truncate	function	truncate the array	A.truncate(hard<2>{}).print();	
malea arrass	function	concatenate all bits	arr <val<3>,2> A = {0b000,0b111};</val<3>	
make_array	Tunction	& make new array	A.make_array(val<2>{}).printb();	
shift_left	function	insert bits, shift left	arr <val<3>,2> A = {0b000,0b111};</val<3>	
SHII C_Tel C		miscre ones, smile icre	A.shift_left(val<2>{0b11}).printb();	
shift_right	function	insert bits, shift	arr <val<3>,2> A = {0b000,0b111};</val<3>	
SHII U_I I I I I I		right	A.shift_right(val<2>{0}).printb();	
fold_xor	function	XOR all elements	arr <val<3>,3> A = {0b100,0b110,0b111};</val<3>	
1014_201			<pre>val<3> x = A.fold_xor();</pre>	
fold_or	function	OR all elements	<pre>val<3> x = A.fold_or();</pre>	
fold_and	function	AND all elements	<pre>val<3> x = A.fold_and();</pre>	
fold_xnor	function	XOR all elements,	<pre>val<3> x = A.fold_xnor();</pre>	
	1011011011	then complement	The state of the s	
fold_nor	function	OR all elements, then complement	<pre>val<3> x = A.fold_nor();</pre>	
fold_nand	function	AND all elements,	<pre>val<3> x = A.fold_nand();</pre>	
TOTA_Halla	lunction	then complement	- ",	
fold_add	function	add all elements	arr <val<3>,3> A = {4,6,7};</val<3>	
		add all didillolled	<pre>val<5> x = A.fold_add();</pre>	

Table 3.2: Public members of class arr besides constructors and operators. The functions highlighted in red have a non-null hardware cost. The functions concat, make_array, shift_left, shift_right treat array elements as chunks of a bit vector. The first array element (index 0) corresponds to the rightmost bits of this bit vector.

3.2. THE RAM TYPE

3.1.4 The hard type

The hard type represents hardware parameters, that is, values that are fixed and known at design time. It takes a single template parameter N which is the value of the hardware parameter. That is, object hard<N>{} represents value N. For example:

```
val < 8 > x = -1;

val < 8 > y = x << hard < 4 > {}; // shift left by 4 bits
```

In many situations, it is possible to substitute a C++ integer (variable or literal) for a hard parameter:

```
val < 8 > y = x << 4; // equivalent to y = x << hard <4 > {}
```

While convenient, this is not always possible though. For example the modulo operation requires the modulus to be a hard parameter:⁶

```
val < 4 > x = -1;
auto y = x % hard < 4 > {};
```

3.2 The ram type

The ram type emulates a random access memory (RAM). It takes two template parameters T and N, where T is the type of data stored in the RAM and N is the memory size in number of such data. Type T can be val or array of val. For example:

```
ram < val <3>,32> mem; // 3-bit data, 32 data
val <5> addr = 10;
val <3> data = 7;
mem.write(addr,data); // RAM write
val <3> readval = mem.read(addr); // RAM read
readval.print(); // prints 7
```

In the Harcom language, the value produced by an an operation on vals generally does not depend on the timing of the input vals. That is, the timing of inputs only affects the timing of the output, not the value. However, there is one exception, which is when reading a RAM. Harcom's RAM model assumes that the time at which a write occurs is the maximum of the address and data timings. When reading a RAM at a given address A, the data returned by the read operation is the data written by the most recent write whose timing is less than or equal to the timing of A. In other words, we cannot read a value that will be written in the future. For example:

```
ram < arr < val < 64 > ,2 > ,1024 > mem;
val < 10 > addr = 100;
arr < val < 64 > ,2 > data = {addr,addr+1};
mem.write(addr,data);
mem.read(addr).print(); // prints 0 0
```

The RAM write is effective when the addition operation (addr+1) is finished, which happens in the future compared to the RAM read operation. So the RAM read returns the old data, which is zero in this example (the value with which the RAM is automatically initialized).

RAMs must obey the following two rules:

⁶A compilation error occurs if the modulus is a C++ integer.

⁷T is the type of the data returned by a read operation.

name	description	example
write	write(addr,data) writes data(valtype or arr) at address addr	<pre>ram<arr<val<64>,2>,256> mem; val<8> addr = 100; arr<reg<64>,2> data = {1,2}; mem.write(addr,data);</reg<64></arr<val<64></pre>
read	read(addr) returns the data stored at address addr	<pre>data = mem.read(addr+1);</pre>
reset	reset the RAM with zeros	mem.reset();
print	prints delay and energy	mem.print();

Table 3.3: Public functions of class ram.

- All RAMs must have the same lifetime as regs. That is, a RAM cannot be created after a reg or another RAM has been destroyed.⁸
- Only a single RAM read and a single RAM write are allowed per clock cycle (otherwise an exception is generated at execution).

Public members of class ram are listed in Table 3.3.

3.3 The rom type

The rom type emulates a read-only memory (ROM). It takes two template parameters T and N, where T is a val type (the type returned by a ROM read) and N is the ROM size in number of such vals. A rom object must be initialized at creation:

```
rom < val < 3 > , 16 > bitcount = {0,1,1,2,1,2,2,3,1,2,2,3,2,3,3,4};
val < 4 > bitvec = 7;
bitcount(bitvec).print(); // prints 3
```

The first element has index 0. The ROM is read with operator (). Despite the name, a ROM is not a memory but is akin to a function.

ROMs are initialized like arrays. In particular, they can be initialized from a function or a lambda:

```
rom < val <3>,16> bitcount = [](u64 i){return std::popcount(i);};
```

3.4 Arithmetic and logical operators

Many operators of the C language can be used with valtypes and have the same meaning as in C. These operators are listed in Table 3.4. Each operator takes one or two valtypes (val or reg) as input. Some binary operators allow to substitute a single hard value for an input valtype. Some binary operators *require* one of the two inputs to be a hard value. The ouput of an operator is always a val.

⁸In other words, all storage (reg or RAM) must have the same lifetime.

operator	operation	input type	output type
==	equal		
!=	not equal		
>	greater than	two vals of same size	val<1>
<	less than	or one val and one hard	Val\17
>=	greater than or equal		
<=	less than or equal		
&	bitwise AND	two vals or	same as longest of the
1	bitwise OR	one val and one hard	input vals
^	bitwise XOR	one var and one nard	input vais
~	bitwise NOT	one val	same as input
<<	shift left	one val and	come oc input vol
>>	shift right	one hard shift count	same as input val
+	add	two vals or	one bit longer than the
-	subtract	one val and one hard	longest input val
-	change sign	one val	same as input
*	multiplication	two vals or	val with enough bits
^	multiplication	one val and one hard	$(\leq 64 \text{ bits})$
/	integer division	unsigned val dividend	val with anough hite
%	modulo (remainder)	hard divisor	val with enough bits

Table 3.4: Arithmetic/logical operators. Inputs are valtypes or hard values. Outputs are vals. All operators have a hardware cost except <<, unsigned >>, and & and | with a hard value.

3.5 Free functions

Table 3.5 lists the free functions that are part of the Harcom language. The functions at the bottom of Table 3.5 are called "utilities" because they are written in the Harcom language. Harcom users could write them themselves, without superuser privilege. Their implementation is located at the end of the "harcom.hpp" file.

The execute_if function is an essential primitive allowing conditional execution. It takes two inputs: a valtype *mask* and a C++ lambda F that can have a C++ integer parameter i. The execute_if primitive executes F(i) for each i corresponding to a mask bit that is set. If F returns a val, execute_if returns an array of vals whose elements corresponding to null mask bits are zeros. For example, execute_if can be used to access a RAM conditionally:

```
ram < val <2>,64> mem;
val <1> cond = false;
val <6> addr = 42;
val <2> data = 3;
execute_if(cond,[&](){mem.write(addr,data);});
val <2> x = execute_if(cond,[&](){return mem.read(addr);});
x.print();
```

When the mask bit is null, no energy is consumed⁹ and the storage (regs/RAMs) written by F is actually unmodified. However, every attempt to write a reg or read/write a RAM, **even when the mask bit is null**, is subject to the one reg write and one RAM read/write per cycle limit. Consequently, writing the same reg or accessing the same RAM inside F is not possible unless the mask is a single bit.

⁹The transistor count is incremented though.

name	description	example
a_plus_bc	compute $a + b \times c$	a_plus_bc(a,b,c).print();
	concatenate multiple vals	val<3> left = 0b111;
concat	into a single val	<pre>val<4> right = 0b0011;</pre>
		<pre>val<7> z = concat(left,right);</pre>
	select(cond,x1,x0)	<pre>val<1> incr = true;</pre>
select	equals x1 if cond is true,	val<4> x = 0;
	x0 otherwise	$val<4>$ y = select(incr, $val<4>$ {x+1},x);
	execute_if(mask,F)	val<4> x = 11;
execute_if	execute_11 (mask,F) executes the C++ lambda F for each mask bit that is set	<pre>auto pp = execute_if(x,</pre>
CACCUBC_II		[&](u64 i){return val<8>{x}< <i;});< td=""></i;});<>
		<pre>pp.fold_add().print("x^2=");</pre>
	util	ities
absolute_value	if signed value is negative,	val<8,int> x = -3;
absolute_value	make it positive	absolute_value(x).print();
	encode a one-hot bit vector	val<8> ask = 0b01000100;
encode		<pre>val<8> onehot = ask.one_hot();</pre>
		<pre>val<3> index = encode(onehot);</pre>
		auto max = [] ($val<4> x$, $val<4> y$) {
	fold(A,op) folds array A	<pre>return select(x>y,x,y);</pre>
fold	with binary associative	};
	operation op	arr <val<4>,4> A = {8,2,13,7};</val<4>
		<pre>fold(A,max).print();</pre>
	scan(A, op) yields the prefix-sum array of array A with binary associative operation op	auto add = [] ($val<4> x$, $val<4> y$) {
		return x+y;
scan		};
		arr <val<4>,8> A = [](){return 1;};</val<4>
		<pre>scan(A,add).print();</pre>

Table 3.5: Free functions. They all have a hardware cost except concat. For execute_if, fold and scan, the hardware cost depends on the function/lambda that is passed as argument.

3.6 The hardware cost of reading values

The Harcom user focuses first on the functional behavior of the microarchitectural algorithm, which is generally independent of timing 10 unless the timing information is used explicitly by the algorithm. Once the algorithm is bug-free and works as expected, the Harcom user tries to reduce the hardware cost.

Reading a val or a reg is associated with a hardware cost, especially a read delay. Harcom does not know at compile time how many times a named value will be read. Therefore, a pessimistic situation is assumed where each read incurs an extra delay, which Harcom models as that of a fanout-of-two (FO2) inverter. The read delay increases linearly with the number of reads. While the delay of a single read can be considered negligible, the accumulation of read delays can be quite significant.

In real circuits, a high fanout (i.e., reading the same value many times) means that we must drive a high capacitance, which takes some time. However, with optimal buffering and gate sizing, delay grows roughly logarithmically with fanout [8, 9], not linearly.

3.6.1 The fanout function

Reading an unnamed value (aka *rvalue*) incurs no hardware cost, as it is known at compile time that such value will be read only once. However, it is not known at compile time how many times a named value (aka *lvalue*) is read. To make the delay of reading a named value logarithmic instead of linear, the Harcom user must use the fanout function:

```
val <4> x = 1;
x.fanout(hard <8>{}); // make delay logarithmic
arr <val <1>,8> A = x.replicate(hard <8>{});
A.print();
```

If the value is actually read more than what was promised with the fanout function, no error is triggered. Instead, the read delay simply grows linearly after the initial logarithmic growth. Compiling with the option -DCHECK_FANOUT forces an exception at execution if the actual fanout exceeds the declared one.

3.6.2 The fol function

Whenever possible, ¹² transient values (vals) that are read only once should remain unnamed. Nevertheless, for program readability, the Harcom user may wish to give a name to a val even though it is read only once. In this situation, if the read delay is deemed non-negligible, it is possible to use function fo1 to "unname" a named value:

```
val <4> x = 1;
arr < val <1>,8> A = x.fo1().replicate(hard <8>{});
A.print();
x.print(); // x has been reset!
```

Attempting to apply fol to a reg triggers a compilation error (a reg cannot be unnamed).

¹⁰Except for RAM reads, as explained in Section 3.2

¹¹This corresponds to chaining FO2 inverters.

¹²Function parameters must have a name, even if they are read only once.

The fo1 function should be used very cautiously. By using fo1, the programmer promises that the value will not be read again. To make it impossible to obtain an unrealistic advantage from a misuse of fo1, a read through fo1 is destructive, that is, the value is reset.

The compiler option -DFREE_FANOUT disables destructive reads and removes all read delays. This option is useful for detecting some misuses of fo1 and for checking whether there is much to gain from optimizing fanouts.

3.6.3 The split type

The split type allows to split the bits of a val into two parts without any read penalty:

```
val <8> x = 0b11000100;
split <3,5> y = x.fo1();
y.left.printb(); // 3 bits (0b110)
y.right.printb(); // 5 bits (0b00100)

Or, using structured binding (C++17):
auto [left,right] = split <3,5>(x.fo1());
left.printb();
right.printb();
```

3.7 The no-hidden-cost (NHC) rule

The Harcom language tries to take into account the hardware complexity of every statement. This is a general rule that can be called the *no-hidden-cost* rule, or **NHC**. Most violations of the NHC rule are caught at compile time with a compilation error, or at execution time with an exception and an error message.

However, unfortunately, not all violations of the NHC rule can be detected automatically. The Harcom language is not a proper programming language, it is C++ programming with Harcom types, plus some self-discipline from the programmer to not violate the NHC rule. In particular, using C++ integers is OK as long as this does not represent any hardware cost. For example, this is valid Harcom language:

```
val <4> A[3] = {1,2,3};
reg <4> B[3];
for (int i=0; i <3; i++) // no hardware cost
  B[i] = A[i]; // hardware cost</pre>
```

In the example above, the body of the for loop has a hardware cost but the loop header itself bears no hardware cost, as it is equivalent to

```
B[0] = A[0];

B[1] = A[1];

B[2] = A[2];
```

Here are some guidelines to avoid violating the NHC rule:

- use valtypes to model data that are unknown at design time;
- do not use non-constant C++ integers (or any other fundamental type) whose lifetime spans multiple clock cycle; if you need modifiable persistent variables, use reg or ram;

- do not access private class members;
- no type punning (C-style cast, void*, union, reinterpret_cast, std::bit_cast, memcpy, etc.)
- do not put Harcom types inside unions;
- no pointer to class member;
- compile with options -Wall -Wextra -Werror.

All features of the C++ language (array, class, function, template,...) can be used as long as the NHC rule is not violated. For example, consider the following two structs:

```
struct bundle1 {
  reg<4> x;
  int y; // NHC violation
};

struct bundle2 {
  reg<4> x;
  const int y; // ok
};
```

In the example above, the two structs contain a reg so they are implicitly persistent. However, the first struct violates the NHC rule because of the non-constant integer field, while the second struct is compatible with the Harcom language.

Harcom types are incompatible with many containers and algorithms of the C++ standard library. For example, trying to insert a reg inside an std::vector generates a compilation error. However, std::array and, to a certain extent, std:tuple are compatible with Harcom types. If using a class or function from the standard library generates no error at compilation and no exception at execution, this is probably OK. Nevertheless, even if everything seems OK, the standard library should not be used without doing tests to check that the NHC rule is not violated.

Using the Harcom library

Figure 4.1 shows a contrived example of utilization of the Harcom library.

4.1 The panel

The *panel* is a global object. The panel contains some global variables that the user can read. For example, variable energy_fJ gives the total energy (in femtojoules) dissipated so far:

```
val <64> x = 0;
x+1;
panel.energy_fJ.print("val+hard:");
f64 e = panel.energy_fJ;
x+x;
std::cout << "val+val:" << panel.energy_fJ - e << std::endl;</pre>
```

Global variables can be read but cannot be modified by the Harcom user. Only the superuser can modify them. Global variable are implicitly convertible to their C++ underlying type, which is f64 (i.e., double) for energy_fJ and u64 for all the other variables. Table 4.1 lists the panel variables and functions that the user and the superuser can utilize.

4.2 The superuser

The superuser is whoever can modify the class harcom_superuser. Class harcom_superuser is defined in the global namespace.

The superuser can transform Harcom data into C++ integers, which is necessary to implement the interface between the part of the simulator implemented in the Harcom language and the rest of the simulator. The superuser can also write or read the timing associated with a Harcom data. Table 4.2 lists the private functions of classes val/reg and arr that the superuser can use.

The timing of a Harcom data can be set by the superuser with the set_time function. The timing of a val can also be set at construction time if the initialization is from a C++ integer:

```
val<4> x = 13; // value=13, timing=0
val<4> y = {7,100}; // value=7, timing=100ps
```

The superuser has access to private assignment operators and can modify a val after construction.

```
#include "harcom.hpp"
hcm::val<64> collatz(hcm::val<64> n) {
  // function whose hardware complexity we seek to evaluate
  using namespace hcm;
  hard <2> two;
  hard <3> three;
  val < 1 > odd = n \% two;
  val <64> inc = execute_if(odd,[&](){return n*three+1;});
  val < 64 > dec = execute_if(~odd,[&]()->val < 64 > {return n/two;});
  return select(odd,inc,dec);
}
struct harcom_superuser {
  uint64_t value = 27;
  harcom_superuser() {
    hcm::panel.clock_cycle_ps = 200;
  void one_cycle() {
    auto [v,t] = collatz(value).get_vt();
    assert(t < hcm::panel.clock_cycle_ps);</pre>
    hcm::panel.next_cycle();
    value = v;
  }
} hsu;
int main() {
  while (hsu.value != 1)
    hsu.one_cycle();
  hcm::panel.cycle.print("total_cycles:__");
  hcm::panel.print();
}
```

Figure 4.1: A contrived example of utilization of Harcom.

25

name	type	description	example
clock_cycle_ps	variable	clock cycle (picoseconds)	<pre>panel.clock_cycle_ps.print();</pre>
cycle	variable	current cycle	<pre>panel.cycle.print();</pre>
storage	variable	total storage (bits)	<pre>panel.storage.print();</pre>
storage_sram	variable	total SRAM bits	<pre>panel.storage_sram.print();</pre>
energy_fJ	variable	total energy (femtojoules)	<pre>panel.energy_fJ.print();</pre>
storage_xtors	variable	total storage transistors	<pre>panel.storage_xtors.print();</pre>
logic_xtors[0]	variable	total logic transistors (0 =	<pre>panel.logic_xtors[0].print();</pre>
logic_xtors[1]	variable	current cycle; 1 = previous)	paner.logic_xtors[o].print(),
total_xtors	function	total transistors	u64 x = panel.total_xtors();
dyn_power_mW	function	dynamic power (milliwatt)	<pre>f64 p = panel.dyn_power_mW();</pre>
sta_power_mW	function	static power (milliwatt)	<pre>f64 p = panel.sta_power_mW();</pre>
print	function	print total	<pre>panel.print();</pre>
next_cycle	function	increment cycle	<pre>panel.next_cycle();</pre>

Table 4.1: Panel variables and functions for the user and the superuser. The user can read variables but cannot modify them. Function next_cycle is for the superuser only.

name	description	example			
	val/reg				
get	transform into C++ int	val<4> x = 13;			
get		u64 v = x.get();			
set_time	set the timing (picoseconds)	x.set_time(100);			
time	read the timing (picoseconds)	u64 t = (x+1).time();			
get_vt	get both value and timing auto [v,t] = x.get_vt();				
	arr				
mo+	transform into std::array of C++	arr <val<4>,3> A = 1,2,3;</val<4>			
get	int	std::array <u64,3> V = A.get();</u64,3>			
set_time	set the timing (same for all	A got time(100):			
sec_time	elements)	A.set_time(100);			
time	maximum timing of elements	u64 t = A.time();			

Table 4.2: Private functions that the superuser can use for interfacing with the rest of the simulator.

4.3 The next_cycle function

The next_cycle function can be called only by the superuser. It is not considered part of the Harcom language but is nevertheless essential to the behavior of persistent types (regs and RAMs). The next_cycle function does three things:

- increment the cycle counter (variable cycle);
- save logic_xtors[0] into logic_xtors[1];
- set logic_xtors[0] to zero.

Registers can be written only once per cycle; RAMs can be read and written only once per cycle. For example:

```
#include "harcom.hpp"
using namespace hcm;

struct harcom_superuser {
  reg<4> x = 0;

  void example() {
    x = x+1; // first write
    panel.next_cycle();
    x = x+1; // second write
    x.print();
  }
} hsu;

int main()
{
  hsu.example();
}
```

It is the call to next_cycle that makes the second write to x possible.¹

4.4 Tips and suggestions

The Harcom language is less flexible than a general-purpose programming language. This section provides some tips and suggestions for programming in the Harcom language.

4.4.1 Compiler options

Table 4.3 lists the compiler options that are available for debugging purpose. The option -DCHEATING_MODE enables the conversion of valtypes to a C++ integer:

```
g++ -std=c++20 -o test_harcom test_harcom.cpp
-Wall -Wextra -Werror -DCHEATING_MODE
```

For example, the user can introduce assert statements:

¹Otherwise, an exception is triggered.

option	effect
-DFREE_FANOUT	disables destructive reads and removes all read delays
-DCHECK_FANOUT	generate an exception if actual fanout exceeds declared one
-DCHEATING_MODE	enables conversion of valtype to C++ int

Table 4.3: Compiler options for debugging.

```
val <4> x = 7;
#ifdef CHEATING_MODE
  assert(x==7);
#endif
```

The options -DFREE_FANOUT and -DCHECK_FANOUT were introduced in Section 3.6.

4.4.2 Fanouts

There are two aspects to an algorithm written in the Harcom language: (1) the functional behavior of the algorithm and (2) its hardware complexity (timing, energy). While these two aspects are not completely independent of each other, the functional behavior is probably the aspect what we want to be correct first. During the initial development of an algorithm, it is not necessary to use the fanout and fo1 functions. Once the functional behavior is deemed correct, fanouts can be optimized. The -DFREE_FANOUT option can be used to obtain an upper bound of the delay that could be saved by optimizing fanouts. If the potential delay reduction is significant, the fanout function should be first applied to values with the highest fanout. Values with a lower fanout can be optimized if the potential delay reduction is still significant.

As explained in Section 3.6, function fo1 should be used very cautiously, as reading a value through it destroys the value. The -DFREE_FANOUT option can be used to check that the functional behavior is not altered by a misuse of fo1.

4.4.3 Isolation

Harcom is intended to estimate the complexity of one or several hardware components. As it would make little sense to intermingle program code corresponding to distinct hardware parts, code written in the Harcom language should be isolated inside C++ functions or classes. For example, in example 4.1, function collatz is written in the Harcom language. The persistent and modifiable variable value is not considered part of the component whose hardware complexity we seek to estimate,² so we locate the variable outside of function collatz.

4.4.4 Templates

The Harcom library provides a utility function static_loop for iterating at compile time over an integer template argument. The function argument is a C++ lambda with one integer template parameter (C++20). For example, the following statement prints 0123456789:

```
static_loop<10>([]<int I>(){std::cout<<I;});
```

The static_loop utility simplifies template metaprogramming with Harcom types. For example:

²Note that function collatz does not access value directly but via a val, so function collatz does not violate the NHC rule.

```
#include "harcom.hpp"
using namespace hcm;
template < u64... N >
struct regs {
  static constexpr u64 size = sizeof...(N);
  std::tuple<reg<N>...> tup;
  template < typename . . . T >
  regs(T...x) : tup{x...} {}
  void print() {
    static_{loop} < size > ([\&] < u64 I > (){
        std::get<I>(tup).print();
    });
  }
};
int main()
  regs < 7,5,6 > rs = \{4,8,16\};
 rs.print();
}
```

Hardware complexity model

5.1 Limitations of the model

Bibliography

- [1] CACTI. https://github.com/HewlettPackard/cacti.
- [2] ChampSim. https://github.com/ChampSim/ChampSim.
- [3] gem5. https://www.gem5.org/.
- [4] McPAT. https://github.com/HewlettPackard/mcpat.
- [5] J. Lowe-Power et al. The gem5 simulator: Version 20.0+. https://arxiv.org/abs/2007.03152, 2020.
- [6] N. Gober, G. Chacon, L. Wang, P. V. Gratz, D. A. Jiménez, E. Teran, S. Pugsley, and J. Kim. The Championship Simulator: architectural simulation for education and competition. https://arxiv.org/abs/2210.14324, 2022.
- [7] S. Li, J. H. Ahn, R. D. Strong, J. B. Brockman, D. M. Tullsen, and N. P. Jouppi. The McPAT framework for multicore and manycore architectures: simultaneously modeling power, area, and timing. *ACM Transactions on Architecture and Code Optimization*, 10(1), April 2013.
- [8] C. Mead and L. Conway. *Introduction to VLSI systems*. Addison-Wesley, 1980.
- [9] I. E. Sutherland, R. F. Sproull, and D. Harris. *Logical effort: designing fast CMOS circuits*. Morgan Kaufmann, 1999.
- [10] S. J. E. Wilton and N. P. Jouppi. CACTI: an enhanced cache access and cycle time model. *IEEE Journal of Solid-State Circuits*, 31(5), May 1996.