## PyMechanical cheat sheet

**/\nsys** 

Version: 0.10 (stable)

### / A. Connect to a <u>remote session</u> of Mechanical from Python

Launch and connect to a session

Launch and connect to Mechanical locally:

```
import ansys.mechanical.core as pymechanical
mechanical = pymechanical.launch_mechanical()
```

Launch Mechanical from a local or remote terminal:

```
# Standalone Mechanical from a local or remote
terminal
ansys-mechanical -r 232 --port 10000 -g
```

Manually connect to this Mechanical session from a local client:

#### / Launch by version

Verify the license and version of Mechanical that is used:

```
print(mechanical)
```

Launch a specific version of Mechanical:

#### Launch the Mechanical UI

Launch the Mechanical UI:

#### Send commands to Mechanical

Run a single command:

```
result1 = mechanical.run_python_script("2+3")
result2 = mechanical.run_python_script(
    "ExtAPI.DataModel.Project.ProjectDirectory"
)
mechanical.run_python_script(
    "Model.AddStaticStructuralAnalysis()"
)
```

Execute a block of commands:

Execute a Python script file:

```
mechanical.run_python_script_from_file(file_path)
```

Import a Mechancial file and print the count of bodies:

Perform project-specific operations:

```
# Get the project directory
mechanical.project_directory

# List the files in the working directory.
mechanical.list_files()
# Save
mechanical.run_python_script(
    "ExtAPI.DataModel.Project.Save(r'D:\\Workdir')")
# Log in two ways:
mechanical._log.info("This is a useful message.")
mechanical.log_message("INFO", "info message")
# Exit
mechanical.exit(force=True)
```

# / B. Load an <u>embedded instance</u> of Mechanical in Python

Embed a Mechanical instance:

```
from ansys.mechanical.core import App
app = App(version=232)
print(app)
```

Extract and merge global API entry points:

```
# Extract the global API entry points (available from
    built-in Mechanical scripting)
from ansys.mechanical.core import global_variables
# Merge them into your Python global variables
globals().update(global_variables(app))
```

Access entry points from Python:

```
ExtAPI # Application.ExtAPI
DataModel # Application.DataModel
Model # Application.DataModel.Project.Model
Tree # Application.DataModel.Tree
Graphics # Application.ExtAPI.Graphics
```

Import a file and print the count of bodies:

```
file = r"D:\\Workdir\\bracket.mechdb"
app.open(file)
allbodies = DataModel.Project.Model.GetChildren(
    Ansys.Mechanical.DataModel.Enums.
        DataModelObjectCategory.Body,
    True)
print(allbodies.Count)
```

Turn on warning logging:

## References from PyMechanical and Mechanical documentation

- Getting started
- Scripting in Mechanical Guide

- Examples
- API reference