
Assembly Language

Continued

Machine with Registers





View of Registers

- * Registers → named storage locations
 - * in ARM: r0, r1, ... r15
 - * in x86 : eax, ebx, ecx, edx, esi, edi
- Machine specific registers (MSR)
 - * Examples: Control the machine such as the speed of fans, power control settings, read the on-chip temperature.
- * Registers with special functions :
 - * Program counter, stack pointer, return address



View of Memory



- Memory
 - One large array of bytes
 - Each location has an address
 - * The address of the first location is 0, and increases by 1 for each subsequent location
- * The program is stored in a part of the memory

The program counter contains the address of the current nstruction


Storage of Data in Memory

- Data Types
 - * char (1 byte), short (2 bytes), int (4 bytes), long int (8 bytes)
- How are multibyte variables stored in memory?
 - Example: How is a 4 byte integer stored?
 - Save the 4 bytes in consecutive locations
 - Little endian representation (used in ARM and x86) \rightarrow The LSB is stored in the lowest location



Big endian representation (Sun Sparc, IBM PPC) \rightarrow The MSB is stored in the lowest location

Little Endian vs Big Endian



Note the order of the storage of bytes



Storage of Arrays in Memory

Single dimensional arrays. Consider an array of integers: a[100]



- * Each integer is stored in either a little endian or big endian format
- * 2 dimensional arrays :
 - * int a[100][100]
 - * float b[100][100]




* Two methods: row major and column major

Row Major vs Column Major

- * Row Major (C, Python)
 - Store the first row as an 1D array
 - * Then store the second row, and so on...
- Column Major (Fortran, Matlab)
 - * Store the first column as an 1D array
 - * Then store the second column, and so on
 - Multidimensional arrays
 - * Store the entire array as a sequence of 1D arrays

Aissembly File

Assembly File Structure: GNU Assembler



- Divided into different sections
- * Each section contains some data, or assembly instructions



Meaning of Different Sections

- * .file
 - * name of the source file
- * .text
 - contains the list of instructions
- * .data



 data used by the program in terms of read only variables, and constants

Structure of a Statement

Instruction

operand 1

operand 2

operand n

- Instruction / operation
 - textual identifier of a machine instruction
- * operand
 - constant (also known as an immediate)



- * register
- memory location

Examples of Instructions


```
sub r3, r1, r2
mul r3, r1, r2
```

- * subtract the contents of *r*2 from the contents of *r*1, and save the result in *r*3
- * multiply the contents of r2 with the contents of r1, and save the results in r3



Generic Statement Structure

Label Directive
Constant
Assembly instructio



- * label → identifier of a statement
- * directive → tells the assembler to do something like declare a function



constant → declares a constant

Generic Statement Structure - II

Label Directive Constant

Assembly instructio



- * assembly statemen[‡] → contains the assembly instruction, and operands
- \rightarrow textual annotations ignored by the assembler

Types of Instructions

- Data Processing Instructions
 - * add, subtract, multiply, divide, compare, logical or, logical and
- Data Transfer Instructions
 - * transfer values between registers, and memory locations
- * Branch instructions
 - branch to a given label
 - Special instructions

interact with peripheral devices, and other programs, set machine specific

Nature of Operands

Classification of instructions

- If an instruction takes n operands, then it is said to be in the n-address format
- Example : add r1, r2, r3 (3 address format)

* Addressing Mode

* The method of specifying and accessing an operand in an assembly statement is known as the addressing mode.



Register Transfer Notation

- Style of specifying the semantics of instructions
- * r1 ← r2
 - transfer the contents of register r2 to register r1
- * $r1 \leftarrow r2 + 4$
 - * add 4 to the contents of register r2, and transfer the contents to register r1
- * r1 ← [r2]




access the memory location that matches the contents of r2, and store the data in register r1

Addressing Modes


- * Let V be the value of an operand, and let r1, r2 specify registers
- * Immediate addressing mode
 - * V ← imm, e.g. 4, 8, 0x13, -3
- * Register direct addressing mode
 - * V ← r1, e.g. r1, r2, r3 ...
- * Register indirect
 - * V ← [r1]



Register Indirect Mode



Base-offset Addressing Mode





Addressing Modes - II

* Base-index-offset

- * V ← [r1 + r2 + offset]
- * example: 100[r1,r2] (V \leftarrow [r1 + r2 + 100])

* Memory Direct

- * $V \leftarrow [addr]$
- * example : [0x12ABCD03]
- * PC Relative



- * V ← [pc + offset]
- * example: 100[pc] (V ← [pc + 100])

Base-Index-Offset Addressing Mode

