IOB-SoC

A RISC-V-based System on Chip

José T. de Sousa

IObundle Lda

June 28, 2020



Outline

- Introduction
- Project setup
- Create an IP core to instantiate in your SoC
- Edit the ./system.mk configuration file to declare a new peripheral
- Instantiate the timer IP in file rtl/src/system.v
- Edit file firmware.c to drive the new peripheral
- Run the firmware in internal SRAM
- Run the firmware in external DDR
- Simulate and implement the system
- Conclusions and future work



Introduction

- Building processor-based systems from scratch is challenging
- The IOB-SoC template eases this task
- Provides a base Verilog SoC equipped with
 - a RISC-V CPU
 - a memory system including boot ROM, RAM and AXI4 interface to DDR
 - a UART communications module
- Users can add IP cores and software to build more complex SoCs
- Here, the addition of a timer IP and its software driver is exemplified





Project setup

- Use a Linux machine or VM
- Install the latest stable version of the open source lcarus Verilog simulator (iverilog.icarus.com)
- Make sure you can access github.com using an ssh key
- At github.com create your SoC repository using github.com/IObundle/iob-soc as a template
- Follow the instructions in the README file to clone the repository in your Linux machine





Create an IP core to instantiate in your SoC

- Create a timer IP core repository or, alternatively, use the one at github.com:IObundle/iob-timer.git
- An IP core can be integrated in an IOb-SoC if it provides the following 2 files:
 - hardware/hardware.mk
 - software/embedded/embedded.mk
- Add the IP core repository as a git submodule of your IOb-SoC repository:
 - git submodule add git@github.com/IObundle/iob-soc submodules/TIMER
- To configure the system to host the IP core, edit the ./system.mk file as in the next slide





Edit the ./system.mk configuration file to declare a new peripheral

```
#FIRMWARE
FIRM_ADDR_W:=13

#SRAM
SRAM_ADDR_W=13

#DDR
USE_DDR:=0
RUN_DDR:=0
DDR_ADDR_W:=30

#BOOT
USE_BOOT:=0
BOOTROM_ADDR_W:=12

#Peripheral list (must match respective submodule name)
PERIPHERALS:=LIART_TIMER
```



Instantiate the timer IP in file rtl/src/system.v

```
'timescale 1ns/1ps
'include "system.vh"
module system (
   time_counter #(.COUNTER_WIDTH(32))
   timer (
           rst (reset_int),
           clk(clk),
           .addr(m_addr[2]),
           . data_in ( m_wdata ) ,
           . data_out(s_rdata['TIMER_BASE]),
           .valid(s_valid['TIMER_BASE]),
           . ready (s_ready [ 'TIMER_BASE])
    );
endmodule
```





Edit the firmware.c file to drive the new peripheral

./software/firmware/firmware.c

```
#include "system.h"
#include "iob-uart.h"
#include "iob_timer.h"
int main()
  //read timer cycle count
  int cycles = timer_get_count(TIMER_BASE):
  uart_init(UART, UART_CLK_FREQ/UART_BAUD_RATE);
  uart_printf(" Hello world!\n");
  uart_txwait():
  //read current timer count and compute elapsed time in clock cycles
  cvcles = timer_get_count(TIMER) - cvcles:
  //print the elapsed time and clock frequency
  uart_printf("Execution time: %dus @%dMHz,115200BAUD\n",(time*1000000)/UART_CLK_FREQ);
  uart_txwait();
  return 0;
```



Run the firmware in internal SRAM

- Run the firmware in internal RAM and disable (re)programming
 - Assign USE_DDR=0 and USE_B00T=0
 - Loading programs after the FPGA is programmed is disabled: if the firmware is modified the FPGA must be recompiled
 - This option is only valid for FPGA which permits memory initialisation
- Run the firmware in internal RAM and enable (re)programming
 - Assign USE_DDR=0 USE_B00T=1
 - Loading programs after the FPGA is programmed is enabled
 - This option is valid for FPGA and ASIC
 - Firmware is (re)loaded via UART



Run the firmware in external DDR

- Run the firmware in external DDR and disable (re)programming
 - Assign USE_DDR=1 and USE_B00T=0
 - This option is only allowed in simulation which permits memory initialisation
 - An FPGA or ASIC implementation will not work
- Run the firmware in external DDR memory and enable (re)programming
 - Define USE_DDR=1 USE_B00T=1
 - This option is valid for FPGA and ASIC
 - Firmware is (re)loaded via UART
 - Third party DDR controller IP core is required



Simulate and implement the system

- To simulate the system just type make
- The firmware, bootloader and system verilog description are compiled as you can see from the printed messages
- The last prints should look like the following

```
IOb—SoC Bootloader:

Reboot CPU and run program...

Hello world!

Total execution time: 1262 us @100MHz
```

- To implement in your chosen FPGA just type make fpga
- To implement in your chosen ASIC just type make fpga
- To load the firmware in the hardware just type make load-firmware



Conclusions and future work

Conclusions

- A tutorial on SoC creation using IOb-SoC is presented
- The addition of a peripheral IP core (timer) is illustrated
- A simple software driver for the IP core is exemplified
- How to compile and run the system is explained
- Options for implementing the main memory are presented

Future work

- Non volatile (flash) external memory support
- Real Time Operating System (RTOS)

