Decoder

March 24, 2017

This block accepts a complex electrical signal and outputs a sequence of binary values (0's and 1's). Each point of the input signal corresponds to a pair of bits.

Input Parameters

- t_integer m{ 4 }
- $\bullet \ \ vector < \texttt{t_complex} > \ iqAmplitudes \{ \ \{ \ 1.0, \ 1.0 \ \}, \{ \ -1.0, \ 1.0 \ \}, \{ \ -1.0, \ -1.0 \ \}, \{ \ 1.0, \ -1.0 \ \} \ \};$

Methods

```
Decoder()
```

 $\label{eq:coder_signal} \begin{tabular}{l} Decoder(vector < Signal *> \& Output Sig) : Block(Input Sig, Output Sig) \\ \end{tabular} \begin{tabular}{l} Decoder(vector < Signal *> \& Output Sig) : Block(Input Sig, Output Sig) \\ \end{tabular}$

```
void initialize(void)
bool runBlock(void)
void setM(int mValue)
void getM()
void setIqAmplitudes(vector<t_iqValues> iqAmplitudesValues)
vector<t_iqValues>getIqAmplitudes()
```

Functional description

This block makes the correspondence between a complex electrical signal and pair of binary values.

To do so it computes the distance in the complex plane between each value of the input signal and each value of the iqAmplitudes vector selecting only the shortest one. It then converts the point in the IQ plane to a pair of bits making the correspondence between the input signal and a pair of bits.

NOTE

Input Signals

Number: 1

 $\textbf{Type:} \quad \textbf{Electrical complex (TimeContinuousAmplitudeContinuousReal)}$

Output Signals

Number: 1

Type: Binary

Examples

As an example take an input signal with positive real and imaginary parts. It would correspond to the first point of the iqAmplitudes vector and therefore it would be associated to the pair of bits 00.

Sugestions for future improvement