NetXPTO - LinkPlanner

19 de Julho de 2017

# Conteúdo

T	mtre	duction	
2		ulator Structure System	<b>3</b>
3	Dev	elopment Cycle	4
4	Visu	alizer	5
5	Case	e Studies	6
	5.1	QPSK Transmitter	6
	5.2	Quantum Noise	8
6	Libr	ary	14
	6.1	Add	15
	6.2	Binary source	16
	6.3	Clock	20
	6.4	Decoder	22
	6.5	Discrete to continuous time	25
	6.6	Homodyne receiver	27
	6.7	IQ modulator	31
	6.8	Local Oscillator	33
	6.9	MQAM mapper	35
	6.10	MOAM transmitter	38

# Introduction

## **Simulator Structure**

LinkPlanner is a signals open-source simulator.

The major entity is the system.

A system comprises a set of blocks.

The blocks interact with each other through signals.

## 2.1 System

You can run the System

## **Development Cycle**

The NetXPTO-LinkPlanner has been developed by several people using git as a version control system. The NetXPTO-LinkPlanner repository is located in the GitHub site http://github.com/netxpto/linkplanner. The more updated functional version of the software is in the branch master. Master should be considered a functional beta version of the software. Periodically new releases are delivered from the master branch under the branch name Release<a href="Year">Year</a><a href="Year">

# Visualizer

visualizer

## **Case Studies**

## 5.1 QPSK Transmitter

This system simulates a QPSK transmitter. A schematic representation of this system is shown in figure 5.1.



Figura 5.1: QPSK transmitter block diagram.

### **System Input Parameters**

Parameter: sourceMode

**Description:** Specifies the operation mode of the binary source.

Accepted Values: PseudoRandom, Random, DeterministicAppendZeros, DeterministicCyclic.

**Parameter:** patternLength

**Description:** Specifies the pattern length used my the source in the PseudoRandom mode.

Accepted Values: Integer between 1 and 32.

Parameter: bitStream

Description: Specifies the bit stream generated by the source in the DeterministicCyclic and

DeterministicAppendZeros mode.

**Accepted Values:** "XXX..", where X is 0 or 1.

**Parameter:** bitPeriod

**Description:** Specifies the bit period, i.e. the inverse of the bit-rate.

**Accepted Values:** Any positive real value.

**Parameter:** *iqAmplitudes* 

**Description:** Specifies the IQ amplitudes.

**Accepted Values:** Any four par of real values, for instance  $\{\{1,1\},\{-1,1\},\{-1,-1\},\{1,-1\}\}\$ , the first

value correspond to the "00", the second to the "01", the third to the "10" and

the forth to the "11".

**Parameter:** numberOfBits

**Description:** Specifies the number of bits generated by the binary source.

**Accepted Values:** Any positive integer value.

Parameter: numberOfSamplesPerSymbol

**Description:** Specifies the number of samples per symbol.

**Accepted Values:** Any positive integer value.

**Parameter:** rollOffFactor

**Description:** Specifies the roll off factor in the raised-cosine filter.

**Accepted Values:** A real value between 0 and 1.

Parameter: impulseResponseTimeLength

**Description:** Specifies the impulse response window time width in symbol periods.

**Accepted Values:** Any positive integer value.

### 5.2 Quantum Noise

#### Introduction

This document describes a simple emission and detection system that uses coherent states as it's means?? of transmission???.

The transmitted information consists in a binary sequence which is ??translated?? in a sequence of coherent states. In this simulation, the used constellation is formed by the states  $\{|\alpha\rangle, |i\alpha\rangle, |-\alpha\rangle, |-i\alpha\rangle\}$ , in which  $\alpha$  is defined as  $\langle n\rangle = |\alpha|^2$  ( $\langle n\rangle$  is the expected number of photons in a state). (METER MELHOR)

One of the main effects studied in this system is quantum noise, which is an intrinsic effect?? to coherent states(VER MARK FOX). In principle???? (VER REFERENCIAS) the variance of a coherent state is given by  $\Delta X_1 \Delta X_2 = \frac{1}{4}$ .

But, given that we combine two photocurrents to obtain an output current, then the total noise will have a combined value of SOMETHING??? Procurar referencias.

Therefore, assuming Gaussian?? (WHY GAUSSIAN?) shot noise, for each quadrature we want  $Var(X_i) = \frac{1}{4}$ ????? (TENHO DE PROCURAR REFERENCIAS)

In this simulation, we introduce quantum noise in the photodiodes. We know that a coherent state has an expected number of photons distributed by a Poisson distribution, which has an average number equal to it's variance. Therefore, when the photodiode detects the power of signal, which is proportional to the number of photons, then it's variance must also be proportional to the number of photons.

In fact the last step in detecting the resulting signal introduces an difference between currents, but that only will increase the variance. Assuming the independence between detections, and it's intrinsic noise (PROCURAR MELHOR PALEIO), then:

$$Var(I_{out}) = Var(I_1) + Var(I_2)$$

Therefore, the best result we can achieve will be  $Var(X) = \frac{1}{4}$ ???? (PROCURAR PALEIO SOBRE ISTO)

### **Functional Description**

The simulation setup is described by diagram in figure 5.2. We start by generating a state from one of the four available ones.???? Then, the signal is received in a Hybrid

Detector??? where the signal is compared with a local oscillator giving four different signals in it's output. Two of those signals are detected by a photodiode which output will be the difference of the two photocurrents. The other two signals will be also be detected by another photodiode, which will obtain the other quadrature of the signal.????? (TEM QUE FICAR MELHOR EXPLICADO).

System Blocks	netxpto Blocks
-	MQAM
-	LocalOscillator
-	Hybrid??
-	Photodiode??
-	Sampler ??



Figura 5.2: Overview of the optical system being simulated.

### Required files

Header Files

File	Description	
netxpto.h	Generic purpose simulator definitions.	
m_qam_transmitter.h	_	
local_oscillator.h	Generates continuous coherent signal.	
optical_hybrid.h	—	
photodiode.h	—	
sampler.h	_	
sink.h	Closes any unused signals.	

## Source Files

File	Description
netxpto.cpp	Generic purpose simulator definitions.
m_qam_transmitter.cpp	_
local_oscillator.cpp	Generates continuous coherent signal.
optical_hybrid.cpp	_
photodiode.cpp	_
sampler.cpp	_
sink.cpp	Closes any unused signals.

## **System Input Parameters**

This system takes into account the following input parameters:

System	Description		
Parameters			
numberOfBitsGener	numberOfBitsGenerateitves the number of bits to be simulated		
bitPeriod	Sets the time between adjacent bits		
wavelength	Sets the wavelength of the local oscillator in the MQAM????		
samplesPerSymbol	Establishes the number of samples each bit in the string is given		
localOscillatorPowerSets the optical power, in units of W, of the local oscillator insid			
	the MQAM		
localOscillatorPowe	ræets the optical power, in units of W, of the local oscillator used for		
	Bob's measurements		
localOscillatorPhase	Sets the initial phase of the local oscillator used in the detection		
transferMatrix	Sets the transfer matrix of the beam splitter used in the homodyne		
	detector		
responsivity	Sets the responsivity of the photodiodes used in the homodyne		
	detectors		
bufferLength	Sets the length of the buffer used in the signals		
iqAmplitudeValues	Sets the amplitude of the states used in the MQAM????		
shotNoise	Chooses if quantum shot noise is used in the simulation		
samplesToSkip	Sets the number of samples to skip when writing out some of the		
	signal files.		

## Inputs

This system takes no inputs.

### **Outputs**

The system outputs the following objects:

**Parameter:** Signals:

**Description:** Binary Sequence used in the MQAM;  $(S_0)$  **Description:** Local Oscillator used in the MQAM;  $(S_1)$  **Description:** Local Oscillator used in the detection;  $(S_2)$  **Description:** Optical Hybrid Outputs;  $(S_3, S_4, S_5, S_6)$ 

**Description:** In phase Photodiode output; (S<sub>7</sub>) **Description:** Quadrature Photodiode output; (S<sub>8</sub>)

**Description:** In phase Sampler output;  $(S_9)$ 

**Description:** Quadrature Sampler output;  $(S_{10})$ 

#### **Simulation Results**

The objective of this simulation was to get the (quantum noise???) associated to the detection of coherent states.



Figura 5.3: Simulation of a constellation of 4 states (n = 100)

We expect that the variance is invariant with the number of photons sent from Alice. The plot in 5.4 show that the simulation also shows this invariance with the number of photons.



Figura 5.4: Simulation of the variance of n.

We can conclude that the expected variance will give us  $Var(X) = \frac{1}{2}$ . The results obtained in our simulations are in accordance with the theoretical prevision???

### **Known Problems**

1. —-

Library

### **6.1** Add

### **Input Parameters**

This block takes no parameters.

## **Functional Description**

This block accepts two signals and outputs one signal built from a sum of the two inputs. The input and output signals must be of the same type.

## **Input Signals**

Number: 2

**Type**: Real, Complex or Complex\_XY signal (ContinuousTimeContinuousAmplitude)

## **Output Signals**

Number: 1

**Type**: Real, Complex or Complex\_XY signal (ContinuousTimeContinuousAmplitude)

### 6.2 Binary source

This block generates a sequence of binary values (1 or 0) and it can work in four different modes:

1. Random

3. DeterministicCyclic

2. PseudoRandom

4. DeterministicAppendZeros

This blocks doesn't accept any input signal. It produces any number of output signals.

### **Input Parameters**

Parameter: mode{PseudoRandom}

(Random, PseudoRandom, DeterministicCyclic, DeterministicAppendZeros)

**Parameter:** probabilityOfZero{0.5}

 $(real \in [0,1])$ 

**Parameter:** patternLength{7}

(integer  $\in$  [1,32])

**Parameter:** bitStream{"0100011101010101"}

(string of 0's and 1's)

**Parameter:** numberOfBits{-1}

(long int)

**Parameter:** bitPeriod{1.0/100e9}

(double)

#### **Methods**

BinarySource(vector\Signal \*\rangle &InputSig, vector\Signal \*\rangle &OutputSig) :Block(InputSig, OutputSig){};

void initialize(void);

bool runBlock(void);

void setMode(BinarySourceMode m) BinarySourceMode const getMode(void)

void setProbabilityOfZero(double pZero)

double const getProbabilityOfZero(void)

void setBitStream(string bStream)

```
string const getBitStream(void)

void setNumberOfBits(long int nOfBits)

long int const getNumberOfBits(void)

void setPatternLength(int pLength)

int const getPatternLength(void)

void setBitPeriod(double bPeriod)

double const getBitPeriod(void)
```

### **Functional description**

The *mode* parameter allows the user to select between one of the four operation modes of the binary source.

**Random Mode** Generates a 0 with probability *probabilityOfZero* and a 1 with probability 1-probabilityOfZero.

**Pseudorandom Mode** Generates a pseudorandom sequence with period 2<sup>patternLength</sup> – 1.

**DeterministicCyclic Mode** Generates the sequence of 0's and 1's specified by *bitStream* and then repeats it.

**DeterministicAppendZeros Mode** Generates the sequence of 0's and 1's specified by *bitStream* and then it fills the rest of the buffer space with zeros.

### **Input Signals**

Number: 0

**Type:** Binary (DiscreteTimeDiscreteAmplitude)

### **Output Signals**

**Number:** 1 or more

**Type:** Binary (DiscreteTimeDiscreteAmplitude)

### **Examples**

#### Random Mode

**PseudoRandom Mode** As an example consider a pseudorandom sequence with patternLength=3 which contains a total of  $7(2^3-1)$  bits. In this sequence it is possible to find every combination of 0's and 1's that compose a 3 bit long subsequence with the exception of 000. For this example the possible subsequences are 010, 110, 101, 100, 111, 001 and 100 (they appear in figure 6.1 numbered in this order). Some of these require wrap.




Figura 6.1: Example of a pseudorandom sequence with a pattern length equal to 3.

**DeterministicCyclic Mode** As an example take the *bit stream '0100011101010101'*. The generated binary signal is displayed in.

**DeterministicAppendZeros Mode** Take as an example the *bit stream '0*100011101010101'. The generated binary signal is displayed in 6.2.

### Sugestions for future improvement

Implement an input signal that can work as trigger.




Figura 6.2: Binary signal generated by the block operating in the *Deterministic Append Zeros* mode with a binary sequence 01000...

### 6.3 Clock

This block doesn't accept any input signal. It outputs one signal that corresponds to a sequence of Dirac's delta functions with a user defined *period*.

### **Input Parameters**

```
Parameter: period{ 0.0 };

Parameter: samplingPeriod{ 0.0 };

Methods

Clock()

Clock(vector<Signal *> &InputSig, vector<Signal *> &OutputSig) :Block(InputSig, OutputSig)

void initialize(void)

bool runBlock(void)

void setClockPeriod(double per)
```

### **Functional description**

void setSamplingPeriod(double sPeriod)

## **Input Signals**

Number: 0

## **Output Signals**

Number: 1

**Type:** Sequence of Dirac's delta functions.

(Time Continuous Amplitude Continuous Real)

## **Examples**




Figura 6.3: Example of the output signal of the clock

## Sugestions for future improvement

### 6.4 Decoder

This block accepts a complex electrical signal and outputs a sequence of binary values (0's and 1's). Each point of the input signal corresponds to a pair of bits.

### **Input Parameters**

```
Parameter: t_integer m{4}

Parameter: vector<t_complex> iqAmplitudes{{1.0, 1.0},{-1.0, 1.0},{-1.0, -1.0},{1.0, -1.0}};

Methods

Decoder()

Decoder(vector<Signal *> &InputSig, vector<Signal *> &OutputSig) :Block(InputSig, OutputSig)

void initialize(void)

bool runBlock(void)

void setM(int mValue)

void getM()

void setIqAmplitudes(vector<t_iqValues> iqAmplitudesValues)

vector<t_iqValues>getIqAmplitudes()
```

### **Functional description**

This block makes the correspondence between a complex electrical signal and pair of binary values using a predetermined constellation.

To do so it computes the distance in the complex plane between each value of the input signal and each value of the *iqAmplitudes* vector selecting only the shortest one. It then converts the point in the IQ plane to a pair of bits making the correspondence between the input signal and a pair of bits.

### **Input Signals**

Number: 1

**Type:** Electrical complex (TimeContinuousAmplitudeContinuousReal)

### **Output Signals**

Number: 1

**Type:** Binary

## **Examples**

As an example take an input signal with positive real and imaginary parts. It would correspond to the first point of the *iqAmplitudes* vector and therefore it would be associated to the pair of bits 00.



Figura 6.4: Example of the output signal of the decoder for a binary sequence 01. As expected it reproduces the initial bit stream

## Sugestions for future improvement

### 6.5 Discrete to continuous time

This block converts a signal discrete in time to a signal continuous in time. It accepts one input signal that is a sequence of 1's and -1's and it produces one output signal that is a sequence of Dirac delta functions.

### **Input Parameters**

```
Parameter: numberOfSamplesPerSymbol{8} (int)
```

#### **Methods**

```
DiscreteToContinuousTime(vector<Signal *> &inputSignals, vector<Signal *> &outputSignals):Block(inputSignals, outputSignals){};

void initialize(void);

bool runBlock(void);

void setNumberOfSamplesPerSymbol(int nSamplesPerSymbol)

int const getNumberOfSamplesPerSymbol(void)
```

### **Functional Description**

This block reads the input signal buffer value, puts it in the output signal buffer and it fills the rest of the space available for that symbol with zeros. The space available in the buffer for each symbol is given by the parameter <code>numberOfSamplesPerSymbol</code>.

### **Input Signals**

```
Number: 1
```

```
Type: Sequence of 1's and -1's. (DiscreteTimeDiscreteAmplitude)
```

### **Output Signals**

```
Number : 1
```

**Type**: Sequence of Dirac delta functions (ContinuousTimeDiscreteAmplitude)

### Example




Figura 6.5: Example of the type of signal generated by this block for a binary sequence 0100...

### 6.6 Homodyne receiver

This block of code simulates the reception and demodulation of an optical signal (which is the input signal of the system) outputing a binary signal. A simplified schematic representation of this block is shown in figure 6.6.




Figura 6.6: Basic configuration of the MQAM receiver

### **Functional description**

This block accepts one optical input signal and outputs one binary signal that corresponds to the M-QAM demodulation of the input signal. It is a complex block (as it can be seen from figure 6.7) of code made up of several simpler blocks whose description can be found in the *lib* repository.

In can also be seen from figure 6.7 that there's an extra internal (generated inside the homodyne receiver block) input signal generated by the *Clock*. This block is used to provide the sampling frequency to the *Sampler*.




Figura 6.7: Schematic representation of the block homodyne receiver.

#### Input parameters

This block has some input parameters that can be manipulated by the user in order oto change the basic configuration of the receiver. Each parameter has associated a function that allows for its change. In the following table (table 6.2) the input parameters and corresponding functions are summarized.

Input parameters	Function	Туре	Accepted values	
		Vector of	<b>Example</b> for a 4-qam	
IQ amplitudes	setIqAmplitudes	coordinate	mapping: { { 1.0, 1.0 },	
1Q ampirtudes		points in the	{ -1.0, 1.0 }, { -1.0, -1.0 },	
		I-Q plane	{ 1.0, -1.0 } }	
Local oscillator	setLocalOscillatorOpticalPower_dE	molaubla(t raal)	Any double greater	
power (in dBm)	setLocalOscillatorOpticali ower_dr		than zero	
Local oscillator	setLocalOscillatorPhase	double(t_real)	Any double greater	
phase	SetLocalOscillatori Hase	double(t_lear)	than zero	
Responsivity of the	setResponsivity	double(t_real)	∈ [0,1]	
photodiodes	setkesponsivity	double(t_fear)	$\in [0,1]$	
Amplification (of	sat A mulification	double(t meel)	Positive real number	
the TI amplifier)	setAmplification	double(t_real)	rositive real number	
Noise amplitude			Pool number creater	
(introduced by the	setNoiseAmplitude	double(t_real)	Real number greater than zero	
TI amplifier)			than zero	
Samples to skipe	setSamplesToSkip	int(t_integer)		
Save internal signals	setSaveInternalSignals	bool	True or False	
Compaling powing	setSamplingPeriod	double	Givem by	
Sampling period			symbolPeriod/samplesPer\$	

Tabela 6.1: List of input parameters of the block MQAM receiver

### Methods

```
HomodyneReceiver(vector<Signal *> &inputSignal, vector<Signal *> &outputSignal) (constructor)
```

void setIqAmplitudes(vector<t\_iqValues> iqAmplitudesValues)

vector<t\_iqValues> const getIqAmplitudes(void)

void setLocalOscillatorSamplingPeriod(double sPeriod)

void setLocalOscillatorOpticalPower(double opticalPower)

void setLocalOscillatorOpticalPower\_dBm(double opticalPower\_dBm)

void setLocalOscillatorPhase(double lOscillatorPhase)

void setLocalOscillatorOpticalWavelength(double lOscillatorWavelength)

void setSamplingPeriod(double sPeriod)

 $void\ set Responsivity (t\_real\ Responsivity)$ 

void setAmplification(t\_real Amplification)

 $void\ set Noise Amplitude (t\_real\ Noise Amplitude)$ 

 $void\ setImpulseResponseTimeLength (int\ impResponseTimeLength)$ 

void setFilterType(PulseShaperFilter fType)

void setRollOffFactor(double rOffFactor)

void setClockPeriod(double per)

void setSamplesToSkip(int sToSkip)

## **Input Signals**

Number: 1

Type: Optical signal

## **Output Signals**

Number: 1

**Type:** Binary signal

## Example

Sugestions for future improvement

### 6.7 IQ modulator

This blocks accepts one inupt signal continuous in both time and amplitude and it can produce either one or two output signals. It generates an optical signal and it can also generate a binary signal.

### **Input Parameters**

Parameter: outputOpticalPower{1e-3}

(double)

Parameter: outputOpticalWavelength{1550e-9}

(double)

**Parameter:** outputOpticalFrequency{speed\_of\_light/outputOpticalWavelength}

(double)

### Methods

IqModulator(vector<Signal \*> &InputSig, vector<Signal \*> &OutputSig) :Block(InputSig, OutputSig){};

```
void initialize(void);
bool runBlock(void);
void setOutputOpticalPower(double outOpticalPower)
void setOutputOpticalPower_dBm(double outOpticalPower_dBm)
void setOutputOpticalWavelength(double outOpticalWavelength)
void setOutputOpticalFrequency(double outOpticalFrequency)
```

### **Functional Description**

This block takes the two parts of the signal: in phase and in amplitude and it combines them to produce a complex signal that contains information about the amplitude and the phase.

This complex signal is multiplied by  $\frac{1}{2}\sqrt{outputOpticalPower}$  in order to reintroduce the information about the energy (or power) of the signal. This signal corresponds to an optical signal and it can be a scalar or have two polarizations along perpendicular axis. It is the signal that is transmited to the receptor.

The binary signal is sent to the Bit Error Rate (BER) meaurement block.

### **Input Signals**

Number: 2

**Type** : Sequence of impulses modulated by the filter (ContinuousTimeContiousAmplitude))

### **Output Signals**

Number: 1 or 2

**Type**: Complex signal (optical) (ContinuousTimeContinuousAmplitude) and binary signal (DiscreteTimeDiscreteAmplitude)

### Example



Figura 6.8: Example of a signal generated by this block for the initial binary signal 0100...

### 6.8 Local Oscillator

This block simulates a local oscillator which can have shot noise or not. It produces one output complex signal and it doesn't accept input signals.

### **Input Parameters**

```
Parameter: opticalPower{ 1e-3 }
Parameter: wavelength{ 1550e-9 }
Parameter: frequency{ SPEED_OF_LIGHT / wavelength }
Parameter: phase{ 0 }
Parameter: samplingPeriod{ 0.0 }
Parameter: shotNoise{ false }
```

#### Methods

```
LocalOscillator()

LocalOscillator(vector<Signal *> &InputSig, vector<Signal *> &OutputSig)
:Block(InputSig, OutputSig){};

void initialize(void);

bool runBlock(void);

void setSamplingPeriod(double sPeriod);

void setOpticalPower(double oPower);

void setOpticalPower_dBm(double oPower_dBm);

void setWavelength(double wlength);

void setPhase(double lOscillatorPhase);
```

### **Functional description**

void setShotNoise(bool sNoise);

This block generates a complex signal with a specified phase given by the input parameter *phase*.

It can have shot noise or not which corresponds to setting the *shotNoise* parameter to True or False, respectively. If there isn't shot noise the output of this block is given by  $0.5 * \sqrt{OpticalPower} * ComplexSignal$ . If there's shot noise then a random gaussian distributed noise component is added to the *OpticalPower*.

## **Input Signals**

Number: 0

## **Output Signals**

Number: 1

Type: Optical signal

## Examples

Sugestions for future improvement

### 6.9 MQAM mapper

This block does the mapping of the binary signal using a *m*-QAM modulation. It accepts one input signal of the binary type and it produces two output signals which are a sequence of 1's and -1's.

### **Input Parameters**

```
Parameter: m{4}
```

(m should be of the form  $2^n$  with n integer)

**Parameter:** iqAmplitudes{{ 1.0, 1.0 }, { -1.0, 1.0 }, { -1.0, -1.0 }, { 1.0, -1.0 }}

#### Methods

```
MQamMapper(vector<Signal *> &InputSig, vector<Signal *> &OutputSig)
:Block(InputSig, OutputSig) {};

void initialize(void);

bool runBlock(void);

void setM(int mValue);

void setIqAmplitudes(vector<t_iqValues> iqAmplitudesValues);
```

### **Functional Description**

In the case of m=4 this block atributes to each pair of bits a point in the I-Q space. The constellation used is defined by the *iqAmplitudes* vector. The constellation used in this case is ilustrated in figure 6.9.

### **Input Signals**

```
Number: 1
```

**Type**: Binary (DiscreteTimeDiscreteAmplitude)

### **Output Signals**

Number: 2

**Type** : Sequence of 1's and -1's (DiscreteTimeDiscreteAmplitude)

### Example




Figura 6.9: Constellation used to map the signal for m=4




Figura 6.10: Example of the type of signal generated by this block for the initial binary signal 0100...

### 6.10 MQAM transmitter

This block generates a MQAM optical signal. It can also output the binary sequence. A schematic representation of this block is shown in figure 6.11.



Figura 6.11: Basic configuration of the MQAM transmitter

### **Functional description**

This block generates an optical signal (output signal 1 in figure 6.12). The binary signal generated in the internal block Binary Source (block B1 in figure 6.12) can be used to perform a Bit Error Rate (BER) measurement and in that sense it works as an extra output signal (output signal 2 in figure 6.12).




Figura 6.12: Schematic representation of the block MQAM transmitter.

### Input parameters

This block has a special set of functions that allow the user to change the basic configuration of the transmitter. The list of input parameters, functions used to change them and the values that each one can take are summarized in table 6.2.

Input parameters	Function	Туре	Accepted values
Mode	setMode()	string	PseudoRandom Random DeterministicAppendZero DeterministicCyclic
Number of bits generated	setNumberOfBits()	int	Any integer
Pattern length	setPatternLength()	int	Real number greater than zero
Number of bits	setNumberOfBits()	long	Integer number greater than zero
Number of samples per symbol	setNumberOfSamplesPerSymb	o <b>l()</b> t	Integer number of the type $2^n$ with n also integer
Roll of factor	setRollOfFactor()	double	∈ [0,1]
IQ amplitudes	setIqAmplitudes()	Vector of coordinate points in the I-Q plane	Example for a 4-qam mapping: { { 1.0, 1.0 }, { -1.0, 1.0 }, { -1.0, -1.0 },
Output optical power	setOutputOpticalPower()	int	Real number greater than zero
Save internal signals	setSaveInternalSignals()	bool	True or False

Tabela 6.2: List of input parameters of the block MQAM transmitter

### Methods

```
MQamTransmitter(vector<Signal *> &inputSignal, vector<Signal *> &outputSignal); (constructor)
```

void set(int opt);
void setMode(BinarySourceMode m)
BinarySourceMode const getMode(void)
void setProbabilityOfZero(double pZero)
double const getProbabilityOfZero(void)
void setBitStream(string bStream)
string const getBitStream(void)

void setNumberOfBits(long int nOfBits) long int const getNumberOfBits(void) void setPatternLength(int pLength) int const getPatternLength(void) void setBitPeriod(double bPeriod) double const getBitPeriod(void) void setM(int mValue) int const getM(void) void setIqAmplitudes(vector<t\_iqValues> iqAmplitudesValues) vector<t\_iqValues> const getIqAmplitudes(void) void setNumberOfSamplesPerSymbol(int n) int const getNumberOfSamplesPerSymbol(void) void setRollOffFactor(double rOffFactor) double const getRollOffFactor(void) void setSeeBeginningOfImpulseResponse(bool sBeginningOfImpulseResponse) double const getSeeBeginningOfImpulseResponse(void) void setOutputOpticalPower(t\_real outOpticalPower) t\_real const getOutputOpticalPower(void) void setOutputOpticalPower\_dBm(t\_real outOpticalPower\_dBm) t\_real const getOutputOpticalPower\_dBm(void)

## **Output Signals**

Number: 1 optical and 1 binary (optional)

Type: Optical signal

## Example



Figura 6.13: Example of the binary sequence generated by this block for a sequence 0100...

## Sugestions for future improvement

Add to the system another block similar to this one in order to generate two optical signals with perpendicular polarizations. This would allow to combine the two optical signals and generate an optical signal with any type of polarization.




Figura 6.14: Example of the output optical signal generated by this block for a sequence 0100...