NetXPTO - LinkPlanner

7 de Julho de 2017

Conteúdo

T	Introduction	2
2	Simulator Structure 2.1 System	3
3	Library	4
4	Visualizer	5
5	Case Studies 5.1 QPSK Transmitter	6
6	Development Cycle	11

Introduction

Simulator Structure

LinkPlanner is a signals open-source simulator.

The major entity is the system.

A system comprises a set of blocks.

The blocks interact with each other through signals.

2.1 System

The System is

Library

Visualizer

Case Studies

5.1 QPSK Transmitter

This system simulates a QPSK transmitter. A schematic representation of this system is shown in figure 5.1.




Figura 5.1: QPSK transmitter block diagram.

System Input Parameters

Input parameters	Description	Accepted values	
		PseudoRandom	
sourceMode	Specifies the operation mode	Random DeterministicAppendZeros	
sourceivioue	of the binary source.		
		DeterministicCyclic	
	Specifies the pattern length	Integer between 1 and 32.	
patternLength	used my the source in the		
	PseudoRandom mode.		
	Specifies the bit stream		
	generated by the source in	"XXX", where X is 0 or 1.	
bitStream	the DeterministicCyclic and		
	DeterministicAppendZeros		
	mode.		
Number of bits generated	setNumberOfBits()	Any integer	
Number of bits	setNumberOfBits()	Integer number greater than zero	
Number of samples	a at Niconala au Offica and a la a Dau Crossala	Integer number of the type 2^n with n ol() also integer	
per symbol	setNumberOiSamplesPerSymb	also integer	
Roll of factor	setRollOfFactor()	∈ [0,1]	
	Vestor of soundingto maintain	Example for a 4-qam mapping: { { 1.0,	
IQ amplitudes	Vector of coordinate points in	1.0 }, { -1.0, 1.0 }, { -1.0, -1.0 }, { 1.0, -1.0	
	the I-Q plane	}}	
Output optical power	setOutputOpticalPower()	Real number greater than zero	
Save internal signals	setSaveInternalSignals()	True or False	

Tabela 5.1: List of input parameters of the block MQAM transmitter

Functional description

This block generates an optical signal (output signal 1 in figure ??). The binary signal generated in the internal block Binary Source (block B1 in figure ??) can be used to perform a Bit Error Rate (BER) measurement and in that sense it works as an extra output signal (output signal 2 in figure ??).

Input parameters

This block has a special set of functions that allow the user to change the basic configuration of the transmitter. The list of input parameters, functions used to change them and the values that each one can take are summarized in table 5.2.

Input parameters	Function	Туре	Accepted values
Mode	setMode()	string	PseudoRandom Random DeterministicAppendZeros DeterministicCyclic
Number of bits generated	setNumberOfBits()	int	Any integer
Pattern length	setPatternLength()	int	Real number greater than zero
Number of bits	setNumberOfBits()	long	Integer number greater than zero
Number of samples per symbol	setNumberOfSamplesPerSymb	o l() t	Integer number of the type 2^n with n also integer
Roll of factor	setRollOfFactor()	double	∈ [0,1]
IQ amplitudes	setIqAmplitudes()	Vector of coordinate points in the I-Q plane	Example for a 4-qam mapping: { { 1.0, 1.0 }, { -1.0, 1.0 }, { -1.0, -1.0 },
Output optical power	setOutputOpticalPower()	int	Real number greater than zero
Save internal signals	setSaveInternalSignals()	bool	True or False

Tabela 5.2: List of input parameters of the block MQAM transmitter

Methods

```
MQamTransmitter(vector<Signal *> &inputSignal, vector<Signal *> &outputSignal);
(constructor)
  void set(int opt);
```

BinarySourceMode const getMode(void)

void setMode(BinarySourceMode m)

void setProbabilityOfZero(double pZero)

 $double\ const\ getProbabilityOfZero (void)$

void setBitStream(string bStream)

string const getBitStream(void)

```
void setNumberOfBits(long int nOfBits)
long int const getNumberOfBits(void)
void setPatternLength(int pLength)
int const getPatternLength(void)
void setBitPeriod(double bPeriod)
double const getBitPeriod(void)
void setM(int mValue) int const getM(void)
void setIqAmplitudes(vector<t_iqValues> iqAmplitudesValues)
vector<t_iqValues> const getIqAmplitudes(void)
void setNumberOfSamplesPerSymbol(int n)
int const getNumberOfSamplesPerSymbol(void)
void setRollOffFactor(double rOffFactor)
double const getRollOffFactor(void)
void setSeeBeginningOfImpulseResponse(bool sBeginningOfImpulseResponse)
double const getSeeBeginningOfImpulseResponse(void)
void setOutputOpticalPower(t_real outOpticalPower)
t_real const getOutputOpticalPower(void)
void setOutputOpticalPower_dBm(t_real outOpticalPower_dBm)
t_real const getOutputOpticalPower_dBm(void)
```

Output Signals

Number: 1 optical and 1 binary (optional)

Type: Optical signal

Example

Sugestions for future improvement

Add to the system another block similar to this one in order to generate two optical signals with perpendicular polarizations. This would allow to combine the two optical signals and generate an optical signal with any type of polarization.

Development Cycle

The NetXPTO-LinkPlanner has been developed by several people using git as a version control system. The NetXPTO-LinkPlanner repository is located in the GitHub site http://github.com/netxpto/linkplanner. The more updated functional version of the software is in the branch master. Master should be considered a functional beta version of the software. Periodically new releases are delivered from the master branch under the branch name ReleaseYear