

Objective

This example demonstrates the RTC Alarm function of the PSoC® 6 MCU Real-time Clock (RTC).

Overview

This code example demonstrates how to configure RTC registers for a daily alarm using the RTC driver Application Program Interface (API) in the Peripheral Driver Library (PDL). A GPIO output is included for an LED to notify alarm expiration. A UART is used to show the current and alarm times.

Requirements

Tools: PSoC Creator™ 4.2; Peripheral Driver Library (PDL) 3.0.1

Programming Language: C (Arm® GCC 5.4-2016-q2-update, Arm MDK Generic)

Associated Parts: All PSoC 6 MCU parts

Related Hardware: CY8CKIT-062-BLE PSoC 6 BLE Pioneer Kit

Hardware Setups

This example uses the kit's default configuration. Refer to the kit guide to ensure the kit is configured correctly.

Software Setup

This code example requires PC terminal software.


Operation

- 1. Connect the CY8CKIT-062-BLE Pioneer Kit to your computer's USB port.
- 2. Open a PC terminal using a tool like Tera Term or PuTTY. Configure it for 115,200 baud at data bit 8, no parity and stop bit 1 to match the UART Component.
- 3. Build the project and program it into the PSoC 6 MCU device. Choose Debug > Program. For more information on device programming, see PSoC Creator Help. Flash for both CPUs is programmed in a single program operation.

Note: Do not delete or replace "stdio_user.h" file.

4. Confirm that the terminal program is working. It should show a starting message in the terminal window as shown in Figure 1.

Figure 1. UART Display Start Message



5. Wait three seconds. It should show the message "Alarm Expired !! Press SW2 for to set alarm for next day" after three seconds (Figure 2).



Figure 2. UART Display Message After RTC Alarm

```
COM19-Tera Term VT

File Edit Setup Control Window Help

CE218964 - RTC Daily Alarm

67/12/17 THU 11:00:00

67/12/17 THU 11:00:01

67/12/17 THU 11:00:02


67/12/17 THU 11:00:03

Alarm Expired !* Press SW2 to set up alarm for the next day

67/12/17 THU 11:00:04
```

- 6. Confirm red LED (LED_R) toggles every one second.
- 7. Press switch SW2. It should show the next alarm information as shown in Figure 3.


Figure 3. UART Display Message After Switch Is Pressed



Design

As Figure 4 shows, this code example features one RTC, one GPIO for LED alarm indicator, one UART for user interface, and one GPIO for alarm switch SW2.

Figure 4. RTC Daily Alarm Schematic





The PSoC 6 RTC is a hardware based function, the alarm time can be configured by the alarm register fields. The daily alarm needs to enable the following time fields: hour, minute, and second. Each alarm field is paired with its own enable field. For example, sec (second) field is paired with secEn (second enable) and dayOfWeek field is paired with dayOfWeekEn field. If an enable field set, the field value will be used for matching the alarm time otherwise the field value will be ignored. For more information, see PSoC 6 BLE Register Technical Reference Manuals.

As Figure 5 shows, the alarm function uses the RTC alarm 1 interrupt. After an alarm has expired, the code prints the alarm expiration message and toggles the red LED (LED_R, P0[3]) every second until the SW2 button is pressed.






Figure 5. RTC Daily Alarm Flowchart

Interrupt Service Routine of RTC Alarm



Interrupt Service Routine of Switch interrupt





Components and Settings

Table 1 lists the PSoC Creator Components used in this example, as well as the hardware resources used by each.

Table 1. List of PSoC Creator Components

Component	Instance name	Propose	Parameter
Real Time Clock	RTC	Provide date and time information	[General Tab]:Enable Interrupt: Check
UART (SCB)	UART	used for printing terminal messages	[General Tab]: TX/RX Mode
Digital Output Pin	LED_R	Provide visual feedback	[General Tab]: HW connection: Uncheck Drive mode: Strong drive
Digital Input Pin	SW2	Provide user interaction	[General Tab]: HW connection: Uncheck Drive mode: Resistive Pull Up
Global Signal Reference	Global Signal	Configure the interrupt	[General Tab]: Global signal name: Port interrupt 0 (PICU[0])
SysInt	IRQ_SW2	Configure the interrupt	Default

Design-Wide / Global Resources

This code example runs on CY8CKIT-062-BLE, which has a PSoC 6 MCU device.

A backup clock is necessary for the RTC to function. For accurate RTC operation, it is recommended that you use a WCO.

Do the following to configure the RTC clock (BakClk) as WCO.

- 1. Double-click Clocks in Design Wide Resources.
- 2. Click Edit Clock... and open Configure System Clocks.
- 3. Enable WCO clock for the backup clock source in **Source Clocks**, as Figure 6 shows.



Figure 6. Enable WCO for the RTC Clock

4. Select WCO for BakClk in **Miscellaneous Clocks**, as Figure 7 shows.



8 Configure System Clocks Source Clocks FLL/PLL High Frequency Clocks Miscellaneous Clocks PILO-> WCO-ILO WCO-32 kHz ±30% Alt Sys Tick Clk HFClk0→ IMO-> IMO LFCk ECO-32 kHz ±30% LFCIk-÷ 8 MHz ±1%

Figure 7. Set the Backup Clock Source to WCO

Pin Allocation

Table 2 shows the physical pins used.

Table 2. Pin names and Locations

Pin Name	Location
LED_R	P0[3]
SW2	P0[4]
UART:tx	P5[1]

Reusing This Example

This example is designed for the CY8CKIT-062-BLE Pioneer Kit. To port the design to a different PSoC 6 MCU device and/or kits, change the target device using the Device Selector and update the pin assignments in the Design Wide Resources Pins settings as needed. For single-core PSoC 6 MCU devices, port the code from *main_cm4.c* to *main.c*.

Related Documents

Application Notes					
AN210781 – Getting Started with PSoC 6 MCU with Bluetooth Low Energy (BLE) Connectivity	Introduction of PSoC 6 MCU with Bluetooth Low Energy (BLE)				
PSoC Creator Component Datasheets					
Real Time Clock	Provides Real Time Clock Settings				
UART	Provides asynchronous communication interface using SCB hardware				
Pins	Supports connection of hardware resources to physical pins				
SysInt	Provides SysInt component settings				
Device Documentation					
PSoC 6 MCU: PSoC 63 with BLE Datasheet	PSoC 6 MCU: PSoC 63 with BLE Architecture Technical Reference Manual PSoC 6 MCU: PSoC 63 with BLE Registers Technical Reference Manual				
Development Kit (DVK) Documentation					
CY8CKIT-062-BLE Pioneer Kit					



Document History

Document Title: CE218964 - PSoC 6 MCU RTC Daily Alarm

Document Number: 002-18964

Revision	ECN	Orig. of Change	Submission Date	Description of Change
*A	5993969	AJYA	12/14/2017	Initial Public Release



Worldwide Sales and Design Support

Cypress maintains a worldwide network of offices, solution centers, manufacturer's representatives, and distributors. To find the office closest to you, visit us at Cypress Locations.

Products

Touch Sensing

Arm® Cortex® Microcontrollers cypress.com/arm

Automotive cypress.com/automotive Clocks & Buffers cypress.com/clocks

Interface cypress.com/interface

Internet of Things cypress.com/iot

Memory cypress.com/memory

Microcontrollers cypress.com/mcu

PSoC cypress.com/psoc

Power Management ICs cypress.com/pmic

cypress.com/touch **USB Controllers** cypress.com/usb

Wireless Connectivity cypress.com/wireless

PSoC® Solutions

PSoC 1 | PSoC 3 | PSoC 4 | PSoC 5LP | PSoC 6 MCU

Cypress Developer Community

Community | Projects | Videos | Blogs | Training | Components

Technical Support

cypress.com/support

All other trademarks or registered trademarks referenced herein are the property of their respective owners.



Cypress Semiconductor 198 Champion Court San Jose, CA 95134-1709

© Cypress Semiconductor Corporation, 2017. This document is the property of Cypress Semiconductor Corporation and its subsidiaries, including Spansion LLC ("Cypress"). This document, including any software or firmware included or referenced in this document ("Software"), is owned by Cypress under the intellectual property laws and treaties of the United States and other countries worldwide. Cypress reserves all rights under such laws and treaties and does not, except as specifically stated in this paragraph, grant any license under its patents, copyrights, trademarks, or other intellectual property rights. If the Software is not accompanied by a license agreement and you do not otherwise have a written agreement with Cypress governing the use of the Software, then Cypress hereby grants you a personal, non-exclusive, nontransferable license (without the right to sublicense) (1) under its copyright rights in the Software (a) for Software provided in source code form, to modify and reproduce the Software solely for use with Cypress hardware products, only internally within your organization, and (b) to distribute the Software in binary code form externally to end users (either directly or indirectly through resellers and distributors), solely for use on Cypress hardware product units, and (2) under those claims of Cypress's patents that are infringed by the Software (as provided by Cypress, unmodified) to make, use, distribute, and import the Software solely for use with Cypress hardware products. Any other use, reproduction, modification, translation, or compilation of the Software is prohibited.

TO THE EXTENT PERMITTED BY APPLICABLE LAW, CYPRESS MAKES NO WARRANTY OF ANY KIND, EXPRESS OR IMPLIED, WITH REGARD TO THIS DOCUMENT OR ANY SOFTWARE OR ACCOMPANYING HARDWARE, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE. To the extent permitted by applicable law, Cypress reserves the right to make changes to this document without further notice. Cypress does not assume any liability arising out of the application or use of any product or circuit described in this document. Any information provided in this document, including any sample design information or programming code, is provided only for reference purposes. It is the responsibility of the user of this document to properly design, program, and test the functionality and safety of any application made of this information and any resulting product. Cypress products are not designed, intended, or authorized for use as critical components in systems designed or intended for the operation of weapons, weapons systems, nuclear installations, life-support devices or systems, other medical devices or systems (including resuscitation equipment and surgical implants), pollution control or hazardous substances management, or other uses where the failure of the device or system could cause personal injury, death, or property damage ("Unintended Uses"). A critical component is any component of a device or system whose failure to perform can be reasonably expected to cause the failure of the device or system, or to affect its safety or effectiveness. Cypress is not liable, in whole or in part, and you shall and hereby do release Cypress from any claim, damage, or other liability arising from or related to all Unintended Uses of Cypress products. You shall indemnify and hold Cypress harmless from and against all claims, costs, damages, and other liabilities, including claims for personal injury or death, arising from or related to any Unintended Uses of Cypress products.

Cypress, the Cypress logo, Spansion, the Spansion logo, and combinations thereof, WICED, PSoC, CapSense, EZ-USB, F-RAM, and Traveo are trademarks or registered trademarks of Cypress in the United States and other countries. For a more complete list of Cypress trademarks, visit cypress.com. Other names and brands may be claimed as property of their respective owners.