Basic SolidWorks


By Friend

Pre-workshop

- Download and install SolidWorks
 https://ubc.service now.com/kb_view_customer.do?sysparm_ar
 ticle=KB0015800
- The CAD team may use different software such as Inventor, but use Solidworks for this workshop
 - The fundamentals are all the same

Agenda

- Sketching, dimensioning, mirroring
- Extrusion, adding text
- Sheet metal




Final product from Basic SolidWorks and Adv. SolidWorks workshops

0. Setting up

Units


• Make sure you're in MMGS for this tutorial!



1. Sketching, dimensioning, mirroring


Create a new part

- File -> New -> Part
- This window should pop up




Sketching any shape

- Select any plane, click "Sketch" at Sketch toolbar, and start sketching the rabbit.
- Do not worry about dimensioning or relationships yet. Just make sure it looks similar to this.




Adding dimensions


- One by one, add the dimensions and relationship according to the image here.
- As long as your original drawing somewhat resembles this, it will come together by itself once you start to add more dimensions.
- Make sure you don't have any extra dimensions or relationships, or you might not be able to add some of the required dimensions shown here.



Adding dimensions


- Make sure all the lines are black when you're done.
 - Black line means that drawing is fully defined.
 There's no ambiguous part or any moving part.
 - o Blue, under-defined.
 - o Red or yellow, over-defined.






Mirroring

- Select to "Mirror Entities"
- Select all the lines except for the leftmost line to mirror, while choosing the leftmost line for everything to be mirrored about




Extrusion

 Click on "Extrude Boss/Base" at Features toolbar, and extrude by 10mm.



Done!

 Save the file as "Item" (not that the file will be relevant later on).



2. Extrusion, adding text

Sketching the base

 On any plane, sketch this, then extrude by 10mm.

To draw the rectangle, it may be helpful to use center-point rectangle instead of the regular two-corner rectangle.

*


Smart Dimension

Sketch


Exit

Sketch


Features




• Draw a concentric circle on the extrusion, then extrude by 10mm.




- Draw a slot to make the arm, then extrude by 5mm.
 - To draw the slot, it may be helpful to use "Straight slot" in Sketch toolbar.



 Draw a concentric circle on the arm, then extrude by 10mm.




• You should have this form at this point.




Adding text

- Select a side face of the arm.
- Go to Sketch toolbar and click "Sketch". Click "Text" to add text.



Adding text

- Choose any text(I'll go for "APSC PASS").
 - Default setting for the text is the document's.
 Untick the option so you can modify text to squeeze it into the given space.
- Extrude 2mm cut.



Done!

Save the file as "Handle"



3. Sheet metal


Adding sheet metal to Toolbar

Two ways:

- Right click on Toolbar and a options will appear. Tick on "Sheet Metal"
- 2. View -> Toolbars -> Sheet Metal


Sketching

Select any plane and sketch accordingly.



Sheet metal


- Go to Sheet metal toolbar, click "Base Flange/Tab".
- Extrude by 30mm.






 Select the top face of the claw, and sketch accordingly.


 Go to Sheet metal toolbar, click "Base Flange/Tab" to add the tab to the claw.



Sheet metal


- One the inner side of the tab, sketch accordingly.
- Extrude by 10mm.





Done!

Save the file as "Claw"



Some further readings

- Get certified with CSWA
 https://www.solidworks.com/sw/support/cs
 wa-academic.htm talk to Rapid's External
 Coordinator for this
 - O There's a good cert. prep. course on Lynda (free with VPL account)