## Wire + void update() + void set\_signal(int signal) + int get\_signal() const #inputs #output Component

## + virtual void update()=0+ virtual void write

(Wire \*base\_address, std::ostream &os=std ::cout)=0



- + PRINT(Wire \*inpA, const char \*label="Nem elnevezett kimenet", std ::ostream &os=std::cout)
  - + void update()
    + void write(Wire \*base
     \_address, std::ostream
     &os=std::cout)
  - + static const char \* get\_name()