PTLsim User's Guide and Reference The Anatomy of an x86-64 Out of Order Microprocessor

Contents

ı	PTLsim User's Guide	6
1	Introducing PTLsim	7
	1.1 Introducing PTLsim	7

II x86 Instruction Set and PTLsim Micro-Operations				
5	x86	Instructions and Micro-Ops (uops)	23	
	5.1	Micro-Ops (uops) and TransOps	23	
	5.2	Descriptions of uops	24	
	5.3	Simple Fast Path Instructions	24	
	5.4	x86-64	24	
	5.5	Operation Sizes		

9	Scheduling, Dispatch and Issue					
	9.1	Clustering and Issue Queue Configuration	37			
	9.2	Cluster Selection	37			
	9.3	Issue Queue Structure and Operation				

15	Cache Hierarchy	52
	15.1 General Configurable Parameters	52
	15.2 Initiating a Cache Miss	53
	15.3 Filling a Cache Miss	54
	15.4 Translation Lookaside Buffers	54

Part I PTLsim User's Guide

Introducing PTLsim

1.1 Introducing PTLsim

PTLsim is a state of the art cycle accurate microprocessor simulator and virtual machine for the x86 and x86-64

1.3 Documentation Roadmap

This manual has been divided into several parts:

• Part I introduces PTLsim and describes its structure and operationž

Getting Started with PTLsim

2.1 Building PTLsim

PTLsim reads configuration option/home/	ns for running	various user	programs by	looking for	a configuration	file named

-trigger

PTLsim Internals

3.1 Overview

The following is an overview of the source files for PTLsim:

• ooocore. cpp is the out of order simulator itself. The microarchitectural model implemented by this simula-

- Template based metaprogramming functions including length of (finds the length of any static array) and log2 (takes the base-2 log of any constant at compile time)
- Floor, ceiling and masking functions for integers and powers of two (floor, truncceil mask, floorptr, ceil ptrmaskptr, signext, etc)
- Bit manipulation macros (bi t,bi tmask,bi ts,l owbi ts,setbi t,cl earbi t,assi gnbi t). Note that the bi tvec template (see below) should be used in place of these macros wherever it is more convenient.
 - Comparison functions (aligned, strequal, inrange, clipto)
 - Modulo arithmetic (add_i ndex_modul o_modul o_span, et al)
 - Definitions of basic x86 SSE vector functions (e.g. x86_cpu_pcmpeqb et al)
 - Definitions of basic x86 assembly language functions (e.g. x86 bsf64 et al)
 - A full suite of bit scanning functions (I sbi ndex, popcount et al)
 - Miscellaneous functions (arraycopysetzero, etc)

Index reference (i ndexref) is a smart pointer which compresses a full pointer into an index into a sp structure (made unique by the template parameters). This class behaves exactly like a pointer when refere	ecific enced,

At this point, the PTLsim image injected into the user process exists in a bizarre environment: if the user program is 32 bit, the boot code will need to switch to 64-bit mode before calling the 64-bit PTLsim entrypoint. Fortunately

Statisticsol

x86 Instructions and Micro-Ops (uops)

5.1 Micro-Ops (uops) and TransOps

Part III Out of Order Processor Model

Fetch Stage

7.1 Instruction Fetching and the Basic Block Cache

As described in Section , x86 instructions are decoded into transops prior to actual execution by the out of order core. Some processors do this translation as x86 instructions are fetched from an L1 instruction cache, while others use a trace cache to store pre-decoded uops. PTLsim takes a middle ground to allow maximum simulation flexibility.

branchpred. predict() function is used to redirect fetching. If the branch is predicted not taken, the sense of the branch's condition code is inverted and the transop's riptaken and ripseq fields are swapped; this ensures all branches are considered correct only if taken. Indirect branches (jumps) have their(80(,6.74769626Tf246.33430Td[(riptaken)]

Frontend and Key Structures

8.1 Resource Allocation

During the Allocate stage, PTLsim dequeues uops from the fetch queue, ensures all resources needed by those uops

8.4 Load Store Queue Entries

Scheduling, Dispatch and Issue

9.1 Clustering and Issue Queue Configuration

The PTLsim out of order model can simulate an arbitrarily complex set of functional units grouped into *clusters*.

Clusters are specified by the Cluster class and are defined by the clusters[] array in ooohwdef. h. Each

fu_mask field)]-234(and)-234(the)

Table 9.1: Issue Queue State Machine

Valid Issued

a functional unit for the uop in that slot and executes it via the ReorderBufferEntry: i ssue() method. After the uop has completed execution (i.e. it cannot possibly be replayed), the rel ease() method is called to remove the slot from the issue queue, freeing it up for incoming uops in the dispatch stage. The collapsing design of the issue queue means that the slot is not simply marked as invalid - all slots after it are physically shifted left by one, leaving a free slot at the end of the array. This design is relatively simple to implement in hardware and makes determining the oldest ready to issue uop very trivial.

Because of the collapsing mechanism, it is critical to note that the slot index returned by i ssue() will become invalid after the next call to the remove() method; hence, it should never be stored anywhere if a slot could be removed from the issue queue in the meantime.

The first uop to annul is determined in the annul of method by scanning backwards in time from the excepting uop until a uop with its SOM start of macro-op°bit is set, as described in Section 5.1. This SOM uop represents the

and the memory range needed by the load overlaps the memory range touched by the store, the load effectively has a dependency on the earlier store that must be resolved before ear39(load)-3 issue. The meaning of "overlapping memory range" is defined more specifically in Section 12.1.

Stores

12.1 Store to Store Forwarding and Merging

writes the address into the corresponding LoadStoreQueueEntry structure before setting its the addrvalid bit as described in Section 8.4. If an exception is detected at this point, the invalid bit in the store queue entry is set and the destination physical register's FLAG_inv flag is set so any attempt to commit the store will fail.

12.2.1 Load Queue Search (Alias Check)

The load queue is then searched to find any loads after the current store in program order which have already issued but have done so without forwarding data from the current store. These loads erroneously issued before the current store (now known to overlap the load's address) was able to forward the correct data to the offending load(s). This situation is known as *aliasing*

the wri teback() function; its sole purpose is to place the uop's physical register into the written state (via the Physi cal Register::wri teback() method) and to move the ROB into its terminal state, ready-to-commit.

Commitment

14.1 Introduction

In dcacheint.h, the two ba on the model being used.	ase classes CacheLi ne The CacheLi ne class	and CacheLi neWi is a standard cache	thVal i dMask are ir line with no actual da	nterchangeable, depending ata (since the bytes in each

the L1 cache. Similarly, an L2 miss but L3 hit results in the STATE_DELI VER_TO_L2 state, and a miss all the way to main memory results in STATE_DELI VER_TO_L3.

In the very unlikely event that either the LFRQ slot or miss buffer are ful6, an exception is returned to out of order core, which typically replays the affected load until space in these structures becomes available. For prefetch requests, only a miss buffer is allocated; no LFRQ slot is needed.

15.3 Filling a Cache Miss

The MissBuffer::clock()

simply checks one of the simulator's Shadow Page Access Tables (SPATs) as described in Section 3.5. For DTLB accesses, the dtl bmap SPAT is used, while ITLB accesses use the itl bmap SPAT. If a bit in the appropriate SPAT

all the information needed	to eventually update	e the branch	predictor at	the end of the	ne pipeline.	The contents will

To solve this problem, the RAS is only updated in the allocate stage immediately after fetch. core's $rename()$ function, the BranchPredictorInterface: updateras()	In the out of order

Part IV Appendices

PTLsim uop Reference

The following sections document the semantics and encoding of each micro-operation (uop) supported by the PTL-sim processor core. The opi nfo[] table in ptl hwdef. cpp and constants in ptl hwdef. h give actual numerical values for the opcodes and other fields described below.

mov and or xor andnot ornot nand nor eqv Logical Operations

Mnemonic	Syntax	Operation	
mov	rd = ra, rb	rd = r	a rb
and	rd = ra, rb	rd = ra	ra & rb
or	rd = ra, rb	rd = ra	ra rb
xor	rd = ra, rb	rd = ra	ra ^ rb
andnot	rd = ra, rb	rd = ra	(~ra) & rb
ornot	rd = ra, rb	rd = ra	(~ra) rb
nand	rd = ra, rb	rd = ra	~(ra & rb)
nor	rd = ra, rb	rd = ra	~(ra rb)
eqv	rd = ra, rb	rd = ra	~(ra ^ rb)

Notes:

add sub addadd addsub subadd subsub add
m subm addc subc $\operatorname{\mathsf{Add}}$ and $\operatorname{\mathsf{Subtract}}$

Mnemonic	Syntax	Operati	on
add	rd = ra, rb	rd = ra	ra + rb
sub	rd = ra, rb	rd = ra	ra - rb
adda	rd = ra, rb, rc*		

sel

Conditional Select

Mnemonic	Syntax	Operation
sel . cc	rd = (ra), rb, rc	rd = (EvalFlags(ra)) ? rc : rb

set Conditional Set



set. sub_set. and Conditional Compare and Set

Mnemonic		Operation	
set sub. cc	rd = ra, rb, rc	rd = rc	EvalFlags(ra - rb) ? 1 : 0
set. and. <i>cc</i>	rd = ra, rb, rc	rd = rc	EvalFlags(ra & rb) ? 1 : 0

Notes:

.

j mp Indirect Jump

Mnemonic	Syntax	Operation
j mp	rip = ra	, ri ptaken ripip = raripNotes:

brp Unconditional Branch Within Microcode

Mnemonic	Syntax	Operation
bru	null = riptaken	

chk

Check Speculation

Mnemonic	Syntax	Operation
chk. cc	rd = ra, recri p, extype	rd = EvalCheck(ra) ? 0 : recrip

- The chk uop verifies *certain* properties about ra. If this verification check passes, no action is taken. If the check fails, chk signals an exception of the user specified type in the *rc* immediate. The result of the chk uop in this case is the user specified RIP to recover at after the check failure is handled in microcode. This recovery RIP is saved in the recoveryrip internal register.
- This mechanism is intended to allow simple inlined uop sequences to branch into microcode if certain conditions fail, since normally inlined uop sequences cannot contain embedded branches.
 One example use is in the REP series of instructions to ensure that the count is not zero on entry (a special corner case).
- · Unlike most conditional uops, the chk

- PageFaul t0nRead if the virtual address (ra + rb) falls on a page not accessible to the caller in the current operating mode, or a page marked as not present.
- Various other exceptions and replay conditions may exist depending on the specific processor core model.

Mnemonic	Syntax	Operation
st	sfrd = [ra, rb], rc, sfra	sfrd = MergeWithSFR((ra + rb), sfra, rc)
st.lo	sfrd = [ra+rb], rc, sfra	sfrd = MergeWithSFR(floor(ra + rb, 8), sfra, rc)
st.hi	sfrd = [ra+rb], rc, sfra	sfrd = MergeWithSFR(floor(ra + rb, 8) + 8, sfra, rc)

- The PTLsim store unit model is described in substantial detail in Section 12.1; this section only gives an overview of the store uop semantics.
- The st family of uops prepares values to be stored to the virtual address specified by the sum *ra* + *rb*.
- The *sfra* operand specifies the store forwarding register (a.k.a. store buffer) to merge the data to be stored (the

.ouy	griment problems,	Thicrocode 341	TOOOIITT U[IEECIS	91(thts)-291(e)30	(лесроооіазоооі	ucsul

I dp I dxp Load from Internal Space

Mnemonic	Syntax	Operation
I dp	rd = [ra, rb]	rd = MSR[ra+rb]
l dxp	rd = [ra+rb]	rd = SignExt(MSR[ra+rb])

Notes:

The I dp and I dxp uops load values from the internal PTLsim address space not accessible to x86 code. Typically this address space is mapped to internal machine state registers (MSRs) and microcode scratch space. The internal address to access is specified by the sum

stp Store to Internal Space

Mnemonic	Syntax	Operation
stp	null = [ra, rb], rc	MSR[ra+rb] = rc

Notes:

.

inshb exthb movhb Byte Operations

Mnemonic	Syntax	Operation	
i nshb	rd = ra, rb	rd = ra[15:8]	rb[7:0]
exthb	rd = ra, rb	rd = ra[7:0]	

movhl movl Merge 32-bit Words

movccr movrcc

Move Condition Code Flags Between Register Value and Flag Parts

Mnemonic	Syntax	Operation
movccr	rd = ra	rd = ra.flags
movrcc	rd = ra	rd.flags = 0 rd.flags = ra
		rd = ra

- The movccr uop takes the condition code flag bits attached to *ra* and copies them into the 64-bit register part of the result.
- The movrcc uop takes the low bits of the *ra* operand and moves those bits into the condition code flag bits attached to the result.
- The bits moved consist of the ZF, PF, SF, CF, OF flags
- The WAIT and INV flags of the result are always cleared since the uop would not even issue if these were set in *ra*.

mul I mul h Integer Multiplication

Mnemonic	Syntax	Operation	on
mul I	rd = ra, rb	rd = ra	lowbits(ra × rb)
mul h	rd = ra, rb	rd = ra	highbits(ra \times rb)

Notes:

.

bt bts btr btc Bit Testing and Manipulation

Mnemonic	Syntax	Operation	
bt	rd = ra, rb	rd.cf = ra[rb]	
		rd = ra (rd.cf) ? -1 : +1	rd.cf = ra[rb]
			rd = ra (rd.cf)

ctpop Count Population of '1' Bits


Mnemonic	Syntax	Operation
ctpop	rd = ra	rd.zf = (ra == 0)
		rd = PopulationCount(ra)

- The ctpop uop counts the number of '1' bits in the *ra* operand.
- The ZF flag of the result is 1 if ra was zero,r7cp7N89704on151.74970T. O0.9a

Floating Point Format and Merging

All floating point uops use the same encoding to specify the precision and vector format of the operands. The uop's *size* field is encoded as follows:

• 00:



maddf9nsuntf7f5F459-6Tf6m54-6T7-5. 4rB593. 5979T/+61n5040. 1992I 2775. 80a. 1992n. madTd593. The. 9626 Fused Multiply Add and Subtract

Mnemonic Syntax Operation maddf

cmpf

Compare Floating Point

Mnemonic	Syntax	Operation	on
cmpf. type	rd = ra, rb	rd = ra	CompareFP(ra, rb, type) ? -1 : 0

- This uop performs the specified comparison of *ra* and *rb*. If the comparison is true, the result is set to all '1' bits; otherwise it is zero. The result is then merged into ra.
- The *cond* field in the uop encoding holds the comparison type. The set of compare types matches the x86 SSE/SSE2 CMPxx instructions.

cvtf. i 2s. i ns cvtf. i 2s. p cvtf. i 2d. I o cvtf. i 2d. hi Convert 32-bit Integer to Floating Point

Mnemonic	Syntax	Operation		Used By
cvtf. i 2s. i ns	rd = ra, rb	rd = ra	Int32ToFloat(rb)	CVTSI 2SS

cvtf. q2s. i ns cvtf. q2d Convert 64-bit Integer to Floating Point

Mnemonic	Syntax	Operation	Used By
cvtf. q2s. i ns	rd = ra, rb	rd = ra Int64ToFloatl0irbl01	CVTSI 2SS
cvtf. q2d	rd = ra	rd = Int64ToDoublel0iral01	(x86-64l01 CVTPI 2PS (x86-64l01

- These uops convert 64-bit integers to single or double precision floating point
- The semantics of these instructions are identical to the semantics of the x86 SSE/SSE2 instructions shown in the table
- The uop size field is not used by these uops

cvtf. d2i cvtf. d2q cvtf. d2i . p Convert Double Precision Floating Point to Integer

Mnemonic	Syntax	Operation	Used By
cvtf. d2i	rd = ra	rd = DoubleToInt32(ra)	CVTSD2SI
cvtf. d2i . p	rd = ra, rb	rd[63:32] = DoubleToInt32(ra)	CVTPD2PI
		rd[31:0] = DoubleToInt32(rb)	CVTPD2DQ
cvtf. e2q	rd = ra	rd = DoubleToInt64(ra)	CVTSD2SI
			(x86-64)

- These uops convert drd = precision floating point values to 32-bit or 64-bit integers
- The semantics of these instructions are identical to the semantics of the x86 SSEx-M3a6tocon -278(or)-278(64

cvtf. d2s. i ns cvtf. d2s. p cvtf. s2d. I o cvtf. s2d. hi Convert Between Double Precision and Single Precision Floating Point

Chapter 18

Performance Counters

PTLsim maintains hundreds of performance and statistical counters and data points as it simulates user code. In Secttom basic mechanisms and data structures through which PTLsim collects these data were disclosed, and a guide to extending the existing set of collection points was presented.

This section is a reference listing of all the current performance counters present in PTLsim by default. The sections below are arranged in a hierarchical tree format, just as the data are represented in PTLsim's data store.

18.1 General

As described in Section 4, PTLsim maintains a hierarchical tree of statistical data. At the root of the tree are a potentially large number of snapshots, numbered starting at 0. The final snapshot, taken just before simulation completes, is labeled as "final". Each snapshot branch contains all of the data structures described in the next few sections. Snapshots

-snapshot configuration (Section 2.3); ifnywithn the "0" and "final" snapshots are provided.

In addition to the snapshopth (Tablifeed to be a made of the snapshopth) and it is addition to the snapshopth (Tablifeed to be a made of the snapshopth) and it is a made of the snapshop that t

18.2 Out of Order Core

summary: summarizes the performance of user code running on the simulator

- cycles: total number of processor cycles simulated
- commits: total number of committed uops
- usercommits: total number of committed x86 instructions
- issues: total number of uops issued. This includes uops issued more than once by through replay (Section 9.3).
- ipc: Instructions Per Cycle (IPC) statistics
 - commit-in-uops: average number of uops committed per cycle
 - issue-in-uops: average number of uops issued per cycle
 - commit-in-user-insns: average number of x86 instructions committed per cycle

NOTE: Because one x86 instruction may be broken up into numerous uops, it is never

– br:

 width: histogram of the issue width actually used on each cycle in each cluster down by cluster, since various clusters have different issue width and policies. 	. This object is further broken
•	

-			