7/23/2018 MIPS Quick Tutorial

# **MIPS Architecture and Assembly Language Overview**

 $Adapted\ from:\ http://edge.mcs.dre.g.el.edu/GICL/people/sevy/architecture/MIPSRef(SPIM).html. Adapted\ from:\ http://edge.mcs.dre.g.el.edu/GICL$ 

[Register Description] [I/O Description]

### **Data Types and Literals**

### Data types:

- Instructions are all 32 bits
- byte(8 bits), halfword (2 bytes), word (4 bytes)
- a character requires 1 byte of storage
- an integer requires 1 word (4 bytes) of storage

#### Literals:

- numbers entered as is. e.g. 4
- characters enclosed in single quotes. <u>e.g.</u> 'b'
- strings enclosed in double quotes. <u>e.g.</u> "A string"

### Registers

- 32 general-purpose registers
- register preceded by \$\\$\\$ in assembly language instruction two formats for addressing:
  - o using register number e.g. \$0 through \$31
  - o using equivalent names <u>e.g.</u> \$t1, \$sp
- · special registers Lo and Hi used to store result of multiplication and division
  - o not directly addressable; contents accessed with special instruction mfhi ("move from Hi") and mflo ("move from Lo")
- stack grows from high memory to low memory

This is from Figure 9.9 in the Goodman&Miller text

Register Number	Alternative Name	Description	
0	zero	the value 0	
1	\$at	(assembler temporary) reserved by the assembler	
2-3	\$v0 - \$v1	(values) from expression evaluation and function results	
4-7	\$a0 - \$a3	(arguments) First four parameters for subroutine. Not preserved across procedure calls	
8-15	\$t0 - \$t7	(temporaries) Caller saved if needed. Subroutines can use w/out saving. Not preserved across procedure calls	
16-23	\$s0 - \$s7	(saved values) - Callee saved. A subroutine using one of these must save original and restore it before exiting. Preserved across procedure calls	
24-25	\$t8 - \$t9	(temporaries) Caller saved if needed. Subroutines can use w/out saving. These are in addition to \$t0 - \$t7 above.  Not preserved across procedure calls.	
26-27	\$k0 - \$k1	reserved for use by the interrupt/trap handler	
28	\$gp	global pointer. Points to the middle of the 64K block of memory in the static data segment.	
29	\$sp	stack pointer Points to last location on the stack.	
30	\$s8/\$fp	saved value / frame pointer Preserved across procedure calls	
31	\$ra	return address	

See also Britton section 1.9, Sweetman section 2.21, Larus Appendix section A.6

# **Program Structure**

- just plain text file with data declarations, program code (name of file should end in suffix .s to be used with SPIM simulator)
- data declaration section followed by program code section

## **Data Declarations**

- placed in section of program identified with assembler directive .data
- declares variable names used in program; storage allocated in main memory (RAM)

### Code

- placed in section of text identified with assembler directive .text
- contains program code (instructions)
- starting point for code e.g.ecution given label main:
- ending point of main code should use exit system call (see below under System Calls)

7/23/2018 MIPS Quick Tutorial

#### **Comments**

```
    anything following # on a line
    # This stuff would be considered a comment
```

• Template for a MIPS assembly language program:

```
# Comment giving name of program and description of function
# Template.s
# Bare-bones outline of MIPS assembly language program

.data  # variable declarations follow this line
# ...

.text  # instructions follow this line

main:  # indicates start of code (first instruction to execute)
# ...
# End of program, leave a blank line afterwards to make SPIM happy
```

# **Data Declarations**

```
format for declarations:
```

```
name: storage_type value(s)
```

- o create storage for variable of specified type with given name and specified value
- value(s) usually gives initial value(s); for storage type .space, gives number of spaces to be allocated

Note: labels always followed by colon (:)

#### **Load / Store Instructions**

- · RAM access only allowed with load and store instructions
- · all other instructions use register operands

## load:

```
lw register_destination, RAM_source
  #copy word (4 bytes) at source RAM location to destination register.

lb register_destination, RAM_source
  #copy byte at source RAM location to low-order byte of destination register,
  # and sign-e.g.tend to higher-order bytes
```

# store word:

```
#store word in source register into RAM destination

sb register_source, RAM_destination
```

register\_destination, value

#store byte (low-order) in source register into RAM destination

### load immediate:

1i

```
#load immediate value into destination register
example:
        .data
var1:
        .word
                23
                                 # declare storage for var1; initial value is 23
        .text
 _start:
                                         # load contents of RAM location into register $t0: $t0 = var1
        1w
                $t0, var1
        li
                $t1, 5
                                               ("load immediate")
        SW
                $t1, var1
                                         # store contents of register $t1 into RAM: var1 = $t1
```

## **Indirect and Based Addressing**

done

• Used only with load and store instructions

### load address:

```
la $t0, var1
```

• copy RAM address of var1 (presumably a label defined in the program) into register \$t0

### indirect addressing:

```
lw $t2, ($t0)
```

• load word at RAM address contained in \$t0 into \$t2

```
sw $t2, ($t0)
```

• store word in register \$t2 into RAM at address contained in \$t0

### based or indexed addressing:

```
lw $t2, 4($t0)
```

- load word at RAM address (\$t0+4) into register \$t2
- "4" gives offset from address in register \$t0

```
sw $t2, -12($t0)
```

- store word in register \$t2 into RAM at address (\$t0 12)
- negative offsets are fine

Note: based addressing is especially useful for:

- · arrays; access elements as offset from base address
- · stacks; easy to access elements at offset from stack pointer or frame pointer

#### example

```
.data
array1:
                .space
                       12
                                        # declare 12 bytes of storage to hold array of 3 integers
                .text
start:
                la
                        $t0, array1
                                                   load base address of array into register $t0
                                                     ("load immediate"
                1i
                        $t1. 5
                                           $±1 = 5
                sw $t1, ($t0)
li $t1, 13
                                           first array element set to 5; indirect addressing
                                            $t1 = 13
                sw $t1, 4($t0)
                                        # second array element set to 13
                li $t1, -7
                                            $t1 = -7
                sw $t1, 8($t0)
                                           third array element set to -7
```

## **Arithmetic Instructions**

- · most use 3 operands
- · all operands are registers; no RAM or indirect addressing
- operand size is word (4 bytes)

```
add
           $t0,$t1,$t2
                                 # $t0 = $t1 + $t2:
                                                               add as signed (2's complement) integers
                                 # $t2 = $t3 D $t4
           $t2,$t3,$t4
sub
addi
           $t2,$t3, 5
                                 # $t2 = $t3 + 5;
                                                            "add immediate" (no sub immediate)
addu
           $t1,$t6,$t7
                                 # $t1 = $t6 + $t7;
                                                               add as unsigned integers
                                 # $t1 = $t6 + $t7;
                                                               subtract as unsigned integers
subu
           $t1,$t6,$t7
                                    multiply 32-bit quantities in $t3 and $t4, and store 64-bit result in special registers Lo and Hi: (Hi,Lo) = $t3 * $t4 Lo = $t5 / $t6 (integer quotient)
mult
           $t3,$t4
                                    Lo = $t5 / $t6 (integer quotient)
Hi = $t5 mod $t6 (remainder)
move quantity in special register Hi to $t0:
move quantity in special register Lo to $t1:
div
           $t5,$t6
mfhi
           $t0
                                                                                                      $t0 = Hi
mflo
                                    used to get at result of product or quotient
           $t2,$t3 # $t2 = $t3
move
```

## **Control Structures**

# Branches

<u>Jumps</u>

• comparison for conditional branches is built into instruction

```
unconditional branch to program label target
           target
                                   branch to target if $t0 = $t1$
branch to target if $t0 < $t1
branch to target if $t0 < $t1
beq
           $t0,$t1,target #
           $t0,$t1,target #
$t0,$t1,target #
h1t
ble
bgt
           $t0,$t1,target
                                #
                                    branch to target if $t0 > $t1
           $t0,$t1,target #
$t0,$t1,target #
                                   branch to target if $t0 >= $t1
branch to target if $t0 <> $t1
bne
           target # unconditional jump to program label target
                                # jump to address contained in $t3 ("jump register")
           $t3
```

Subroutine Calls

subroutine call: "jump and link" instruction

```
jal sub_label # "jump and link"
```

- copy program counter (return address) to register \$ra (return address register)
- jump to program statement at sub label

subroutine return: "jump register" instruction

```
jr $ra # "jump register"
```

• jump to return address in \$ra (stored by jal instruction)

Note: return address stored in register \$ra; if subroutine will call other subroutines, or is recursive, return address should be copied from \$ra onto stack to preserve it, since jal always places return address in this register and hence will overwrite previous value

### System Calls and I/O (SPIM Simulator)

- · used to read or print values or strings from input/output window, and indicate program end
- · use syscall operating system routine call
- first supply appropriate values in registers \$v0 and \$a0-\$a1
- result value (if any) returned in register \$v0

The following table lists the possible syscall services.

Service	Code in \$v0	Arguments	Results
print_int	1	\$a0 = integer to be printed	
print_float	2	\$f12 = float to be printed	
print_double	3	\$f12 = double to be printed	
print_string	4	\$a0 = address of string in memory	
read_int	5		integer returned in \$v0
read_float	6		float returned in \$v0
read_double	7		double returned in \$v0
read_string	8	\$a0 = memory address of string input buffer \$a1 = length of string buffer (n)	
sbrk	9	\$a0 = amount	address in \$v0
exit	10		

- o The print\_string service expects the address to start a null-terminated character string. The directive .asciiz creates a null-terminated character string.
- o The read\_int, read\_float and read\_double services read an entire line of input up to and including the newline character.
- The read\_string service has the same semantices as the UNIX library routine fgets.
  - It reads up to n-1 characters into a buffer and terminates the string with a null character.
  - If fewer than n-1 characters are in the current line, it reads up to and including the newline and terminates the string with a null character.
- The sbrk service returns the address to a block of memory containing n additional bytes. This would be used for dynamic memory allocation.
- The exit service stops a program from running
- e.g.  $\,\,$  Print out integer value contained in register \$t2

```
li $v0, 1 # load appropriate system call code into register $v0; # code for printing integer is 1
move $a0, $t2 # move integer to be printed into $a0: $a0 = $t2
syscall # call operating system to perform operation
```

e.g. Read integer value, store in RAM location with label int\_value (presumably declared in data section)

```
li $v0, 5  # load appropriate system call code into register $v0;  # code for reading integer is 5 syscall  # call operating system to perform operation sw $v0, int_value  # value read from keyboard returned in register $v0;  # store this in desired location
```

e.g. Print out string (useful for prompts)

 $\underline{\text{e.g.}}$  To indicate end of program, use  $\underline{\text{exit}}$  system call; thus last lines of program should be: