# AC-DC power flow modeling technical note

Santiago Peñate Vera and Josep Fanals i Batllori

18th December 2023

## 1 Converter coupled AC-DC modeling

Converter coupled modeling was introduced in the PhD thesis of Abraham Álvarez (Universal branch model for the solution of optimal power flows in hybrid AC/DC grids). In this modeling framework the converters are treated as a regular branch with a shunt susceptance ( $b_{eq}$ ) that is used to make zero the reactive power at the DC side (the from side) of the branch.




Figure 1: Full Unified Branch Model.

The power flow linearization formulation is:

$$\begin{bmatrix} \frac{\partial P}{\partial \theta} & \frac{\partial P}{\partial Vm} & \frac{\partial P}{\partial beq} & \frac{\partial P}{\partial m} & \frac{\partial P}{\partial \tau} \\ \frac{\partial Q}{\partial \theta} & \frac{\partial Q}{\partial Vm} & \frac{\partial Q}{\partial beq} & \frac{\partial Q}{\partial m} & \frac{\partial Q}{\partial \tau} \\ \frac{\partial Q}{\partial \theta} & \frac{\partial Q}{\partial Vm} & \frac{\partial Q}{\partial beq} & \frac{\partial Q}{\partial m} & \frac{\partial Q}{\partial \tau} \\ \frac{\partial Q}{\partial \theta} & \frac{\partial Q}{\partial Vm} & \frac{\partial Q_f}{\partial beq} & \frac{\partial Q_f}{\partial m} & \frac{\partial Q_f}{\partial \tau} \\ \frac{\partial Q_f}{\partial \theta} & \frac{\partial Q_t}{\partial Vm} & \frac{\partial Q_t}{\partial beq} & \frac{\partial Q_t}{\partial m} & \frac{\partial Q_f}{\partial \tau} \\ \frac{\partial P}{\partial \theta} & \frac{\partial P}{\partial Vm} & \frac{\partial P}{\partial beq} & \frac{\partial P_f}{\partial m} & \frac{\partial P_f}{\partial \tau} \\ \frac{\partial P}{\partial \theta} & \frac{\partial P_f}{\partial Vm} & \frac{\partial P_f}{\partial beq} & \frac{\partial P_f}{\partial m} & \frac{\partial P_f}{\partial \tau} \\ \frac{\partial P}{\partial \theta} & \frac{\partial P_f}{\partial Vm} & \frac{\partial P_f}{\partial beq} & \frac{\partial P_f}{\partial m} & \frac{\partial P_f}{\partial \tau} \\ \end{bmatrix} \times \begin{bmatrix} \Delta \theta & \forall i_{pv} \cup i_{pq} \\ \Delta Vm & \forall i_{pq} \\ \Delta b_{eq} & \forall k_{zero}^b \cup k_{V_f}^b \\ \Delta m & \forall k_{Q_f}^m \cup k_{V_f}^m \cup k_{V_f}^m \\ \Delta \tau & \forall k_{P_f}^m \cup k_{P_f}^d \end{bmatrix} = \begin{bmatrix} \Delta P & \forall i_{pv} \cup i_{pq} \\ \Delta Q & \forall i_{pq} \cup i_{V_f}^b \cup i_{V_t}^m \\ \Delta Q_f & \forall k_{Q_f}^m \cup k_{zero}^b \\ \Delta Q_f & \forall k_{Q_f}^m \cup k_{Zero}^b \\ \Delta Q_t & \forall k_{Q_f}^m \cup k_{Q_f}^b \\ \Delta P_f & \forall k_{Q_f}^m \\ \Delta P_f & \forall k_{P_f}^f \\ \Delta P_{dp} & \forall k_{P_f}^d \end{bmatrix}$$

The droop power residual is:

$$\Delta P_{dp} = -P_f^{calc} - (P_f^{esp} + K_{dp} \cdot (Vm_f - Vm_f^{esp}))$$
(2)

Note that when formulating the problem, we have two bus-related unknowns  $(\Delta\theta, \Delta Vm)$  and two equations  $(\Delta P, \Delta Q)$  and for these, variations occur respecting the two-unknown, two-equations restriction. For the branches we have three unknowns  $(\Delta b_{eq}, \Delta m, \Delta \tau)$  and equations to match. So for the branches we must respect the relation of the branch unknowns to the branch equations. That is done with the indexing. Hence, the indices are very relevant in this formulation:

- $i_{pv}$ : Indices of the PV buses.
- $i_{pq}$ : Indices of the PQ buses.
- $k_{zero}^{beq}$ : indices of the branches (converters) making  $Q_f = 0$  with  $b_{eq}$ .

- $k_{V_f}^{b_{eq}}$ : indices of the branches controlling  $V_f$  with  $b_{eq}$ .
- $i_{V_f}^{b_{eq}}$ : indices of the from buses of branches controlling  $V_f$  with  $b_{eq}$ .
- $k_{Q_f}^m$ : indices of the branches controlling  $Q_f$  with m.
- $k_{Q_t}^m$ : indices of the branches controlling  $Q_t$  with m.
- $k_{V_t}^m$ : indices of the branches controlling  $V_t$  with m.
- $i_{V_t}^m$ : indices of the to buses of the branches controlling  $V_t$  with m.
- $k_{P_f}^{\tau}$ : indices of the branches controlling  $P_f$  with  $\tau$ .
- $k_{P_f}^{dp}$ : indices of the branches with voltage droop control.

Observe that i is used for bus indexing with the bus-related magnitudes  $(\theta, Vm, P \text{ and } Q)$ . k is used for branch related indexing with the branch-related magnitudes  $(b_{eq}, m, \tau, P_f, Q_f \text{ and } Q_t)$ 

#### 1.1 Example




Figure 2: Coupled converter model example grid.

## 2 Converter decoupled AC-DC modeling

The converter is a decoupled branch in the sent that the from and to sides are not galvanically connected in the model. Hence the coupling needs to be done via equations.




Table 1: General branch on the left. Decoupled converter model on the right

The power flow linearization formulation is:

$$\begin{bmatrix} \frac{\partial P}{\partial \theta} & \frac{\partial P}{\partial V_m} & \frac{\partial P}{\partial P_f} & \frac{\partial P}{\partial P_t} & \frac{\partial P}{\partial Q_t} \\ \frac{\partial Q}{\partial \theta} & \frac{\partial Q}{\partial V_m} & \frac{\partial Q}{\partial P_f} & \frac{\partial Q}{\partial P_t} & \frac{\partial Q}{\partial Q_t} \\ \frac{\partial P_{conv}}{\partial \theta} & \frac{\partial P_{conv}}{\partial V_m} & \frac{\partial P_{conv}}{\partial P_f} & \frac{\partial P_{conv}}{\partial P_t} & \frac{\partial P_{conv}}{\partial Q_t} \end{bmatrix} \times \begin{bmatrix} \Delta \theta & \forall i_{pv} \cup i_{pq} \\ \Delta V_m & \forall i_{pq} \\ \Delta P_f & \forall k_{conv} \\ \Delta P_t & \forall k_{conv} \\ \Delta Q_t & \forall k_{conv} \end{bmatrix} = \begin{bmatrix} \Delta P & \forall i_{pv} \cup i_{pq} \\ \Delta Q & \forall i_{pq} \\ \Delta P_{conv} & \forall k_{conv} \end{bmatrix}$$
(3)

Active power nodal balance:

$$\Delta P = P^{calc} - P^{esp} \tag{4}$$

Reactive power nodal balance:

$$\Delta Q = Q^{calc} - Q^{esp} \tag{5}$$

Converter power balance:

$$\Delta P_{conv} = P_f + P_t - P_{loss} \tag{6}$$

In this equation  $P_f$  and  $P_t$  are variables to be found iteratively.

#### 2.1 Example




Figure 3: Decoupled converter model example grid.

#### 2.2 Control mapping

It is assumed that each converter controls two magnitudes. Then, the control modes are the ones indicated in Table 2, as described in [alvarez2021universal]. The AC and DC sides of each control mode are classified into grid-forming (GFM) or grid-following (GFL) following the principles depicted in [gomis2020principles].

There are only 2 rules to be followed when setting the control modes of VSCs:

Table 2: Control modes and types of VSCs with the corresponding constraints.

Control mode	Constraint DC	Constraint AC	AC Type	DC Type
1	$\theta$	$V_t$	GFM	GFL
2	$P_f$	$Q_t$	$\operatorname{GFL}$	$\operatorname{GFL}$
3	$P_f$	$V_t$	$\operatorname{GFL}$	$\operatorname{GFL}$
4	$V_f$	$Q_t$	$\operatorname{GFL}$	$\operatorname{GFM}$
5	$V_f$	$V_t$	$\operatorname{GFL}$	$\operatorname{GFM}$
6	$V_f$ droop	$Q_t$	$\operatorname{GFL}$	$\operatorname{GFM}$
7	$V_f$ droop	$V_t$	$\operatorname{GFL}$	$\operatorname{GFM}$

- 1. Each AC grid has to have only 1 slack bus.
- 2. Each DC grid has to have only 1 slack bus.

The next step is to merge the controls in Table 2 with the system of equations (3). Table 3 identifies the map between the known and unknown variables and the controls.

Table 3: Control modes and types of VSCs with the corresponding constraints.

Control mode	Known DC	Known AC	Unknown DC	Unknown AC
1	-	$\theta, V_t$	$V_f, P_f$	$P_t, Q_t$
2	$P_f$	$Q_t$	$V_f$	$\theta, V_t, P_t$
3	$P_f$	$V_t$	$V_f$	$\theta, P_t, Q_t$
4	$V_f$	$Q_t$	$P_f$	$\theta, V_t, P_t$
5	$V_f$	$V_t$	$P_f$	$\theta, P_t, Q_t$
6	$V_f$ droop	$Q_t$	$P_f$	$\theta, V_t, P_t$
7	$V_f$ droop	$V_t$	$P_f$	$\theta, P_t, Q_t$