

Self-Study Summary Collection

Volume 1
Engineering

Anton Augustsson

January 17, 2026

Contents

1 Scope	5
2 Finite Element Method (FEM)	7
2.1 Introduction	7
2.2 Key Concepts	7
2.3 Steps in FEM	8
2.4 Mathematical Formulation	8
2.5 Advantages and Applications	9
3 Computer Aided Design	11
4 Material Science	13
4.1 Plastics	13
4.1.1 Nylon	13
4.1.2 PLA	13
4.1.3 ABS	13
4.2 Composites	13
4.2.1 Carbon Fiber	13
4.2.2 Kevlar	13
4.3 Metals	13
4.3.1 Aluminum	13
4.3.2 Titanium	13
4.3.3 Bronze	13
4.3.4 Copper	13
4.3.5 Iron	13
4.3.6 Steel	13
4.3.7 Carbon Steel	13
4.3.8 Stainless steel	13
4.3.9 Metal Alloys	13
4.4 Metal Hardening	14
4.4.1 Bulk Hardening	14
4.4.2 Case Hardening	15
4.4.3 Hardening by Microstructural Control	15
4.4.4 Thermo-Mechanical Treatments	16
5 Machining	17
6 Molding	19

7 Electronics Manufacturing	21
8 Semiconductors Manufacturing	23
9 Metrology	25
10 Hydraulics	27
10.1 Introduction and Fluid Properties	27
10.2 Pascals Law with Examples for Hydraulic Systems	27
10.2.1 Pascals Law	27
10.2.2 Force Multiplier	27
10.2.3 Hydraulic Cylinder	28
10.3 Hydraulic Schematics	28
10.4 Series and Parallel Hydraulic Circuits	29
10.5 Hydronic Cylinder	29
10.6 Check Valves	29
10.7 Pressure Relief Valves	29
10.8 Directional Control Valves	29
10.9 Accumulators	29
10.10 Filters and Conditioning	29
10.11 Hydraulic Pumps	29
10.11.1 Gear Pumps	29
10.11.2 Vane Pumps	29
10.11.3 Piston Pumps	29
10.12 Flow Control Valves	29
10.13 Flow Control Methods	29
10.13.1 Meter In	29
10.13.2 Meter Out	29
10.13.3 Bypass	29
10.14 Vented and Remote Controlled Pressure Relief Valves	29
10.15 Sequence Valves	29
10.16 Pressure Reducing Valves	29
10.17 Introduction to Electronically Controlled Systems	29
10.18 Control Relays	29

Chapter 1

Scope

Chapter 2

Finite Element Method (FEM)

2.1 Introduction

The **Finite Element Method (FEM)** is a numerical technique for solving boundary value problems in engineering and mathematical physics. It subdivides a large problem into smaller, simpler parts called *finite elements*, and then systematically reassembles them into a global solution.

Can be used for different types of analysis.

- Solid mechanics:
 - Static analysis;
 - Dynamic analysis;
 - Buckling analysis;
 - Modal analysis;
- Fluid mechanics;
- Heat transfer;
- Electromagnetic;

2.2 Key Concepts

- **Domain Discretization:** The problem domain is divided into finite elements (triangles, quadrilaterals, tetrahedra, etc.), which creates a *mesh*. There are also different dimensions the element can be, i.e., 1D: Line, 2D: surface, 3D: solid;
- **Field variables:** the forces affect the solid object in static analysis, e.g stresses, strains, displacement.
- **Displacement vector:** each node, i.e., a connection point to another element, has some degrees of freedom that represents axial, bending, shear and torsional in the case of a line element. For a line element the displacement vector $\{u\}$ will be $\{u_1, v_1, \theta_1, u_2, v_2, \theta_2\}^T$, see figure ???. Displacement vector $\{u\} = \{u_1, v_1, w_1, \theta_{x1}, \theta_{y1}, \theta_{z1}, u_2, v_2, w_2, \theta_{x2}, \theta_{y2}, \theta_{z2}\}^T$
- **Shape Functions:** Interpolation functions (often denoted by ϕ_i) that approximate the solution within each element.

- **Weak Formulation:** The problem is reformulated into a *weak* or *variational form*, typically by applying the method of weighted residuals.
- **Stiffness Matrix:** A system of algebraic equations is derived from the weak form, resulting in a global stiffness matrix \mathbf{K} .




Figure 2.1: fig:displacement-vector

2.3 Steps in FEM

1. **Discretization of the Domain:** Divide the domain into finite elements.
2. **Selection of Shape Functions:** Choose shape functions ϕ_i to approximate the solution.
3. **Derivation of Element Equations:** Formulate the element stiffness matrix \mathbf{K}_e and force vector \mathbf{F}_e .
4. **Assembly of Global System:** Assemble all element equations into a global system:

$$\mathbf{K}\mathbf{u} = \mathbf{F}$$

where \mathbf{K} is the global stiffness matrix, \mathbf{u} is the nodal displacement vector, and \mathbf{F} is the global force vector.

5. **Application of Boundary Conditions:** Apply constraints and boundary conditions to the system.
6. **Solution of Algebraic Equations:** Solve the resulting system of equations for nodal values.
7. **Post-Processing:** Compute derived quantities (stresses, strains) and visualize results.

2.4 Mathematical Formulation

Weak Form: For a general PDE of the form: $\mathcal{L}(u) = f$ in Ω with boundary conditions: $u = u_D$ on Γ_D and $\nabla u \cdot \mathbf{n} = q$ on Γ_N . The weak form is: $\int_{\Omega} \phi \mathcal{L}(u) d\Omega = \int_{\Omega} \phi f d\Omega + \int_{\Gamma_N} \phi q d\Gamma$ for all test functions ϕ .

2.5 Advantages and Applications

- **Advantages:**

- Can handle complex geometries and boundary conditions.
 - Applicable to various types of problems (structural, thermal, fluid dynamics).

- **Applications:**

- Structural analysis (stress and deformation).
 - Heat transfer.
 - Fluid flow.
 - Electromagnetic fields.

Chapter 3

Computer Aided Design

Chapter 4

Material Science

4.1 Plastics

4.1.1 Nylon

4.1.2 PLA

4.1.3 ABS

4.2 Composites

4.2.1 Carbon Fiber

4.2.2 Kevlar

4.3 Metals

4.3.1 Aluminum

4.3.2 Titanium

4.3.3 Bronze

4.3.4 Copper

4.3.5 Iron

4.3.6 Steel

4.3.7 Carbon Steel

4.3.8 Stainless steel

4.3.9 Metal Alloys

4.4 Metal Hardening




Figure 4.1: Metal hardening processes and their resulting material properties

4.4.1 Bulk Hardening

These processes change the microstructure throughout the entire part, primarily for ferrous metals (steels).

Quenching and Tempering

- **Process:** Austenitizing (heating to a high temperature), then rapidly cooling (quenching) in oil, water, or polymer to form a very hard, brittle martensitic structure. This is followed by tempering (reheating to a lower temperature) to reduce brittleness and achieve the desired toughness/hardness balance.
- **Result:** High strength and good toughness.

Austempering

- **Process:** An interrupted quench where the steel is cooled rapidly to a temperature above martensite formation and held (isothermally transformed) to form bainite.
- **Result:** Good strength and ductility with less distortion than conventional quench and temper.

Martempering

- **Process:** Similar to austempering, but the part is cooled through the martensite transformation range and then tempered. The martensite transformation range is the specific temperature interval during rapid cooling where austenite in a steel transforms into martensite, starting at the Martensite Start (M_s) temperature and ending at the Martensite Finish (M_f) temperature. The goal is to minimize thermal stress and distortion.
- **Result:** Martensite structure with reduced risk of cracking and distortion.

4.4.2 Case Hardening

These processes harden only the outer surface ("case") of the part while maintaining a softer, tougher interior ("core"). Ideal for wear-resistant components that must withstand impact.

Carburizing

- **Process:** The part is heated in a carbon-rich environment (gas, solid, or liquid). Carbon diffuses into the surface, creating a high-carbon layer. It is subsequently quenched to harden the carbon-rich case.
- **Result:** A hard, wear-resistant surface over a tough core.

Nitriding

- **Process:** The part is heated in an atmosphere of ammonia gas or plasma (ion nitriding). Nitrogen atoms diffuse into the surface, forming very hard nitride compounds without the need for a quenching step.
- **Result:** Extremely hard surface, excellent wear and fatigue resistance, minimal distortion.

Carbonitriding

- **Process:** Similar to gas carburizing, but the atmosphere contains both carbon and nitrogen. This allows for hardening at a slightly lower temperature.
- **Result:** A hard case with better hardenability than carburizing alone.

Induction Hardening

- **Process:** An alternating current is passed through a copper coil, generating a localized magnetic field that rapidly heats the surface of a steel part. The part is then immediately quenched.
- **Result:** A localized, hard surface layer. Very fast and efficient.

Flame Hardening

- **Process:** Similar to induction hardening, but an oxy-acetylene flame is used to heat the surface instead of an electromagnetic induction.
- **Result:** A hard surface layer. More suitable for large parts or low-volume production.

4.4.3 Hardening by Microstructural Control

These methods strengthen a material by altering its internal structure through chemistry or processing.

Precipitation Hardening

- **Process:** Primarily for aluminum, magnesium, nickel, and stainless steels. The alloy is solution treated, quenched, and then aged (heated to a moderate temperature). Fine particles "precipitate" within the matrix, impeding dislocation movement.
- **Result:** Very high strength-to-weight ratio.

Work Hardening

- **Process:** A metal is plastically deformed at a temperature below its recrystallization point (e.g., by cold rolling, hammering, drawing). This deformation increases dislocation density, making further deformation more difficult.
- **Result:** Increased strength and hardness, but decreased ductility.

Solid Solution Hardening

- **Process:** The base metal (solvent) has atoms of an alloying element (solute) dissolved within its crystal lattice. The solute atoms distort the lattice, creating stress fields that impede dislocation motion.
- **Result:** A stronger, harder alloy than the pure metal. (e.g., Brass is harder than pure copper due to zinc atoms in solution).

4.4.4 Thermo-Mechanical Treatments

These combine controlled plastic deformation and heat treatment to achieve superior properties.

Ausforming

- **Process:** Steel is plastically deformed in a metastable austenitic condition (after cooling from austenitizing but before transforming to pearlite or bainite) and then quenched to form martensite.
- **Result:** Exceptional combination of strength and toughness.

Chapter 5

Machining

Chapter 6

Molding

Chapter 7

Electronics Manufacturing

Chapter 8

Semiconductors Manufacturing

Chapter 9

Metrology

Chapter 10

Hydraulics

This compendium on hydraulics is based on Jim Pytel excellent course called “Hydraulics Training” on YouTube. I highly recommend viewing it, its also more correct than what is written in this compendium since Mr. Pytel is much more knowledgeable about Hydraulics than me. Additional, Yuken Kogyo Co.,LTD has an great book on hydraulics [1].

10.1 Introduction and Fluid Properties

Hydraulics systems transfer power by fluid within a close system. The advantage over pneumatic systems, which uses air, is that most fluids are incompressible, resulting in the ability of hydraulic actuators, e.g., hydraulic cylinder, to hold its position even under high loads.

A substance’s resistance to uniform compression is measured in terms of Bulk modulus (B), $B = \Delta P/(\Delta V/V)$, where P is pressure and V is volume. For water the bulk modulus is 2190 MPa [2] in 20 C and in typical heavy machinery application the pressure is between 20–35 MPa, meaning that the volume will only decrease about 9-15.9 mL for each liter of water. Water is typically not used in hydronic systems, instead mineral-based hydraulic oil that are derived from crude oil or synthetic-based hydraulic oil, which have a slightly lower bulk module. But even for high pressure systems 50 MPa under 20 C the bulk modulus is 1880 MPa [3], resulting a volume decrease of.... Temperature has a greater effect on volume, however, both need to be taken into account.

Mineral-based and synthetic-based hydronic oil has additional properties over water, it acts as a lubricant. It also provides a seal for hydraulic cylinders, unlike water that could leak between chambers?

Another properties...

10.2 Pascals Law with Examples for Hydraulic Systems

10.2.1 Pascals Law

A pressurized static fluid in a closed vessel exerts pressure equally in all direction throughout the fluid and works octagonal on a plane. Pressure (P [Pa or psi]) can be expressed as a fraction of the force (F [Nm or lbf]) per unit area (A [m^2 or in^2]).

$$P = \frac{F}{A}$$

10.2.2 Force Multiplier

A small weight providing small force can lift a large weight requiring large force.




Figure 10.1: Positively charged rod next to some conductive object

10.2.3 Hydraulic Cylinder

A small weight providing small force can lift a large weight requiring large force.




Figure 10.2



(a) Hydraulic Cylinder expressed in force with pressure P_1/P_2 , areas A_1/A_2 , and force F_0/F_1 .(b) Hydraulic Cylinder expressed in speed with flow rate Q_1/Q_2 , areas A_1/A_2 , and speed V_1 .

Figure 10.3

10.3 Hydraulic Schematics



10.4 Series and Parallel Hydraulic Circuits**10.5 Hydronic Cylinder****10.6 Check Valves****10.7 Pressure Relief Valves****10.8 Directional Control Valves****10.9 Accumulators****10.10 Filters and Conditioning****10.11 Hydraulic Pumps****10.11.1 Gear Pumps****10.11.2 Vane Pumps****10.11.3 Piston Pumps****10.12 Flow Control Valves****10.13 Flow Control Methods****10.13.1 Meter In****10.13.2 Meter Out****10.13.3 Bypass****10.14 Vented and Remote Controlled Pressure Relief Valves****10.15 Sequence Valves****10.16 Pressure Reducing Valves****10.17 Introduction to Electronically Controlled Systems****10.18 Control Relays**

Bibliography

- [1] YUKEN KOGYO CO.,LTD. Overseas Business Department, *Basic Hydraulics and Components*. Hamamatsucho Seiwa Bldg., 4-8, Shiba-Daimon 1-Chome, Minato-ku, Tokyo 105-0012, JAPAN: YUKEN KOGYO CO.,LTD., Mar. 2006, Printed in Japan, ISBN: Not provided.
- [2] C. E. Brennen, *An Internet Book on Fluid Dynamics*. 2024, Accessed: 2025-12-31. [Online]. Available: <http://brennen.caltech.edu/fluidbook/>.
- [3] H. Gholizadeh, R. Burton, and G. Schoenau, “Fluid bulk modulus: A literature survey,” *International Journal of Fluid Power*, 2019, Unpublished manuscript or technical report.