Contents

| | | Page |
|----------|---|------|
| 1 | Introduction | 11 |
| 2 | Advanced Encryption System 128 | 12 |
| | 2.1 Overview | . 12 |
| | 2.2 Algorithm | . 13 |
| 3 | Key addition and inversion | 14 |
| | 3.1 Add Round Key | . 14 |
| | 3.2 Inverse Add Round Key | . 15 |
| 4 | Substitution Operation | 16 |
| | 4.1 Substitution bytes() Transformation | . 16 |
| | 4.2 Inverse Sub-bytes() Transformation | . 18 |
| 5 | Shifting Operation | 20 |
| | 5.1 Shift-Rows() Transformation | . 20 |
| | 5.2 Inverse Shift-Rows() Transformation | . 21 |
| 6 | Column Operations | 22 |
| | 6.1 Mix Column | . 22 |
| | 6.2 Inverse Mix Column | . 27 |
| 7 | Key Expansion | 31 |
| | 7.1 SubByte, Rotword and RoundConstant (Rcon) | . 32 |
| | 7.2 Key Expansion in Pictures | . 34 |
| 8 | \mathbf{UART} | 36 |
| | 8.1 UART for 8 bit Data Transfer | . 36 |
| 9 | UART 128 bits | 38 |
| | 9.1 Baud Bate | 38 |

| | 9.2 | Uart Transmitter | 38 |
|----|------|--|-----------|
| | 9.3 | Uart Receiver | 42 |
| 10 | Pip | belined Implementation | 46 |
| | 10.1 | Encryption Pipeline | 47 |
| | | 10.1.1 Division of encryption circuit into three parts | 47 |
| | | 10.1.2 Three circuits for Encryption | 48 |
| | | 10.1.3 Final Encryption Pipeline | 50 |
| | 10.2 | Decryption Pipeline | 51 |
| | | 10.2.1 Division of decryption circuit into three parts | 51 |
| | | 10.2.2 Three circuits for Decryption | 52 |
| | | 10.2.3 Final Decryption Pipeline | 54 |
| | 10.3 | Full Implementation | 55 |
| 11 | Res | sult | 56 |
| | 11.1 | Simulation for encryption with uart | 56 |
| | 11.2 | Simulation for decryption with uart | 56 |
| | 11.3 | FPGA Implementation | 56 |
| 12 | Cha | allenges | 57 |
| 13 | Coı | nclusion | 58 |
| 14 | Ver | CODE : | 59 |
| | 14.1 | $encryption_main.v \dots \dots$ | 59 |
| | 14.2 | main_encrypt.v | 59 |
| | 14.3 | encrypt_first.v | 60 |
| | 14.4 | $encrypt_mid.v \dots \dots \dots \dots \dots \dots \dots \dots \dots $ | 62 |
| | 14.5 | encrypt_final.v | 63 |
| | 14.6 | main_first.v | 65 |
| | 14.7 | main_mid.v | 65 |
| | 14.8 | main final.y | 66 |

| | 14.9 addRoundKey.v | 66 |
|----|-------------------------------|-----|
| | 14.10substitution.v | 66 |
| | 14.11aes_S_box.v | 67 |
| | 14.12 <i>shift_rows.v</i> | 69 |
| | 14.13mix_col.v | 69 |
| | $14.14GF_2_8multiplier.v$ | 70 |
| 15 | Verilog: Decryption(CODE) | 71 |
| | 15.1 decryption_main.v | 71 |
| | 15.2 inverse_main_decrypt.v | 72 |
| | 15.3 decrypt_first.v | 73 |
| | 15.4 decrypt_mid.v | 74 |
| | 15.5 decrypt_final.v | 76 |
| | 15.6 inverse_main_first.v | 78 |
| | 15.7 inverse_main_mid.v | 78 |
| | 15.8 inverse_main_final.v | 79 |
| | 15.9 addRoundKey.v | 79 |
| | $15.10 Inv_substitution.v$ | 79 |
| | $15.11aes_invS_box.v$ | 80 |
| | $15.12inv_shift_rows.v$ | 81 |
| | $15.13 inverse_mix_col.v$ | 82 |
| | 15.14inv_GF_2_8 multiplier.v | 83 |
| 16 | Verilog : Key Expansion(CODE) | 84 |
| | 16.1 key.v | 84 |
| | 16.2 key_expand.v | 85 |
| | 16.3 aes_sbox.v | 86 |
| 17 | Verilog: UART(CODE) | 88 |
| | 17.1 rx.v | 88 |
| | 18.0.4 | 0.1 |

| 18 Device Compilation Code | 93 |
|--------------------------------------|----|
| 18.1 main.v for FPGA with encryption | 93 |
| 18.2 main.v for FPGA with decryption | 94 |

List of Figures

| | | Page |
|----|--|------|
| 1 | AES-128 | . 12 |
| 2 | Inverse Add Round Key Pseudo Circuit | . 14 |
| 3 | Add Round Key Schematics | . 14 |
| 4 | Add Round Key Pseudo Circuit | . 15 |
| 5 | Inverse Add Round Key Schematics | . 15 |
| 6 | Substitution Bytes Pseudo Circuit | . 16 |
| 7 | Sub-bytes Schematic View | . 17 |
| 8 | Inverse Substitution Bytes Pseudo Circuits | . 18 |
| 9 | Inverse Sub-bytes Schematic View | . 19 |
| 10 | Shift Rows Pseudo Circuits | . 20 |
| 11 | Inverse Shift Rows Pseudo Circuits | . 21 |
| 12 | Mix Column Pseudo Circuits | . 22 |
| 13 | Pseudo Circuit for multiplication by 1 | . 23 |
| 14 | Pseudo Circuit for multiplication by 2 | . 24 |
| 15 | Pseudo Circuit for multiplication by 3 | . 25 |
| 16 | Pseudo Circuit for multiplication by 3 | . 25 |
| 17 | Schematic View of Mix Columns | . 26 |
| 18 | Inverse Mix Column Pseudo Circuits | . 27 |
| 19 | Pseudo Circuit for multiplication by 09 | . 28 |
| 20 | Pseudo Circuit for multiplication by 0B | . 28 |
| 21 | Pseudo Circuit for multiplication by 0D | . 29 |
| 22 | Pseudo Circuit for multiplication by 0E | . 29 |
| 23 | Schematic View of Inverse Mix Columns | . 30 |
| 24 | Key Generation pseudo circuit | . 31 |
| 25 | Key Generation pseudo code | . 31 |
| 26 | Round Constant(RCON) | . 32 |
| 27 | AES 128 Key Schedule | 34 |

| 28 | AES_128 Key Expansion Schematics | 35 |
|----|---|----|
| 29 | UART | 37 |
| 30 | UART-128 bit Transmitter Input Output | 38 |
| 31 | UART-128 bit Transmitter State Diagram | 39 |
| 32 | State Init | 40 |
| 33 | State Setup | 40 |
| 34 | State Writedata | 41 |
| 35 | UART-128 bit Receiver Input Output | 42 |
| 36 | UART-128 bit Receiver State Diagram | 42 |
| 37 | State Init | 43 |
| 38 | State Start | 43 |
| 39 | State Read data | 44 |
| 40 | State Stop | 44 |
| 41 | Every rising edge of FPGA clock | 45 |
| 42 | Full AES Encryption, Decryption and Key Generation | 46 |
| 43 | Full AES_128 bit Encryption | 47 |
| 44 | Encryption Broken down to different parts that can be in turn implemented to state machine. | 47 |
| 45 | Three main circuit for Encryption | 48 |
| 46 | State machine implementation of different part of Encryption | 49 |
| 47 | Final Encryption Pipeline | 50 |
| 48 | Full AES_128 bit Decryption | 51 |
| 49 | Decryption broken down to different parts that can be in turn implemented to state machine. | 51 |
| 50 | Three main circuit for Decryption | 52 |
| 51 | State machine implementation of different part of Decryption | 53 |
| 52 | Final Decryption Pipeline | 54 |
| 53 | State machine implementation of different parts of Encryption | 55 |
| 54 | Final implementation, Computer to FPGA with encryption | 56 |
| 55 | Final implementation, FPGA to Computer with decryption | 56 |
| 56 | Timing error without pipeline of encryption/decryption | 57 |
| 57 | Timing error with pipeline of encryption/decryption: 2 circuits | 57 |

List of Tables

| | | Page |
|----|---|------|
| 1 | AES Transformation Method | . 12 |
| 2 | Add Round Key | . 14 |
| 3 | Inverse Add Round Key | . 15 |
| 4 | Sub bytes () Transformation | . 17 |
| 5 | Inverse Sub bytes () Transformation | . 19 |
| 6 | Shift Rows () Transformation | . 20 |
| 7 | Inverse Shift Rows () Transformation | . 21 |
| 8 | Mix Col Matrix and Input Data Matrix | . 22 |
| 9 | Mix Column Operation | . 22 |
| 10 | Column wise multiplication in Mix Col Operation | . 22 |
| 11 | Remainder of 100000000 when divided by irreducible polynomial (2^8) | . 23 |
| 12 | Algorithm for Multiplication by 2 | . 23 |
| 13 | Inverse Mix Col Matrix and Input Data Matrix | . 27 |
| 14 | Inv Mix Column Operation | . 27 |
| 15 | Column wise multiplication in Inv Mix Col Operation | . 27 |
| 16 | Round Constant(RCON) Generation Over Galios Field (2^8) | . 33 |
| 17 | Baudrate and clocks per bit selection | . 38 |
| 18 | Input/Output wire for Uart Transmitter | . 39 |
| 19 | Input/Output wire for Uart Reciever | . 42 |
| 20 | Input/Output wires for First, Between and last | . 50 |
| 21 | Input/Output wires for First, Between and last | . 54 |

1. Introduction

With the advent of the digital age, data became the definition of the world around us describing not only the ambient surrounding but also our personal information. Each data shared between two parties could be easily accessible bestowing utmost transparency of concerned parties. Hence, the requirement to securely transfer data became inevitable. Several encryption techniques utilizing the substitution of each letter to a known and reversible data field came into existence. But, computing power allowed illegal personnel to decrypt data without authorization. Hence, powerful techniques were required which were immune to attacks but simpler to process and exchange files. Encryption techniques with personal keys with the aid of already defined abstract algebra came into popularity. People with keys could easily extract information from jargon and people without keys would be unable to decrypt despite huge processing power.

Advanced Encryption Standard (AES) is a symmetric block cipher defined in US Federal Information Processing Standard (FIPS). AES comes in three versions; AES_128, AES_192, and AES_256. The personal key and the data slice taken are represented by the numeric part of the AES naming system[5]. AES is one of the most widely used and proven encryption systems used all around the world. AES has resisted all crypto-analysis and proved unbreakable since its introduction. This paper explores what makes AES such a successful cryptography technique.

AES encryption system consists of four main operations in encryption and a similar set of operations in decryption which equalizes the four operations of encryption. Each operation involves different hardware configurations. Verilog, a hardware description language was used for producing the synthesizable design and its verification. These hardware configurations were written in a modular format and are reused throughout each process described in the report.

The other important part of the project was the real-time communication of the Field Programmable Gate Arrays(FPGA) boards using AES Encryption and Decryption. The communication method of choice implemented between the devices was UART, which stands for Universal Asynchronous Receiver/Transmitter. UART, an asynchronous serial data transmission protocol was chosen for this particular project because of its simplicity as well as its minimalist techniques. The basic unit of operation is an 8-bit method that is 8-bits of data is sent or received at a time, and which is expanded to 16 rounds to make it compatible with 128-bit AES. To conclude, whilst plain data see 8-bit data transfer, encrypted/decrypted data works with 16 8-bit data transfers in tandem.

This project is successful in creating a secure real-time communication link between FPGAs, each with AES-128 bits encryption and decryption. This paper is wrapped around the details of the AES, each sub-process involved in encryption and decryption techniques, UART protocol and implementation, communicating different FPGAs as well as with a computer, describing hardware schematics as well as documenting the results after each process and the final outcome.

2. Advanced Encryption System 128

2.1. Overview

AES is based on a design principle known as a substitution–permutation network, and is efficient in both software and hardware [key1]. AES takes in data in blocks of 128 bits and encrypts them using the input 128 bit cipher key. The basic processing unit for AES algorithm is byte and all operations are done in the Galios finite field (2^8) . The finite field operations are performed on two dimensional 4^*4 array of bytes which is known as State.

Table 1: AES Transformation Method

| | Each box represent 8 bit out of 128 bit | | | | | | | | | | | | | |
|---------|---|-------|------------|---------------|---------|------|------|---------------|---------------|-----------|-----------|--------|-------------|--|
| in_00 | in_04 | in_08 | in_12 | \rightarrow | S_00 | S_04 | S_08 | S_12 | \rightarrow | out_00 | out_04 | out_08 | out_12 | |
| in_01 | in05 | in_09 | $in_{-}13$ | \rightarrow | S_01 | S_05 | S_09 | S_13 | \rightarrow | out_01 | out_05 | out_09 | out_13 | |
| in_02 | in_06 | in_10 | in_14 | \rightarrow | S_02 | S_06 | S_10 | S_14 | \rightarrow | out_02 | out_06 | out_10 | $out_{-}14$ | |
| in_03 | in_07 | in_11 | $in_{-}15$ | \rightarrow | S_03 | S_07 | S_11 | S_15 | \rightarrow | out_03 | out_07 | out_11 | out_15 | |
| | Inp | out | | \rightarrow | Process | | | \rightarrow | Output | | | | | |

The input plain-text is pasted into state as shown above and all operations are done into the state. The end state is then taken as output. Here's the main breakdown of all operations involved with AES Encryption and Decryption.




Figure 1: AES-128

2.2. Algorithm

1. Encryption Algorithm

- (a) Key Expansion: Eleven Round Keys are generated from the input cipher key using Key Expansion algorithm.
- (b) Addition of Initial Round Key: A bitwise-XOR operation of initial roundkey (k0) is carried out with the input data of 128 bits.
- (c) 9 Rounds of Transformations: Following transformations take place in each round, for a total of nine rounds. As a round is completed, it goes to the beginning of round until completion of 9 rounds. The key changes in each round from (k1) all the way to k(9).
 - SubBytes: Each byte of the state is substituted non-linearly using Rijndael S-box.
 - ShiftRows: The 16 byte data is arranged in 4 by 4 grid, and shiftRows transformation () is carried out in the grid.
 - MixColumns: The columns of the 4×4 matrix is multiplied to a mix_colmns matrix to obtain output.
 - AddRoundKey: A bitwise-XOR operation of the expanded roundkey is carried out with the data of 128 bits.

(d) 10th Round:

- SubBytes: Each byte of the state is substituted non-linearly using Rijndael S-box.
- ShiftRows: The 16 byte data is arranged in 4 by 4 grid, and shiftRows transformation () is carried out in the grid.
- AddRoundKey: A bitwise-XOR operation of the expanded roundkey is carried out with the data of 128 bits.

2. Decryption Algorithm

- (a) Initial round:
 - AddRoundKey: A bitwise-XOR operation with last part of the expanded roundkey(k10) is carried out with the encrypted data of 128 bits.
 - invShiftRows: Iverse shift row() transformation is done on the output from the step above.
 - invSubBytes: Each byte of the state is substituted non-linearly using Rijndael S-box.
- (b) 9 Rounds of Transformations: Following transformations take place in each round, for a total of nine rounds. As a round is completed, it goes to the beginning of round until completion of 9 rounds. The key changes in each round for (k9) all the way to k(1).
 - AddRoundKey: A bitwise-XOR operation of the expanded roundkey is carried out with the data of 128 bits.
 - invMixColumns: The columns of the 4×4 matrix is multiplied to a inv_mix_colmns matrix to obtain output. The inv_mix_colmns matrix is the inverse of mix_columns matrix in $GF(2^8)$.
 - invShiftRows: Iverse shift row() transformation is done on the output from the step above.
 - invSubBytes: Each byte of the state is substituted non-linearly using Rijndael S-box.
- (c) 10th Round: The ouput from the above step is now XOR'ed with the intial round key (k0) generated through key expansion algorithm.

3. Key addition and inversion

3.1. Add Round Key



Figure 2: Inverse Add Round Key Pseudo Circuit

In Galios Field(2^8) the addition operator is realized by bitwise \bigoplus operation. AES encryption is based on Galios Field(2^8). The add round key operation is performed by using bitwise \bigoplus operator. This operation defines the relationship between the key used in the encryption and the data. With the initial decided key that is shared by two concerned organization, both organization employ key expansion methods to produce 10 more keys. [4] Add round key is employed 11 different times to mask the data to be encrypted.

• Pseudo Code for Add Round Key

$Output \ of \ Add \ Round \ Key = 128 ext{-}Bit \ Input \ Data igoplus 128 ext{-}Bit \ Key$

The 128-Bit data and 128-Bit key are both arranged in 4×4 matrix for graphical representation. Each element in the matrix cell in 8-Bit data. Corresponding element from key matrix and data matrix are taken and bit wise \bigoplus operation is performed to obtain the output as shown in the table 18.In hardware level, the linear busses are arranged for the required configuration instead of creating a 2D busses.





Figure 3: Add Round Key Schematics.



3.2. Inverse Add Round Key



Figure 4: Add Round Key Pseudo Circuit

Bitwise \bigoplus toggles the bits of input data, whenever there is '1', is the corresponding bit of the Key used in add round key. Hence, repeating the process using the same key again toggles the same bits to produce the original data. In terms of abstract algebra, in Galois Field(2⁸) each number is its own additive inverse.[4] Hence, the addition operator is realized by bitwise \bigoplus operation and the subtraction operator is also realized by the bitwise \bigoplus operation. The inverse add round key operation is performed by using bitwise \bigoplus operator between the cryptic data and the same key used to create the cryptic data from the original one.

• Pseudo Code for Add Round Key

$$Original\ Data = Cryptic\ Data igoplus 128 ext{-}Bit\ Key$$





Figure 5: Inverse Add Round Key Schematics.



4. Substitution Operation

4.1. Substitution bytes() Transformation




Figure 6: Substitution Bytes Pseudo Circuit

The Sub-bytes Transformation () is a byte substitution operation performed on each individual byte of the 128-bit data. Each byte is substituted to a different byte using a well-defined substitution box called S-box. S-box contains a mapping of each byte from 00 to FF.

| | ng. AE5-5ubstitution box | | | | | | | | | | | | | | | |
|---|--------------------------|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|
| | 0 | 1 | 2 | 3 | 4 | 5 | 6 | 7 | 8 | 9 | a | b | c | d | e | f |
| 0 | 63 | 7C | 77 | 7B | F2 | 6B | 6F | C5 | 30 | 01 | 67 | 2B | FE | D7 | AB | 76 |
| 1 | CA | 82 | С9 | 7D | FA | 59 | 47 | F0 | AD | D4 | A2 | AF | 9C | A4 | 72 | C0 |
| 2 | В7 | FD | 93 | 26 | 36 | 3F | F7 | CC | 34 | A5 | E5 | F1 | 71 | D8 | 31 | 15 |
| 3 | 04 | C7 | 23 | С3 | 18 | 96 | 05 | 9A | 07 | 12 | 80 | E2 | EB | 27 | B2 | 75 |
| 4 | 09 | 83 | 2C | 1A | 1B | 6E | 5A | A0 | 52 | 3B | D6 | В3 | 29 | E3 | 2F | 84 |
| 5 | 53 | D1 | 00 | ED | 20 | FC | B1 | 5B | 6A | СВ | BE | 39 | 4A | 4C | 58 | CF |
| 6 | D0 | EF | AA | FB | 43 | 4D | 33 | 85 | 45 | F9 | 02 | 7F | 50 | 3C | 9F | A8 |
| 7 | 51 | A3 | 40 | 8F | 92 | 9D | 38 | F5 | ВС | В6 | DA | 21 | 10 | FF | F3 | D2 |
| 8 | CD | 0C | 13 | EC | 5F | 97 | 44 | 17 | C4 | A7 | 7E | 3D | 64 | 5D | 19 | 73 |
| 9 | 60 | 81 | 4F | DC | 22 | 2A | 90 | 88 | 46 | EE | В8 | 14 | DE | 5E | 0B | DB |
| a | E0 | 32 | 3A | 0A | 49 | 06 | 24 | 5C | C2 | D3 | AC | 62 | 91 | 95 | E4 | 79 |
| b | E7 | C8 | 37 | 6D | 8D | D5 | 4E | A9 | 6C | 56 | F4 | EA | 65 | 7A | AE | 08 |
| c | BA | 78 | 25 | 2E | 1C | A6 | B4 | C6 | E8 | DD | 74 | 1F | 4B | BD | 8B | 8A |
| d | 70 | 3E | B5 | 66 | 48 | 03 | F6 | 0E | 61 | 35 | 57 | В9 | 86 | C1 | 1D | 9E |
| e | E1 | F8 | 98 | 11 | 69 | D9 | 8E | 94 | 9B | 1E | 87 | E9 | CE | 55 | 28 | DF |
| f | 8C | A1 | 89 | 0D | BF | E6 | 42 | 68 | 41 | 99 | 2D | 0F | В0 | 54 | BB | 16 |

fig: AES-Substitution Box

The S-box is constructed by performing the following transformation:

- Calculate the multiplicative inverse in the finite field $GF(2^8)$ of the byte.
- Apply the following transformation to the byte: $b_i' = b_i \bigoplus b_{(i+4)mod8} \bigoplus b_{(i+5)mod8} \bigoplus b_{(i+6)mod8} \bigoplus b_{(i+7)mod8} \bigoplus c_i$ Here, b_i represents i^th bit of the byte and c_i represents i^th of a constant byte with a value of 63.

The second operation is performed in each bit of the entire byte b_0 through $b_7[[5]]$. As the above two transformations are performed in each byte ranging from 00 to FF, a S-box is generated which contains the unique mapping of each byte as shown below:

And, the substitution byte for the input byte is determined by looking at the intersection of row and column. For example, the substitution byte of 59 will the intersection of a row with index '5' and column with index '9' which is cb. It can be located in the substitution box below.

• Pseudo code for substitution byte transformation :

S-box(data[0:7], substituted-data[0:7])

This is for the first byte and it goes all the way down to 16^{th} byte where a byte is mapped to a different byte using the S-box.

Table 4: Sub bytes () Transformation

| A0 | A4 | A8 | A12 | | S0 | S4 | S8 | S12 |
|----|----|-----|-----|---|----|----|-----|-----|
| | | | A13 | | | | s9 | |
| A2 | A6 | A10 | A14 | = | S2 | S6 | S10 | S14 |
| A3 | A7 | A11 | A15 | | S3 | S7 | S11 | S15 |

The schematics of sub-bytes() transformation is shown below:




Figure 7: Sub-bytes Schematic View

4.2. Inverse Sub-bytes() Transformation




Figure 8: Inverse Substitution Bytes Pseudo Circuits

The Inverse Sub-bytes () Transformation is also a byte substitution operation performed on the individual byte of the 128-bit data during decryption. It is similar to sub-bytes () Transformation where each byte is substituted to a different byte using a well-defined substitution box called Inverse S-box. Just like S-box, this also contains a mapping of each byte from 00 to FF and is inverse of the S-box.

And, the substitution byte for the input byte is determined by looking at the intersection of row and column. For example, the substitution byte of cb will the intersection of a row with index 'c' and column with index 'b' which is 59. This can be located in the Inverse Substitution box below.

| | ng. ADS-inverse Substitution Dox | | | | | | | | | | | | | | | |
|---|----------------------------------|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|
| | 0 | 1 | 2 | 3 | 4 | 5 | 6 | 7 | 8 | 9 | a | b | c | d | e | f |
| 0 | 52 | 09 | 6A | D5 | 30 | 36 | A5 | 38 | BF | 40 | A3 | 9E | 81 | F3 | D7 | FB |
| 1 | 7C | E3 | 39 | 82 | 9B | 2F | FF | 87 | 34 | 8E | 43 | 44 | C4 | DE | E9 | СВ |
| 2 | 54 | 7B | 94 | 32 | A6 | C2 | 23 | 3D | EE | 4C | 95 | 0B | 42 | FA | С3 | 4E |
| 3 | 08 | 2E | A1 | 66 | 28 | D9 | 24 | B2 | 76 | 5B | A2 | 49 | 6D | 8B | D1 | 25 |
| 4 | 72 | F8 | F6 | 64 | 86 | 68 | 98 | 16 | D4 | A4 | 5C | CC | 5D | 65 | В6 | 92 |
| 5 | 6C | 70 | 48 | 50 | FD | ED | В9 | DA | 5E | 15 | 46 | 57 | A7 | 8D | 9D | 84 |
| 6 | 90 | D8 | AB | 00 | 8C | ВС | D3 | 0A | F7 | E4 | 58 | 05 | В8 | В3 | 45 | 06 |
| 7 | D0 | 2C | 1E | 8F | CA | 3F | 0F | 02 | C1 | AF | BD | 03 | 01 | 13 | 8A | 6B |
| 8 | 3A | 91 | 11 | 41 | 4F | 67 | DC | EA | 97 | F2 | CF | CE | F0 | B4 | E6 | 73 |
| 9 | 96 | AC | 74 | 22 | E7 | AD | 35 | 85 | E2 | F9 | 37 | E8 | 1C | 75 | DF | 6E |
| a | 47 | F1 | 1A | 71 | 1D | 29 | C5 | 89 | 6F | В7 | 62 | 0E | AA | 18 | BE | 1B |
| b | FC | 56 | 3E | 4B | C6 | D2 | 79 | 20 | 9A | DB | C0 | FE | 78 | CD | 5A | F4 |
| c | 1F | DD | A8 | 33 | 88 | 07 | C7 | 31 | B1 | 12 | 10 | 59 | 27 | 80 | EC | 5F |
| d | 60 | 51 | 7F | A9 | 19 | B5 | 4A | 0D | 2D | E5 | 7A | 9F | 93 | С9 | 9C | EF |
| e | A0 | E0 | 3B | 4D | AE | 2A | F5 | В0 | C8 | EB | BB | 3C | 83 | 53 | 99 | 61 |
| f | 17 | 2B | 04 | 7E | BA | 77 | D6 | 26 | E1 | 69 | 14 | 63 | 55 | 21 | 0C | 7D |

fig: AES-Inverse Substitution Box

• Pseudo code for Inverse substitution byte transformation :

Inverse-S-box(data[0:7], inverse-data[0:7])

This is for the first byte and it goes all the way down to 16^{th} byte where a byte is mapped to a different byte using inverse S-box.

Table 5: Inverse Sub bytes () Transformation

| S0 | S4 | S8 | S12 | | A0 | A4 | A8 | A12 |
|----|----|-----|-----|---|----|----|-----|-----|
| S1 | S5 | S9 | S13 | | A1 | A5 | A9 | A13 |
| S2 | S6 | S10 | S14 | = | A2 | A6 | A10 | A14 |
| S3 | S7 | S11 | S15 | | A3 | A7 | A11 | A15 |

The schematics of inverse sub-bytes () transformation is shown below:




Figure 9: Inverse Sub-bytes Schematic View

5. Shifting Operation

5.1. Shift-Rows() Transformation




Figure 10: Shift Rows Pseudo Circuits

The shift rows() transformation is about shifting bytes in each row of a matrix by a certain offset as determined in the algorithm. The data are arranged in a 4 by 4 grid which is shown in the figure below. The following transformation is applied in each row[5]:

- The first row is left unchanged.
- The bytes in the second row are shifted one position to the left.
- The bytes in the second row are shifted two positions to the left.
- The bytes in the second row are shifted three positions to the left.

The array of bytes before and after transformation is shown below:

Table 6: Shift Rows () Transformation

| S0 | S4 | S8 | S12 | | S0 | S4 | S 8 | S12 |
|----|----|-----|-----|---|-----|-----|------------|-----|
| S1 | S5 | S9 | S13 | | S5 | S9 | s13 | S1 |
| S2 | S6 | S10 | S14 | = | S10 | S14 | S2 | S6 |
| S3 | S7 | S11 | S15 | | S15 | S3 | S7 | S11 |

• Pseudo code for shift rows() transformation :

```
shifted byte[0:7] = substituted byte[0:7]
shifted byte[8:15] = substituted byte [104:11]
shifted byte[16:23] = substituted byte [80:87]
shifted byte [24:31] = substituted byte [53:63]
```

This is for the first column, and the pattern is similar for all the other columns as shown in figure above.

5.2. Inverse Shift-Rows() Transformation




Figure 11: Inverse Shift Rows Pseudo Circuits

The Inverse shift rows() transformation is about shifting bytes in each row of a matrix by a certain offset as determined in the algorithm during decryption. The following transformation is applied in each row:

- The first row remains unchanged.
- The bytes in the second row are shifted one position to the right.
- The bytes in the second row are shifted two positions to the right.
- The bytes in the second row are shifted three positions to the right.

The array of bytes before and after transformation is shown below:

Table 7: Inverse Shift Rows () Transformation

| S0 | S4 | S8 | S12 | | S0 | S4 | S8 | S12 |
|----|----|-----|-----|---|-----|-----|-----|-----|
| S1 | S5 | S9 | S13 | | S13 | S1 | s5 | S9 |
| S2 | S6 | S10 | S14 | = | S10 | S14 | S2 | S6 |
| S3 | S7 | S11 | S15 | | S7 | S11 | S15 | S3 |

• Pseudo code for inverse shift rows/() transformation:

inverse shifted byte[0:7] = inverse mix-column byte[0:7]

inverse shifted byte [8:15] = inverse mix-column byte [40:47] inverse shifted byte [16:23] = inverse mix-column byte [80:87] inverse shifted byte [24:31] = inverse mix-column byte [120:127]

This is for the first column, and the pattern is similar for all the other columns as shown in figure above.

6. Column Operations

6.1. Mix Column




Figure 12: Mix Column Pseudo Circuits

Mix Column operation is a crucial part of AES Encryption Decryption. Mix Column utilizes finite field arithmetic in Galois Field(2^8). 128-bit data is accepted in each mix column operation and it returns 128-bit data[5]. The 128-bit data entered is arranged in a 4×4 matrix. The 4×4 matrix contains 16 elements as shown in table 8. Each element is of size 8 bit which can be represented by 2 hexadecimal characters.

Table 8: Mix Col Matrix and Input Data Matrix

| Mix | Col | Matr | ix | | Inpu | ıt Dat | a Matr | ix |
|-----|-----|------|----|-----|------|--------|--------|-----|
| 02 | 03 | 01 | 01 | | D0 | D4 | D8 | D12 |
| 01 | 02 | 03 | 01 | and | D1 | D5 | D9 | D13 |
| 01 | 01 | 02 | 03 | | D2 | D6 | D10 | D14 |
| 01 | 01 | 02 | 03 | | D3 | D7 | D11 | D15 |

After the input data is arranged in 4×4 matrix, it undergoes matrix multiplication with the Mix Col Matrix as shown is table 9.

Table 9: Mix Column Operation

| Mix | c Col | Matr | ix | | Inpu | ıt Dat | a Matr | ix | | Out | Output Data Matrix | | | |
|-----|-------|------|----|---|------|--------|--------|-----|---|-----|--------------------|-----|-----|--|
| 02 | 03 | 01 | 01 | | D0 | D4 | D8 | D12 | | O0 | O4 | 08 | O12 | |
| 01 | 02 | 03 | 01 | × | D1 | D5 | D9 | D13 | = | O1 | O5 | O9 | O13 | |
| 01 | 01 | 02 | 03 | | D2 | D6 | D10 | D14 | | O2 | O6 | O10 | O14 | |
| 01 | 01 | 02 | 03 | | D3 | D7 | D11 | D15 | | О3 | 07 | O11 | O15 | |

Column Wise multiplication is visualized in table 10.

Table 10: Column wise multiplication in Mix Col Operation

| - | | | | | | | | 0 0 - 0 P 0 - 0 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 |
|---|---------|----------|---------|----|---|-----------|---|---|
| | Mix | | Matr | | | Input Col | | Output Col |
| | 02 | 03 | 01 | 01 | | D_n | | O_n |
| | 01 | 02 | 03 | 01 | × | D_{n+1} | = | O_{n+1} |
| | 01 | 01 | 02 | 03 | | D_{n+2} | | $O_{-}n + 2$ |
| | 01 | 01 | 02 | 03 | | D_{n+3} | | O_{n+3} |
| | $n \in$ | $\{0, 4$ | , 8, 12 | } | | | | |

The matrix multiplication only involves multiplication by 01,02 and 03 in Galios Field(2^8).

• Irreducible Polynomial

The irreducible polynomial $x^8 + x^4 + x^3 + x + 1$ is utilized if our multiplication operation exceeds 8 bits. Since, our multiplication only involves multiplication by 01,02 and 03, the irreducible operation only needs to be subtracted once. This will provides us the remainder when our 9 bit output is divided by the irreducible polynomial. But, since we only need 8 bit as our output, we can ignore the ninth bit from the beginning and just utilize $x^4 + x^3 + x + 1$ as our irreducible polynomial.

• Example of Remainder

| Table 11: Remainder of 100000000 when divided by | y irreducible j | oolynomial (| (2^8) |) |
|--|-----------------|--------------|---------|---|
|--|-----------------|--------------|---------|---|

| Binary Position | 8 | 7 | 6 | 5 | 4 | 3 | 2 | 1 | 0 |
|-----------------|-----|---|---|---|---|---|---|---|---|
| 8 | 1 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
| (8+4+3+1+0) * 0 | 1 | 0 | 0 | 0 | 1 | 1 | 0 | 1 | 1 |
| XOR Remainder | 0 | 0 | 0 | 0 | 1 | 1 | 0 | 1 | 1 |
| Binary | 0 | 0 | 0 | 0 | 1 | 1 | 0 | 1 | 1 |
| Hex | 1 I | 3 | | | | | | | |

• Multiplication by 01 Multiplication by one returns the original input as nothing is changed.




Figure 13: Pseudo Circuit for multiplication by 1

• Multiplication by 02




Figure 14: Pseudo Circuit for multiplication by 2

• Multiplication By 03In Galois Field(2^8), multiplication is distributive over addition. Hence multiplication by 03 can be converted to multiplication by one and two.

 $input \times 03 = input \times (11) = input \times (10 \oplus 01) = input \times 10 \oplus input \times 01 = input \times 2 \oplus input$ Thus, utilizing multiplication by 02, we can achieve multiplication by 03.




Figure 15: Pseudo Circuit for multiplication by 3

• Addition Addition in $GF(2^8)$ is simply bitwise xor operation.




Figure 16: Pseudo Circuit for multiplication by 3

Hence, Mix Column operation is conducted in $\mathrm{GF}(2^8)$ feild using the above principle of multiplication and addition.




Figure 17: Schematic View of Mix Columns

6.2. Inverse Mix Column




Figure 18: Inverse Mix Column Pseudo Circuits

Inverse Mix Column operation inverts the changes performed to Mix Column. [4] It utilizes finite field arithmetic in Galois Field(2^8). 128-bit data is accepted in each inverse mix column operation and it returns 128-bit data. The 128-bit data entered is arranged in a 4×4 matrix. The 4×4 matrix contains 16 elements as shown in table 13. Each element is of size 8 bit which can be represented by 2 hexadecimal characters.

Table 13: Inverse Mix Col Matrix and Input Data Matrix

| Inv I | Mix C | ol Ma | atrix | | Inpu | ıt Dat | a Matr | ix |
|-------|-------|-------|-------|-----|------|--------|--------|-----|
| 0E | 0B | 0D | 09 | | D0 | D4 | D8 | D12 |
| 09 | 0E | 0B | 0D | and | D1 | D5 | D9 | D13 |
| 0D | 09 | 0B | 0D | | D2 | D6 | D10 | D14 |
| 0B | 0D | 09 | 0E | | D3 | D7 | D11 | D15 |

After the input data is arranged in 4×4 matrix, it undergoes matrix multiplication with the Inv Mix Col Matrix as shown is table 14.

Table 14: Inv Mix Column Operation

| Inv | Mix C | Col Ma | atrix | | Inpu | ıt Dat | a Matr | ix | | Out | put D | ata Ma | trix |
|-----|-------|--------|-------|---|------|--------|--------|-----|---|-----|-------|--------|------|
| 0E | 0B | 0D | 09 | | D0 | D4 | D8 | D12 | | O0 | O4 | O8 | O12 |
| 09 | 0E | 0B | 0D | × | D1 | D5 | D9 | D13 | = | O1 | O5 | O9 | O13 |
| 0D | 09 | 0B | 0D | | D2 | D6 | D10 | D14 | | O2 | O6 | O10 | O14 |
| 0B | 0D | 09 | 0E | | D3 | D7 | D11 | D15 | | O3 | Ο7 | O11 | O15 |

Column Wise multiplication is visualized in table 15.

Table 15: Column wise multiplication in Inv Mix Col Operation

| 010 10 | | CALLLIA | ***100 11 | rarer | phoadion in i | 11 1 11. | in cor operas |
|---------|---------------|---------|-----------|-------|---------------|----------|---------------|
| Inv | Mix C | Col Ma | trix | | Input Col | | Output Col |
| 0E | 0B | 0D | 09 | | D_n | | O_n |
| 09 | 0E | 0B | 0D | × | D_{n+1} | = | O_{n+1} |
| 0D | 09 | 0B | 0D | | D_{n+2} | | $O_{-}n + 2$ |
| 0B | 0D | 09 | 0E | | D_{n+3} | | O_{n+3} |
| $n \in$ | $\{0, 4, 8\}$ | 8, 12} | | | | | |

The matrix multiplication only involves multiplication by 0E,0B,0D, and 09 in Galois Field(2⁸).

• Multiplication by 09

$$\begin{split} input \times 09 &= input \times (00001001) = input \times (1000 \oplus 0001) = (input \times 1000) \oplus (input \times 0001) \\ input \times 1000 &= input \times (10) \times (10) \times (10) = input \times 2 \times 2 \times 2 \\ input \times 0001 &= input \end{split}$$

Hence,

$$input \times 09 = (input \times 2 \times 2 \times 2) \oplus (input)$$




Figure 19: Pseudo Circuit for multiplication by 09

• Multiplication by 0B

$$input \times 0B = input \times (00001011) = input \times (1000 \oplus 0010 \oplus 0001) = (input \times 1000) \oplus (input \times 0010) \oplus (input \times 0001)$$

$$input \times 0B = (input \times 2 \times 2 \times 2) \oplus (input \times 2) \oplus (input)$$

Smart Implementation by reducing repetition:

$$input \times 0B = (((input \times 2 \times 2) \oplus input) \times 2) \oplus input$$




Figure 20: Pseudo Circuit for multiplication by 0B

• Multiplication by 0D

$$input \times 0D = input \times (00001101) = input \times (1000 \oplus 00100 \oplus 0001) = (input \times 1000) \oplus (input \times 0100) \oplus (input \times 0001)$$

$$input \times 0D = (input \times 2 \times 2 \times 2) \oplus (input \times 2 \times 2) \oplus (i$$

Smart Implementation by reducing repetition:

$$input \times 0D = (((input \times 2) \oplus input) \times 2 \times 2) \oplus input$$




Figure 21: Pseudo Circuit for multiplication by 0D

• Multiplication by 0E

$$input \times 0E = input \times (00001110) = input \times (1000 \oplus 00100 \oplus 0010) = (input \times 1000) \oplus (input \times 0100) \oplus (input \times 0010)$$

$$input \times 0E = (input \times 2 \times 2 \times 2) \oplus (input \times 2 \times 2) \oplus (input \times 2)$$

Smart Implementation by reducing repetition:

$$input \times 0E = (((input \times 2) \oplus input) \times 2) \oplus input) \times 2$$




Figure 22: Pseudo Circuit for multiplication by 0E




Figure 23: Schematic View of Inverse Mix Columns

7. Key Expansion




Figure 24: Key Generation pseudo circuit

Overview: Round Keys required for each AddRoundKey iteration is derived from a single Cipher Key by the means of the KeyExpansion algorithm. In AES_128, we have 11 total key additions that require 11 keys[3]. Each key is 128 bit and is divided into 4 words of 1 byte length to perform mathematical operation. The first four words i.e w[0], w[1], w[2], w[3] contains the input cipher key. The key expansion Pseudocode is given below:

```
KeyExpansion( [127:0] cipher_key, [127:0] expanded_key[0:10])

{
    If (nr == 0)

    W[0] = cipher_key(127: 96)
    w[1] = cipher_key(95:64)
    w[2] = cipher_key(63: 32)
    w[3] = cipher_key(31:0)

    expanded_key = {w[0],w[1],w[2],w[3]}
else
    for(i = 1; i < 11, nr = 4*i ; i++)

{
        temp = W[ nr - 1];

        temp = SubByte (RotByte(temp)) ^ Rcon[];

    W[nr] = W(nr -4) ^ temp;
    W[nr+1] = W(nr ) ^ w(nr - 3);
    W[nr+2] = W(nr +1) ^ w(nr - 2);
    W[nr+3] = W(nr +2) ^ w(nr - 1);
    expanded_key = {W[nr],W[nr+1],W[nr+2],W[nr+3]}
}
</pre>
```

Figure 25: Key Generation pseudo code

Initially, the input cipher key is divided into four 32 bit words; w[0], w[1], w[2], and w[3]. We call this round zero. We use the word which contains the least significant bits of the previous key (w[3], w[7], w[11]..) and passes it sequentially to ROTWORD, then SUBBYTE, and then bitwise XOR with RCON. Then, the temp result and other previous words are used to calculate further words as we go along. At i=10, we get our final word, w[43], and thus 11 keys are generated. The key expansion is designed in such a way that if a single bit in the input key sequence changes, it would affect every other key generated afterward. We explain the main operations; ROTWORD, SUBBYTE, and RCON below:

7.1. SubByte, Rotword and RoundConstant (Rcon)

RotWord

RotWord performs a one-byte circular left shift on a word. This means that an input word [B0, B1, B2, B3] is transformed into [B1, B2, B3, B0].[3]

Subword

SubByte performs a byte substitution on each byte of its input word, using the Rijndael S-box as described above in Section 5.1. [3]

Rcon

Rcon, as described by the Rijndael documentation, is the exponentiation of 2 to a user-specified value. This operation is not performed with regular integers, rather in Rijndael's finite field. RCON could be expressed as:

$$rc_i = egin{cases} 1 & ext{if } i = 1 \ 2 \cdot rc_{i-1} & ext{if } i > 1 ext{ and } rc_{i-1} < 80_{16} \ (2 \cdot rc_{i-1}) \oplus 11 ext{B}_{16} & ext{if } i > 1 ext{ and } rc_{i-1} \geq 80_{16} \end{cases}$$

Figure 26: Round Constant(RCON)

where multiplication is defined in the Galius Field $(GF(2^8))$. [3]

| Round | 1 | 2 | 3 | 4 | 5 | 6 | 7 | 8 | 9 | 10 |
|-------|----|----|----|----|----|----|----|-----|----|----|
| Hex | 01 | 02 | 04 | 08 | 10 | 20 | 40 | 80 | 1b | 36 |
| Dec | 01 | 02 | 04 | 08 | 16 | 32 | 64 | 128 | 27 | 54 |

Let look at Rcon(9),

$$Rcon(9) = 2 * Rcon(9-1)$$
$$Rcon(9) = 2 * Rcon(8)$$

Since the mulitplication is over $(GF(2^8))$,

$$Rcon(9) = 2 * Rcon(8) mod(x^8 + x^4 + x^3 + x + 1)$$

 $Rcon(9) = 256 mod(x^8 + x^4 + x^3 + x + 1)$

Now, 256 in polynomial form is $1 * x^8$ where x = 2. So our operation returns as :

$$Rcon(9) = 8mod(8+4+3+1+0)$$

where the numbers represent the powers of the binary number. We illustrate this operation below:

Table 16: Round Constant (RCON) Generation Over Galios Field $(2\,\hat{\ }8)$

| Binary Position | 8 | 7 | 6 | 5 | 4 | 3 | 2 | 1 | 0 |
|-----------------|-----|---|---|---|---|---|---|---|---|
| 8 | 1 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
| (8+4+3+1+0) * 0 | 1 | 0 | 0 | 0 | 1 | 1 | 0 | 1 | 1 |
| XOR Remainder | 0 | 0 | 0 | 0 | 1 | 1 | 0 | 1 | 1 |
| Binary | 0 | 0 | 0 | 0 | 1 | 1 | 0 | 1 | 1 |
| Hex | 1 I | 3 | | | | | | | |

7.2. Key Expansion in Pictures




Figure 27: AES_128 Key Schedule




Figure 28: AES_128 Key Expansion Schematics

8. UART

8.1. UART for 8 bit Data Transfer

When we talk about connecting our phone to a computer or vice-versa for any kind of file transfers, USB is the most widely used interface which allows from charging our phones to sending/receiving files at a high speed to and from another device. In a similar manner, for hardware communication purposes, or simply communicating FPGA with a computer, we need an interface and protocols that govern the transfer and receiving of data. UART is one of the simplest and widely used methods of talking to the FGPA using a computer and also communicating different FPGAs.

UART stands for Universal Asynchronous Receiver/Transmitter. By definition, it is a hardware communication protocol that uses asynchronous serial communication with configurable speed where asynchronous means there is no clock signal to synchronize the output bits from the transmitting device going to the receiving end. A UART is an interface that sends out usually a byte at a time over a single wire. Embedded systems, micro-controllers, and computers mostly use UART as a form of device-to-device hardware communication protocol as well as a way to talking to the FPGAs. Two UARTs directly communicate with each others using two wires for their transmitting and receiving ends.

The two signals of each UART device are named Transmitter(Tx) and Receiver(Rx). The main motive of a transmitter and receiver line for each device is to transmit and receive serial data intended for serial communication. The UART transmitter and receiver have to agree on some parameters, such as:

• Baud Rate: 9600

• Number of data bits: 8

• Parity Bit : 0

• Stop Bits: 1

• Flow Control: None

Baud rate: The frequency at which the receiver captures the incoming bits and colloquially, the frequency at which the transmitter sends the outgoing bits.

The number of data bits: It is set to eight bits at a time. That means, in each round, a byte is sent over the channel.

Parity bit: It is to check the validity of the transmitted data over UART, and is appended after the data is sent which is calculated by doing an XOR operation on all of the bits.

Stop Bits: A stop is always set is 1, and it indicates the end of transmission of a byte.

Flow Control: It is likely to be set to None, and is not widely used in present days applications.




Figure 29: UART

Working Mechanism:

- 1) Uart receives parallel data from the data bus and creates a serial packet and adds a start bit stop bit and a parity bit.
- 2) Start bit pulls UART line to 0 (usually kept at 1), which indicates the receiver to capture incoming data while stop bit will stop communication by pulling the line back to 1.
- 3) The receiver will ignore start, stop, and parity bits and captures data into the parallel stream, and sends it to the data buses. [1]

Now, we will talk about the UART transmitter and UART receiver in details.

9. UART 128 bits

9.1. Baud Rate

Baud rate is the rate at which information is transferred in a communication channel that includes the number of bits exchanged per second in serial communication between two devices. It is quite important in the UART channel as UART protocol is asynchronous and thus, is necessary for the transmitter and receiver to transfer and receive the data at the same speed. In the serial port, the baud rate of "9600 baud" means a maximum of 9600 bits of data can be transferred per second.

For example, the FPGA board has a 100 Mhz clock cycle, with a baud rate of 9600 bits per seconds, each bit is being transferred and received every 10417 cycles (i.e. 100000000 cycles/sec — 9600 bits/sec). And, each bit is being captured exactly in the midway of 10417 cycles for the consistency and accuracy of the data.

The UART line stays at logic high '1', and a transmitter is activated, with start bit '0', the line is active and transmits 8 bits serially, the end recognized by the stop bit '1', and then the UART line stays at high logic '1' and wait for the next stream of data. A similar procedure occurs in the receiver side, which remains at logic high '1' and as it receives the start bit '0', it captures the next 8 bits of data at the baud rate serially and remains logic high '1' at the completion and wait for the next stream of bits. [2]

Table 17: Baudrate and clocks per bit selection

| FPGA clock speed | 100MHZ |
|------------------|----------------------------|
| Baud_rate | 9600 bits per seconds |
| clock_per_bits | 10417 clock cycles per bit |

9.2. Uart Transmitter




Figure 30: UART-128 bit Transmitter Input Output

Table 18: Input/Output wire for Uart Transmitter

| I/O | Wire | Size(bit) | Utilization |
|--------|-------------|-----------|--|
| | clock | 1 | Clock for operations |
| | data | 128 | data that needs to be sent |
| | data_state | 1 | Data_ state is a flag that initiates the transmitter module. |
| Input | reset | 1 | Resets the transmitter to state Init. |
| Output | data_out_tx | 1 | Output pin. |




Figure 31: UART-128 bit Transmitter State Diagram

1. Init: In this state is the transmitter goes to state setup if the data_state flag from the receiver is 1.




Figure 32: State Init

2. Setup:In this state, the transmitter breaks the 128 bit data into 16 8bit chunks, assigns start and stops bits making it 10 bits of data and passes it to the next state i.e. Write Data.




Figure 33: State Setup

3. Write Data:In this state, the transmitter sends the chunk of data received from Setup state and assigns it to the output transmitter pin every clocks_per_bits number of cycles. If the number of bytes sent is 16 then it goes to state Init. If the number of bytes sent is not 16, it increments the number of bytes sent counter by 1 ignoring the start and stop bits and goes to state Setup again.




Figure 34: State Writedata

9.3. Uart Receiver




Figure 35: UART-128 bit Receiver Input Output

Table 19: Input/Output wire for Uart Reciever

| I/O | Wire | Size(bit) | Utilization |
|--------|------------|-----------|--|
| | clock | 1 | Clock for operations |
| Input | data_in | 1 | It represents the pin that acts as reciever for FPGA. |
| | data_out | 128 | Output pin. |
| Output | data_state | 1 | Flag that represents new set of 128 bit has been received. |




Figure 36: UART-128 bit Receiver State Diagram

1. Init: The FPGA waits until Data= 0 and then goes to Start.




Figure 37: State Init

2. Start: It waits for half clocks_per_bits and checks if the Data_in is still 0. If Data_in is still 0, it proceeds to next state i.e. Read.




Figure 38: State Start

3. Read:In this state, the receiver reads 8 bits of data from the Data_in pin every clock_per_bits cycle and increments the number of bytes received by 1. Then, it proceeds to next state i.e. Stop.




Figure 39: State Read data

4. Stop:In this state, the receiver checks is the number of bytes received is 16 or not. If it has received 16 bytes of data, it updates the data_out register and also sends a flag that new data has been received. Then, it proceeds to next state i.e. Init.




Figure 40: State Stop

5. Every Clock Cycle: Every rising edge of FPGA clock, the device checks if the state is stop or init. If the state is stop, then it saves the 8 bit acquired data to a temporary input. It also check if the total acquired data is 128 data and released the 128 bit to the output of receiver. If the state is init then, it clears the output of data after waiting for clock_per_bit times 160 clock cycles.




Figure 41: Every rising edge of FPGA clock

10. Pipelined Implementation

The entire process of encryption and decryption is broken down to small steps which are pipelined for efficient transmission of files.




Figure 42: Full AES Encryption, Decryption and Key Generation.

10.1. Encryption Pipeline

This is the encryption process. Key generation is a circuit without registers so they are ignored. Appropriate keys are passed at appropriate circuits.




Figure 43: Full AES_128 bit Encryption.

10.1.1. Division of encryption circuit into three parts

The full encryption shown in figure 43 is broken down to three chunks as shown in figure 44. These three chunks as combined to form three circuits as shown in figure 45.




Figure 44: Encryption Broken down to different parts that can be in turn implemented to state machine.

10.1.2. Three circuits for Encryption

Each of these circuit take in 128 bit data and output 128 bit data. Combination of these three circuits represents complete encryption. The circuit First has three parts as the inital circuit has only add roundkey whilst Between circuit and Final Circuit are more complex.




Figure 45: Three main circuit for Encryption.

Each of these three circuit are combine with a state machine circuit. The state machine circuit algorithm is shown in figure 46. The FSM circuit takes a data_state and 128 bit data as input. The FSM assigns the 128 bit data to the circuit associated with it. After waiting for clock_per_bit times 16 clock cycles, the FSM changes the output of to the new 128 bit data which is the output of the device associated with it. It also sends a completion flag (data_state) as output.




Figure 46: State machine implementation of different part of Encryption.

10.1.3. Final Encryption Pipeline




Figure 47: Final Encryption Pipeline

Each of these devices above i.e. First, Between and Last has the following input and output as shown in the table 20. The encode_state is connected to data_state of the next circuit and the data_out is connected to the data_in of the next circuit.

Table 20: Input/Output wires for First, Between and last

| 1 / 1 | | | | | |
|---|--------------|------|--|--|--|
| I/o | Wire | Size | | | |
| | data_in | 128 | | | |
| Input | data_state | 1 | | | |
| | data_out | 128 | | | |
| Output | encode_state | 1 | | | |
| These are wires which are connected to internal registers | | | | | |

10.2. Decryption Pipeline

This is the decryption process. Key generation is a circuit without registers so they are ignored. Appropriate keys are passed at appropriate circuits.




Figure 48: Full AES_128 bit Decryption.

10.2.1. Division of decryption circuit into three parts

The full decryption shown in figure 48 is broken down to three chunks as shown in figure 49. These three chunks as combined to form three circuits as shown in figure 50.




Figure 49: Decryption broken down to different parts that can be in turn implemented to state machine.

10.2.2. Three circuits for Decryption

Each of these circuit take in 128 bit data and output 128 bit data. Combination of these three circuits represents complete encryption. The circuit Last has three parts as the final circuit has only add roundkey whilst between circuit and First Circuit are more complex.




Figure 50: Three main circuit for Decryption.

Each of these three circuit are combined with a state machine circuit. The state machine circuit algorithm is shown in figure 51. The FSM circuit takes a data_state and 128 bit data as input. The FSM assigns the 128 bit data to the circuit associated with it. After waiting for clock_per_bit times 16 clock cycles, the FSM changes the output of to the new 128 bit data which is the output of the device associated with it. It also sends a completion flag (data_state) as output.




Figure 51: State machine implementation of different part of Decryption.

10.2.3. Final Decryption Pipeline




Figure 52: Final Decryption Pipeline

Each of these devices above i.e. First, Between and Last has the following input and output as shown in the table 21. The encode_state is connected to data_state of the next circuit and the data_out is connected to the data_in of the next circuit.

Table 21: Input/Output wires for First, Between and last

| r / r | | | | | |
|---|--------------|------|--|--|--|
| I/o | Wire | Size | | | |
| | data_in | 128 | | | |
| Input | data_state | 1 | | | |
| | data_out | 128 | | | |
| Output | encode_state | 1 | | | |
| These are wires which are connected to internal registers | | | | | |

10.3. Full Implementation

Finally each of these devices i.e. receiver, encrypter/decrypter and transmitter are connected. Receiver takes in data, completes receiving 128 bit data and outputs the 128 bit data and a completion flag. When the encrypter/decrypter sees a completion flag, it starts to encrypt/decrypt the data. Once encrypter/decrypter completes encryption/decryption, it outputs the encrypted/decrypted data along with a completion flag. Once the transmitter sees a completion flag, it starts to transmit the 128 bit data which is the output of encrypter/decrypter. The python codes is created with encryption/decryption requirement of 128 bit data.




Figure 53: State machine implementation of different parts of Encryption

Python data_sender code reads a file, and makes it a multiple of 128 bit by adding 8'b11111111 multiple times at the end of the data. Similarly, the python receives code, reads data and ends reading data whenever it encounter 8'b1111111. Hence, the data used to convert out data to a multiple of 128 bit is also used as end flag by receiver.

References

- [1] "A review on serial communication by UART". http://ijarcsse.com/Before_August_2017/docs/papers/Volume_3/1_January2013/V3I1-0220.pdf Date Accessed = "2021-04-20".
- [2] "Design of a 9-bit UART module based on Verilog HDL". 2012 10th IEEE International Conference on Semiconductor Electronics (ICSE), 2012, pp. 570-573, doi: 10.1109/SMElec.2012.6417210. Date Accessed = "2020-11-20".
- [3] "The Rijndael Block Cipher". "https://csrc.nist.gov/csrc/media/projects/cryptographic-standards-and-guidelines/documents/aes-development/rijndael-ammended.pdf"DateAccessed="2020-20-20".
- [4] Ako Abdullah. Advanced encryption standard (aes) algorithm to encrypt and decrypt data. 06 2017.
- [5] "Hakhamaneshi, Bahram and Arad, Behnam". "A Hardware Implementation of the Advanced Encryption Standard (AES) Algorithm using SystemVerilog", "01" "2010".