Basic I/O System Design

Course Teacher:

Md. Obaidur Rahman, Ph.D.

Professor

Department of Computer Science and Engineering (CSE)
Dhaka University of Engineering & Technology (DUET), Gazipur.

Course ID: CSE - 4619

Course Title: Peripherals, Interfacing and Embedded Systems

Department of Computer Science and Engineering (CSE),

Islamic University of Technology (IUT), Gazipur.

Lecture References:

Book:

Microprocessor and Microcomputer – Based System Design,
 Author: Mohamed Rafiquzzaman

Lecture Materials:

- I/O System Design, Dr. Esam Al_Qaralleh, CE Department, Princess Sumaya University for Technology.
- COMPUTER ORGANISATION & ARCHITECTURE, Lecture-9 (Input-Output), Dr. Masri Ayob.
- http://home.iae.nl/users/pouweha/lcd/lcd0.shtml

Basic I/O System

- A **Microprocessor** is a great tool for solving problem but is of little or no use if it can't communicate with other devices.
- Input-Output devices (or peripherals) such as Keyboards, Mouse, LEDs, Displays are essential components of the microprocessor-based or microcontroller-based systems.

Input


- Receive data from peripheral (i.e., device)
- Send data to computer

Output

- Receive data from computer
- Send data to peripheral (i.e., device)

Basic I/O System

- 8086 processor uses address bus pins AD[0:15] to locate an I/O port
- ▶ 65,536 possible I/O ports
- Data transfer between ports and the processor occurs over data bus
- AL (or AX) is the processor register that takes input data (or provide output data)



Overview of Micro-Computer Structure

- A microcomputer has three basic blocks: a central processing unit (CPU), a memory unit, and an input/output (I/O) unit.
- The CPU(microprocessor) executes all the instructions and performs arithmetic and logic operations on data.
- ▶ <u>A memory unit</u> stores both data and instructions. The memory section typically contains ROM and RAM chips.
- ▶ A system bus (comprised of several wires) connects these blocks – Address Bus, Data Bus and Control Bus.

Clock Signals

The system clock signals are contained in the control bus.




FIGURE 2.3 Typical clock signal.

- The number of cycles per second (hertz, abbreviated Hz) is referred to as the clock frequency.
- Clock Cycle = 1/f; where, f is the clock frequency.
- Clock frequency determines the speed of the microcomputer.

Single-Chip Microprocessor

- ▶ The microprocessor is the CPU of the microcomputer
- The logic inside the microprocessor chip can be divided into three main areas: the register section, the control unit, and the arithmetic-logic unit (ALU).




FIGURE 2.4 Microprocessor chip with the main functional elements.

Registers


- The *number*, size, and *types of registers* vary from one microprocessor to another.
- There are four basic microprocessor registers:
 - Instruction register
 - Program counter
 - Accumulator
 - Pointer and Index Register
 - Segment Register

Basic I/O System

- ► I/O devices serve two main purposes
 - To communicate with outside world
 - To store data
- I/O Controller Chip (e.g., 8255) acts as an interface between the systems bus and I/O device.
 - Relieves the processor of low-level details
 - Takes care of electrical interface
- I/O Controller Chips have three types of registers
 - Data register
 - Command register
 - Status register



Block Diagram of Basic I/O System



Block Diagram of Basic I/O System

- Access one port at a time is called Serial Interfacing.
- ▶ To read (receive) binary data from an input peripheral
 - ▶ MPU places the address of an input port on the *address bus*, enables the input port by asserting the RD signal, and reads data using the *data bus*.
- ▶ To write (send) binary data to an output peripheral
 - MPU places the address of an output port on the **address bus**, places **data** on **data bus**, and asserts the WR signal to enable the output port.

Remember:

- Writing to the port
 - When the MPU sends out or transfers data to an output port
- Reading from the port
 - When the MPU receives data from an input port

I/O Instructions


- ▶ **IN** is the instruction that reads information from an I/O device.
- ▶ OUT is the instruction that writes/sends data to an I/O device.
- In reality the data transfer takes place between the microprocessor accumulator (AL or AX) and the I/O device.
- The I/O device may be identified using two methods:
 - **Fixed address** A byte called **p8** immediately following the **opcode** stores an 8 bit I/O address. This is called fixed because this is stored with the **opcode** in the ROM.
 - Variable address Register DX holds a 16 bit I/O address.
 Because this can be changed.


Accessing I/O Devices

- ▶ To communicate with an I/O device, 2 things needed-
 - ▶ Access to various registers (data, status,...)
 - ▶ This access depends on I/O address mapping,
 - □ Two basic ways
 - □ Memory-mapped I/O
 - □ Isolated I/O
 - ▶ A protocol to communicate (to send data, ...)
 - Three types
 - □ Programmed I/O
 - □ Interrupt-driven I/O
 - □ Direct memory access (DMA)

Memory Mapped I/O

- A device is mapped to a memory location. Sending data to the particular location causes interaction with the device.
- Reading and writing are similar to memory read/write with same address bus
- Uses same memory read and write signals
- Most processors use this I/O mapping





Memory Mapped I/O

Advantages:


- Less complication,
- Less circuitry
- Less decoding
- No need to use special signal
- MOV instruction can be used instead of IN and OUT

Disadvantage:

A portion of the memory system is used as the I/O Mapping

▶ Isolated I/O

- Separate I/O address space
- Separate I/O read and write signals are needed
 - ▶ I/O read
 - ▶ I/O write
- This is the most common form of I/O transfer technique used with Intel processors.
- Pentium supports isolated I/O of 64 KB address space.



00000

Isolated I/O

- ▶ On Personal computers Isolated I/O is used.
- ▶ 8 bit port addresses are used to access devices located on system board.
- 16 bit port address are used to access serial and parallel ports as well as video and disk drive systems.

Isolated I/O

Advantages:

In this system no memory is wasted for I/O mapping.

Disadvantage:

- Instructions IN and OUT need to be used to perform data transfer.
- Separate signals are also needed to interact with the I/O devices which separate it from normal memory access instructions.

Accessing I/O Ports in 8086

Register I/O instructions

IN accumulator, port8; direct format


□ Useful to access first 256 ports

IN accumulator, DX ; indirect format

DX gives the port address

Accessing I/O Ports in 8086

Addressing Space




☐ Accessing directly by instructions

I/O Data Transfer Techniques

- Data transfer involves three basic techniques
 - Programmed I/O
 - DMA
 - Interrupt-driven I/O

I/O Data Transfer Techniques



Programmed I/O

- CPU has direct control over I/O
 - Sensing status
 - Read/write commands
 - Transferring data
- CPU waits for I/O module to complete operation
- Programmed I/O Wastes CPU time

Addressing I/O Devices

- Under programmed I/O data transfer is very like memory access (CPU viewpoint)
- Each device given a unique identifier
- CPU commands contain identifier (address)


Programmed I/O – Detail Steps

- CPU requests I/O operation
- I/O module performs operation
- I/O module sets status bits
- CPU checks status bits periodically polling
- ► I/O module does not inform CPU directly
- I/O module does not interrupt CPU
- CPU may wait or come back later

Interrupt Driven I/O

- It Overcomes CPU Waiting Time Problem of Programmed I/O
- No repeated CPU checking of device
- ► I/O module interrupts when it is ready
- Interrupt Handler Chip is responsible to make successful data transfer.

Transfer of Control via Interrupts



Multiple Interrupts


Disable interrupts

- Processor will ignore further interrupts whilst processing one interrupt
- Interrupts remain pending and are checked after first interrupt has been processed
- Interrupts handled in sequence as they occur


Define priorities

- Low priority interrupts can be interrupted by higher priority interrupts
- When higher priority interrupt has been processed, processor returns to previous interrupt

Multiple Interrupts - Sequential




Multiple Interrupts – Nested



Interrupt Driven I/O: Detail Steps

- CPU issues read command
- I/O module gets data from peripheral whilst CPU does other work
- I/O module interrupts CPU
- CPU requests data
- I/O module transfers data

Simple Interrupt Processing




Direct Memory Access (DMA)

- Interrupt driven and programmed I/O require active CPU intervention
 - Hence, the data transfer rate is limited
 - For typical microprocessors I (one) byte of data transfer between RAM and I/O take 5 − 10 microseconds.
 - Hence, CPU is tied up
- DMA is the answer
 - ▶ DMA is more efficient for transferring large volumes of data.

Direct Memory Access (DMA)

- DMA doesn't make use of the microprocessor to do the transfer so who is going to do the READ and WRITE operation?
- A **DMA Controller Chip** is may be built into the microprocessor or may be found external.
- We can see that the DMA controller has to perform operations that are very similar to operations performed by a microprocessor.
- They are thus generally designed and built by microprocessor manufacturers.

Typical DMA Module Diagram



DMA Operation – Detail Steps

- CPU tells DMA controller:-
 - Read/Write
 - Device address
 - Starting address of memory block for data
 - Amount of data to be transferred
- CPU carries on with other work
- DMA controller deals with transfer
- DMA controller sends interrupt when finished

Thank You!!

