

#### On this Lesson

- Issues regarding performance of caches
- Measuring Performance
- Performance parameters
- · Performance improvement methods

# Performance of a Microprocessor

- · Two main factors
  - Wasted cycles due to pipeline hazards
  - Memory latency
- · Memory latency effect is reduced by caches
  - On hits there is no response delay (assuming one cycle access time)
  - On misses there is a response delay due to the transfer of memory blocks
- In the analysis of performance of pipelines there were three non stated assumptions:
  - There was a cache serving memory access
  - Memory hit time was one cycle
  - The only misses were due to missed predictions (a miss occurred when fetching the first location of the instruction stream that should be executed).

## **Cache Performance Issues**

- A cache may respond as quick as one CPU cycle on a hit.
- Misses introduce a miss penalty due to the memory latency of each memory access needed to transfer a memory block.
- The miss penalty could be different for instructions misses and data misses (load/store misses)
- The miss penalty could be different for read misses (instruction fetches or loads) and write misses (stores).
- Misses involving the replacement of a written cache block requires the transfer of two blocks
  - a write-back block from cache to memory
- a miss block from memory to the cache.

#### **Cache Performance Measurements**

- Cache performance is usually measured in terms of the number of cycles per instruction (CPI).
- The CPI involves three factors:
  - •the time it takes to access a memory location in the cache
  - •the time penalty introduced by a miss
  - •one stall cycle in the case of load/stores accesses due to the structural pipeline hazard

#### **Calculating CPI**

Consider a cache with an access time of one cycle and a miss penalty of 25 cycles For the following ARM program only structural hazards are generated, and that none of the branches do branch. Determine the CPI.

	Hazard Penalty	Access Result	Miss Penalty	Access Result	Miss Penalty
1	1	Hit		Hit	
1		Hit			
1		Miss	25		
1		Hit			
1	1	Hit		Miss	25
1	1	Miss	25	Hit	
1	1	Hit		Hit	
1		Hit			
1		Hit			
1		Hit			
	1	Penalty  1	Penalty	Penalty	Penalty

CPI = Total cycles/Total instructions = (10 + 4 + 50 + 25)/10 = 89/10 = 8.9

1

# **Calculating CPI by Formula**

 $CPI = CPI_{BASE} + CPI_{MISSES}$ 

CPI BASE: Cache access time in cycles

 $CPI_{MISSES} = CPI_{IM} + CPI_{DM}$ 

CPI<sub>IM</sub>: CPI component due to instruction misses

CPI<sub>DM</sub>: CPI component due to data (loads/stores) misses

CPI<sub>IM</sub> = MissRate<sub>INSTRUCTIONS</sub> x MissPenalty<sub>INSTRUCTIONS</sub>

CPI<sub>DM</sub> = (Stall Cycle + MissRate<sub>DATA</sub> x MissPenalty<sub>DATA</sub> ) x % load/store instructions

# Calculating CPI by Formula

Consider a cache with an access time of one cycle and a miss penalty of 25 cycle For the following ARM program only structural hazards are generated, and that none of the branches do branch. Determine the CPI.

From previous slides:

MissRateInstructions = 2/10 = .2

MissRatedata = 1/4 = .25

% load/store instructions = 4/10 = .4

MissPenaltyDATA = MissPenaltyINSTRUCTIONS = 25

CPI M = MissRate M structions x MissPenalty M structions = .2 x 25 = 5

CPI DM = (Stall Cycle + MissRateDATA x MissPenaltyDATA ) x % load/store instructions

 $CPIDM = (1 + .25 \times 25) \times .4 = 2.9$ 

 $CPI_{MISSES} = CPI_{IM} + CPI_{DM} = 5 + 2.9 = 7.9$ 

CPI = CPI BASE + CPI MISSES = 1 + 7.9 = 8.9 cycles/instruction

#### Cache Performance: An Example

Consider a CPUrunning at 1 Ghz with a cache with a hit time of one cycle, a miss penalty of 20ns, and a hit rate of 98% for instructions and data accesses. Determine the CPI if 26% of the instructions are data accesses.

Cycle period = 1/1Ghz = 1 ns

MissPenaltyInstructions = MissPenaltyDatA = 20 ns/1 ns = 20 cycles

MissRateInstructions = MissRateDATA = 100% - 98% = 2% = .02

CPI<sub>IM</sub> = .02 x 20 = .4

 $CPI_{DM} = (1 + .02 \times 20) \times .25 = .35$ 

CPI MISSES = CPI IM + CPI DM = .4 + .35 = .75 cycles per instruction

CPI BASE = 1 cycle/instruction

CPI = CPI BASE + CPI MISSES = 1 + .75 = 1.75 cycles per instruction

#### **Another Example:**

CPU running at 800Mhz. A cache with a hittime of one cycle, instruction miss penalty of 16ns, data miss penalty of 24ns, instruction hit rate of 97%, data hit rate of 96%. Determine the CPI if 30% of the instructions are data accesses.

Cycle period = 1/500Mhz = 2 ns

MissPenaltyINSTRUCTIONS = 16 ns/2 ns = 8 cycles

MissPenaltyDATA = 24ns/2ns= 12 cycles

MissRateInstructions = 100% - 97% = .03, MissRateDATA = 100% - 96% = .04

CPI<sub>IM</sub> = .03 x 8 = .12

 $CPI_{DM} = (1 + .04 \times 12) \times .3 = .444$ 

CPI MISSES = CPI IM + CPI DM = . 12 + .444 = .564 cycles per instruction

CPI BASE = 1 cycles/instruction

CPI = CPI BASE + CPI MISSES = 1 + .564 = 1.564 cycles per instruction

#### **Cache Performance Improvement**

- Split Caches
- Prefetching
- Increasing Cache-Memory Data Bus
- Interleaved Memory

#### **Split Caches**

- Instead of using one cache to handle instructions and data, some microprocessors use a cache to handle instructions and another to handle data.
- The advantage of this configuration is that it eliminates the one cycle stall in the instruction pipeline due to load/store conflicts with instruction fetches (structural hazard).
- Data Miss Penalty

Unified cache: Stall Cycle + Miss Penalty x Miss Rate

Split cache: Miss Penalty x Miss Rate

12

#### **Split Cache Example**

Consider a CPUrunning at 1 Ghz with a split cache with a hit time of one cycle, a miss penalty of 20ns, and a hit rate of 98% for instructions and data accesses. Determine the CPI if 25% of the instructions generate load/store accesses.

MissRateInstructions = MissRateData = 100% - 98% = 2% = .02MissPenaltyInstructions = MissPenaltyData = 20 ns/1 ns = 20 cycles

 $CPI_{IM} = .02 \times 20 = .4$ 

 $CPI_{DM} = (.02 \times 20) \times .25 = .1$ 

CPI MISSES = CPI IM + CPI DM = .4 + .1 = .5 cycles per instruction

CPI IDEAL = 1 cycle/instruction

CPI = CPI IDEAL + CPI MISSES = 1 + .5 = 1.5 cycles per Instruction

\* A unified cache yields a CPI of 1.75 for the same case (slide 9).

#### **Prefetching**

- Allocates cache blocks from primary memory into the cache before they are needed
- · It could has the following effects:
  - Improve hit ratio
  - Generate unnecessary blocks transfers
  - Reduce hit ratio

14

# **Increasing Cache-Memory Data Bus**

- The transfer of blocks between the cache and memory takes place through a bus with a bandwidth of several bytes.
- Normally, the block size is larger than the bus bandwidth.
- Transfer of a block requires multiple memory access
- Typically each memory access requires a few cycles to send the address, a memory latency time, and a few cycles to transfer the data (all this account for the miss penalty).
- Increasing the data bus bandwidth reduces the number of memory access, what results in a reduction of the overall miss need by
- Due to hardware limitations the data bus cannot be increased arbitrarily.

## Data Transfer Between Memory and Cache

- The transfer of one block to a cache normally requires several consecutive memory accesses.
- The total transfer time of a memory access has three components:

Address Send Time (AST) – time to send the address an initiate the access

Memory Latency Time (MLT) – time the memory takes to complete the operation


Data Transfer Time (DTT) – Time it takes to transfer data through the data bus

Address Send Time (AST) Memory Latency Time (MLT) Data Transfer Time (DTT)

16

#### **Block Transfer on Regular Memory**

If a transfer of a block requires two memory accesses then, the total transfer time is 2x(AST + MLT + DTT)




In general the total transfer time for a block of a regular memory is.

 $\label{eq:BTTT} \textbf{BTTT} = \textbf{n} \times (\textbf{AST} + \textbf{MLT} + \textbf{DTT}) = \text{Miss Penalty,}$  where n is the number of memory accesses required to transfer a block

#### **Interleaved Memory**

- Memory is organized in banks of bytes, the size of the data bus, that can be accessed independently.
- A block is distributed among the banks.
- Transfer of a block requires rounds of consecutives accesses to each of the banks.
- Each access to successive banks is only separated by an address send time.

18



# In general the total transfer time for a block of an interleaved memory is, BTTT = m x (AST + MLT + k•DTT) = Miss Penalty, where m = number of memory banks access rounds required to transfer a block k = the number of banks

