Control Design

Digital system

- **Data Processing Unit** (DPU): capable of performing certain operations on data.
- Control Unit (CU): issues control signals or instructions to DPU
- CU signals selects the functions to be performed at specific times and route the data through the appropriate functional units.
- DPU is logically reconfigured by the CU to perform certain set of (micro) operations.
- Sequence of these micro-operations are important.

Control Design

Functions of CU:

 Instruction sequencing: methods by which instructions are selected for execution or control of the processor is transferred from one instruction to another.

 Instruction Interpretation: methods used for activating the control signals that cause the DPU to execute the instructions.

Instruction sequencing

- Each instruction can explicitly specify the address of its successor(s).
- It may increase the instruction length, which in turn increases the cost of memory where it is stored.
- I1 is stored in location A, and I2 is its successor.
- Let Program Counter (PC) contains A of I1, the address of I2 is can be determined by PC ← PC+k, where k is the word length of I1.

Instruction sequencing

Increment of PC can be automatic.

- So, PC makes it unnecessary for an instruction to specify the address of its successor.
- Branch Instruction: Specifies implicitly/explicitly an instruction address X.
- Unconditional branch always alters the flow of control by causing PC ← X.

Instruction sequencing

 Conditional branch first tests the condition C (a result generated by earlier instruction, and stored in a status register).

 If C is present, then PC ← X, otherwise PC is incremented to point to the next consecutive instruction.

Program Control Transfer

 Often it is required to temporal transfer of control from P1 to P2 due to subroutine call or interrupt.

- Subroutine call: CALL X (X is address of the first instruction of P2)
- First contents of PC is stored (after fetching CALL) in a predetermined location, then X is loaded into PC.

At then end of P2, transfer is returned back to P1.

Program Control Transfer

 In case of interrupt, call instruction is replaced by interrupt signal.

 Interrupt branch address is fixed a priori, or comes with the interrupt request.

Control Stack

Stack is used to store return address.

 Also used to store pass variables (from P1 to P2), and variables that are local to P2.

 Each time a call is executed, return address is stored at top of the stack, PC is loaded with SUB address.

```
CALL SUB;
```

PUSH PC;

PC← SUB;

Control Stack

A return is effected by RETURN (equivalently to POP).


LIFO organization of pushdown stack is used.

No restriction on the use of recursive calls.

 Top of the stack varies dynamically; no interference with one another.

Control Stack

 Because return location is saved in top-of-stack, which varies dynamically, successive PUSH operations to save return addresses do not interfere with one another.



Use of pushdown stack to control recursive subroutine call

- A stack with n k-bit words is implemented using k n-bit shift registers having left and right-shit capabilities.
- One end of the shift register is defined as top-of-the-stack.
- Push/pop operation is done by activating the proper control line.

- Two possible error conditions may arise: stack overflow and stack underflow.
- Error is detected by a counter in the circuit to indicate the no.
 of words currently in the stack.
- Counter in incremented (decremented) by each push(pop) operation.
- Combination of push(pop) and count n(0) results in overflow(underflow).





FIGURE 4.2
A stack constructed from shift registers.


- Smaller stack: Shift register, Larger stack: RAM
- Push: memory write, and pop: memory read
- Stack pointer (SP): this register contains address of the memory location currently acting as top-of-the-stack.
- A pop operation implies reading M using SP.
- SP either decrements (pop) or increments (push).

- Limit register (L): Contains highest stack address.
- Base Register (B): Contains lowest stack address.
- B, L and SP define the boundary of the stack.
- SP>L: Overflow and SP<B: Underflow.



Instruction Interpretation

Control signals ->via control lines->outside



- -- Control and data are relative.
- -- Same physical lines can be used for either data or control at different levels.

Control Specifications:

C'_{out}:- Controls the operation of DPU (main function of CU).

C'_{in}:- Enables the data being processed to influence the CU, and allows data-dependent decisions to be made.

e.g. error, overflow (unusual conditions)

C"_{out}:- Transmitted to other CUs, indicating the status such as 'busy' or 'operation completed'.

C"_{in}:- Received from the other CUs e.g. supervisory controller.

- Start/stop/timing information.

c" & c" out: Synchronize with other CU

Behavior of CU

Flowchart/ Description language or both

- Once a DPU design has been completed, and the control points are identified, each micro operation Z←f(x) can be identified with a set of control lines {c_{ij}} that must be activated in order to execute that micro operation.
- Formal specification of the input/output behavior

Implementation methods

- Hardwired CU (HCU): Sequential logic circuit, which generates specific sequences of control signals.
 - Minimizes the no. of components.
 - Maximizes the speed of operation.
- Once constructed, changes in behavior can be implemented by re-designing and physically re-wiring the unit.
- => Lack of structure makes HCU costly to design and debug.

2) Microprogramming:-

- Maurice V. Wilkes (1950)
- flexible & systematic

Activate control lines {c_{i,i}}

- A (micro)instruction stored in a special addressable memory called a Control Memory (CM).

Microprogram: Sequence of micro instructions (MI) needed to execute a particular operation.

- Fetch the MI from CM one at a time, and use them to activate the control lines directly.

- It is know as Micro-programmed control unit
- Firmware
- Permanent software programmed into a read-only memory.
- Design changes can easily be made by altering the contents of the CM
- Emulation: A micro-programmed CPU can execute programs written in the machine language of several different computers.

Limitation:-

Costly than HCU due to CM & its circuitry. Slower due to fetch from CM.

Since the improvements in memory technology, it is now a standard method of designing CU

Hardwired control:-

Trade-off: Amount of hardware, speed and cost.

Design methods in practice are ad hoc, heuristic, cannot easily be formalized (due to large no. of instructions, & complex interdependency).

3 main methods (apt for small CU like RISC):

- State- table method
- Delay-Element method
- 3) Sequence counter method

No one can win over other

State-table Method

- Like any finite-state sequential machine

Input Combinations c _{in}				
State	l ₁	I ₂		l _m
S ₁	S _{1,1} ,Z _{1,1}			$S_{1,m}$, $Z_{1,m}$
S ₂	$S_{2,1}$, $Z_{2,1}$			S _{2,m} ,Z _{2,m}
•	•			•
•	•			·
S _n	$S_{n,1}$, $Z_{n,1}$			$S_{n,m}$, $Z_{n,m}$

C_{in}: Input

C_{out}: output

Row: Set of internal states {S_i}

Internal state: Information stored at discrete point of time

Column: Set of external signals to CU

Entry in row S_i and column $I_j: S_{i,j}, Z_{i,j}$

S_{i,i}: Next state of CU

 $\mathbf{Z}_{i,j}$: Set of output signals $Z_{i,j}$ from C_{out} that are activated by the application of I_j to CU when it is in state S_i .

Pros: Systematic technique for minimizing no. of gates, flip-flops.

Cons:

- i) No. of states, i/p conditions may be so huge that size of the table & computation time become excessive.
- ii) Tends to conceal useful info about circuits behavior e.g. loop.
- iii) Due to random structure, debugging and maintenance become difficult.

Generate the sequence of signals at times t₁, t₂,
 . , t_n using a Hardwired Control Unit

• Initial signal START (t_1) is fanned out to $\{c_{1,j}\}$ to perform first micro operation.

If START(t_1) is also entered into a time delay element of delay $t_2 - t_1$, the output of that circuit, START(t_2) can be used to activate { $c_{2,i}$ }.


Likewise, another delay element of delay $t_3 - t_2$, with input START(t_3) can be used to activate { $c_{3,i}$ }.

Sequence of delay-elements.

• D flip-flop is used to ensure synchronous operation.

Can be constructed from flow-chart.


 Circuit mirrors the flow of control through the flow-chart.




Each sequence of two successive micro operations require a delay element.

Signals that are intended to activate the same control line C_i are fed to an OR gate whose output is C_i .

This line may then be connected to the control point it activates.




K-lines in the flowchart that merge to a common line are transformed into a k-input OR gate.



A decision box can be implemented by two AND gates. It forms a 1-bit de-multiplexer controlled by the test variable x (or a Boolean function f(x)).

An example:



Output

control


pulse


- Complex circuit may be required if an input becomes significant amount of out of phase with the clock due to propagation delays between delay elements.
- **Cons: 1)** No. of delay elements needed is approximately equal to the no. of states.
 - **2)** Each delay element is a sequential circuit of equal or greater complexity than a flip flop.
 - 3) Synchronization becomes difficult.

Sequence Counter Method

- Output of **Modulo-k sequence counter** is connected to 1/k clocked decoder.
- If the count enable input is connected to a clock source, counter cycles continually through its k states.
- Decoder generates k-pulse signals $\{\Phi_i\}$ on its output lines, separated by one clock period.
 - called **phase signals**.
- Two additional input lines and a flip-flop are provided for turning the counter on and off.

Sequence Counter Method





FI


USEFULLNESS - Many digital circuits are designed to perform a relatively small number of actions repeatedly.

This type of behavior can be described by a flowchart consisting of a single closed-loop containing k-steps.

Example

CPU behavior represents as a:


- Each pass through the loop: 1 instruction cycle
- Each step, 1 clock period (approximately)
- Modulo-6 sequence counter
- Each signal Φi activates some set of control lines in step i of every instruction cycle
- Single closed-loop



It is required to vary the operations performed in step i depending on certain control signals

$$C_{in} = \{ C'_{in}, C''_{in} \}$$


A logic circuit N combines C_{in} with the timing signals $\{\Phi_i\}$ generated by the sequence counter.



Relationship- Sequence counter and Delay-element.

 Modulo-k sequence counter is equivalent to cascade of k-s delay elements

- Connect k^{th} output line Φ_k to the end line, so that counter shuts itself of after one complete cycle.




Cascade of DEs

Equivalent sequence counter

Also a cascade of k-DEs can be made to behave like a sequence counter by connecting its output to its input via an additional DE and an OR gate

- ➤ Modulo-k ring counter
- A cascade of identical DEs is essentially a shift register.



A DE circuit that behaves like a sequence counter.

MICROPROGRAMMED CONTROL

- Every instruction in a CPU is implemented by a sequence of one/more set of concurrent micro operations.
- ➤ Each micro operation is associated with a specific set of control lines which, when activated, cause that micro operation to take place.

- ➤ Since the no. of instructions and control lines are huge, HCU could be exceedingly complicated.
- ➤ Information stored in ROM/RAM, called Control Memory (CM).
- ➤ Control signals to be activated at any time are specified by a microinstruction, which is fetched from CM.

- ➤ Each microinstruction explicitly or implicitly specifies the next microinstruction to be used.
- Sequencing
- ➤ A set of related microinstructions: **micro program**.
- Relatively easy to change the design.

A micro-programmed computer C1 used to execute programs written in m/c language L2 (other m/c C1) by placing an emulator for L2 in the CM of C1.

➤C1 is then said to be capable of emulating C2

- Comparable with assembly language, but requires more detail knowledge of the processor h/w.
- Symbolic language->micro-assembly language

Micro-assembler

Wilkes' Design

Microinstruction:

1. Control Field: Indicates the control lines to be activated.

2. Address Field: Indicates the address in the CM of the next microinstructions s to be executed.

Ki,Ci: if Ki=1,Ci is activated

- CM: Row-> microinstruction
- Col -> Control/Address lines
- CMAR -> control memory address register which stores the address of the current instruction.
- ➤ May be loaded from an external source as well as from an address fields

External source provides the starting address microprogram stored in the CM

- ➤ CM is organized as a program logic array of diodes.
- ➤ This is partial matrix & consists of 2 components control signals & address of next microinstruction.
- ➤ CMAR can be loaded by the IR or by the address field of CM. On getting an input from the IR, CM provides a 3 bit address to the 3 x 8 decoder.
- This is an entry point address to the CM.

- ➤On the basis of this address, decoder activates one of the eight output lines (horizontal).
- This activated line, in turn, generates control signals and the address of the next microinstruction to be executed.
- This address is once again fed to the CMAR resulting in activation of another control line and address field.
- This cycle is repeated till the execution of the instruction is achieved.

- Ability to respond to external signal
- S flip-flop is used to indicate an external condition

 Conditional jump: One of the two possible address fields to be selected.




Figure 1: Wilkes Control Unit

Area of concern: word length of microinstruction (influence the cost and size of CM)

- 1. Max no. of simultaneous micro-operations that must be specified (i.e., degree of parallelism)
- 2. The way control information is represented
- The way the next microinstruction address is specified

Control Memory (early design): ROM or ROS (Read Only Store)


- Because ROM (i.e. diode) provides faster access than RAM (i.e. ferrite core)
- Microprogrammed processor was viewed as permanent except for correction or minor change (enhancement)

Wilkes Idea: Writable CM (WCM)

- allows instruction set to be changed by changing the microprograms that interpret the instruction opcode
- It can provide same machine with different instruction sets which may be tailored for specific applications.
- Computer with WCM implies no instruction set in usual sense (dynamically microprogrammable)

Parallelism in Microinstructions:-


Micro-programmable processor characterized by the max. no. of micro-operations that can be specified by a single microinstruction (several hundred)




Microinstruction format (IBM sys./370 model 145):

- 1: Operations to be performed
- 2-3: Mostly addresses of CPU registers
- If all combination of parallel micro-operations were specified by single opcode, the no. of opcode would be enormous.
- Decoder circuit was needed then (added complexity)
- Solⁿ:- Divide the microinstruction specification port into k disjoint control fields.

Each control field is associated with a set of micro-operations any of which can be performed simultaneously with the micro-operations specified by the remaining control fields.





CM address information

Un

- 90-bit microinstruction format of IBM sys/360 Model 50 (shaded areas are control fields)
- 3-bit control fields 65-67 which controls the right input to the CPU adder. This field indicates which of the several possible registers should be connected to the right input of the CPU adder.
- 68-72 define different operations of adder such as binary or decimal.
- 21 other control fields : used for different purposes

- The scheme in which there is a control field for every control line is *wasteful* of *CM* space, since many combinations of control signals are never used.
- In general, any n-independent control signals can be encoded in a control field of $[log_2(n+1)]$ bits, assuming that it is necessary to specify a no-operation condition when no control signals are to be activated.

Un-encoded format: Control signals may be derived directly from the microinstruction.

Suppose MI is loaded into CM data register, called microinstruction register μ IR. The outputs of the control part of μ IR are the control lines.

When encoded fields are used, each control field must be connected to a decoder from which control signals are derived.

Horizontal Microinstructions:

- 1) Long formats
- 2) Ability to express a high degree of parallelism

3) Little encoding of the control information

Vertical Microinstructions:

1) Short formats

2) Limited ability to express parallel micro operations


3) Considerable encoding of the control information

A horizontal microinstruction format allows *no encoding* of control information, whereas a vertical form does.

A vertical microinstruction can specify only one micro operation (*no parallelism*), while a horizontal one can specify many micro operations.

Not entirely independent

control fields



No encoding

Some encoding

Complete Encoding

Microinstruction Addressing:

- Each MI contains the CM address of the next MI to be executed.
- For branching, two possible next address are included.

Advantage: No time lost in address generation

Limitation: Wasteful of CM space

Solution: microprogram counter (µPC) for branching

Analogous to PC at instruction level

Since only MIs have to be fetched from CM, the μ PC is also used as CMAR.

Conditional Branching:

- The condition to be tested is a condition variable or flag generated by the DPU.
- If several such conditions exist, a condition select subfield is included in the microinstruction.
- The branch address may be contained in the MI itself, in which case it is loaded into CMAR, when a branch condition is satisfied.

Another Approach:-

Allow the condition variables to modify the contents of the CMAR directly, thus eliminating wholly or partly the need for branch addresses in MIs.

Example: overflow when v=1

No overflow when v=0

Skip on overflow: logically connect v to count enable input of μPC at an appropriate point in the MI cycle. Allows overflow condition to increment μPC using an extra time, performing skip operation.

Micro operation Timing:

- Each MI generates a set of CSs, which are active for duration of MIs' execution cycle.
- Monophase: a single clock pulse synchronizes all control signals.
- Polyphase: The number of MIs needed to specify a particular operation can be reduced by dividing the MI cycle into several sequential phases.
- It adds complexity as requirement of specifying the phase during which a control signal is to be activated.

Example: Register Transfer operation

 $R \leftarrow f(R_1, R_2)$ R can be R_1 or R_2




Phase Ø1: Transfer the contents of the $R_1 \& R_2$ to the inputs of the f unit

Phase Ø2: Store the result in a temporary register/latch (L).

Phase Ø3: Transfer the contents of L to destination register R


Phase Ø4: Fetch the next MI from CM.



Micro operation Timing

Fetch & execute steps can be overlapped

• Replace μ IR by a pair of registers forming a two-segment pipeline, while one MI in μ IR₁ is being executed, the next MI can be fetched and placed in μ IR₀.



Residual Control

 Store the Control field in a register which continues to exercise until it is modified by a subsequent MI.

 Application: When MI is used to allocate a resource e.g. connection between two units may be established by an MI and maintained for a long period via Residual Control.


Control Unit Organization

• A *Condition Select* field is used to specify the external condition to be tested in case of conditional branch MI.


 An Address field contains the next address to be used when a branch condition is satisfied (μPC provides next MI address when no branching)

Control Unit Organization

 Rest specifies (un/encoded) format of the CS that must be activated to perform the desired micro operation.



MI format



- The contents of the addressed word in CM are transferred to the μIR
- Control fields are decoded (if required) and used to generate CS for DPU
- μPC is then incremented.
- For branch instruction in μ IR, the contents of the MI Address field are loaded in μ PC.
- MUX activates parallel-load control i/p of μPC based on status of the external condition variables

<i>s</i> ₀	s_1	Meaning	
0	0	No branching	MUX: x_0 , x_1 , x_2 , x_3 (4 i/ps) x_i routed to MUX o/p when $S_0S_1 = i$
0	1	Branch if $v_1 = 1$	
1	0	Branch if $v_2 = 1$	
1	1	Unconditional branch	

• A provision is made for loading μPC with an address from an external source, used for loading the starting address of the desired micro program in cases where CM contains more than one micro program.

Nanoprogrammed Computer

 In some machines, the MIs do not directly issue the signals that control the hardware.

 They are used to access 2nd CM, called nanoControl Memory (nCM).

First used in 1970 by Nanodata Corp.

Nanoprogrammed Computer


Two levels of CMs:

- 1. Higher level: Microcontrol memory µCM (MI)
- 2. Lower Level: Nanocontrol memory nCM (nanoinstruction NI)

Consider the dimensions:

 μ CM: $H_m \times W_m$

 $nCM: H_n \times W_n$



Two level control store organization for nanoprogramming


Nanoprogrammed Computer

- Typically, MIS are encoded in a vertical format, so that although H_m is large, W_m is small.
- NIs usually have a highly parallel horizontal format making W_n large.
- If many MIs can be interpreted by the same nanoprogram, then H_n can be kept relatively small.

Advantages


• It can reduce the total size of CMs needed, this translates to smaller chip area.


 Greater design flexibility resulting from the loosening the bonds between instruction and hardware with two intermediate levels of control rather than one.



One level

$$S1 = H_m (N + \Gamma \log_2 H_m)$$
(i)





Two level

- In 2-level design, μ CM again stores H_m MIs, but N-bit Control fields are transferred to nCM.
- In place of latter, each MI in μCM contains [log₂H_n] bit address to specify any NI location in nCM.

Hence size becomes,

 $S_2 = H_m ([log_2 H_m] + [log_2 H_n]) + NH_n$ (Assuming no branching, so no explicit addressing)

$$S_2 = H_m ([log_2 H_m] + [log_2 H_n]) + NH_n$$

Suppose all control bit patterns are different, it can be written as

$$H_n = r H_m$$

where r = ratio of the number of unique control states to the total number of H_n of control states needed to implement all instructions

So, $S_2 = H_m ([log_2 H_m] + [log_2 r H_m]) + NrH_m$ $= H_m (2[log_2 H_m] + [log_2 r] + Nr)(ii)$ If N=70, H_m =650, r=0.4 so that H_n =260

 $S_1 = 52,240$

 $S_2 = 30,550$

That means, 52450-30550=21850 bits of control storage (42% of S_1) are saved.

In general, 2-level design requires less memory space if $S_2 < S_1$

Hence, from equation (i) & (ii), the following inequality must be satisfied

$$N \ge [\log_2 H_m] + [\log_2 r] + rN$$

Disadvantage

Reduction in speed due to extra memory access for nCM and a more complex CU organization.