If your Transbot packing list include U disk, as shown below. Please check following tutorials seriously.




This step includes three cases, please check the corresponding operation according to your actual situation.

Case-A: You have NVIDIA Jetson NANO 4GB developer kit. As shown below.



Please insert the U disk we provided in the USB port of NVIDIA Jetson NANO 4GB board. Then, open the power switch on Transbot. Wait patiently 3~5mins, it will start normally.

Case-B: You bought Transbot with Yahboom Jetson NANO 4GB (SUB) board. As shown below.



Please insert the U disk we provided in the USB port of Jetson NANO 4GB SUB board. Then, open the power switch on Transbot. Wait patiently 3~5mins, it will start normally.

Case-C: You bought Transbot without Jetson NANO 4GB (SUB), and you bought Yahboom Jetson NANO 4GB(SUB) or other brand Jetson NANO 4GB(SUB) board individually.



1) Write Yahboom eMMC boot file

About how to write this file, please check [FAQ] ---[Write eMMC boot file] on our website.

2)Insert the U disk we provided in the USB port of Jetson NANO 4GB SUB board.

Finally, open the power switch on Transbot. Wait patiently 3~5mins, it will start normally.