Introduction to ROS2: Basics, Motion, and Vision

Geesara Kulathunga



Content



- Working with tmux
- Workspace
- Build System
- ROS1 vs ROS2
- Nodes
- ROS1 Nodelets and ROS2 Composition
- Topics and Messages
- Launch and run
- Package
- Publisher, Subscriber, and Service
- Parameters

Working with tmux



tmux, a program that runs in a terminal. It allows multiple other terminal programs to be run inside it. To install tmux: **sudo apt install tmux**

Ctrl+b c Create a new window (with shell)

Ctrl+b w Choose window from a list

Ctrl+b 0 Switch to window 0 (by number)

Ctrl+b , Rename the current window

Ctrl+b % Split current pane horizontally into two panes

Ctrl+b " Split current pane vertically into two panes

Ctrl+b o Go to the next pane

Ctrl+b ; Toggle between the current and previous pane

Ctrl+b x Close the current pane

ROS Workspace



Check available ROS2 packages

apt-cache search ros_version, e.g., ros-humble

Set PATH and enable ROS2 within the system

source /opt/ros/ros_version/setup.bash echo "source /opt/ros/ros_version/setup.bash" » /.bashrc

change /opt/ros/ in case if you installed into another location

ROS Workspace



Default workspace is located at /some_path/ros/ros_version/setup.bash

You can create ros workspace in a location you prefer

```
mkdir -p /catkin_ws/src
cd /catkin_ws
colcon build
cd ./install && pwd
echo source 'pwd'/setup.bash » /.bashrc
source install/setup.bash
echo $AMENT_PREFIX_PATH
```

ROS Build System



colcon build is used to build the the ros packages and generate executable, libraries, and interfaces

to navigate to workspace

>cd /catkin_ws

to build your package

>colcon build —packages-select package_name Note:whenever package is built, it is required to >source ./install/setup.bash

ROS Build System





to see catkin workspace

colcon list

Example



Hello world!

- > cd /catkin_ws/src
- > git clone https://github.com/GPrathap/ros2 intro.git
- > cd ../ && colcon build —packages-select hello_world
- > source install/setup.bash
- > ros2 launch hello_world pub_sub_variant_1.py

ROS1 Master (roscore) No more in ROS2






Figure: https://www.youtube.com/watch?v=NmidmSS9Ylk

ROS1 Master (roscore)



- The centralized controller or manager
- Register nodes (sub-programs) when starts with the master
- 3 Handle communication between nodes (sub-programs (nodes))
- Also, provide the Parameter server, which is shared among the Nodes that is used to retrieve parameters
- 5 rosout, which is /rosout, logging purpose
- for roscore = master + parameter_server + rosout


to start the master

roscore

ROS2 there is no master, no parameter server, hence no roscore. All parameters are node-specific

ROS1 vs ROS2





DDS (Data Distribution Service) is an open-standard connectivity framework for real-time systems, which enables distributed systems to operate securely as an integrated whole.

Mazzeo, G., Staffa, M. (2020). TROS: Protecting Humanoids ROS from Privileged Attackers. International Journal of Social Robotics, 12, 827-841.

ROS Nodes





Figure: https://www.youtube.com/watch?v=NmidmSS9Ylk

ROS Nodes (Processors/pub-programs)



- Do you know the different between threads and processors
- Each nodes executes as a processor
- Node APIs: rclcpp, rclpy

to run a node

ros2 run package_name node_name

to see active nodes

ros2 node list

to get information about a node

ros2 node info node name

ROS Topics





Figure: https://www.youtube.com/watch?v=NmidmSS9Ylk

ROS Topics



- Topics can be used to communicate among the nodes
- Nodes can publish, subscribe or both, typically 1 to n connection exist between a publisher and subscribers

to see active topics list

ros2 topic list

to subscribe to a topic

ros2 topic echo /topic

to get information about a topic

ros2 topic info topic name

ROS Launch



- The configuration of the system includes what programs to run, where to run them, what arguments to pass them
- Launch files are written in Python, XML, or YAML
- **3** executable: executable of the node
- **package**: which package that the considered node belongs
- **5** parameters: parameters to be passed to the node
- **output**: where to log the output: console or log file

ROS Package



- **launch folder**: contains launch files each of which may have defined multiple nodes or includes another multiple launch files
- 2 src folder: source files
- package.xml: or manifest file, contains the package meta data
- CMakeLists.txt: dependencies, executable, and exporting all meta information

ROS Package Creation



dummy package with several dependencies

ros2 pkg create <package_name> --dependencies [depend1] [depend2] [depend3]

- > ros2 pkg create first_package ——dependencies rclcpp std_msgs
- > source install/setup.bash

ROS Package's Package.xml



- **name**: name of the package
- **version**: it should be defined with three integers separated by dots
- **description**: objective of the package
- **buildtool_depend**: dependencies that are required for the build tool
- **build_depend**: dependencies of the package
- **build_export_depend**: dependencies that are included in the headers
- **exec_depend**: dependencies of shared libraries











- Message contains information to be transformed
- 2 Typically comprises of a nested structure of primitive data types, e.g., integer, double, float, boolean, and string.
- Define as *.msg

to see type of a topic

ros2 topic type /topic

to publish a message over a topic

ros2 topic pub /topic type <message>



Odometry message example

```
std_msgs/Header header
string child_frame_id
geometry_msgs/PoseWithCovariance pose
geometry_msgs/TwistWithCovariance twist
```

Header message example

uint32 seq time stamp string frame_id

More info: http://docs.ros.org/en/noetic/api/nav_msgs/html/msg/Odometry.html

ROS Message Create



Friend's message

mkdir -p catkin_ws/src/hello_world/msg cd catkin_ws/src/hello_world/msg touch **R**obot**D**etails.msg

Robot's message content

string name string id

ROS Message: Standard Types



Primitive type	Serialization	C++	Python
bool (1)	unsigned 8-bit int	uint8_t(2)	bool
int8	signed 8-bit int	int8_t	int
uint8	unsigned 8-bit int	uint8_t	int(3)
int16	signed 16-bit int	int16_t	int
uint16	unsigned 16-bit int	uint16_t	int
int32	signed 32-bit int	int32_t	int
uint32	unsigned 32-bit int	uint32_t	int
int64	signed 64-bit int	int64_t	long
uint64	unsigned 64-bit int	uint64_t	long
float32	32-bit IEEE float	float	float
float64	64-bit IEEE float	double	float
string	ascii string (4)	std::string	string
time	secs/nsecs signed 32-bit ints	ros::Time	rospy.Time
duration	secs/nsecs signed 32-bit ints	ros::Duration	rospy.Duration

ROS Message Create Cont.



Package Dependencies

buildtool_depend: ament_cmake

depend: rclcpp builtin_interfaces rosidl_default_generators action_msgs

exec_depend: rosidl_default_runtime

ROS Message Create Cont.



to find dependencies

```
find_package(ament_cmake REQUIRED)
find_package(builtin_interfaces REQUIRED)
find_package(rosidl_default_generators REQUIRED)
```

to generate messages

```
rosidl_generate_interfaces(PROJECT_NAME "msg/FriendInfo.msg" "msg/R2D2.msg" "srv/FriendInfoService.srv" DEPENDENCIES builtin_interfaces)
```

ROS Service





ROS Service



- Peer-to-peer
- Execute sequentially, i.e, request and then have to wait till the response
- *.srv is the file type that defines the service that has two parts: a request and a response. When creating a service, request and response is separated by "—", which is given in the next slide
- Similar analogy how topic works, yet services are two way transports. A service does one-to-one communication, topic does many to many communication

ROS Service Create



create a service

mkdir -p catkin_ws/src/hello_world/srv cd catkin_ws/src/hello_world/srv touch **R**obot**A**ctions.srv

service

string name string id

string heartbeat

ROS Service Create Cont.



to generate a service (define in CMakeLists.txt)

rosidl_generate_interfaces(PROJECT_NAME

"msg/FriendInfo.msg"

"msg/R2D2.msg"

"srv/FriendInfoService.srv"

DEPENDENCIES builtin_interfaces)

ROS Service



to run a service

ros2 launch hello_world service_server.py

to call a service

ros2 launch hello_world service_client.py

ros2 service call service_name message

ros2 service call /set_heartbeat friend_msgs/srv/FriendInfoService "id: 456, value: 5678"

ros2 run hello_world service_client 4567

ROS Publisher



to write a publisher

mkdir -p catkin_ws/src/first_package/scripts cd catkin_ws/src/first_package/scripts touch hello_pub.py chmod +x hello_pub.py

ROS Publisher






ROS Publisher Create



```
import relpy
from rclpy.node import Node
from std msgs.msg import String
class MinimalPublisher(Node):
    def init (self):
        super(). __init__('minimal_publisher')
        self.publisher = self.create publisher(String, 'topic', 10)
        timer period = 0.5 # seconds
        self.timer = self.create timer(timer period, self.callback)
        self.i = 0
    def callback(self):
        msq = String()
        msg.data = 'Hello World: %d' % 567
        self.publisher .publish(msg)
```

ROS Subscriber





ROS Subscriber



to write a subscriber

mkdir -p catkin_ws/src/first_package/scripts cd catkin_ws/src/first_package/scripts touch hello_sub.py chmod +x hello sub.py

ROS Subscriber Create



```
import relpy
from rclpy.node import Node
from std msgs.msg import String
class MinimalSubscriber(Node):
    def init (self):
        super(). __init__('minimal_subscriber')
        self.subscription = self.create subscription(
            String, 'topic', self. listener callback, 10)
        self.subscription # prevent unused variable warning
    def listener callback(self. msg):
        self.get logger().info('l_heard: "%s" ' % msg.data)
```

ROS Subscriber and Publisher Install



to install scripts (define in CMakeLists.txt)

install(PROGRAMS scripts/hello_pub.py scripts/hello_sub.py DESTINATION lib/\$PROJECT_NAME)

Let's try to say hello!



to run

ros2 run hello_world hello_sub.py ros2 run hello_world hello_pub.py

ROS parameters



Parameters in ROS are associated with **individual nodes**. Parameters are used to **configure** nodes **at startup (and during runtime)**, without changing the code. The **lifetime** of a parameter is tied to the **lifetime of the node**.

- To see the parameters that belongs to each node ros2 param list
- To get a parameter value ros2 param get /node_name param_name
- To set a parameter value ros2 param set /node_name param_name value
- To load a set of parameters ros2 param load /node_name param_list.yaml
- To load a set of parameters when it starts ros2 run /package_name /node_name --ros-args --params-file param_list.yaml
- To set params when node starts ros2 run /package_name /node_name
 - --ros-args -p argv1:=456 -p argv2:=4567

ROS1 Nodelets and ROS2 Composition



- Conceptually node and nodelets (or compositions) are same
- These are designed to reduce to overhead, i.e., without copying the data, when running on the same machine
- Quite complicated to implement
- Nodelets (or compositions) are designed to provide a way to run multiple algorithms on a single machine, in a single process, without incurring copy costs when passing messages

ROS Components



Composing multiple nodes in a single process

- To see the available component types ros2 component types
- To run the in-build ros2 component manager ros2 component types
- To see running component list ros2 component list
- To load a component ros2 component load /ComponentManager ros2_composition composition::SenderNode
- To unload a component ros2 component unload /ComponentManager ros2_composition composition::SenderNode
- Compile-time composition, e.g., ros2 launch ros2_composition composition_demo_launch.py