# 211: Computer Architecture Spring 2017

Instructor: Prof. Santosh Nagarakatte

### Topics:

- C programming conclusion
- Data Representation
  - Reading: Chapter 2.1, 2.2, 2.3, 2.4, 2.5

# Signed/Unsigned in C

- Unsigned values in C
  - Declare unsigned int i = 10;
  - Use typecasts i = (unsigned) j;
- -1 when interpreted as a unsigned value is a huge number is
  - $\cdot 2^{n} 1$

# Sign extension

Signed integer	4-bit representation	8-bit representation	16-bit representation
+1	0001	0000001	000000000000001
-1	1111	11111111	111111111111111

# Floating point

Integers typically written in ordinary decimal form

■ E.g., 1, 10, 100, 1000, 10000, 12456897, etc.

But, can also be written in scientific notation

■ E.g., 1x10<sup>4</sup>, 1.2456897x10<sup>7</sup>

What about binary numbers?

- Works the same way
- $\bullet$  0b100 = 0b1x22

Scientific notation gives a natural way for thinking about floating point numbers

 $\bullet$  0.25 = 2.5x10<sup>-1</sup> = 0b1x2<sup>-2</sup>

How to represent in computers? Why not use fixed point numbers?

# **IEEE** floating point standard

Most computers follow IEEE 754 standard

Single precision (32 bits)

Double precision (64 bits)

Extended precision (80 bits)

S Exponent Fraction

### **Numerical Values**

#### Three different cases:

- Normalized values
  - exponent field  $\neq$  0 and exponent field  $\neq$  2<sup>k</sup>-1 (all 1's)
  - exponent = binary value Bias
    - » Bias =  $2^{k-1}$ -1 (e.g., 127 for float)
  - Value of the number = 1.(mantissa field)
  - Ex: (sign: 0, exp: 1, mantissa: 1) would give 0b1.1x2<sup>-126</sup>
- Denormalized values
  - exponent field = 0
  - exponent = 1 − Bias (e.g., -126 for float)
  - Value of the number = mantissa field (no leading 1)
  - Ex: (sign: 0, exp: 0, mantissa: 10) would give 0b10x2<sup>-126</sup>
- Special values: represent +∞, -∞, and NaN

### **Decimal to IEEE Floating Point**

5.625

In binary

 $101.101 \rightarrow 1.01101 \times 2^{2}$ 

Exponent field has value 2

add 127 to get 129

Exponent is 10000001

Mantissa is 01101

Sign bit is 0

0 10000001 01101000000000000000000

### Floating point in C

#### 32 bits single precision (type float)

- 1 bit for sign, 8 bits for exponent, 23 bits for mantissa
  - Sign bit: 1 = negative numbers, 0 = positive numbers
  - Exponent is power of 2
- Have 2 zero's
- Range is approximately -10<sup>38</sup> to 10<sup>38</sup>

#### 64 bits double precision (type double)

- 1 bit for sign, 11 bits for exponent, 52 bits for mantissa
- Majority of new bits for mantissa → higher precision
- Range is -10<sup>308</sup> to +10<sup>308</sup>

### One more example

Convert 12.375 to floating point representation Binary is 1100.011

1.100011 x 2<sup>3</sup>

Exponent = 127 + 3 = 130 = 0b10000010

Mantissa = 100011

Sign = 0

### Floating Point Operations

- No exact representation for a floating point
  - Mantissa is only 23 bits in 32 bit representation
  - Least significant bits may be dropped
- Floating point operations are not associative
  - (3.14 + 1e10) 1e10 != 3.14 + (1e10 1e10). Why?

Let's say we have a 6-bit floating point representation with 1-bit for the sign, 3-bits for the exponent and 2-bits for the Mantissa.

What is the bias?

A: 7

B: 3

C: 1

D: 8

Let's say we have a 6-bit floating point representation with 1-bit for the sign, 3-bits for the exponent and 2-bits for the Mantissa.

What is the abstract representation for a normalized value?

Let's say we have a 6-bit floating point representation with 1-bit for the sign, 3-bits for the exponent and 2-bits for the Mantissa.

Which of this is a normalized floating point value?

A: 1 001 11

B: 0 111 00

C: 1 110 11

D: 0 000 11

Let's say we have a 6-bit floating point representation with 1-bit for the sign, 3-bits for the exponent and 2-bits for the Mantissa.

Which of this is a denormalized floating point value?

A: 0 001 11

B: 1 000 11

C: 0 100 00

D: 1 111 11

Let's say we have a 6-bit floating point representation with 1-bit for the sign, 3-bits for the exponent and 2-bits for the Mantissa.

Which of this is a representation of infinity?

A: 1 101 11


B: 0 000 11

C: 0 111 11

D: 0 111 00

### **Hardware Software Interface**

### **Programming Meets Hardware**



How do you get performance?

# **Performance with Programs**

(1) Program: Data structures + algorithms

(2) Compiler translates code

(3) Instruction set architecture

(4) Hardware Implementation

### **Instruction Set Architecture**

- (1) Set of instructions that the CPU can execute
  - (1) What instructions are available?
  - (2) How the instructions are encoded? Eventually everything is binary.
- (2) State of the system (Registers + memory state + program counter)
  - (1) What instruction is going to execute next
  - (2) How many registers? Width of each register?
  - (3) How do we specify memory addresses?
    - Addressing modes
- (3) Effect of instruction on the state of the system

### IA32 (X86 ISA)

There are many different assembly languages because they are processor-specific

- IA32 (x86)
  - x86-64 for new 64-bit processors
  - IA-64 radically different for Itanium processors
  - Backward compatibility: instructions added with time
- PowerPC
- MIPS

We will focus on IA32/x86-64 because you can generate and run on iLab machines (as well as your own PC/laptop)

■ IA32 is also dominant in the market although smart phone, eBook readers, etc. are changing this

### X86 Evolution

8086 – 1978 – 29K transistors – 5-10MHz

1386 – 1985 – 275K transistors – 16-33 MHz

Pentium4 – 2005 – 230M transistors – 2800-3800 MHz

Haswell -2013 -> 2B transistors -3200-3900 MHz

#### Added features

- Large caches
- Multiple cores
- Support for data parallelism (SIMD) eg AVX extensions

### CISC vs RISC

CISC: complex instructions : eg X86

- Instructions such as strcpy/AES and others
- Reduces code size
- Hardware implementation complex?

RISC: simple instructions: eg Alpha

- Instructions are simple add/ld/st
- Increases code size
- Hardware implementation simple?

### **Aside About Implementation of x86**

About 30 years ago, the instruction set actually reflected the processor hardware


■ E.g., the set of registers in the instruction set is actually what was present in the processor


As hardware advanced, industry faced with choice

- Change the instruction set: bad for backward compatibility
- Keep the instruction set: harder to exploit hardware advances
  - Example: many more registers but only small set introduced circa 1980

Starting with the P6 (PentiumPro), IA32 actually got implemented by Intel using an "interpreter" that translates IA32 instructions into a simpler "micro" instruction set

### P6 Decoder/Interpreter





### **Assembly Programming**


Brief tour through assembly language programming Why?

- Machine interface: where software meets hardware
- To understand how the hardware works, we have to understand the interface that it exports


Why not binary language?

- Much easier for humans to read and reason about
- Major differences:
  - Human readable language instead of binary sequences
  - Relative instead of absolute addresses


# **Assembly Programmer's View**




### **Memory**




### **Memory Access: Read**




### **Memory Access: Write**





### **Memory Access: Write**





### **Processor: ALU & Registers**


















# **Putting It All Together**



# C & Assembly Code

#### **Sample C Code**

```
int accum;
                           gcc -O1 -m32 -S code.c
int sum(int x, int y)
                            Generated Assembly
  int t = x + y;
                           sum:
  accum += t;
                                push %ebp
  return t;
                                mov1 %esp, %ebp
                                movl 12(%ebp), %eax
                                addl 8(%ebp), %eax
                                addl %eax, accum
                                popl %ebp
```

ret

## C & Machine Code

#### Sample C Code objdump -d code.o int accum; 0000000 <sum>: int sum(int x, int y){ 0. 55 push %ebp int t = x + y; 1: 89 e5 mov %esp,%ebp accum += t; mov 0xc(%ebp),%eax 3: 8b 45 0c return t; 6: 03 45 08 add 0x8(%ebp),%eax 01 05 00 00 00 00 add %eax, accum qcc -O1 -m32 -c code.c qdb code.o f: 5d %ebp pop $(qdb) \times 100xb sum$ 10: **c3** ret

```
<sum>: 0x55 0x89 0xe5 0x8b 0x45 0x0c 0x03 0x45
0x8 <sum+8>: 0x08 0x01 0x05 0x00 0x00 0x00 0x00 0x5d
0x10 <sum+16>: 0xc3 Cannot access memory at address 0x11
```

# **Assembly Characteristics**

## Sequence of simple instructions

## Minimal Data Types

- "Integer" data of 1, 2, or 4 bytes
  - Data values
  - Addresses (untyped pointers)
- Floating point data of 4, 8, or 10 bytes
- No aggregate types such as arrays or structures
  - Just contiguously allocated bytes in memory

## No type checking

- Interpretation of data format depends on instruction
- No protection against misinterpretation of data

# **Assembly Characteristics**

## 3 types of Primitive Operations


- Perform arithmetic function on register or memory data
- Transfer data between memory and register
  - Load data from memory into register
  - Store register data into memory
- Transfer control
  - Unconditional jumps to/from procedures
  - Conditional branches

# **x86 Characteristics**

Variable length instructions: 1-15 bytes

Can address memory directly in most instructions

Uses Little-Endian format (Least significant byte in the lowest address)



Rutgers University Santosh Nagarakatte 42

# **Instruction Format**

#### **General format:**

opcode operands

## Opcode:

- Short mnemonic for instruction's purpose
  - movb, addl, etc.

## Operands:

- Immediate, register, or memory
- Number of operands command-dependent

## Example:

■ movl %ebx, (%ecx)

# **Machine Representation**

Remember, each assembly instruction translated to a sequence of 1-15 bytes

Opcode	addressing mode	other bytes
--------	-----------------	-------------

First, the binary representation of the opcode

Second, instruction specifies the addressing mode

- The type of operands (registers or register and memory)
- How to interpret the operands

Some instructions can be single-byte because operands and addressing mode are implicitly specified by the instruction

■ E.g., pushl

# x86 Registers

## General purpose registers are 32 bit

Although operations can access 8-bits or 16-bits portions

Originally categorized into two groups with different functionality

- Data registers (EAX, EBX, ECX, EDX)
  - Holds operands
- Pointer and Index registers (EBP, ESP, EIP, ESI, EDI)
  - Holds references to addresses as well as indexes

Now, the registers are mostly interchangeable


## Segment registers

Holds starting address of program segments

• CS, DS, SS, ES

Jagarakatte 45

# x86 Registers



**32 BITS** 

# **x86 Programming**

- Mov instructions to move data from/to memory
  - Operands and registers
- Addressing modes
- Understanding swap
- Arithmetic operations
- Condition codes
- Conditional and unconditional branches
- Loops and switch statements

## **Data Format**

Byte: 8 bits

■ E.g., char

Word: 16 bits (2 bytes)

■ E.g., short int

Double Word: 32 bits (4 bytes)

■ E.g., int, float

Quad Word: 64 bits (8 bytes)

■ E.g., double

Instructions can operate on any data size

- movl, movw, movb
  - Move double word, word, byte, respectively
- End character specifies what data size to be used

# **MOV** instruction

#### Most common instruction is data transfer instruction

- Mov SRC, DEST: Move source into destination
- SRC and DEST are operands
- DEST is a register or a location
- SRC can be the contents of register, memory location, constant, or a label.
- If you use gcc, you will see movl <src>, <dest>
- All the instructions in x86 are 32-bit

## Used to copy data:


- Constant to register (immediate)
- Memory to register
- Register to memory
- Register to register

Cannot copy memory to memory in a single instruction

# **Immediate Addressing**

## Operand is immediate

- Operand value is found immediately following the instruction
- Encoded in 1, 2, or 4 bytes
- \$ in front of immediate operand
- E.g., movl \$0x4040, %eax



# Register Mode Addressing

Use % to denote register

■ E.g., %eax

Source operand: use value in specified register

Destination operand: use register as destination for value

## Examples:

- movl %eax, %ebx
  - Copy content of %eax to %ebx
- movl \$0x4040, %eax → immediate addressing
  - Copy 0x4040 to %eax
- movl %eax, 0x0000f → Absolute addressing
  - Copy content of %eax to memory location 0x0000f

# **Indirect Mode Addressing**

## Content of operand is an address

Designated as parenthesis around operand

Offset can be specified as immediate mode

#### Examples:

- movl (%ebp), %eax
  - Copy value from memory location whose address is in ebp into eax
- movl -4(%ebp), %eax
  - Copy value from memory location whose address is -4 away from content of ebp into eax

# **Indexed Mode Addressing**

## Add content of two registers to get address of operand

- movl (%ebp, %esi), %eax
  - Copy value at (address = ebp + esi) into eax
- movl 8(%ebp, %esi),%eax
  - Copy value at (address = 8 + ebp + esi) into eax

## Useful for dealing with arrays

- If you need to walk through the elements of an array
- Use one register to hold base address, one to hold index
  - E.g., implement C array access in a for loop
- Index cannot be ESP

# Scaled Indexed Mode Addressing

Multiply the second operand by the scale (1, 2, 4 or 8)

- movl 0x80 (%ebx, %esi, 4), %eax
  - Copy value at (address = ebx + esi\*4 + 0x80) into eax

Where is it useful?

# **Address Computation Examples**

%edx	0xf000
%ecx	0x100

Expression	Computation	Address
0x8(%edx)	0xf000 + 0x8	0xf008
(%edx,%ecx)	0xf000 + 0x100	0xf100
(%edx,%ecx,4)	0xf000 + 4*0x100	0xf400
0x80(,%edx,2)	2*0xf000 + 0x80	0x1e080

# mov1 Operand Combinations

# Source Destination C Analog | Imm | Reg | mov1 \$0x4, %eax | temp = 0x4; | | Mem | mov1 \$-147, (%eax) | \*p = -147; | | Reg | Reg | mov1 %eax, %edx | temp2 = temp1; | | Mem | mov1 %eax, (%edx) | \*p = temp; | | Mem | Reg | mov1 (%eax), %edx | temp = \*p; |

Cannot do memory-memory transfers with single instruction

# **Stack Operations**

By convention, %esp is used to maintain a stack in memory

Used to support C function calls

%esp contains the address of top of stack

Instructions to push (pop) content onto (off of) the stack

- pushl %eax
  - $\bullet$  esp = esp -4
  - Memory[esp] = eax
- popl %ebx
  - ebx = Memory[esp]
  - $\bullet$  esp = esp + 4

Where does the stack start? We'll discuss later