

User Manual

Device Placement

Step 1: Placement

Place the putter inside the clamp, ensuring that the logo is aligned with the putter face. As show in image 1.

Step 2: Sliding

Slide the device up on the shaft of the putter, positioning it just below the grip. As shown in image 2.

Step 3: Closing

Close the top part of the device, ensuring a secure fit.

Step 4: Pressing

Press firmly on the top part of the device until you hear a click sound, indicating it is securely fastened.



Image 1 Image 2





Powering On

Step 1: Power Switch

Locate the power switch on the device located on the side panel.

Step 2: Turning On

Switch the power switch to the "ON" position. The device will start up, and the indicator color will be green to indicate that it is turned on.

Step 3: Connecting to Mobile Device

- Ensure that your mobile device's Bluetooth is enabled and in pairing mode.
- Open the device's companion mobile application and follow the instructions to connect the device to your mobile device.
- Once the device successfully establishes a connection with your mobile device, the indicator color will change to blue, indicating a successful connection.

Step 4: Turning Off

To turn off the device, switch the power switch to the "OFF" position. The device will power down, and the indicator light will turn off

Note: for device number 5 the switch position for on and off is inverse

Device(Off Position) OnePuttPro Device(On Position)





For 5th device

LED Indicator Light

Step 1: Indicator Light Status

Observe the indicator light on the device to determine its status.

Step 2: Red Light (Device Needs Charging)


- If the indicator light is red, it indicates that the device needs charging.
- Connect the device to a power source using the provided charging cable.
- Allow the device to charge until the indicator light turns green or blue, indicating that it is ready for pairing or data capturing.

Step 3: Green Light (Ready to Pair)

- If the indicator light is green, it indicates that the device is ready to pair with a mobile device.
- Ensure that your mobile device's Bluetooth is enabled and in pairing mode.
- Open the device's companion mobile application and follow the instructions to pair the device with your mobile device.

Step 4: Blue Light (Paired and Data Capturing)

- Once the device successfully pairs with your mobile device, the indicator light will turn blue.
- The blue light indicates that the device is paired, and it is actively capturing data.



Charging Status Indicator

Step 1: Charging status

Locate the charging status indicator on the device. It is usually located near the charging port.

Step 2: Blue Light (Charging Complete)

- Connect the device to a power source using the provided charging cable.
- When the device starts charging, the charging status indicator will turn blue.
- Leave the device connected until the charging status indicator turns blue, indicating that the charging is complete.
- Once the charging is complete, disconnect the device from the power source.

Step 3: Red Light (Charging in Progress)

- If the charging status indicator remains red, it means that the device is still charging.
- Ensure that the device is properly connected to the power source and wait for the charging process to complete.
- Keep the device connected until the charging status indicator turns blue, indicating that the charging is complete.

On Charging(Red Light)






Charging Done(Blue Light)







OnePuttPro App Login

- Log in to your OnePuttPro account using your registered username and password. If you have forgotten your password, look for the "Forgot password" option and follow the instructions to reset it.
- If you haven't created a user account yet, you can register by providing the required information and following the registration process. If you already have an account, proceed to the next step.








Practice

How to Connect and Start Practicing with the OnePuttPro Device:


1. Homepage

You should now be on the homepage or main screen of the application.




2. Access Device Menu

- Go to the Device menu located at the bottom of the screen
- Tap on this Device button/icon to open the device menu.




3. Select OnePuttPro Device

- Within the device menu, search for "1PuttPro" or a similar option that corresponds to your device.
- Tap on the 1PuttPro device option to select it.



4. Connect the Device


Once you've selected the OnePuttPro device, the application will likely prompt you to connect to it.






5. Permission for Bluetooth (If First Time)

- If this is the first time you're connecting the device, your device may ask for permission to access Bluetooth.
- Grant permission by tapping "Allow" or a similar option when prompted.



6. Connection Confirmation

Once successfully connected, the app should display a green indicator or some other visual cue to confirm that the device is connected.





7. Practise Parameters


- Navigate within the app to the "Practice Session" screen.
- This screen may have various practice parameters and settings that you can customize to your liking.

8. Select Practice Parameters


Depending on your training goals and preferences, select the specific parameters for your practice session. This could include options such as distance, slope, target, or other relevant settings.

9. Start Practice

- After configuring your practice parameters, look for a "Start Practice" button or similar action that initiates the practice session.
- Tap on this button to begin your practice session with the selected parameters.



ı	Deviation	Target	
Angle of lie start	± 0 °	0	
Angle of lie impact	± 0 °	0	
Loft Angle	± 0 m/s²	0	
Acceleration Impact	0	0	



Practice Session

- The OnePuttPro device utilizes a color indicator square to provide visual cues during the data capture process.
- Here's how the color indicator square behaves.


Red: The red color indicates that the device is not currently capturing any Putting Motion and is not capturing data

Blue: When the color indicator square turns blue, it signifies that the device is ready and in putting position and capturing data.

Green: Once you are in the putting position, the colour indicator square will turn green. This indicates that the device is actively recording data.

- To initiate the data capture process, follow these steps
 - Position yourself for the putt and align your shot.
 - Wait for approximately 1.5 seconds while maintaining your putting position. During this
 time, the device will emit a beep sound, and the colour indicator square will change to
 indicate that data recording has begun.
 - Make your putt while the device is recording the data(Blue Indicator). The device will
 capture relevant information about your putt, such as the stroke dynamics and clubface
 alignment.
 - Once the putt is completed, the device will play a sound to indicate the end of data capture.
 - The results of your putt, including relevant statistics or feedback, should be displayed on the app or website screen.
 - Please note that the specific features and behavior of the OnePuttPro device may vary, so it's always recommended to refer to the device's user manual or instructions provided by the manufacturer for accurate and up-to-date information on its usage.


Practice Session




Display of Statistics

- After a valid putt is made, the app will display the putting statistics on the screen.
- Take note of the relevant stats provided, such as accuracy, distance, or other relevant metrics.
- Reset and Prepare for the Next Putt:
- The app will reset automatically after a few seconds, typically within 5 seconds.
- A red indicator will appear, suggesting that the app is ready to record the next putt.
- Repeat the Process
- Continue making putts and allowing the app to record and display the statistics.
- Take breaks as needed and resume the process when ready.

Display of Statistics





Display of Statistics







Ending the Session

- To end your putting session, either tap the "Stop" or "End Session" button on the app's interface.
- disconnect from your oneputtpro device and connect to internet.
 This is an important step as app will not proceed further untill you are connected to internet
- Review your session data and save it if desired.
- Exit the app or proceed to use other features provided by the Golf Putting App.





