
AUTODESK



Revit to IFC Scheduler – User Guide





Table of Contents

1	Int	troduc	ction	3
	1.1	Purp	ose	3
	1.2	Ove	view	3
2	Us	age		4
	2.1	Logi	1	4
	2.2	IFC :	Settings Set Names	5
	2.2	2.1	Adding Default IFC Settings Set Names	5
	2.2	2.2	Removing Default IFC Settings Set Names	7
	2.3	BIM	360 Accounts	8
	2.3	3.1	Enabling a BIM 360 Account	8
	2.4	BIM	360 Projects	10
	2.4	1.1	Viewing the Project List	10
	2.4	1.2	View a Single Project	. 10
	2.5	Conv	versions	12
	2.5	5.1	Ad-hoc Conversions	. 12
	2.5	5.2	Create new Scheduled Conversion	14
	2.5	5.3	Edit Existing Schedule	16
	2.5	5.4	Delete Existing Schedule	17
	2.5	5.5	View Conversion history	19
	2.6	Land	juage	
	2.6		Change Language	



List of Figures

Figure 1 Login Page	4
Figure 1 Login PageFigure 2 Settings Page	6
Figure 3 Adding an IFC Settings Set Name	6
Figure 4 Settings Page	7
Figure 5 Delete Set Name Popup	8
Figure 6 Settings Page	9
Figure 7 Projects page	10
Figure 8 Single Project Page	11
Figure 9 Project Tree View	12
Figure 10 'Convert Selected to IFC Now' popup	13
Figure 11 Single Project Page	14
Figure 12 New Schedule Page	15
Figure 13 Existing Schedule Page	16
Figure 14 Existing Schedule Page	17
Figure 15 Delete Schedule popup	18
Figure 16 Single Project Page	19
Figure 17 Conversion List Page	20
Figure 18 View a single model run	20



1 Introduction

1.1 Purpose

This document provides usage and configuration instructions for the code sample, Revit to IFC Scheduler, developed by the Autodesk Consulting team and maintained by the Autodesk Forge Help team.

1.2 Overview

This code sample demonstrates the usage of Model Derivative API, which allows you to convert a Revit `.rvt` file stored in BIM 360 Docs to `.ifc` format, on a scheduled or ad-hoc basis. It uses the Forge Model Derivative API to do so.

© 2022 Autodesk Version No: 1.2



2 Usage

2.1 Login

When accessing the application, you will be asked to login using your Autodesk account. There are three levels of users of the application:

1. Application Admins:

- These users may enable or disable BIM 360 Accounts, adjust account-level settings, and define default IFC Settings Set Names
- b. These users are assigned in the Azure App Service Configuration Settings for online deployments, or `appsettings.Development.json` for local deployments.

2. BIM 360 Account Admins:

- a. These users may see all projects in accounts of which they are admins, and of which have been activated by the Application Admin.
- b. These users are assigned in BIM 360.

3. BIM 360 Project Admins:

- a. These users may see all projects to which they have been given access, which is in accounts that have been activated by the Application Admin.
- b. These users are assigned in BIM 360.

If the user logs in with an account that does not have the necessary access, they will see no data.




Figure 1 Login Page

© 2022 Autodesk Version No: 1.2



2.2 IFC Settings Set Names

When creating an IFC file, Revit uses a group of predefined settings to control the specific IFC version, file type, phase to export, and more. These settings are called IFC Settings Sets. Revit provides nine default IFC Settings Sets by default, and Revit users can copy and edit these sets.

The Forge Model Derivative service will convert Revit files into IFC files using a named IFC Settings Set if provided or will use the default setting in the file if no name is specified. In addition, application Admins may predefine commonly used names on the Settings page, which will then show in all places throughout the application where input is required.

See IFC Export Setup Options | Autodesk Knowledge Network to learn more about IFC Settings Sets. Here is the name list of Revit built-in IFC export settings (since Revit 2017) of Forge Model Derivative service:

- IFC2x3 Coordination View 2.0
- IFC2x3 Coordination View
- IFC2x3 GSA Concept Design BIM 2010
- IFC2x3 Basic FM Handover View
- IFC2x2 Coordination View
- IFC2x2 Singapore BCA e-Plan Check
- IFC2x3 Extended FM Handover View
- IFC4 Reference View
- IFC4 Design Transfer View

2.2.1 Adding Default IFC Settings Set Names

- 1. Navigate to the 'Settings' page, via the link at the top of the page
- 2. Click 'Add IFC Settings Set Name'
- 3. Type in a name, and click 'Create Set Name






Figure 2 Settings Page




Figure 3 Adding an IFC Settings Set Name



2.2.2 Removing Default IFC Settings Set Names

- 1. Navigate to the 'Settings' page, via the link at the top of the page
- 2. Click 'Delete' next to the desired IFC Settings Set Name
- Click 'Delete Set Name'




Figure 4 Settings Page






Figure 5 Delete Set Name Popup

2.3 BIM 360 Accounts

2.3.1 Enabling a BIM 360 Account

To enable a BIM 360 Account, an Application Admin must do the following:

- 1. Click on 'Settings' on the starting page
- 2. Toggle the 'Include in Project List' switch in the 'Accounts' list.






Figure 6 Settings Page



2.4 BIM 360 Projects

2.4.1 Viewing the Project List

Account and Project Admins may see the list of all projects to which they have access by clicking the Projects link at the top of the page.




Figure 7 Projects page

2.4.2 View a Single Project

Both Account and Project Admins may view projects to which they have access by selecting the desired project from the Project List on the left-hand side.

© 2022 Autodesk Version No: 1.2






Figure 8 Single Project Page



2.5 Conversions

The primary application of this tool is to convert Revit models to IFC using the Forge Model Derivative API. Note that this action has a token cost associated with it, as described at https://forge.autodesk.com/pricing

If a model has not changed since the last conversion to IFC, it will not be converted again.

2.5.1 Ad-hoc Conversions

A single model, or multiple models, may be converted to IFC on-demand:

- 1. Select the files or folders to be converted in the folder tree
- 2. Press the 'Convert Selected to IFC Now' button.
- 3. Choose or type the desired IFC Settings Set Name. If left blank or the file does not have the selected set name, the Model Derivative system will use the default settings in that individual Revit file.




Figure 9 Project Tree View






Figure 10 'Convert Selected to IFC Now' popup



2.5.2 Create new Scheduled Conversion

A single model, or multiple models, may be scheduled to convert on a user-defined schedule.

- Select the files and folders to be converted from the folder tree.
- 2. Press the 'Create Scheduled Conversion' button.
- 3. Edit the Schedule Name
- 4. Choose from the 'IFC Setting5. Set the schedule as desired. Choose from the 'IFC Settings Set Name in Revit' dropdown, or type in a custom value.
- 6. Press 'Save Changes'

Note. If a folder is selected, and new models are added to this folder of step 1, they will be included in the next scheduled conversion.




Figure 11 Single Project Page






Figure 12 New Schedule Page



2.5.3 Edit Existing Schedule

Any admin may edit all portions of an existing schedule with access to the project:

- 1. Select the project from the 'Schedules' panel.
- 2. To change the name, edit the 'Schedule name' text box.
- 3. To change the IFC Settings set name, choose from the IFC Settings Set Name dropdown, or type in a custom value.
- 4. To change the schedule, select from the various schedule values.
- 5. To change the included folders and files, select the desired folders and files from the folder tree.
- 6. Press the 'Save Changes' button.




Figure 13 Existing Schedule Page



2.5.4 Delete Existing Schedule

Any admin may delete existing schedules with access to the project.

- 1. Select the project from the 'Schedules' panel.
- 2. Press the 'Delete Schedule' button.
- 3. Confirm by pressing the 'Delete' button in the popup.




Figure 14 Existing Schedule Page






Figure 15 Delete Schedule popup



2.5.5 View Conversion history

With their status and details, all past conversions are available in a per-project list.

- 1. Navigate to the single project page
- 2. Press the 'Conversion History' button
- 3. To see details on a specific conversion, click on the row




Figure 16 Single Project Page






Figure 17 Conversion List Page




Figure 18 View a single model run



2.6 Language

The application may be run in either English or Norwegian.

2.6.1 Change Language

Any user may change their language by selecting the 'en' or 'no' button at the top of the screen.

- Press either 'en' or 'no' at the top of the screen.
 Some text, such as column headers, will not update until the page is reloaded.



Change history

Date	Version	Author	Description
18-Jan-22	1.0	Daniel Clayson	Document Creation
23-Feb-22	1.1	Eason Kang	Logo & Footer Change, and consistency correction
01-Mar-22	1.2	Eason Kang	Add name list of Revit built-in IFC export settings

		list	

Name	Title	Organization

Approval history

Date	Version	Approver	Comments
Click here to enter a date.			

Document references

No.	Title	Version	Author


Abbreviations

Term	Description

Terminology

Term	Description

Page 22 © 2022 Autodesk Version No: 1.2



Autodesk and the Autodesk logo are registered trademarks of Autodesk, Inc., and/or its subsidiaries and/or affiliates in the USA and/or other countries. All other brand names, product names, or trademarks belong to their respective holders. Autodesk reserves the right to alter product and service offerings, and specifications and pricing at any time without notice, and is not responsible for typographical or graphical errors that may appear in this document. © 2022 Autodesk, Inc. All rights reserved.