Semaphore using FreeRTOS on LPC2148

e-Yantra Team

July 19, 2016

Contents

1	1 What is FreeRTOS		
	1.1 Advantage of FreeRTOS	3	
	1.2 Drawbacks/Disadvantages (write some fancy word)	3	
2	Requirement		
3	Getting Started!	4	
	3.1 DataTypes	4	
	3.2 Variable Names	4	
	3.3 Macros	4	
	3.4 Creating Tasks	4	
	3.5 Frequently used API's	5	
4	Introduction to semaphore	6	
	4.1 Binary Semaphores	6	
	4.2 Mutex	6	
	4.3 Counting Semaphore	6	
	4.4 Mutex vs Binary Semaphore	6	
5	Binary Semaphore	8	
	5.1 Code:	8	
		10	
6	Mutex	11	
	6.1 Code:	11	
		13	
7	Counting Semaphore	14	
•	-	14	
		17	
8	Task Notification	19	
O		20	
		23	
9	References	24	

1 What is FreeRTOS

For statrters FreeRTOS is just a bunch of C files which enables us to implement RTOS in around 32 microcontrollers. FreeRTOS provides files which can be used in multiple microcontrollers with some microcontroller specific support files.

The main advantage of Implementing FreeRTOS in any microcontroller is the ability to multi-task.

MultiTasking enables the device to execute multiple "Tasks" at the same time. MultiTasking in single core systems is implemented by allocating each task a time slice of the processor, In this way Multiple Tasks can be executed at the "same time".

1.1 Advantage of FreeRTOS

- 1. Proper Utilization of Resources.
- 2. Low foot-print.
- 3. Priority based scheduling of Tasks.
- 4. API's for Semaphores.
- 5. API's for Making and managing queues.

1.2 Drawbacks/Disadvantages (write some fancy word)

- 1. Use of TaskNotification to implement MailBox.
- 2. Not readily Portable to all devices.
- 3. Limited source material.

2 Requirement

- 1. Knowledge of C++
- 2. FreeRTOS source files/API
- 3. Keil compiler
- 4. Flash magic
- 5. FireBird V (LPC2148)

3 Getting Started!

3.1 DataTypes

FreeRTOS defines counterparts of few basic data types

Data Type	General Data Type
portCHAR	char
portSHORT	short
portLONG	long
portTickType	This is used to store the tick count
portBASE_TYPE	Generally used for Bool type data, is 32 bit for 32 bit type uC

3.2 Variable Names

The Data type is prefixed to the name of a variable for e.g

In vTaskDelay "v" denotes the return type "void".

In xTaskCreate "x" denotes portBASE_TYPE.

3.3 Macros

Refer to page 168-169 of the RTOS document by Richard Barry.

3.4 Creating Tasks

- BaseType_t :Can be used to check if the task has been created or not.If
 the returned value is pdTRUE the task has been created if pdFALSE
 is returned the task was not created.
- pvTaskCode:This parameter is a pointer to the task which has been created.
- pcName :Name given to a Task created so that user can easily identify a task, this parameter enables the programmer to easily identify a task.
- usStackDepth: The amount of memory/space which a given task is to be allocated is passed as a parameter through this value.
- uxPriority: Each task is assigned a priority on the basis of which it is allocated the processor time priority assigned are natural numbers, as the value of number increases priority increases.
- pxCreatedTask: Tasks are assigned handles using which they can be referred by other tasks.

Same Task can have multiple instances by varying the priority, parameters passed ,pcName.

3.5 Frequently used API's

- vTaskDelay: Takes the Clock Ticks as parameter and suspends the Task for those many cycles. e.g vTaskDelay(1000);
- vTaskSuspend: Takes Taskhandle as a parameter and Suspends the "passed" task indefinitely. e.g. vTaskSuspend(t1): suspends task t1 vTaskSuspend(NULL): suspends running task
- vTaskResume :Also Takes Taskhandle as a parameter resumes the Task from suspended state e.g. vTaskResumed(t1) : resumes task t1
- tskIDLE_PRIORITY: Priority of the idle task, used to fix priority of Tasks created.

4 Introduction to semaphore

There are a limited number of resources available to any system, Similarly any microcontroller has a limited number resources available.

As the complexity of the application Increases the number of Tasks running also Increases, more and more Tasks compete for the available Processor time or The I/O devices available.

To ensure equal availability of resources to all the Tasks Operating Systems provide a facilities through semaphores.

The Greek word sema means sign or signal, and -phore means carrier . So Semaphore = signalling.

Semaphores can be classified into

- Binary Semaphores
- Mutex
- Counting Semaphores

4.1 Binary Semaphores

Binary semaphores are used for Task synchronisation. If a process ocuppies a resource the value of Binary semaphore is 1 else 0 i.e it gives information only if the resource is available or not.

4.2 Mutex

Mutex stands for Mutual Exclusion. Any Task which requires a resource can "Block" the resource when the Task uses the resource it can "Give" the resource.

4.3 Counting Semaphore

Counting semaphores are used to count resources and keep track of Multiple resources.

4.4 Mutex vs Binary Semaphore

 Mutexes are used for Resource Protection from other tasks//processes whereas Binary semaphores are used for task synchronistaion

- It is the responsibility of the occupying function to release the mutex,but a binary semaphore can be released even from ISR or any other functions.
- On the implementation level it is the Responibility of the Coder to ensure that the Mutex is only given by the task which takes it.

5 Binary Semaphore

5.1 Code:

```
#include<stdlib.h>
#include"FreeRTOS.h"
#include" task.h"
#include"LCD.h"
#include" semphr.h"
SemaphoreHandle_t xSemaphore;
//Look in the sample programs for Included functions variables etc
void forward(void *pvparam)
         vTaskDelay(5); //Added so that Back Task can occupy the resource
         if (xSemaphoreTake(xSemaphore,portMAX_DELAY)==pdTRUE)
                         Stop();
                         Forward();
                   UART0_SendStr("Forward\n");
                 vTaskDelay(5);//To avoid same Tasking Taking resources tu
        }
}
void back(void *pvparam)
        \mathbf{while}(1)
         if(xSemaphoreTake(xSemaphore,portMAX_DELAY)==pdTRUE)
                         Stop();
                         Back();
                  UART0_SendStr("Back\n");
                 vTaskDelay(5);
        }
void control_switcher(void *pvparam)
```

```
\mathbf{while}(1)
                  {xSemaphoreGive(xSemaphore);
                         UARTO_SendStr("Semaphore_given\n");
                         vTaskDelay(1200);
                           }
}
                 int main()
        PINSEL0 = 0x000000000;
                                                                                                                                                                                                                                                                                     // Reset all pins as GPIO
       PINSEL1 = 0x000000000;
       PINSEL2 = 0x000000000;
        DelaymSec (40);
                                                                      Init_Peripherals();
                                                                      UART0\_SendStr(" \setminus t \setminus tBinary\_Semaphore \setminus n");
                                  xSemaphore=xSemaphoreCreateBinary();
                                                                     xTaskCreate(forward,"forward", 300, NULL, tskIDLE\_PRIORITY + 1, No. 100, NULL, tskIDLE_PRIORITY + 1, No. 100, NULL, tskI
                                                                      xTaskCreate(back,"back", 300 ,NULL, tskIDLE_PRIORITY + 1, NULL);
                                                                     x Task Create (\verb|control_switcher||, \verb|"control_switcher"|, 300 , NULL, tskIDI | (\verb|control_switcher||, 300 , NULL), tskIDI | (\verb|control_switcher||, 300 ,
                                                                      vTaskStartScheduler(); //Task Scheduling
                                                                      while (1);
}
```

• Variable declaration

SemaphoreHandle_t xSemaphore;

This statement declares a variable of type "SemaphoreHandle_t"

• Creation of the semaphore

xSemaphore=xSemaphoreCreateBinary();

• Working of code

The forward function Waits for portMAX_DELAY i.e for maximum amount of time so that the control of Resources is available.

Similarly the back function waits for maximum time to get access to the resources.

As soon as execution of Tasks starts the resources are occupied by the back function (vTaskDelay restricts forward function), The control_switcher function is suspended for 1200 clock counts and Gives away the semaphore.

As soon as the semaphore is released the forward function waiting for allocation of resources occupies them, the cycle continues with control_switcher releasing the semaphore.

• Serial monitor Output

Binary Semaphore

Semaphore given

Back

Semaphore given

Forward

Semaphore given

Rack

Semaphore given

Forward

Semaphore given

Back

6 Mutex

6.1 Code:

```
#include < stdlib . h>
#include "FreeRTOS.h"
#include "task.h"
#include "LCD.h"
#include" semphr . h"
//Refer to actual code for necessary functions and codes
SemaphoreHandle_t xSemaphore=0;//Creation of Variable for semaphore
  void forward(void *pvparam)
         \mathbf{while}(1)
                 if (xSemaphoreTake(xSemaphore,1000) == pdTRUE)
// if available then
                     UART0_SendStr("Forward\n");
                          Forward();
                                                            // task suspended
                     vTaskDelay(1200);
                          Stop();
                          xSemaphoreGive(xSemaphore);
// after resource task completed, return the semaphore
                 else
                          UART0_SendStr("Forward_function_access_denied\n")
                  vTaskDelay(200);
         }
}
void back(void *pvparam)
          \mathbf{while}(1)
                          if (xSemaphoreTake(xSemaphore,1000) == pdTRUE)
                          UART0_SendStr("Back\n");
                          Back();
                                                                     // perform
                          vTaskDelay(1200);
data tasks ();
```

```
Stop();
                          xSemaphoreGive(xSemaphore);
/\!/\ after\ shared\ data\ task\ completed\,,\ return\ the\ semaphore
                    // if available then
        else
                 { UART0_SendStr("Back_Function_access_denied\n");
        vTaskDelay(200);
  int main()
 PINSEL0 = 0x000000000;
                                  // Reset all pins as GPIO
 PINSEL1 = 0x000000000;
 PINSEL2 = 0x000000000;
 DelaymSec(40);
        Init_Peripherals();
        UART0\_SendStr("\t\tMutex\n");
        xSemaphore = xSemaphoreCreateMutex(); //Use the Handle as a MUT
        xTaskCreate (forward \,, "forward" \,, \ 300 \ , NULL, \ tskIDLE\_PRIORITY \,+ \, 1 \,, \ NULL)
        xTaskCreate(back,"back", 300 ,NULL, tskIDLE_PRIORITY + 1, NULL);
        vTaskStartScheduler(); //Task Scheduling
        while (1);
}
```

• Variable declaration

SemaphoreHandle_t xSemaphore;

This statement declares a variable of type "SemaphoreHandle_t"

• Creation of Mutex

xSemaphore = xSemaphoreCreateMutex();

• Working of code

There are Two Tasks forward and back, when executed

The forward function Waits for 1000 clock cycles for the resources, In case the resources are not available the Task sends a message about The lack of availability of resources. Similarly the back function waits for same amount of time for resources.

As soon as execution of Tasks starts the resources are occupied by one of the task and that task blocks the acess of those resources through a mutex.

The task executes and when the execution is completed it "Gives" the Mutex and therefore the releases the resources, another waiting task then occupies those resources and blocks for a period of time it requires.

• Serial monitor Output

Mutex

Back

Forward function access denied

Forward

Back Function access denied

Back

Forward function access denied

Forward

Back Function access denied

Back

7 Counting Semaphore

:Implemented by dining Philosophers Problem

```
7.1 Code:
```

```
Note: To use mutex semaphore you need to initialize configUSE_MUTEXES to
*/
#include < stdlib . h>
#include "FreeRTOS.h"
#include "task.h"
#include "LCD.h"
#include" semphr.h"
SemaphoreHandle_t xSemaphore=0;//Creation of Variable for semaphore
int s=0;
int forks_avail[5] = \{0,0,0,0,0,0\}; //The value of Variable is 0 if a fork is
void vfork( void * pvParameters )
{
         int i;
         const unsigned char* str;
         str = ( const unsigned char * ) pvParameters;
         //Assignment of forks available on the basis of name of Philosphe
         if(str[1] == '1')
         \{i=0;\}
         if(str[1] == '2')
         \{i=1;\}
         if (str[1] == '3')
         \{i=2;\}
         if(str[1] == '4')
         \{i=3;\}
         if (str[1] == '5')
         \{i = 4;\}
         \mathbf{while}(1)
         //Waits for 1000 ticks for forks to be avaliable
```

```
//If available checks if the fork is adjacent (Right) or not
        if ((xSemaphoreTake(xSemaphore, 1000) = pdTRUE)&&(forks_avail
{
                 forks_avail[i]=1;
                 UART0_SendStr(\&str[0]);
                 UART0_SendStr(": Right_fork_obtained\n");
        if (( xSemaphore Take ( xSemaphore, 2000 ) == pdTRUE )&&(forks_avail
        { //Waits for 2000 ticcks for Left fork to be available
                         forks_avail [(i+1)\%5]=1;
                         UART0_SendStr(\&str[0]);
                         UART0_SendStr(": Left_fork_obtained_Eating_:)\n");
                         vTaskDelay (2000);
                         UART0_SendStr(\&str[0]);
                         UART0_SendStr(":Ate\_\n");
                         xSemaphoreGive(xSemaphore);
                         xSemaphoreGive(xSemaphore);
                         forks_a vail[i]=0;
                         forks_avail [(i+1)\%5]=0;
                     UART0_SendStr(\&str[0]);
                         UART0\_SendStr(":Thinking\_\n");
                         vTaskDelay(3000);
}
                 else
            UART0_SendStr(\&str[0]);
                 UART0\_SendStr(":Returned\_Right\_fork:(\_\n");
                 xSemaphoreGive(xSemaphore);
                 forks_avail[i]=0;
        }
   else
           UART0_SendStr(\&str[0]);
           UART0\_SendStr(":Hungry\n");
```

```
vTaskDelay (3000);
                    }
 }
  int main()
 PINSEL0 = 0x000000000;
                                        // Reset all pins as GPIO
 PINSEL1 = 0x000000000;
 PINSEL2 = 0x000000000;
 Init_Peripherals();
          UART0\_SendStr(" \setminus t \setminus tCounting\_Semaphore \setminus n");
          xSemaphore = xSemaphoreCreateCounting(5, 5);
           if( xSemaphore != NULL )
     {
          UART0_SendStr("\tSemaphore_Created\n");
xTaskCreate(vfork, "Philospher_1", 300, "P1", tskIDLE_PRIORITY + 1, NULL);
xTaskCreate(vfork,"Philospher\_2", 300 ,"P2", tskIDLE\_PRIORITY + 1, NULL);\\
xTaskCreate (\,vfork\,,"\,Philospher\,\,\,\,\,\,300\,\,\,\,\,,"P3"\,,\,\,tskIDLE\,\,\,\,PRIORITY\,\,+\,\,1\,,\,\,NULL)\,;
xTaskCreate(vfork,"Philospher_4", 300 ,"P4", tskIDLE_PRIORITY + 1, NULL);
xTaskCreate(vfork,"Philospher_5", 300 ,"P5", tskIDLE_PRIORITY + 1, NULL);
                    vTaskStartScheduler(); // Task Scheduling
      }
          while (1) // Never reaches this Part of the main
          \{UART0\_SendStr("\t\tSemaphore\_not\_Created\n");
}
```

• Variable declaration

```
SemaphoreHandle_t xSemaphore;
```

This statement declares a variable of type "SemaphoreHandle_t"

• Creation of Counting semaphore

```
xSemaphore = xSemaphoreCreateCounting(5,5);
```

Here 1st parameter gives the maximum count and 2nd parameter is the initial count. If the semaphore is used for counting events 2nd parameter would be 0 and if used for resources management it would be equal to maximum or initial count.

• Task Creation

```
xTaskCreate(vfork,"Philospher 1", 300 ,"P1", tskIDLE_PRIORITY + 1, NULL);
.
```

Here vfork is a single Task which on variation of Parameter P1,P2...etc behaves as a different task,ecah task has its own stack and act as if they are independent. All the tasks have same priority and get equal time at the processor.

• Working of code

The Tasks created are by changing the parameters of a single task.

When each time a "Philosopher" is allocated the processor time it checks for the number of available "Forks". If the forks are available and then check for the Right fork and the philosopher "picks up the left fork" then when the "Philosopher" again gains the processor time it waits for Left fork to be available and proceeds to eat.

when 5 "Philosophers" are allocated simulatenously the semaphore keeps track of the available forks .

```
• Serial monitor output
 P3:Hungry
 P5:Ate
 P5:Thinking
 P4:Left fork obtained Eating :)
 P2:Right fork obtained
 P4:Ate
 P4:Thinking
 P2:Left fork obtained Eating:)
 P1:Right fork obtained
 P3:Hungry
 P5:Hungry
 P2:Ate
 P2:Thinking
 P1:Left fork obtained Eating :)
 P4:Right fork obtained
 P1:Ate
 P1:Thinking
 P4:Left fork obtained Eating:)
 P3:Right fork obtained
 P5:Hungry
 P2:Hungry
 P4:Ate
 P4:Thinking
 P3:Left fork obtained Eating:)
 P1:Right fork obtained
 P3:Ate
 P3:Thinking
 P1:Left fork obtained Eating :)
 P5:Right fork obtained
 P2:Hungry
 P4:Hungry
 P1:Ate
 P1:Thinking
```

8 Task Notification

There occurs instances when tasks needs to communicate with each other. Semaphores are one of the methods by which tasks communicate with each other. Two other methods by which tasks communicate with each other are

- 1. MailBox
- 2. Queues

Tasks in mailbox communicate by sending "Mails" to each other.In FreeRTOS mailbox is implemented by Task Notification.

Each Task has an associated notification value using which they can be "notified". When a task is notified, Task notifications can update the receiving task's notification value in the following ways:

- Set the receiving task's notification value without overwriting a previous value
- Overwrite the receiving task's notification value
- Set one or more bits in the receiving task's notification value
- Increment the receiving task's notification value

8.1 Code:

```
#include < stdlib . h>
#include "FreeRTOS.h"
#include "task.h"
#include" semphr.h"
TaskHandle_t xHandle = NULL;
void vnoticer( void * pvParameters )
  uint32_t ulNotifiedValue=0x01;
    \mathbf{while}(1)
      if (xTaskNotifyWait (0x00,0xffff,&ulNotifiedValue,1000)==pdTRUE)
                 if ( ulNotifiedValue | 0x01 ) = 0x01 )
//checking if the received message is same as the sent
  { UART0\_SendStr("Received\_\_\_MSG\_from\_N1\_\n");
                                                           }
       else if ( ulNotifiedValue | 0x02 ) = 0x02 )
     UART0\_SendStr("Received\_\_\_MSG\_from\_N2\n");
                                                           }
                 else if ( ulNotifiedValue | 0x03 ) = 0x03 )
     UARTO_SendStr("Received___MSG_from_N3\n");
       else if ( (ulNotifiedValue | 0x04 ) = 0x04 )
      UART0\_SendStr("Received\_\_\_MSG\_from\_N4\n");}
         else
      UARTO_SendStr("Learn_Programming_!\n");}
}
else
{ UART0_SendStr("No_Notice\n"); }
}
}
```

```
void vn1( void * pvParameters )
   xHandle = xTaskGetHandle( "Noticer" );
   \mathbf{while}(1)
         vTaskDelay(4000);
         UART0\_SendStr("N1\_sent\_a\_Message \n");
         xTaskNotify(xHandle, 0x01, eSetBits);
         }
void vn2( void * pvParameters )
   xHandle = xTaskGetHandle( "Noticer" );
   \mathbf{while}(1)
         vTaskDelay(5000);
         UART0\_SendStr("N2\_sent\_a\_Message \n");
         xTaskNotify(xHandle, 0x02, eSetBits);
         }
void vn3( void * pvParameters )
{
   xHandle = xTaskGetHandle( "Noticer" );
   \mathbf{while}(1)
         vTaskDelay(6000);
         UART0\_SendStr("N3\_sent\_a\_MSG\n");
         xTaskNotify(xHandle, 0x03, eSetBits);
         }
void vn4( void * pvParameters )
```

```
{
            xHandle = xTaskGetHandle( "Noticer" );
            \mathbf{while}(1)
            {
                                 vTaskDelay (7000);
                                 UART0\_SendStr("N4\_sent\_a\_MSG\n");
                                 xTaskNotify(xHandle, 0x04, eSetBits);
                                }
}
        int main()
                                                                                                                                  // Reset all pins as GPIO
    PINSEL0 = 0x000000000;
   PINSEL1 = 0x000000000;
   PINSEL2 = 0x000000000;
    Init_Peripherals();
                                 UART0\_SendStr("\t\tMailBox\_using\_Task\_Notification\n");
                                                                 {\tt xTaskCreate(vn1,"Notifier",~300~,NULL,~tskIDLE\_PRIORITY~+}
                                                                 {\tt xTaskCreate(vn2,"Notifier",~300~,NULL,~tskIDLE\_PRIORITY~+}
                                                                  xTaskCreate(vn3,"Notifier", 300 ,NULL, tskIDLE\_PRIORITY + xTaskCreate(vn4,"Notifier", 300 ,NULL, tskIDLE\_PRIORITY + xTaskCreate(v
                                 xTaskCreate(vnoticer, "Noticer", 300, NULL, tskIDLE_PRIORITY + 1,
                                                                 vTaskStartScheduler(); //Task Scheduling
                                 while (1) // Never reaches this Part of the main
                                 UART0\_SendStr("\t\tMailBox\_Bypassed\n");
}
```

Above is a simple code which has four tasks(vn1,vn2,vn3,vn4) which notify a 5th task 'noticier', The 5th task prints which task notified it.

• xTaskNotify() This function is used to notify other tasks general format is as specified below

```
xTaskNotify(xHandle, 0x03, eSetBits);
\\((Task Handle, Notification value, eAction))
```

Parameters

- Task handle: The handle of the task which needs to be notified.
- **Notification value**: Value used for notification
- eAction: The type of action which is to be carried out upon the specified task. The types are as specified below:
 - * eNoAction: The Task receives the value but no action takes place, can used to Resume a suspened task.
 - * eSetBits: The existing Notification value will be Bitwise ORed with the Notified value to obtain a new value.
 - * eIncrement :Increments the existing value.
 - * eSetValueWithOverwrite :Overwrites the existing Notification value.

Return value : Returns pdTRUE if Task has been Notified else pdFALSE.

• xTaskNotifyWait() The Function waits to receive a Notification and has parameters which govern the actions upon the received data.

```
xTaskNotifyWait(0x00,0xffff,&ulNotifiedValue,1000) \\((clear bits on entry, clear bits on exit, notified value,time)
```

Parameters

- ulBitsToClearOnEntry:Specifies the Bit position which needs to be cleared as soon as the Notification is received.
- ulBitsToClearOnExit :Specifies the Bit position which needs to be cleared before xTaskNotifyWait() function exits if a notification was received
- pulNotificationValue: The Notification value before exit is taken and stored in this.

 xTicksToWait :This specifies the timeout period for which the function call waits for a notification.

• Working

Tasks vn1,vn2,vn3,vn4 With different frequencies send a "message" to a noticer task through a hex value, these hex values are compared to find out which task sent the message.

For the first few ticks no task is sending a notification so the noticier prints a "No Notice" message, as It starts receiving messages it starts acknowledging the received messages.

MailBox using Task Notification

No Notice

No Notice

No Notice

N1 sent a Message

Received MSG from N1

N2 sent a Message

Received MSG from N2

N3 sent a MSG

Received MSG from N3

N4 sent a MSG

Received MSG from N4

N1 sent a Message

Received MSG from N1

No Notice

N2 sent a Message

Received MSG from N2

No Notice

N3 sent a MSG

ReceivN1 sent a Message

ed MSG from N3

Received MSG from N1

No Notice

9 References

- $1.\ http://www.rtos.be/2013/05/mutexes-and-semaphores-two-concepts-fortwo-different-use-cases/$
- $2. \ http://www.ocfreaks.com/cat/embedded/lpc2148-tutorials/$
- $3. \ http://www.freertos.org/Inter-Task-Communication.html\\$
- 4. http://tinymicros.com/
- $5. \ http://www.profdong.com/elc4438_spring2016/\\ USINGTHEFREERTOSREALTIMEKERNEL.pdf$