Simple Monte Carlo Simulator

1. Introduction:

The Simple Monte Carlo simulator is a standalone executable written in C++ to allow for the Simple Monte Carlo modelling of Avalanche Photodiodes and Single Photon Avalanche photodiodes.

a) Current Materials available:

- Silicon (Si)
- Indium Gallium Phosphide (InGaP)
- Gallium Arsenide (GaAs)

b) Capable of simulating:

- Gain
- Excess Noise Factor
- Breakdown Probability
- Time to Breakdown
- Timing Jitter
- Drift Velocity
- Ionization Coefficients

2. Software Links:

GitHub Repository: https://github.com/jdpetticrew/Simple-Monte-Carlo-Simulator

Archived Copy vTBD: TBD

Software Metapaper: TBD

3. Modes:

There are three simulation modes in the software:

Mode	Capabilities	
Diode Properties	Gain	
	 Excess Noise Factor 	
	 Breakdown Probability 	
	 Time to Breakdown 	
Drift Velocity	 Electron Drift Velocity 	
	 Hole Drift Velocity 	
Impact Ionization Coefficients	Electron Coefficient	
	 Hole Coefficient 	

4. Use of Diode Properties Mode:

a) Setup

Before launching the executable two text files need to be created:

1) doping profile.txt, which contains the doping of the device to be simulated.

The N-type region must be specified first. Doping concentrations to be specified in atoms/cm³ and widths to be specified in μm . See example below for a P-I-N device with an N-type I region that's 0.13 μm .

```
-3e18
-2e16, 0.13
3e18
```

The built in Poisson equation solver can work with an infinite number of layers, and it will always ignore the specified width of the 1st and last region specified.

2) bias_input.txt, which contains a list of applied biases to simulate. Only put 1 bias per line.

b) Running the Software

Launch the executable

Program will prompt for a material choice:

```
F:\Simple Monte Carlo Simulator.exe

Material: 1) Si, 2) GaAs, 3) InGaP
```

Program will then prompt for a mode choice. Enter 1 for Diode Properties.

```
F:\Simple Monte Carlo Simulator.exe

Material: 1) Si, 2) GaAs, 3) InGaP

1
Mode: 1) Diode Properties, 2) Drift Velocity, 3) Impact Ionization Coefficients

-
```

Program will then prompt for a number of divisions per transit time. This decides size of the time bins. It is calculated as below

```
Bin\ Width = \frac{Time\ for\ electron\ at\ saturation\ velocity\ to\ cross\ depletion\ width}{Number\ of\ Divisions}
```

A typical value would be 10000.

```
F:\Simple Monte Carlo Simulator.exe

Material: 1> Si, 2> GaAs, 3> InGaP

1
Mode: 1> Diode Properties, 2> Drift Velocity, 3> Impact Ionization Coefficients
1
How many divisions per transit time:
-
```

Next the Program will prompt for the injection condition:

Number	Condition	Description
1	Pure Electron	Injects a Single electron at the P-Region edge.
2	Pure Hole	Injects a Single hole at the N-Region edge.

```
Material: 1) Si, 2) GaAs, 3) InGaP

Mode: 1) Diode Properties, 2) Drift Velocity, 3) Impact Ionization Coefficients

How many divisions per transit time:
10000
1)Pure Electron, 2)Pure Hole:
```

The program will prompt for a simulation time. This is the maximum time from injection of carriers that it will simulate the device for encase not all the carriers have left the device. Typically we specify 1000 ps for this.

```
F:\Simple Monte Carlo Simulator.exe

Material: 1) Si, 2) GaAs, 3) InGaP

1
Mode: 1) Diode Properties, 2) Drift Velocity, 3) Impact Ionization Coefficients
1
How many divisions per transit time:
10000
1)Pure Electron, 2)Pure Hole:
1
Simulation Time in ps:
10000
Number of trials (Default=10000):
```

Finally the program will ask for a number of trials per voltage. A Table of typical values is provided below.

Usage	Value
Gain and Excess Noise simulation	10000
Quickly working out breakdown probability	1000
Accurate breakdown probability simulation	10000-20000
Timing Characteristics	20000+

```
F:\Simple Monte Carlo Simulator.exe

Material: 1) Si, 2) GaAs, 3) InGaP

Mode: 1) Diode Properties, 2) Drift Velocity, 3) Impact Ionization Coefficients

How many divisions per transit time:
10000
1) Pure Electron, 2) Pure Hole:
1
Simulation Time in ps:
10000
Number of trials (Default=10000):
500
4 0
Width = 1.360946e-007
timestep = 1.360946e-016
Completed trial: 100 Gain=1.000000 Pb=0.000000 . Max array index=1
```

The program will now output the width (μ m) and the time step size (ps). It will also update the output every 100 trials with the Gain, calculated by counting impact ionization events, the breakdown probability and the Max array index. The max array index is the maximum number of electron hole pairs that have been created at this voltage.

c) Output files

File Name	Description
scattering_rates.txt	Calculated scattering rates for the material
scattering_pb.txt	Calculated scattering probabilities for the material
Vgain_out.txt	V=simulated voltage, two columns. Column 1 has the trial
	number, column 2 is the simulated current from Ramos
	theorem.
Vtime_to_breakdown.txt	V=simulated voltage, two columns. Column 1 has the trial
	number, column 2 is time (ps) the trial took reach a current
	threshold of 0.1 mA
Veventcounter.txt	Ignore this file
Multiplication.txt	Contains Gain (M), excess noise factor (F) from counting
	impact ionization events, breakdown probability (Pb) per
	voltage.
Result.txt	Contains Gain (M), excess noise factor (F) from Ramos
	theorem and Mean time to breakdown (ps).
VHist.txt	V=simulated voltage, two columns. Column 1 is the central
	value for the histogram bin (in ps), column 2 contains the
	number of breakdown events detected in that bin.

d) Post Processing

Using a script it is possible to extract the timing jitter value from either the *Hist.txt* files or from the raw time to breakdown data in the *time_to_breakdown.txt* files.

5. Use of Drift Velocity Mode:

a) Running the Software

Launch executable

Program will prompt for a material choice.

```
F:\Drift_SMC.exe

Material: 1> Si, 2> GaAs, 3> InGaP
```

Program will then prompt for a mode choice. Enter 2 for Drift Velocity.

```
F:\test\Simple Monte Carlo Simulator.exe

Material: 1> Si, 2> GaAs, 3> InGaP

Mode: 1> Diode Properties, 2> Drift Velocity, 3> Impact Ionization Coefficients

Minimum Electric Field (kV/cm):
```

Then it will prompt for a minimum electric field, followed by a maximum electric field. Unless the hard coded value has been changed the program will calculate the drift velocity incrementing the electric field between user specified min and max in 1 kV/cm steps.

```
F\test\Simple Monte Carlo Simulator.exe

Material: 1> Si, 2> GaAs, 3> InGaP

1
Mode: 1> Diode Properties, 2> Drift Velocity, 3> Impact Ionization Coefficients

2
Minimum Electric Field (kV/cm):
400
Maximum Electric Field (kV/cm):
500
—
```

b) Output files

File Name	Description
scattering_rates.txt	Calculated scattering rates for the material
scattering_pb.txt	Calculated scattering probabilities for the material
evelocity.txt	Two Columns. Column 1 is the electric field (kV/cm), column 2 is the
	drift velocity (m/s).
hvelocity.txt	Two Columns. Column 1 is the electric field (kV/cm), column 2 is the
	drift velocity (m/s).

6. Use of Impact Ionization Coefficient Mode:

a) Running the Software

Launch executable

Program will prompt for a material choice.

```
F:\Ionization_SMC.exe

Material: 1) Si, 2) GaAs, 3) InGaP
```

Program will then prompt for a mode choice. Enter 3 for Impact Ionization Coefficient Mode.

```
F:\test\Simple Monte Carlo Simulator.exe

Material: 1> Si, 2> GaAs, 3> InGaP

1
Mode: 1> Diode Properties, 2> Drift Velocity, 3> Impact Ionization Coefficients

3
Minimum Electric Field (kU/cm):
-
```

Program will prompt for electric field values then will simulate electric fields in 20kV/cm steps between the minimum and maximum specified value. The simulation will calculate the distance travelled between 20000 consecutive impact ionization events for both electrons and holes.

```
Material: 1) Si, 2) GaAs, 3) InGaP

1 Mode: 1) Diode Properties, 2) Drift Velocity, 3) Impact Ionization Coefficients

3 Minimum Electric Field (kV/cm):
400 Maximum Electric Field (kV/cm):
500
```

b) Output Files

File Name	Description	
Fepdf.txt	Contains the electron data, where F is the electric field strength in	
	kV/cm. Contains 2 columns. Column 1 is the impact ionization event	
	number, column 2 is the distance travelled, in meters, since either	
	injection or the previous impact ionization event.	
Fhpdf.txt	Contains the hole data, where F is the electric field strength in kV/cm.	
	Contains 2 columns. Column 1 is the impact ionization event number,	
	column 2 is the distance travelled, in meters, since either injection or the	
	previous impact ionization event.	
Alpha_beta.txt	Contains three columns. Column 1 Electric Field (kV/cm). Column 2 and 3	
	are alpha and beta respectively (1/m). Alpha and beta have been	
	calculated as the inverse of the mean distance between consecutive	
	impact ionization events.	

7. Citations

Please use the following citations for the material parameter sets:

Silicon

X. Zhou, J. S. Ng, and C. H. Tan, 'A simple Monte Carlo model for prediction of avalanche multiplication process in Silicon', J. Inst., vol. 7, no. 08, p. P08006, 2012. DOI: https://doi.org/10.1088/1748-0221/7/08/P08006

Indium Gallium Phosphide

C. H. Tan, R. Ghin, J. P. R. David, G. J. Rees, and M. Hopkinson, 'The effect of dead space on gain and excess noise in InO. 48GaO. 52P p+ in+ diodes', Semiconductor science and technology, vol. 18, no. 8, p. 803, 2003. DOI: https://doi.org/10.1088/0268-1242/18/8/314

Gallium Arsenide

S. A. Plimmer, J. P. R. David, D. S. Ong, and K. F. Li, "A simple model for avalanche multiplication including deadspace effects", IEEE Trans. Electron Devices, vol. 46, no. 4, pp. 769–775, 1999. DOI: https://doi.org/10.1109/16.753712