

# CSE460: VLSI Design

Lecture 1


Very Large Scale Integration or VLSI

# Contents

- Topics of this course
- History
- Transistors
- Moore's law
- Types of chips
- Design abstraction
- Design methodology

# What will you learn in this course?

- You may have heard people say that electronics are made from sand, but do you know how?



# What will you learn in this course?



- A solid introduction to VLSI
- Different kinds of chips/ICs
- How to build one
- Theoretical background to making a good chip
- Quality measures of a chip
- The complete lifecycle of a chip

# The Transistor

- Transistor concept
  - Transistors can be viewed as **electrically controlled switches** with a control terminal and two other terminals that are **connected** or **disconnected** depending on the *voltage* or *current* applied to the control terminal


# Transistor Invention

- 1947: First transistor was built
  - John Bardeen and Walter Brattain built the first functioning point contact transistor at Bell Labs
  - Nearly classified as military secret
  - Later publicly introduced by Bell Labs
  - **Nobel Prize in Physics in 1956 for Bardeen, Brattain, and their supervisor William Shockley**
  - *We have called it the Transistor, T-R-A-N-S-I-S-T-O-R, because it is a resistor or semiconductor device which can amplify electrical signals as they are transferred through it from input to output terminals. It is, if you will, the electrical equivalent of a vacuum tube amplifier. But there the similarity ceases. It has no vacuum, no filament, no glass tube. It is composed entirely of cold, solid substances.*






# First IC

- 1959: U.S. Patent 3,138,743 for "Miniaturized Electronic Circuits"
  - Several years later after the invention of transistors, Jack Kilby at Texas Instruments realized the potential for miniaturization if multiple transistors could be built on one piece of silicon
  - **Kilby received the Nobel Prize in Physics in 2000 for the invention of the integrated circuit**






# Bipolar Junction Transistor

- Bipolar Junction Transistor (BJT)
  - Developed by Bell Labs
- More reliable, less noisy, and more power-efficient than the point contact transistor
- BJTs require a small current into the control (*base*) terminal to switch much larger currents between the other two (*emitter* and *collector*) terminals
- **Power being dissipated by these base currents even when idle**



# Metal Oxide Semiconductor Field Effect Transistor

- 1960s: (MOSFETs) began to enter production
- Metal Oxide Semiconductor Field Effect Transistors or MOSFETs offer the compelling advantage that they **draw almost zero control current while idle.**
- Two flavors: nMOS and pMOS
- Three terminals: *Gate* (control), *Drain* and *Source*



# First MOSFET Gates




- 1963: First logic gate using MOSFETs
    - Frank Wanlass at Fairchild described the first logic gates using MOSFETs
  - Fairchild's gates used both nMOS and pMOS transistors, earning the name Complementary Metal Oxide Semiconductor, or CMOS
  - The circuits used discrete transistors but consumed six orders of magnitude less power than their bipolar counterparts
  - With the development of the silicon planar process, MOS integrated circuits became attractive for their low cost because each transistor occupied less area and the fabrication process was simpler
- Integration Levels
- SSI:** 1-12 gates
- MSI:** 13-99 gates
- LSI:** 100-9999 gates
- VLSI:** 10-99.9 k gates
- ULSI:** >100k gates

# Trend in MOSFET IC Design


- Early commercial processes used only pMOS transistors and suffered from poor performance, yield, and reliability
- Processes using nMOS transistors became common in the 1970s
- While nMOS process was less expensive than CMOS, nMOS logic gates still consumed power while idle
- Power consumption became a major issue in the 1980s as hundreds of thousands of transistors were integrated onto a single die
- CMOS processes were widely adopted and replaced all the other technologies (pMOS, nMOS)

# Types of MOSFET

- pMOS, nMOS, CMOS
- Metal–insulator–semiconductor field-effect transistor (MISFET)
- Floating-gate MOSFET (FGMOS)
- Power MOSFET
- Multi-gate field-effect transistor (MuGFET)
- Quantum field-effect transistor (QFET)





# A Closer Look



Packan P, Akbar S, Armstrong M, et al. High performance 32nm logic technology featuring 2nd generation High-k + metal gate transistors. In: International Electron Devices Meeting, IEEE, 2009. 659–662

Cross sectional view of intel's 32nm CMOS devices



# A Closer Look



Photomicrograph of a submicron MOS transistor (courtesy Agere)


# Moore's Law

- 1965: Gordon Moore plotted # transistors on each chip vs year
  - Fit straight line on semi-log scale
  - Transistor counts have doubled about every 2 years




# Moore's Law

- Process generations
  - A manufacturing technology at a particular *channel length (feature size)* is called a **technology node/process node** (micron, submicron, nanometer technologies)



MOSFET scaling (process nodes)	Year
10 μm – 1971	
6 μm – 1974	
3 μm – 1977	
1.5 μm – 1981	
1 μm – 1984	
800 nm – 1987	
600 nm – 1990	
350 nm – 1993	
250 nm – 1996	
180 nm – 1999	
130 nm – 2001	
90 nm – 2003	
65 nm – 2005	
45 nm – 2007	
32 nm – 2009	
22 nm – 2012	
14 nm – 2014	
10 nm – 2016	
7 nm – 2018	
5 nm – 2020	






# Moore's Law

- Moore's law and intel microprocessors

microprocessor	date of introduction	# transistors
80286	2/82	134,000
80386	10/85	275,000
80486	4/89	1,200,000
Intel Pentium™	3/93	3,100,000
Intel Pentium Pro™	11/95	5,500,000
Intel Pentium II™	1997	7,500,000
Intel Pentium III™	1999	9,500,000
Intel Pentium 4™	2000	42,000,000
Intel Itanium™	2001	25,000,000
Intel Itanium 2™	2003	220,000,000
Intel Itanium 2™ (9 MB cache)	2004	592,000,000

# Chip Lifecycle

- A wafer > fabrication > chips > packaging



# Slide References

1. <https://en.wikipedia.org/wiki/MOSFET>
2. <https://www.techspot.com/article/1840-how-cpus-are-designed-and-built-part-3/>
3. <https://ieeexplore.ieee.org/document/5424253>
4. Wayne Wolf - Modern VLSI Design IP based design
5. Jan M. Rabaey - Digital Integrated Circuits
6. Weste and Harris - CMOS VLSI Design

Thank you!