
FluCom Interface Board / HAT for Raspberry Pi

Build Manual and Bill of Materials

1) Table of Content

- 1) Table of Content
- 2) General description
- 3) A bit more detailed
- 4) Schematics
- 5) Bill of Materials
- 6) Jumper Settings / Connectors
- 7) Notes, ToDos and known issues

FluCom Interface Board / HAT for Raspberry Pi



2) General description

The FluCom Interface is a stack-on board (HAT) for a Raspberry Pi 3 or higher. It's purpose is to interface with Pods for the Fluke 9000 series Microsystem Troubleshooter which is still used today to diagnose and repair vintage computer equipment such as arcade game pcbs. It is designed to be used in conjunction with the FlukeEmu software.

As of now, this software/hardware solution does provide all the basic functionality of an original mainframe/pod system including serial port and virtual tape drive support.

It does not support the Fluke 9000 series probe / signature analysis, as this will require additional hardware. If and when this functionality will be implemented we cannot tell yet.

The idea behind the project is to use readily available parts to provide an as-simple-as-possible (cheap) way to replace a Fluke 9010a Mainframe system.

The board and its design files are made available under the CERN Open Hardware License: https://ohwr.org/project/cernohl/wikis/Documents/CERN-OHL-version-2

3) A bit more detailed

Logic level shifting is done by TXS0104E IC's for the databus as well as POWERFAIL and !PODPRESENT lines.

For handshaking / control lines, individual channels are used (MOSFET- driven for !MAINSTAT / !RESET and a simple voltage divider for !PODSTAT and SYNC), as running the handshaking lines through the level shifter IC's would result in unstable communication.

The board can provide power to both the Raspberry Pi and the pod using an off-the-shelf DC-DC converter, requiring only a single 12V external supply (using the barrel jack or the 2 channel- screw terminal). For these power inputs, simple reverse voltage protection is provided by D1. If powered in this configuration, jumpers J6 enable/disable the individual rails. These jumpers could also be used to physically switch on and off the power rails.

Alternatively, external power inputs can be used to power the individual rails (5V Raspi, 5V Pod, -5V Pod and 12V Pod) using the 5 channel screw terminal on the side of the board. In this case, most jumpers can/should be omitted (more details below). No reverse voltage protection is provided here, so please be careful.

LEDs indicate power to the respective rails; the LEDs and their corresponding current limiting resistors can be omitted if you don't need them.

This DC-DC- converter is used, as it can provide more than enough current to power a Raspberry Pi4 / Pod / Display combo even for more power-hungry pods:

https://www.robotshop.com/jp/en/dfrobot-dc-dc-buck-converter-614v-to-5v-8a.html

The current Version of the Board uses TSSOP packages for the level shifters as these were the only ones available at the time when the board was designed. These require decent to good soldering skills and equipment (preferably a microscope or at the very least a good lense).


Also, a wide spaced header (or a stack of two) will be needed to connect to the Raspberry Pi in order to provide enough clearance for the pod- connectors.

The rest of the board should be pretty straight forward to assemble.

As usual, I would strongly recommend soldering all low-profile components (SMD) first.

Good luck with building and have fun!

4) Schematics




FluCom2 Build Manual V0.95, March 2022 by NOVINTIC

5) Bill of Materials

| Component | 45 | | | |
|---------------|------|--------------------|-----------------------|---|
| Ref | Qnty | Value | Cmp name (KiCad) | Footprint |
| C1, - C6, | 6 | 0.1uF | C_Small | Capacitor_SMD:C_0805_2012Metric_Pad1.15x1.40mm_HandSolder |
| C7, | 1 | 4.7uF | C_Small | Capacitor_SMD:C_0805_2012Metric_Pad1.15x1.40mm_HandSolder |
| C8, | 1 | 10uF | C_Small | Capacitor_SMD:C_0805_2012Metric_Pad1.15x1.40mm_HandSolder |
| D1, | 1 | B320 | B320 | Diode_SMD:D_SMC |
| D2, - D5, | 4 | LED_Small | LED_Small | LED_SMD:LED_0805_2012Metric_Pad1.15x1.40mm_HandSolder |
| J1, | 1 | Raspberry_Pi_3_4 | Raspberry_Pi_3_4 | Connector_PinHeader_2.54mm:PinHeader_2x20_P2.54mm_Vertical |
| J2, | 1 | Debug | Conn_02x13_Top_Bottom | Fluke6809POD:PinHeader_2x13_P2.54mm_Vertical_Fluke_Numbering_mirrored |
| J3, | 1 | Auxillary | Conn_02x05_Odd_Even | Connector_PinHeader_2.54mm:PinHeader_2x05_P2.54mm_Vertical |
| J4, | 1 | DB25_Female | DB25_Female | DSUB-25_Female_Horizontal_P2.77x2.54mm_EdgePinOffset9.40mm |
| J5, | 1 | POWER | Screw_Terminal_01x05 | TerminalBlock:TerminalBlock_bornier-5_P5.08mm |
| J6, | 1 | PWset | Conn_02x04_Odd_Even | Connector_PinHeader_2.54mm:PinHeader_2x04_P2.54mm_Vertical |
| J7, | 1 | 12V in | Screw_Terminal_01x02 | TerminalBlock:TerminalBlock_bornier-2_P5.08mm |
| J8, | 1 | 12V in Barrel Jack | Barrel_Jack | Connector_BarrelJack:BarrelJack_Horizontal |
| JP1, | 1 | OE | Jumper_NC_Small | Connector_PinHeader_2.54mm:PinHeader_1x02_P2.54mm_Vertical |
| JP3, | 1 | Onboard -5V | Jumper_NC_Small | Connector_PinHeader_2.54mm:PinHeader_1x02_P2.54mm_Vertical |
| JP4, | 1 | Jumper_NC_Small | Jumper_NC_Small | Connector_PinHeader_2.54mm:PinHeader_1x02_P2.54mm_Vertical |
| Q1, Q2, | 2 | BSS138 | BSS138 | Package_TO_SOT_SMD:SOT-23 |
| R1, | 1 | 10K? | R_Small | Resistor_SMD:R_0805_2012Metric_Pad1.15x1.40mm_HandSolder |
| R2, - R6, R8, | 6 | 10K | R_Small | Resistor_SMD:R_0805_2012Metric_Pad1.15x1.40mm_HandSolder |
| R7, R9, | 2 | 20K(10K ok?) | R_Small | Resistor_SMD:R_0805_2012Metric_Pad1.15x1.40mm_HandSolder |
| R10, R11, R13 | 3 | 300R | R_Small | Resistor_SMD:R_0805_2012Metric_Pad1.15x1.40mm_HandSolder |
| R12, | 1 | 700R | R_Small | Resistor_SMD:R_0805_2012Metric_Pad1.15x1.40mm_HandSolder |
| TP1, | 1 | TestPoint | TestPoint | Connector_PinHeader_2.54mm:PinHeader_1x01_P2.54mm_Vertical |
| U1, U2, U3, | 3 | TXS0104EPW | TXS0104EPW | Package_SO:TSSOP-14_4.4x5mm_P0.65mm |
| U4, | 1 | CK1408 | CK1408 | Converter_DCDC:CK1408 |
| U5, | 1 | B0505S | B0505S | Converter_DCDC:Converter_DCDC_muRata_CRE1xxxxxxSC_THT |

6) Jumper Settings / Connectors



Connectors:

J1: Raspberry Pi GPIO

J2 and J4: Pod connectors

J3: Not used yet (add on board?)

J5: Screw terminal for direct power inputs

J6: Power Jumpers. See pictures on the right side. Could in theory be used to switch individual rails on/off.

From top to bottom:

+5V

+5VPod

+12VPod

-5VPod

J7: Screw terminal (single 12V input)

J8: Barrel jack (single 12V input)

Jumpers:

JP1: Chip enable for the level-shifters (will most

likely be removed in later revisions)

JP2: (was removed)


JP3: Enable on-board -5V. (is powered by +5V

POD rail).


JP4: Enable on-board DC-DC converter

(generates +5V and +5VPod


This might look a bit complicated, but referring to the schematics, things should be obvious.



Single 12V input (JP4 must be closed!)



Individual inputs (only one +5V used)



All individual inputs used

7) Notes, ToDos and known issues

- R1 and JP1 will most likely be removed the idea was to be able to protect the pods from arbitrary GPIO behavior during startup or whatever. This does not seem to be necessary. Output enable will just be tied high +3.3V.