# MTE321 Formulas

# Stresses

## **Deformation Elongation**

$$\delta = \frac{FL}{EA}$$
$$\delta = \frac{\sigma L}{E}$$

#### **Torsional Forumals**

#### Stress

R is the radial distance

$$\tau = \frac{Tr}{J}$$

$$Z_p = \frac{J}{c}$$

$$\tau_{max} = \frac{T}{Z_p}$$

### Deformation

 $\theta$  is the angle of twist across L For non-circular shafts K is section polar second moment of area and

$$T = \frac{P}{\omega} \quad T_{lb \cdot in} = 63000 \frac{P}{\omega}$$

$$\theta = \frac{TL}{GJ}$$

$$Non-Circular \quad \tau = \frac{T}{Q}$$

$$Non-Circular \quad \theta = \frac{TL}{GK}$$

#### Thin-Walled Closed Tubes

A = median area boundary, U is length of median boundary

$$K = \frac{4A^2t}{U}$$
$$Q = 2tA$$

#### **Shear Stress**

V section shear force, Q is the first moment area, and t is the section thickness

$$\tau_{(y)} = \frac{VQ}{It}$$
 Rectangular Beam  $\tau_{max} = \frac{3V}{2A}$  Solid Round Beam  $\tau_{max} = \frac{4V}{3A}$  Hollow Round Beam  $\tau_{max} = \frac{2V}{A}$ 

### Beam Bending

M is the moment at the section, y is the distance from the neutral axis

$$\sigma_y = -\frac{My}{I}$$

## **Stress Concentrations**

#### **Stress Concentration Factor**

 $\mathbf{K}_{\mathrm{t}}$  is material and loading dependent, values greater than 3 are a waste

$$\sigma_{max} = K_t \sigma_{nom}$$

#### Curved Beam Bending

$$\sigma_{(r)} = \frac{M(\theta)(R-r)}{Ar(r_c - R)}$$

#### Thermal Strain

$$\epsilon_x^m = -\alpha \delta T$$

## Principle Stresses

$$tan2 heta_{\sigma} = rac{2 au_{xy}}{\sigma_{x} - \sigma_{y}} \ \sigma_{1,2} = rac{\sigma_{x} + \sigma_{y}}{2} \pm \sqrt{\left(rac{\sigma_{x} - \sigma_{y}}{2}
ight)^{2} + au_{xy}^{2}}$$