# **Equations:**

#### **Area Vectors:**

Area vectors are obtained by taking the area under the relevant segment of the median VCG  $(\mathbf{V}(t) = [X(t), Y(t), Z(t)])$  QRST complex using the trapezoidal rule:

$$\mathbf{QRS}_{\text{area}} = \int_{Q_{\text{on}}}^{Q_{\text{off}}} \mathbf{V}(t) dt = \left[ \int_{Q_{\text{on}}}^{Q_{\text{off}}} X(t) dt, \int_{Q_{\text{on}}}^{Q_{\text{off}}} Y(t) dt, \int_{Q_{\text{on}}}^{Q_{\text{off}}} Z(t) dt \right]$$
(1)

$$\mathbf{T}_{\text{area}} = \int_{Q_{\text{off}}}^{T_{\text{off}}} \mathbf{V}(t) dt = \left[ \int_{Q_{\text{off}}}^{T_{\text{off}}} X(t) dt, \int_{Q_{\text{off}}}^{T_{\text{off}}} Y(t) dt, \int_{Q_{\text{off}}}^{T_{\text{off}}} Z(t) dt \right]$$
(2)

## Peak Vectors:

Peak vectors are obtained by taking the value of relevant segment of V at the time point which is of maximum distance from the origin:

$$\mathbf{QRS}_{\text{peak}} = [X(t_{Qmax}), Y(t_{Qmax}), Z(t_{Qmax})]$$
(3)

$$\mathbf{T}_{\text{peak}} = [X(t_{Tmax}), Y(t_{Tmax}), Z(t_{Tmax})] \tag{4}$$

where  $t_{Qmax}$  is the time of max distance of the QRS loop from the origin, and  $t_{Tmax}$  is the time of max distance of the T loop from the origin. These times correspond to the maximum values of the QRS complex and T wave in the VM lead, respectively.

#### Spatial Ventricular Gradient:

The Spatial Ventricular Gradient (SVG) is the vector created by the QRST integrals in X, Y, and Z:

$$\mathbf{SVG} = \mathbf{QRS}_{\text{area}} + \mathbf{T}_{\text{area}} = \int_{Q_{\text{exp}}}^{T_{\text{off}}} \mathbf{V}(t)dt = \left[ \int_{Q_{\text{exp}}}^{T_{\text{off}}} X(t) dt, \int_{Q_{\text{exp}}}^{T_{\text{off}}} Y(t) dt, \int_{Q_{\text{exp}}}^{T_{\text{off}}} Z(t) dt \right]$$
(5)

## Vector Magnitude:

Vector magnitude (VM) is defined as the Euclidean norm of the VCG:

$$VM = \sqrt{X^2 + Y^2 + Z^2}$$
 (6)

### Azimuth Angle:

Azimuth is defined as the angle in the transverse (XZ) plane with negative angles pointing anterior, and positive angles pointing posterior (see **Figure ??**). Azimuth can take values from 0 to  $\pm 180$  degrees, with 0 degrees pointing to towards the left, and  $\pm 180$  degrees pointing towards the right.

$$\operatorname{azimuth} = \arctan\left(\frac{Z}{X}\right) \tag{7}$$

### **Elevation Angle:**

Elevation is defined as the angle up from pointing straight down towards the ground (see **Figure ??**). Values range from 0 to 180 degrees, with 0 degrees pointing towards the feet and 180 degrees pointing towards the head.

elevation =  $\arccos\left(\frac{Y}{VM}\right)$  (8)

## **Absolute Integrals:**

The sum absolute integral (SAI) is defined as the area under the absolute value of the QRST complex:

$$SAI_{i} = \int_{Q_{on}}^{T \text{ off}} |V_{i}(t)| dt \qquad \text{for } i = X, Y, Z, \text{ or VM}$$

$$(9)$$

SAI QRST is defined as:

$$SAI QRST = SAI_x + SAI_y + SAI_z = \int_{Q_{on}}^{Toff} |X(t)| dt + \int_{Q_{on}}^{Toff} |Y(t)| dt + \int_{Q_{on}}^{Toff} |Z(t)| dt$$
(10)

#### QRST Angles:

The spatial QRST angle is the 3-dimensional angle between QRS and T vectors:

QRST Angle = 
$$\arccos\left(\frac{\mathbf{QRS} \cdot \mathbf{T}}{|\mathbf{QRS}| |\mathbf{T}|}\right)$$
 (11)

where the peak QRST angle uses  $\mathbf{QRS}_{peak}$  and  $\mathbf{T}_{peak}$ , and the area QRST angle (also known as mean QRST angle) uses  $\mathbf{QRS}_{area}$  and  $\mathbf{T}_{area}$ .

#### Total Cosine R to T (TCRT):

TCRT was calculated as previously described using singular value decomposition [1].

## VCG Loop Length:

Loop length is calculated as the sum of distances covered as the VCG loop increments by each sample For example, QRS loop length is calculated as:

$$\sum_{i=Q_{\text{on}}}^{Q_{\text{off}-1}} \sqrt{(X_{i+1} - X_i)^2 + (Y_{i+1} - Y_i)^2 + (Z_{i+1} - Z_i)^2}$$
(12)

and T loop length is calculated as:

$$\sum_{i=Q_{\text{off}}}^{T_{\text{off}-1}} \sqrt{(X_{i+1} - X_i)^2 + (Y_{i+1} - Y_i)^2 + (Z_{i+1} - Z_i)^2}$$
(13)

### VCG Loop Speed:

The instantaneous speed of the QRS or T loops  $(v_i)$  in mV/s for a VCG with frequency f is calculated as the distance traveled in a sample of time:

$$v_i = \sqrt{(X_{i+1} - X_i)^2 + (Y_{i+1} - Y_i)^2 + (Z_{i+1} - Z_i)^2} / \Delta t$$
 where  $\Delta t = 1000/f$  (14)

### Left Ventricular Hypertrophy (LVH):

LVH metrics are calculated as previously described: The Cornell Voltage is calculated as the sum of the S wave in lead V3 + the R wave in lead aVL [2]. The Sokolow-Lyon LVH criteria is calculated as the sum of the S wave in lead V1 and the maximum of the R wave in either lead V5 or V6 [3].

### **QRS** Electrical Axis:

The ECG electrical axis  $(E_A)$  in the frontal plane is calculated as:

$$E_A = \arctan\left(\frac{2F}{\sqrt{3}I}\right) \tag{15}$$

where F is the R wave - S wave in the lead aVF median beat, I is the R wave - S wave in the lead I median beat, and arctan is the 2-argument arctangent (results are  $-180 \deg$  to  $+180 \deg$ ) to assign the positive and negative values correctly based on established conventions. Notably, the factor of  $2/\sqrt{3}$  is included to account for variations in signal amplitude when calculating the electrical axis using a combination of a bipolar ECG lead (Lead I) and an augmented unipolar lead (aVF). See [4] for further information.

#### VCG Loop Morphology and Singular Value Decomposition:

The singular value decomposition (SVD) is used to find the best fit planes for the QRS and T loops separately. Let  $X' = X - c_x$ ,  $Y' = Y - c_y$ , and  $Z' = Z - c_z$  where the centroid  $\mathbf{c} = (c_x, c_y, c_z)$  is the mean QRS or T vector. Then let the matrix  $\mathbf{M}'$  have the centroid-subtracted leads as columns. The SVD of  $\mathbf{M}'$  is:

$$\mathbf{M}' = \mathbf{U}\mathbf{S}\mathbf{V}^T \tag{16}$$

After SVD, unit vectors that span the best fit plane for the VCG loop are given by the columns of V.

The 3 singular values along the diagonal of matrix **S**, when squared, give the proportion of mean-squared error or variance ( $\sigma^2$ ) in the direction of the 3 corresponding basis vectors in matrix **V**:

$$S = \begin{bmatrix} S_1 & 0 & 0 \\ 0 & S_2 & 0 \\ 0 & 0 & S_3 \end{bmatrix} \qquad \sigma^2 = \begin{bmatrix} S_1^2 & 0 & 0 \\ 0 & S_2^2 & 0 \\ 0 & 0 & S_3^2 \end{bmatrix}$$
 (17)

The columns are arranged such that  $S_1 > S_2 > S_3$ . Assuming that the VCG loop is approximately planar, the third column of matrix **V** is normal to the best fit plane; let this vector be denoted by **n**. Note that if the the VCG loop is perfectly coplanar, then  $S_3 = 0$ . The major and minor axes of the VCG loop are then given by the first and second columns of **V**, respectively.

### VCG Loop Coplanarity:

The degree of VCG loop coplanarity is assessed in 2 ways. First, the mean standard error (MSE) in the direction normal to the best fit plane  $(S_3^2)$  is obtained from squaring the 3rd singular value as noted above. If  $S_3^2 = 0$  then all points in the loop are coplanar. Coplanarity is also assessed by calculating RMSE for points in the VCG loop compared to the points projected onto the best fit plane:

For a given point in the QRS or T loops  $\mathbf{s} = [s_x, s_y, s_z]$  let  $\mathbf{s}' = \mathbf{s} - \mathbf{c}$ . Then the projection  $s'_{\text{proj}}$  relative to the centroid  $\mathbf{c}$  onto the best-fit plane is found by subtracting out the component of the vector in the direction of the normal vector  $\mathbf{n}$  defined above:

$$\mathbf{s'}_{\text{proj}} = \mathbf{s'} - (\mathbf{s'} \cdot \mathbf{n})\mathbf{n} \tag{18}$$

The contribution to the RMSE is then the square root of the mean distance between corresponding points  $\mathbf{s}$  and  $\mathbf{s}_{\text{proj}}$ . Using this metric, if all points are coplanar, RMSE = 0.

#### VCG Loop Dihedral Angle:

VCG loop dihedral angle is defined as the 3-dimensional angle between the unit normal vectors that define the QRS loop best fit plane  $(N_{\rm QRS})$  and the T loop best fit plane  $(N_{\rm T})$ . By convention, the dihedral angle is an acute angle:

Dihedral Angle = 
$$\arccos(|N_{QRS} \cdot N_T|)$$
 (19)

#### VCG Loop Roundness:

Assuming that the MSE in the direction normal to the best fit plane should be relatively small compared to the MSE in the plane itself, the "roundness" (R) of the VCG loop is defined as the ratio of the largest to second largest singular values:

$$R = S_1/S_2 \tag{20}$$

If R = 1 the VCG loop is a perfect circle, and as the value of R increases above 1 the loop is more oval or oblong.

#### VCG Loop Perimeter:

QRS and T loop perimeter are calculated as the length of the QRS or T loop projected into the best fit plane with the set of points defined as  $M_{\text{proj}}$ , and is analogous to the QRS and T loop length which is the length of the loop without projection (set of points defined as M). The perimeter of  $M_{\text{proj}}$  is calculated using Matlab polyshapes.

## VCG Loop Area:

QRS and T loop area are calculated as the area of the QRS or T loop projected into the best fit plane with the set of points defined as  $M_{\text{proj}}$ . The area of  $M_{\text{proj}}$  is calculated using Matlab polyshapes.

# References

- [1] B. Acar, G. Yi, K. Hnatkova, and M. Malik. Spatial, temporal and wavefront direction characteristics of 12-lead T-wave morphology. *Med Biol Eng Comput*, 37(5):574–584, Sep 1999.
- [2] P. M. Okin, M. J. Roman, R. B. Devereux, and P. Kligfield. Electrocardiographic identification of increased left ventricular mass by simple voltage-duration products. *Journal of the American College of Cardiology*, 25(2):417-423, 1995.
- [3] M. Sokolow and T. P. Lyon. The ventricular complex in left ventricular hypertrophy as obtained by unipolar precordial and limb leads. *American Heart Journal*, 37(2):161–186, 1949.
- [4] D. Novosel, G. Noll, and T. F. scher. Corrected formula for the calculation of the electrical heart axis. Croat Med J, 40(1):77-79, Mar 1999.