CSS 422 Hardware and Computer Organization

Introduction to the Assembler

Professor: Yang Peng

The slides are re-produced by the courtesy of Dr. Arnie Berger and Dr. Wooyoung Kim



Topic

- Assembly programming and 68000 microprocessor architecture
 - Chapter 7 by Berger
 - Chapter 2 by Clements
 - The chapters are available on Canvas
 - https://canvas.uw.edu/courses/1408528/pages/textbooks
 - Quick Reference
 - http://www.easy68k.com/files/EASy68KQuickRef.pdf



From C/C++ to Machine Code

- Write your code in Visual Studio, Xcode, Vim, or ...
- Compile it using Visual Studio, Xcode, Gcc/G++, or ...
 - Cross-compiler: compile the code for a (micro)computer system with a processor of different architecture
 - Compiling, linking, and assembling
- Run the compiled program (binaries, images, etc.) on the same or a different computer with a processor of the same architecture
 - Run the cross-compiled program on a system with a processor of different architecture
 - Loading and executing
- The "compiled program" is called "Machine Code"



Introduction to Assembly Language

- Every computer system has a fundamental set of operations it can perform
- These operations are defined by the instruction set of the processor
 - The instruction set is the atomic element of the processor
 - All the complex operations are achieved by building sequences of these fundamental operations
 - Called Machine Language or Machine Code
- Assembly language is the human readable form of the machine language

```
Instead of writing a program in machine language as:
```

```
00000412 307B7048
00000416 327B704A
0000041A 1080
0000041C B010
0000041E 67000008
00000422 1600
00000424 61000066
00000428 5248
0000042A B0C9
```

```
We write the program in assembly language as:
MOVEA.W (TEST_S,PC,D7),A0
                               *We'll use address indirect
MOVEA.W (TEST_E,PC,D7),A1
                               *Get the end address
MOVE.B
          D0,(A0)
                               *Write the byte
CMP.B
          (A0),D0
                               *Test it
BEQ
          NEXT LOCATION
                               *OK, keep going
MOVE.B
          D0,D3
                               *Copy bad data
BSR
          ERROR
                               *Bad byte
ADDQ.W
          #01.A0
                               *Increment the address
CMPA.W
          A1,A0
                               *Are we done?
```



Why Assembly Language?

- Computer programming depends upon a knowledge of the processor
 - Understanding assembly language is of understanding the computing engine
 - Performance optimization
 - Debugging
 - Kernel development
 - Mixed C and Assembly language programming in Linux kernel

- Haven't compilers made assembly language obsolete?
 - Not all processor architectures have compilers to support



Assembly Language

There is a 1:1 correspondence between assembly language instructions and machine language instructions

MOVE.B D1,D3 ← 1601

- The assembly language instructions (called *mnemonics*) give a human readable indication of what the instruction does
- For example:

MOVE.B : Move (Copy) one byte of data

– CMP.B : Compare two bytes of data

BEQ : Branch to a different instruction if the "result" is zero

ADD.W : Add two "word" values




Format of the 68000 Instruction

Each instruction has a label, op-code, operands (0 to 2)

Label	Op-Code	Operand1	Operand2	*Comment
THIS	MOVE.B	\$1234	\$5678	*an example

- Label: a symbolic name, usually refers to a memory address
 - Label is a tool for a readable program





Format of the 68000 Instruction

Op-code: Instructions to the microprocessor

Example: MOVE, CMP

 Pseudo Op-codes (Assembler directives): Used to help make the program readable, instructions to the assembler program

Example: ORG, EQU, SET, REG, DC, DCB, DS, END

Operands: (0 operand, 1 operand, 2 operands)

O operand: NOP (No OPeration, do nothing)

1 operand: BRA FOO (BRanch Always)

2 operands: ADD.W D0,D3

Operand is one of Effective Addressing modes (where is the data?)

	ORG	\$400	*Start of code
	MOVE.B	Y,D0	*Get first operand
	ADDI.B	#24,D0	*Add constant
	MOVE.B	D0,Sum	*Store the result
	ORG	\$600	*Start of data area
Υ	DC.B	27	*Store the constant 27 in memory
Sum	DS.B	1	*Reserve a byte for Sum



Instruction Set Architecture

• In order to program in assembly language, we must be familiar with the **programmer's model of the processor**, which includes:

Instruction Set and Effective Addressing Modes

- Instruction Set
 - Tells the processor what to do (opcode)
- Effective Addressing Modes
 - 1. Describe how the processor **accesses the data** that the instruction will operate on, and
 - 2. Describe what to do with the data after the operation
- Before we can create an assembly language program, we need to understand the architecture of the machine we are programming for
 - Unlike C/C++, assembly language is not portable between computers with processors of different architectures
 - E.g., an assembly language program written for a Pentium processor will not run on an ARM7 architecture processor




Effective Addressing Modes

- In 68K manual, each instruction has different codes for each EA mode
 - **Dn**: data register direct: D0, D1, ..., D7
 - An: address register direct : A0, A1, ..., A6
 - (An): address register indirect: (A0), (A1), ..., (A6)
 - (An)+: address register indirect with post-increment
 - -(An): address register indirect with pre-decrement
 - (xxx).W: Absolute addressing (word)
 - (xxx).L: Absolute addressing (long-word)
 - #<data>: Immediate Addressing
 - (d_{16}, An) : address register indirect with displacement (EA = $(An)+d_{16}$)
 - (d_8, An, Xn) : address register indirect with index $(EA = (An)+(Xn)+d_8)$
 - (d₁₆, PC): Program counter with displacement (EA = (PC) +d₁₆)
 - (d_8, PC, Xn) : Program counter with index $(EA = (PC)+(Xn)+d_8)$




Microprocessor Component Systems

- Three major busses of an MC68000 microprocessor
 - Address Bus: Unidirectional, homogeneous (24 lines)
 - Data Bus: Bidirectional, homogeneous (16 lines)
 - Status Bus: Heterogeneous, additional control and housekeeping signals
 - Three-bus system, similar in other processors






Hardware Organization of the MC68000





User Programming Model

For most applications, the architectural model of the 68000 is the *User Programmer's Model*






Two's Complement Arithmetic

- Arithmetic overflow
 - Adding two positive number results in a negative number
 - Adding two negative number results in a positive number
- If the result is **out of range**, the computer results in an **incorrect answer**.
- How to detect the overflow? Check V bit and C bit
- 68K CCR register: XNZVC
 - V = 1 when overflow \rightarrow out of range (error)
 - C = 1 when there is a carry \rightarrow got carry bit (if V=0, it is not an error)



Two's Complement Arithmetic

- In a 4-bit system (range -8 to 7)
- 1. 7 + (-3) = 4




carry = 1 0 100

No overflow: V=0, C=1

carry-out bit is invisible.
Then the answer is 4 (correct)

$$2. (-7) + (-8)$$



carry = **1 0** 001

Overflow (sign bit changed to 0): V=1, C=1.

Incorrect result, error.



Introduction to Easy68K Simulator

- Step 1: Using an **ASCII-only TEXT EDITOR**, write your program as a series of instructions, line by line, then save the file (.X68)
- Step 2: Use the assembler program, Easy68K, to assemble (**not compile**!) the ASCII text file to an **object** file (.S68) and a **listing** file (.L68)
- Step 3: Use the simulator program in Easy68K to run your program on your PC

We write the program in assembly language as: MOVEA.W (TEST_S,PC,D7),A0 *We'll use address indirect MOVEA.W (TEST_E,PC,D7),A1 *Get the end address MOVE.B D0,(A0) *Write the byte CMP.B (A0),D0*Test it BEQ **NEXT LOCATION** *OK, keep going MOVE.B D0,D3 *copy bad data BSR **ERROR** *Bad byte ADDQ.W #01.A0 *increment the address CMPA.W A1,A0 *are we done?

machine language 00000412 307B7048 00000416 327B704A 0000041A 1080 0000041C B010 0000041E 67000008 00000422 1600 00000424 61000066 00000428 5248 0000042A B0C9

Source file Object file

17