Newbie's Guide to AVR Timers

Dean Camera

January 8, 2012

Introduction

The timer systems on the AVR series of Microcontrollers are complex beasts. They have a myriad of uses ranging from simple delay intervals right up to complex PWM (more on this later) generation. However, despite the surface complexity, the function of the timer subsystem can be condensed into one obvious function: to measure time.

We use timers every day—the most simple one can be found on your wrist. A simple clock will time the seconds, minutes and hours elapsed in a given day—or in the case of a twelve hour clock, since the last half-day. AVR timers do a similar job, measuring a given time interval.

The AVR timers are very useful as they can run asynchronous to the main AVR core. This is a fancy way of saying that the timers are separate circuits on the AVR chip which can run independent of the main program, interacting via the control and count registers, and the timer interrupts. Timers can be configured to produce outputs directly to pre-determined pins, reducing the processing load on the AVR core.

One thing that trips those new to the AVR timer is the clock source. Like all digital systems, the timer requires a clock in order to function. As each clock pulse increments the timer's counter by one, the timer measures intervals in periods of one on the input frequency:

$$Timer Resolution = \frac{1}{Input Frequency}$$

This means the smallest amount of time the timer can measure is one period of the incoming clock signal. For instance, if we supply a 100Hz signal to a timer, our period becomes:

Timer Resolution =
$$\frac{1}{\text{Input Frequency}}$$

= $\frac{1}{100Hz}$
= .01s

For the above example, our period becomes .01 seconds, thus our timer will measure in multiples of this. If we measure a delay to be 45 timer periods, then our total delay will be 45 times .01 seconds, or .45 seconds.

For this tutorial, I will assume the target to be ann ATMEGA16, running at at 1MHz clock. This is a nicely featured AVR containing certain timer functionality we'll need later on. As modern AVRs come running off their internal \approx 1MHz RC oscillator by default, you can use this without a problem (although do keep in mind the resultant timing measurements will be slightly incorrect due to the RC frequency tolerance).

In the sections dealing with toggling a LED, it is assumed to be connected to PORTB, bit 0 of your chosen AVR (pin 1 of DIP AVRMEGA16).

To start off, we will deal with basic timer functionality and move on from there.

Timers running at F_{cpu}

We'll start with a simple example. We'll create a simple program to flash a LED at about 20Hz. Simple, right?

First, let's look at the pseudo-code required to drive this example:

```
Set up LED hardware
Set up timer

WHILE forever
IF timer value IS EQUAL TO OR MORE THAN 1/20 sec THEN
Reset counter
Toggle LED
END IF
END WHILE
```

Very simple. We're just starting out, so we'll use the polled method of determining the elapsed time - we'll put in an IF statement in our code to check the current timer value, and act on it once it reaches (or exceeds) a certain value. Before we start on the timer stuff, let's create the skeleton of our project:

```
#include <avr/io.h>
int main (void)
{
    // TODO: Set up LED hardware

    // TODO: Set up timer

    for (;;)
    {
        // TODO: Check timer value, reset and toggle LED when count matches 1/20 of a second
    }
}
```

Extremely simple. I'm going to assume you are familiar with the basics of setting up AVR ports as well as bit manipulation (if you're uncertain about the latter, refer to this excellent tutorial). With that in mind, I'll add in the LED-related code and add in the IF statement:

Now we need to start dealing with the timer. We want to do nothing more than start it at 1MHz, then check its value later on to see how much time has elapsed. We need to deviate for a second and learn a little about how the timer works in its most basic mode.

The AVR timer circuits come in two different widths, 8 and 16 bit. While the capabilities of the two timer types differ, at the most basic level (simple counting), the only difference is the maximum amount of time the timer can count to before overflowing and resetting back to zero. Those familiar with C will know that an unsigned eight bit value can store a value from 0 to $2^8 - 1$, or 255, before running out of bits to use and becoming zero again. Similarly, an unsigned 16 bit value may store a value from 0 to $2^{16} - 1$, or 65535 before doing the same.

As the name suggests, an 8 bit timer stores its value as an eight bit value in its count register, while the 16 bit timer stores its current count value in a pair of eight bit registers. Each advancement of the counter register for any AVR timer indicates that one timer period has elapsed.

Our project needs a fairly long delay, of $\frac{1}{20}$ of a second. That's quite short to us humans, but to a microcontroller capable of millions of instructions per second it's a long time indeed!

Our timer will be running at the same clock speed as the AVR core to start with, so we know that the frequency is 1MHz. One MHz is $\frac{1}{1000000}$ of a second, so for each clock of the timer only one millionth of a second has elapsed! Our target is $\frac{1}{20}$ of a second, so let's calculate the number of timer periods needed to reach this delay:

```
Target Timer Count = \frac{1}{\text{Target Frequency}} / \frac{1}{\text{Timer Clock Frequency}} - 1

= \frac{1}{20} / \frac{1}{1000000-1}

= \frac{.05}{0.000001-1}

= 50000 - 1

= 49999
```

So running at 1MHz, our timer needs to count to 49999 before $\frac{1}{20 \text{th}}$ of a second has elapsed - the normal calculated value is decremented by one, as the 0th count of the timer still takes one tick. That's a very large value - too large for an 8 bit value! We'll need to use the 16 bit timer 1 instead.

Firstly, we need to start the timer at the top of our main routine, so that it will start counting. To do this, we need to supply the timer with a clock; as soon as it is clocked it will begin counting in parallel with the AVR's CPU core (this is called synchronous operation). To supply a clock of $F_{\rm cpu}$ to the timer 1 circuits we need to set the CS10 bit (which selects a $F_{\rm cpu}$ prescale of 1 - more on that later) in the TCCR1B, the Timer 1 Control Register B.

Now, with only one line of code, we've started the hardware timer 1 counting at 1MHz - the same speed as our AVR. It will now happily continue counting independently of our AVR. However, at the moment it isn't very useful, we still need to do something with it!

We want to check the timer's counter value to see if it reaches $\frac{1}{20}$ of a second, or a value of 49999 at 1MHz as we previously calculated. The current timer value for timer 1 is available in the special 16-bit register, TCNT1. In actual fact, the value is in two 8-bit pair registers TCNT1H (for the high byte) and TCNT1L (for the low byte), however the C library implementation we're using helpfully hides this fact from us.

Let's now add in our check to our code - it's as simple as testing the value of TCNT1 and comparing against our wanted value, 49999. To prevent against

missed compares (where the timer updates twice between checks so our code never sees the correct value), we use the equal to or more than operator, ">=".

Great! We've only got one more line of code to write, to reset the timer value. We already know the current value is accessed via the TCNT1 register for Timer 1, and since this is a read/write register, we can just write the value 0 to it once our required value is reached to rest it.

And there we have it! We've just created a very basic program that will toggle our LED every $\frac{1}{20}$ of a second at a 1MHz clock. Testing it out on physical hardware should show the LED being dimmer than normal (due to it being pulsed quickly). Good eyesight might reveal the LED's very fast flickering.

Next, we'll learn about the prescaler so we can try to slow things down a bit.

Prescaled Timers

In part one of this tutorial we learned how to set up our 16-bit timer 1 for a 1/20 second delay. This short (to us humans) delay is actually quite long to our AVR - 50,000 cycles in fact at 1MHz. Notice that Timer 1 can only hold a value of 0-65535 - and we've almost reached that! What do we do if we want a longer delay?

One of the easiest things we can do is to use the timer's prescaler, to trade resolution for duration. The timer prescaler is a piece of timer circuitry which allows us to divide up the incoming clock signal by a power of 2, reducing the resolution (as we can only count in 2^n cycle blocks) but giving us a longer timer range.

Let's try to prescale down our Fcpu clock so we can reduce the timer value and reduce our delay down to a nice 1Hz. The Timer 1 prescaler on the ATMEGA16 has divide values of 1, 8, 64, 256 and 1024 - so let's re-do our calculations and see if we can find an exact value.

Our calculations for our new timer value are exactly the same as before, except we now have a new prescaler term. We'll look at our minimum resolution for each first:

$$\begin{array}{ll} \text{Timer Resolution} & = & \frac{1}{\text{Input Frequency/Prescale}} \\ & = & \frac{\text{Prescale}}{\text{Input Frequency}} \end{array}$$

For a 1MHz clock, we can construct a table of resolutions using the available prescaler values and a Fcpu of 1MHz.

Prescaler Value	Resolution @ 1MHz
1	1uS
8	8uS
64	64uS
256	256uS
1024	1024uS

If you recall our equation for calculating the timer value for a particular delay in part 1 of this tutorial, you'll remember it is the following:

$$\text{Target Timer Count} = \frac{1}{\text{Target Frequency}} / \frac{1}{\text{Timer Clock Frequency}} - 1$$

However, as we've just altered the prescaler term, the latter half is now different. Substituting in our new resolution equation from above we get:

$$\text{Target Timer Count} = (\frac{1}{\text{Target Frequency}} / \frac{\text{Prescale}}{\text{Input Frequency}}) - 1$$

Or, rearranged:

$$\mbox{Target Timer Count} = (\frac{\mbox{Input Frequency}}{\mbox{$Prescale$}} / \mbox{Target Frequency}) - 1$$

Now, we want to see if there is a prescaler value which will give an *exact* delay of 1Hz. One Hertz is equal to one cycle per second, so we want our compare value to be one second long, or 1000000uS. Let's divide that by each of our resolutions and put the results in a different table:

Prescaler Value	Target Timer Count
1	999999
8	125000
64	15624
256	3905.25
1024	975.5625

The results are interesting. Of the available prescaler values, we can immediately discount 256 and 1024 - they do not evenly divide into our wanted delay period. They are of course usable, but due to the rounding of the timer count value the resultant delay will be slightly over or under our needed delay. That leaves us with three possible prescales; 1, 8 and 64.

Our next task is to remove the values that aren't possible. On an 8-bit timer, that means discounting values of more than $2^8 - 1$, or 255, as the value won't fit into the timer's 8-bit count register. For our 16-bit timer, we have a larger range of 0 to $2^{16} - 1$, or 65535. Only one of our prescaler values satisfies this requirement — a prescale of 64 — as the other two possibilities require a timer count value of more bits than our largest 16-bit timer is capable of storing.

Let's go back to our original timer program and modify it to compare against our new value of 15624, which we've found to be 1 second at a prescale of 64 and a $F_{\rm cpu}$ of 1MHz:

Note I've removed the timer setup line, as it is no longer valid. We want to set up our timer to run at Fcpu/64 now. To do this, we need to look at the datasheet of the ATMEGA16 to see which bits need to be set in which control registers.

Checking indicates that we need to set both the CS10 and CS11 prescaler bits in TCCR1B, so let's add that to our program:

Compile it, and we're done! Remembering that our timer runs as soon as it gets a clock source, our program will now work, flashing the LED at a frequency of 1Hz.

Long Timer Delays in Firmware

So far, we've learned how to use the timers in their most basic counting mode to delay a specified duration. However, we've also discovered a limitation of the timers — their maximum duration that their timer count registers can hold. We've managed to get a 1Hz delay out of a prescaled 16-bit timer with a prescale, but what if we want a delay of a minute? An hour? A week or year?

The answer is to create a sort of prescaler of our own in software. By making the hardware timer count to a known delay — say the 1Hz we created earlier — we can increment a variable each time that period is reached, and only act after the counter is reached a certain value. Let's pseudocode this so we can get a better understanding of what we want to do:

```
Set up LED hardware
Set up timer
Initialise counter to 0

WHILE forever
IF timer value IS EQUAL TO 1 sec THEN
Increment counter
Reset timer
IF counter value IS EQUAL TO 60 seconds THEN
Toggle LED
END IF
END IF
END WHILE
```

The above pseudocode will build on our last experiment - a timer with a one second count - to produce a long delay of one minute (60 seconds). It's very simple to implement - all we need extra to our last example is an extra IF statement, and a few variable-related lines. First off, we'll re-cap with our complete code as it stands at the moment:

We need some code to create and initialise a new counter variable to 0, then increment it when the counter reaches one second as our pseudocode states. We also need to add in a test to see if our new variable reaches the value of 60, indicating that one minute has elapsed.

```
#include <avr/io.h>
int main (void)
   // TODO: Initialise a new counter variable to zero
  DDRB \mid = (1 << 0); // Set LED as output
  TCCR1B \mid= ((1 << CS10) | (1 << CS11)); // Set up timer at Fcpu
       /64
   for (;;)
      // Check timer value in if statement, true when count matches
           1 second
      if (TCNT1 >= 15625)
         TCNT1 = 0; // Reset timer value
         // TODO: Increment counter variable
         // TODO: Check here to see if new counter variable has
             reached 60
         if ()
         {
            // TODO: Reset counter variable
            PORTB \hat{}= (1 << 0); // Toggle the LED
         }
      }
  }
```

Now that we have our new program's structure, replacing the TODOs becomes very simple. We want a target count of 60, which is well within the range of an unsigned integer variable, so we'll make our counter variable of type unsigned integer. The rest of the code is fairly straightforward, so I'll add it all in at once:

```
#include <avr/io.h>
int main (void)
{
   unsigned char ElapsedSeconds = 0; // Make a new counter variable
        and initialise to zero
  DDRB \mid = (1 \ll 0); // Set LED as output
  TCCR1B \mid = ((1 \ll CS10) \mid (1 \ll CS11)); // Set up timer at Fcpu
   for (;;)
      // Check timer value in if statement, true when count matches
           1 second
         (TCNT1 >= 15624)
         TCNT1 = 0; // Reset timer value
         ElapsedSeconds++;
         if (ElapsedSeconds == 60) // Check if one minute has
            ElapsedSeconds = 0; // Reset counter variable
            PORTB \hat{}= (1 << 0); // Toggle the LED
         }
      }
  }
```

Compile and run, and the LED should toggle once per minute. By extending this technique, we can produce delays of an arbitrary duration. One point of interest is to note that any timing errors compound - so if the timer input frequency is 1.1MHz rather than 1.0MHz our one minute timer will be sixty times that small error out in duration. For this reason it is important to ensure that the timer's clock is as accurate as possible, to reduce long-term errors as much as possible.

The CTC Timer Mode

Up until now, we've been dealing with the timers in a very basic way - starting them counting, then comparing in our main routine against a wanted value. This is rather inefficient - we waste cycles checking the timer's value every time the loop runs, and slightly inaccurate (as the timer may pass our wanted compare value slightly while processing the loop). What if there was a better way?

Well, there is. The AVR timers usually incorporate a special function mode called "Clear on Timer Compare", or CTC for short. The CTC operating mode does in hardware what we've previously experimented in software; it compares in hardware the current timer value against the wanted value, and when the wanted value is reached a flag in a status register is set and the timer's value reset.

This is extremely handy; because the comparing is done in hardware, all we have to worry about is checking the flag to determine when to execute our LED toggling - much faster than comparing bytes or (in the case of the 16-bit timer) several bytes.

CTC mode is very straightforward. Before we look into the implementation, let's pseudocode what we want to do.

```
Set up LED hardware
Set up timer in CTC mode
Set timer compare value to one second

WHILE forever
IF CTC flag IS EQUAL TO 1 THEN
Toggle LED
Clear CTC flag
END IF
END WHILE
```

Short and to the point. Note that the name of the mode is Clear on timer compare - the timer's value will automatically reset each time the compare value

is reached, so we only need to clear the flag when the delay is reached. This set-and-forget system is very handy, as once the timer is configured and started we don't need to do anything other than check and clear its status registers.

Now then, we'll grab our previous example, modifying it to fit with our new pseudocode:

Now, we need to flesh out the skeleton code we have. First up we need to configure our timer for CTC mode. As you might be able to guess, we want to configure our timer, thus the bits we want will be located in the timer's Control registers. The table to look for is the one titled "Waveform Generation Mode Bit Description", and is located in the timer control register descriptions for each timer. This table indicates all the possible timer modes, the bits required to set the timer to use those modes, and the conditions each mode reacts to.

You should note that our previous examples have ignored this table altogether, allowing it to use its default value of all mode bits set to zero. Looking at the table we can see that this setup corresponds to the "Normal" timer mode. We want to use the CTC mode of the timer, so let's look for a combination of control bits that will give us this mode.

Interestingly, it seems that two different combinations in Timer 1 of the AT-MEGA16 will give us the same CTC behaviour we desire. Looking to the right of the table, we can see that the "Top" value (that is, the maximum timer value for the mode, which corresponds to the compare value in CTC mode) uses different registers for each. Both modes behave in the same manner for our purposes and differ only by the register used to store the compare value, so we'll go with the first.

The table says that for this mode, only bit WGM12 needs to be set. It also says that the register used for the compare value is named OCR1A.

Looking at the timer control registers (TCCR1A and TCCR1B) you should notice that the WGM1x bits - used to configure the timer's mode - are spread out over both registers. This is a small pain as you need to find out which bits are in which register, but once found setting up the timer becomes very easy. In fact, as we only have one bit to set — WGM12 — our task is even easier. The ATMEGA16's datasheet says that WGM12 is located in the TCCR1B register, so we need to set that.

The second task for this experiment is to set the compare value - the value that will reset the timer and set the CTC flag when reached by the timer. We know from the datasheet that the register for this is OCR1A for the MEGA16 in the first CTC timer mode, so all we need is a compare value. From our previous experiment we calculated that 1Hz at 1MHz with a prescaler of 64 needs a compare value of 15624, so let's go with that.

```
}
}
```

There, almost done already! Last thing we need is a way of checking to see if the compare has occurred, and a way to clear the flag once its been set. The place to look for the compare flags is in the timer's Interrupt Flag register — an odd place it seems, but the reason will become clear in the next section dealing with timer interrupts. The ATMEGA16's Timer 1 interrupt flags are located in the combined register TIFR, and the flag we are interested in is the "Output Compare A Match" flag, OCF1A. Note the "A" on the end; Timer 1 on the ATMEGA16 has two CTC channels (named channel A and channel B), which can work independently. We're only using channel A for this experiment.

Checking for a CTC event involves checking the OCF1A flag in this register. That's easy - but what about clearing it? The datasheet includes an interesting note on the subject:

...OCF1A can be cleared by writing a logic 1 to its bit location

Very strange indeed! In order to clear the CTC flag, we actually need to set it - even though it's already set. Due to some magic circuitry inside the AVR, writing a 1 to the flag when its set will actually cause it to clear itself. This is an interesting behaviour, and is the same across all the interrupt bits. There's a good reason for the flags to be cleared this way, although it is a little outside the scope of this tutorial.

Despite that, we can now add in our last lines of code to get a working example:

And there we have it, a working 1Hz LED flasher using the CTC timer mode!

CTC Mode using Interrupts

For all our previous experiments, we've been using a looped test in our main code to determine when to execute the timer action code. That's fine, but what if we want to shift the responsibility of choosing when to execute the timer code to the AVR hardware instead? To do this, we need to look at the timer interrupts.

Interrupts are events that when enabled, cause the AVR to execute a special routine (called an Interrupt Service Routine, or ISR for short) when the interrupt conditions are met. These interrupts can happen at any time and when executing the main routine is paused while the ISR executes, the main routine continues until the next interrupt. This is useful for us, as it means we can eliminate the need to keep checking the timer value and just respond to its interrupt events instead.

The AVR timers can have several different Interrupts - typically Overflow, Compare and Capture. Overflow occurs when the timer's value rolls past it's maximum and back to zero (for an 8 bit timer, that's when it counts past 11111111 in binary and resets back to 000000000). However, for this section we'll deal with the Compare interrupt, which occurs in CTC mode when the compare value is reached.

Again, we'll pseudocode this to start with:

```
Set up LED hardware
Set up timer in CTC mode
Enable CTC interrupt
Enable global interrupts
Set timer compare value to one second

WHILE forever
END WHILE

ISR Timer Compare
Toggle LED
END ISR
```

We can start off this by working with our skeleton main code, used in previous examples. I'll skip the details on the parts already discussed in previous sections.

```
#include <avr/io.h>
int main (void)
{
   DDRB |= (1 << 0); // Set LED as output
   TCCR1B |= (1 << WGM12); // Configure timer 1 for CTC mode

   // TODO: Enable CTC interrupt
   // TODO: Enable global interrupts

   OCR1A = 15624; // Set CTC compare value to 1Hz at 1MHz AVR
        clock, with a prescaler of 64

   TCCR1B |= ((1 << CS10) | (1 << CS11)); // Start timer at Fcpu/64

   for (;;)
   {
    }
}
// TODO: Add compare ISR here</pre>
```

Note how it's a modified version of the non-interrupt driven CTC example covered in the last section. All we need to do is tell the timer to run the compare ISR we define when it counts up to our compare value, rather then us polling the compare match flag in our main routine loop.

We'll start with creating the ISR first, as that's quite simple. In AVR-GCC — specifically, the avr-libc Standard C Library that comes with it — the header file for dealing with interrupts is called (unsurprisingly) "interrupt.h" and is located in the avr subdirectory. We need to include this at the top of our program underneath our include to the IO header file. The top of our code should look like this:

```
#include <avr/io.h>
#include <avr/interrupt.h>

int main (void)
{
    ...
```

This gives us access to the API for dealing with interrupts. We want to create an ISR for the Timer 1 Compare Match event. The syntax for defining an ISR body in AVRGCC is:

```
ISR(VectorName_vect)
{
    // Code to execute on ISR fire here
}
```

Where *VectorName* is the name of the ISR vector which our defined ISR handles. The place to go to find this name is the "Interrupt" section of the datasheet, which lists the symbolic names for all the ISR vectors that the chosen AVR supports. When writing the vector name into GCC, replace all spaces with underscores, and append "_vect" to the end of the vector's name.

Like in part four we are still dealing with Channel A Compare of Timer 1, so we want the vector named "TIMER1 COMPA". In GCC this is called "TIMER1_COMPA_vect", after performing the transformations outlined in the last paragraph. Once the ISR is defined, we can go ahead and write out it's body, adding the LED toggling code.

Notice how we don't clear the CTC event flag like in part four — this is automatically cleared by the AVR hardware once the ISR fires. Neat, isn't it!

Running the code so far won't yield any results. This is because although we have our ISR all ready to handle the CTC event, we haven't enabled it! We need to do two things; enable the "TIMER1 COMPA" interrupt specifically, and turn on interrupt handling on our AVR.

The way to turn on our specific interrupt is to look into the second interrupt-related register for our timer, TIMSK. This is the Timer Interrupt Mask register, which turns on and off ISRs to handle specific timer events. Note that on the ATMEGA16 this single register contains the enable bits for all the timer interrupts for all the available timers. We're only interested in the Timer 1 Compare A Match interrupt enable bit, which we can see listed as being called OCIE1A (Output Compare Interrupt Enable, channel A).

By setting that bit we instruct the timer to execute our ISR upon compare match with our specified compare value. Let's put that line into our program's code and see how it all looks.

```
#include <avr/io.h>
#include <avr/interrupt.h>
int main (void)
{
    DDRB |= (1 << 0); // Set LED as output

    TCCRIB |= (1 << WGMI2); // Configure timer 1 for CTC mode

    TIMSK |= (1 << OCIE1A); // Enable CTC interrupt
    // TODO: Enable global interrupts

    OCRIA = 15624; // Set CTC compare value to 1Hz at 1MHz AVR clock, with a prescaler of 64

    TCCRIB |= ((1 << CS10) | (1 << CS11)); // Start timer at Fcpu/64

    for (;;)
    {
        }
}
ISR(TIMER1_COMPA_vect)
{
        PORTB ^= (1 << 0); // Toggle the LED
}</pre>
```

Only one more thing to do — enable global interrupts. The AVR microcontrollers have a single control bit which turns on and off interrupt handling functionality. This is used in pieces of code where interrupt handling is not desired, or to disable interrupts while an ISR is already being executed. The latter is done automatically for us, so all we need to do is turn on the bit at the start of our code, and our compare interrupt will start to work.

The command to do this is called sei() in the avr-libc library that ships with WinAVR, and is named to correspond with the assembly instruction which does the same for AVRs (the SEI instruction). That's irrelevant however, as we just need to call the command in our code.

```
#include <avr/io.h>
#include <avr/interrupt.h>
int main (void)
{
    DDRB |= (1 << 0); // Set LED as output

    TCCR1B |= (1 << WGM12); // Configure timer 1 for CTC mode

    TIMSK |= (1 << OCIE1A); // Enable CTC interrupt</pre>
```

And our example is finished! Running this will give a nice 1Hz LED flashing, using the timer's event interrupts. The nice thing is that the timer operation is now completely handled for us in hardware — once set up, we just need to react to the events we've configured. Notice that our main loop is now empty; if this is the case you may put sleep commands inside the main loop to save power between compares.

Pure Hardware CTC

You probably think by now that we've improved our example as much as possible — after all, what more improvements are there to make? Well, it's time to finish of the CTC topic by looking at the hardware outputs.

All AVR's pins have alternative hardware functions. These functions (currently non re-routable) when activated interface the IO pins directly to the AVR's internal hardware - for instance the Tx/Rx alternative functions which are the direct interface to the AVR's USART subsystem. Alternative pin functions can be very useful; as they can be internally connected straight to a hardware subsystem, the maximum possible performance can be achieved.

In this section, we'll be looking at the Compare Output settings of the AVR timer.

Looking at the timer 1 control registers, we can see a few pairs of bits we've previously ignored, called (for timer 1) COM1A1/COM1AO and COM1B1/COM1BO. Bonus points to anyone who's linked the "A" and "B" parts of the bit names to the timer compare channels — you're spot on.

These bits allow us to control the hardware behaviour when a compare occurs. Instead of firing an interrupt, the hardware can be configured to set, clear or toggle the OCxy (where "x" is the timer number, "y" is the channel letter for timers with more than one channel) hardware pins when a compare occurs. We can use the toggle function with our LED flasher, so that the hardware toggles the LED's state for us automatically, making it a true set-and-forget operation.

Before we do anything else, let's work out which pins of our ATMEGA16 are linked to the Compare Output hardware — we want the pins with alternative functions starting with "OC". On our PDIP package version, that maps to:

GPIO Pin	Alternative Function
PB3	OC0
PD4	OC1B
PD5	OC1A

So timer 0 has one Compare Output channel, while timer 1 has two (channels A and B) as we've already discovered. As always we'll just deal with Channel A in our example.

Now we have a problem. All the previous chapters have assumed the LED is attached to PORTB, bit 0 - but we'll have to move it for this chapter. As stated above the alternative functions cannot be moved to another pin, so we must move moses...I mean, our LED, to the pin with the required alternative function.

Timer 1 Channel A's Compare Output is located on PD5, so move the LED there for the rest of this example. Now, let's psudocode: