Component	Functional Purpose	Failure Mode	Failure Effect	Failure Cause	Previous Situation				Assigned Action	Improved Situation				
					S	L	D	RPN	Assigned Action	S	Т	D	RPN	
Battery	Provide current to all systems in the air	Battery Fire	Damage to property and risk to human life	Charging or storage error	10	2	3	60	Assign safety officer	10	1	2	20	
Flight Boundaries	Limit flight to safe areas	Dangorous crash	Damage to property and risk to human life	Flight boundary violation	10	3	2	60	Assign saftey Pilot	10	2	1	20	
				Unsafe flight boundaries	10	2	1	20	Assign saftey Pilot	10	1	1	10	
Personal Saftey Equipment	Inhibit personal injury	Foreign object in eye	Loss of sight	Foreign objects near props	10	4	3	120	Establish protocal to keep props clear	10	2	2	40	
				Saftey glasses not applied	10	7	3	210	Add saftey glasses to field flight checklist	10	3	3	90	
Propulsion System	Provides thrust to aicraft	Motors start while hands are near props	Abrasions and lascerations	Lack of communication	10	6	5	300	Establish protocal to yell "Clear Props" whenever starting motors	10	1	1	10	
				Arm disarm switch failure	10	4	6	240	Require system to be unpowered or pops removed to work near motors	10	1	6	60	
Takeoff & Landing Procedure	Facilitate beginning and end of mission	Aicraft impacts person or property	Damage to property and risk to human life	Unsafe aicraft flight path	10	3	3	90	Require all personnel to be behind aicraft flight path before takeoff and landing	10	1	3	30	
	S: Severity of failure effect L: Likelihood of failure occurring D: Dectability of cause before failure occurs RPN: Risk Priority number (5*L**D)													