Stars 2020 Test/Audit/Parameters

```
00:01 - Lamps
XX:XX - Displays
00:03 - Solenoids
00:04 - Switches
00:05 - Sound
01 - Award Score Level 1
02 - Award Score Level 2
03 - Award Score Level 3
04 - High Score to Date
05 - Current Credits
o6 - Total plays (Audit)
07 - Total replays (Audit)
08 - Total times high score was beaten (Audit)
09 - Chute #2 coins (Audit)
10 - Chute #1 coins (Audit)
11 - Chute #3 coins (Audit)
12 - Free play off/on (0, 1)
13 - Ball Save Num Seconds (0, 6, 11, 16, 21)
14 - Music Level (0, 1, 2, 3)
15 - Tournament Scoring (0-no, 1-yes)
16 - Reboot
17 - Skill Shot Levels Up Stars (o-no, 1-yes)
18 - Number of Stars to Start With (o-none, 1-one random)
19 - Tilt Warning (0, 1, 2)
20 - Award Score Override (0 - 7, 99)
21 - Balls per game Override (3, 5, 99)
22 - Spinner Chime (o-none, 1-half, 2-every, 3-alternating)
23 - Scrolling Scores (0-no, 1-yes)
24 - Extra Ball Award (0 - 100,000) [only used for Tournament Scoring]
25 - Special Award (0 - 100,000) [only used for Tournament Scoring]
26 - Star Level Lock In Award (0=25k times level, or 1,000 - 100,000)
27 - Playfield Validation (o-any switch, 1-allow right spinner, 2-major switch)
```

29 - Wizard Switch Reward (0=off, 1,000 - 100,000)

28 - Wizard Mode Duration Num Seconds (0, 15, 30, 45, 60)

Activating the Slam Switch at any time will reboot into Attract Mode.