Antenna Array Theory

The coordinate system referenced for the array factor calculation is illustrated in Figure 1. The angle φ refers to azimuthal (x-y) plane which is defined with respect to the +x axis and is rotated in the x-y plane about the z axis for $0 < \varphi < 2\pi$. Besides, θ refers to elevation (z) plane which is defined with respect to the +z axis and is defined for $0 < \theta < \pi$ [1,2].




Figure 1. Antenna Coordinate System [1,2]

In Figure 1, $\widehat{a_r}$ is the unit vector of the position vector r (the vector along the direction of the incoming signal) and γ is the angle between the array axis and the position vector. In this figure, it is given as the angle between x-axis and r as an example.

According to Figure 1,

$$\widehat{a_r} = \sin\theta \cos\phi \widehat{a_x} + \sin\theta \sin\phi \widehat{a_y} + \cos\theta \widehat{a_z}$$
 (1)

where $\widehat{a_x}$, $\widehat{a_y}$, $\widehat{a_z}$ are unit vectors along the relevant axis.

Hence, for an array along x-axis:

$$\widehat{a_x} \cdot \widehat{a_r} = \widehat{a_x} \left(\sin \theta \cos \phi \widehat{a_x} + \sin \theta \sin \phi \widehat{a_y} + \cos \theta \widehat{a_z} \right) \tag{2}$$

$$\Rightarrow \widehat{a_x} . \widehat{a_r} = \sin \theta \cos \phi \tag{2.1}$$

For an array along y-axis:

$$\widehat{a_y} \cdot \widehat{a_r} = \widehat{a_y} \left(\sin \theta \cos \phi \widehat{a_x} + \sin \theta \sin \phi \widehat{a_y} + \cos \theta \widehat{a_z} \right) \tag{3}$$

$$\Rightarrow \widehat{a_{y}} \cdot \widehat{a_{r}} = \sin \theta \sin \phi \tag{3.1}$$

For an array along z-axis:

$$\widehat{a_z} \cdot \widehat{a_r} = \widehat{a_z} \left(\sin \theta \cos \phi \widehat{a_x} + \sin \theta \sin \phi \widehat{a_y} + \cos \phi \widehat{a_z} \right) \tag{4}$$

$$\Rightarrow \widehat{a_z} . \widehat{a_r} = \cos \theta \tag{4.1}$$

Linear Array Along Z-Axis

In order to give a better physical interpretation of the array theory, N- element array along a line (i.e. z axis) can be considered as shown in Figure 2. The total field of this array, assuming no mutual coupling effect between the elements [1,3], is determined by the vector addition of the fields radiated by the individual elements. Here, $r_1, r_2,...,r_N$ represent the distance of the individual element to the far-field observation point and $d_1,d_2,...d_N$ represent the distance of each array elements from the first (reference) element.




Figure 2. Linear array along z axis

Accordingly, the far electromagnetic fields of the first elements is calculated as follows [1]:

$$E_1 = I_0 \frac{e^{-jkr_1}}{4\pi r_1} \tag{5}$$

where E_1 : The field of an isotropic radiator located at the origin, I_0 : Excitation of the isotropic radiator, r_1 : Distance of the observation point from the origin, k:wave number = $2\pi/\lambda$, λ : wavelength

In addition to this, the current magnitudes of the array elements are supposed to be equal and the current on the array element located at the origin is considered as the phase reference (zero phase). Thus,

$$I_1 = I_0, \quad I_2 = I_0 e^{j\beta_2}, \dots, I_N = I_0 e^{j\beta_N}$$
 (6)

where β represents the difference in the phase of the signals in adjacent elements. Antenna arrays can be controlled by the relative phase β between the elements.

It is explicitly seen from Figure 2 that the path length of the wave received at element 1 is greater than the path length of element 2. This path length difference effects directly the propagation of wave whether the waves interfere constructively or destructively. Assume the array is in far field, the path length will become approximately parallel that allows to use simple trigonometry to define path difference. Since the field point is in the far field, the vectors from elements are assumed parallel. If the signals arrive from angle θ to the antenna boresight, then according to geometry in Figure 2, the relationship of individual elements' distances from the observation point is formed by the reference distance r_1 as follows:

$$r_2 = r_1 - d_1 \cos \theta, \tag{7}$$

$$r_3 = r_2 - (d_2 - d_1)\cos\theta \implies r_3 = r_1 - d_2\cos\theta \tag{8}$$

 $r_N = r_1 - d_{N-1} cos\theta \tag{9}$

It should be noted that $dcos\theta <<$ r. Therefore, the subtraction in the denominator of equations (10-12) can be ignored in order to calculate the far electromagnetic fields of other elements.

Hence,

$$E_2 = I_0 e^{j\beta_2} \frac{e^{-jk(r_1 - d_1 \cos \theta)}}{4\pi (r_1 - d_1 \cos \theta)} \Rightarrow E_2 = E_1 e^{j(\beta_2 + kd_1 \cos \theta)}$$
(10)

$$E_{3} = I_{0}e^{j\beta_{3}} \frac{e^{-jk(r_{1} - d_{2}cos\theta)}}{4\pi e^{-jk(r_{1} - d_{2}cos\theta)}} \Rightarrow E_{3} = E_{1}e^{j(\beta_{3} + kd_{2}cos\theta)}$$
(11)

$$E_N = I_0 e^{j\beta_N} \frac{e^{-jk(r_1 - d_{N-1}cos\theta)}}{4\pi(r_1 - d_{N-1}cos\theta)} \Rightarrow E_N = E_1 e^{j(\beta_N + kd_{N-1}cos\theta)}$$
(12)

Then, the overall array far field is calculated using superposition:

$$E_t = \sum_{m=1}^N E_m \Rightarrow E_t = E_1 [1 + e^{j\left(\beta_2 + kd_1 cos\theta\right)} + \dots + e^{j\left(\beta_N + kd_{N-1} cos\theta\right)}] \quad (13)$$

It is apparent from the equation (13) that the total field of the array is equal to the field of a single element (**Element factor**, E_1) positioned at the origin multiplied by a factor which is known as the **Array Factor**:

$$AF = \left[1 + e^{j(\beta_2 + kd_1 \cos\theta)} + \dots + e^{j(\beta_N + kd_{N-1} \cos\theta)}\right] \tag{14}$$

Considering eq. (14), the array factor of a linear array along z axis is also expressed as:

$$AF = \sum_{n=0}^{N-1} e^{j(kd_n \cos\theta + \beta_n)}$$
 (15)

where k: the wave propagation constant ($k=2\pi/\lambda$), d_n : distance of n^{th} element from the reference. N: Total number of elements in the array, β : Phase Delay

These two key factors utilized to represent the total radiation pattern of an antenna array in the far field $E(\theta, \phi)$. In general, the functional relationship of these factors is given by equation 16 [4, 5] and 17 [6]:

$$G(\theta, \phi) = EF(\theta, \phi).AF(\theta, \phi) \tag{16}$$

$$G(\theta, \phi) = EF(\theta, \phi) + AF(\theta, \phi) \text{ in dB}$$
 (17)

where $G(\theta, \phi)$: Array's radiation pattern, $AF(\theta, \phi)$: Array Factor, $EF(\theta, \phi)$: Element Factor

Considering all of the above, the array factor for an array along x-axis, y-axis and z- axis are calculated as follows:

Array Factor of a linear array along x axis :
$$AF = \sum_{n=0}^{N-1} e^{j(kd_n sin\theta cos\phi + \beta_n)}$$
 (18)

Array Factor of a linear array along y axis :
$$AF = \sum_{n=0}^{N-1} e^{j(kd_n sin\theta sin\phi + \beta_n)}$$
 (19)

Array Factor of a linear array along z axis :
$$AF = \sum_{n=0}^{N-1} e^{j(kd_n cos\theta + \beta_n)}$$
 (20)

where k: the wave propagation constant ($k=2\pi/\lambda$), d_n : distance of n^{th} element from the reference. N: Total number of elements along the relevant axis, β : Phase Delay

In general, array factor can be written as:

$$AF = \sum_{n=0}^{N-1} e^{j(\psi)} \quad \text{where } \psi \text{: Phase function, the real part of the exponential function that varies depending upon the axis. n: nth element from the reference N: Total number of elements along the axis } \tag{21}$$

To have a better visualisation, array factor plots are generally obtained by means of normalized array factor with dB unit. Therefore, equation (22) is used to generate the relevant plots in the user interface.

$$AF_n = \frac{1}{N} \sum_{n=0}^{N-1} e^{j(\psi)}$$
 where ψ : Phase function, the real part of the exponential function that varies depending upon the axis. n: n^{th} element from the reference N: Total number of elements along the axis

As it is described, phase function (ψ) depends both θ and ϕ angles for an array along x- or y-axis. In this case, one of these angles must be kept constant with respect to the plane (E or H) while other is varied over an appropriate range. This means:

For array along x axis:
$$\psi_x = kd_n \sin\theta \cos\phi + \beta_n$$
 (23)

- x-y (H plane): $\theta = 90 \Rightarrow \psi_x = k d_n cos \phi + \beta_n$
- y-z (E plane): $\phi = 0 \Rightarrow \psi_x = kd_n \sin\theta + \beta_n$

For array along y axis: $\psi_y = kd_n \sin\theta \sin\phi + \beta_n$ (24)

- x-y (H plane): $\theta = 90 \Rightarrow \psi_y = kd_n \sin\phi + \beta_n$
- y-z (E plane): $\phi = 90 \Rightarrow \psi_y = kd_n \sin\theta + \beta_n$

It should be noted that phase delay β_n may be calculated with respect to the method of steering a phased array which can be phase shifting or True Time Delay (TTD). Accordingly,

$$\beta_n = k_0 d_n u$$
 for phase shifting (25)

$$\beta_n = k d_n \mathbf{u}$$
 for TTD (26)

where u may be $cos\phi_0$, $sin\theta_0$, $sin\phi_0$ depending on the axis and plane. $k_0=2\pi/\lambda_0$, $k=2\pi/\lambda$. (λ : The wavelength where TTD is based on, λ_0 : The wavelength the phase shift is based on.

Planar Arrays

In order to obtain the normalized array factor pattern of a planar array, the multiplication of the linear arrays in the relevant axes is required. For instance, for a planar array composed of the elements positioned along x and y axis, the array factor will be:

$$AF = AF_x * AF_y$$

$$\Rightarrow AF = \frac{1}{N_x} \sum_{n=0}^{N_x - 1} e^{j(\psi_x)} * \frac{1}{N_y} \sum_{n=0}^{N_y - 1} e^{j(\psi_y)}$$
(27)

where, N_x : Number of elements along x axis, N_y : Number of elements along y axis, $\psi_x = k d_n sin\theta cos\phi + \beta_n$, $\psi_y = k d_n sin\theta sin\phi + \beta_n$

Total Array Gain

Total array gain can be directly linked to the combination of single antenna gain and the array directivity factor [7] (or commonly called directivity [8-10]) when all the losses are neglected. Accordingly, the gain pattern of an array in the simulation was created by considering the single antenna gain and the directivity factor (DF) as follow:

$$DF = D(\theta, \phi) = \frac{4\pi U(\theta, \phi)}{\int_0^{2\pi} \int_0^{\pi} U(\theta, \phi) \sin\theta d\theta d\phi}$$
(28)

where $U(\theta, \phi)$: Radiation Intensity

The array radiation intensity can also be associated with the square of the array factor [4,7]:

$$DF = D(\theta, \phi) = \frac{4\pi AF^2}{\int_0^{2\pi} \int_0^{\pi} AF^2 \sin\theta d\theta d\phi}$$
 (29)


In case of uniform weighting, the peak directivity of a broadside linear array can be expressed in terms of half power beamwidth (HPBW) [10] as given by the equation 30 to simplify the calculation in particular for non-uniformly spaced array elements. It should be noted that the directivity of an end-fire array is two times higher than a broadside array [1]. Accordingly, a relation between end-fire array's directivity and HPBW can also be expressed via equation 31.

$$D_{broadside\ array} = \frac{101.5}{HPBW\ [^{\circ}]} \tag{30}$$


$$D_{end-fire\ array} = \frac{46535}{HPBW^{2}[°]}$$
 (31)

Array Layout


In the user interface, it is possible to investigate the array factor pattern for three different geometrical configurations which are uniformly spaced array, non-uniformly asymmetrical spaced array and non-uniformly symmetrical array as shown by Figure 3.



a) Uniformly spaced Linear array



b) Non-Uniformly Asymmetrical Linear array



c) Non-Uniformly Symmetrical Linear array

Figure 3. Different Geometrical Configurations

The relation of each distance for non-uniform configurations are associated with 'increase rate' which is mathematically the differences between two successive distances:

increase rate =
$$d_n - d_{n-1}$$

References

- [1] Balanis C. A. Antenna Theory: Analysis and Design (3rd edition), 2005.
- [2] Connor J.D. Antenna Array Synthesis Using the Cross Entropy Method, 2008.
- [3] Reckeweg M. and Rohner C. Antenna Basics, 2015
- [4] Skolnik M. I. Introduction to Radar Systems (2nd edition), 1980.
- [5] Zooghby A. E. Smart Antenna Engineering, 2005.
- [6] Delos P., Broughton B., Kraft J. Phased Array Antenna Patterns—Part 1: Linear Array Beam Characteristics and Array Factor, 2020.
- [7] Stutzman, W.L., Thiele, G.A, Antenna Theory and Design.1981
- [8] Nuttall A. H., Cray. B.A., Approximations to Directivity for Linear, Planar, and Volumetric Apertures and Arrays. 1997.
- [9] Balanis C. A. Antenna Theory: Analysis and Design (3rd edition), 2005.
- [10] Elliot R.S, Antenna Theory and Design.1981