


Tri-State Buffer (Bufoe)

1.10

Features

- Buffer with Output Enable signal
- Feedback signal



General Description

The Tri-State Buffer (Bufoe) component is a non-inverting buffer with an active high output enable signal. When the output enable signal is true, the buffer functions as a standard buffer. When the output enable signal is false, the buffer turns off.

When to Use a Tri-State Buffer

The Tri-State Buffer should be used to interface to a shared bus such as I²C. Tri-State Buffers should not be used for internal logic. Tri-State Buffers can only be used with an I/O pin.

Input/Output Connections

This section describes the various input and output connections for the Tri-State Buffer.

x – Input

Input to the buffer.

oe - Input

This is the output enable connection. When oe is true ('1'), the buffer will be on. When oe is false ('0'), the buffer output is in a high-impedance state.

y - Inout

This connection is connected to the output of the buffer. When oe is true ('1'), this connection is an output, and y has the same value as x. When oe is false ('0'), this connection may be used as an input.

yfb – Output

This is the feedback signal from the y connection. When oe is true ('1') the yfb and y have the same value as x. When oe is false ('0'), yfb has the same value seen at y irrespective of x.

Placement

Each I/O port is limited to four unique output enable signals.

Component Changes

This section lists the major changes in the component from the previous version.

Version	Description of Changes
1.10.f	Minor datasheet edits and updates.
1.10.e	Minor datasheet edits and updates.
1.10.d	Minor datasheet edits and updates.
1.10.c	Minor datasheet edits and updates.
1.10.b	Minor datasheet edits and updates.
1.10.a	Minor datasheet edits and updates.
1.10	The component now consistently has an active high output enable signal. (The previous version was active low for some devices and active high for others.)

© Cypress Semiconductor Corporation, 2009-2017. This document is the property of Cypress Semiconductor Corporation and its subsidiaries, including Spansion LLC ("Cypress"). This document, including any software or firmware included or referenced in this document ("Software"), is owned by Cypress under the intellectual property laws and treaties of the United States and other countries worldwide. Cypress reserves all rights under such laws and treaties and does not, except as specifically stated in this paragraph, grant any license under its patents, copyrights, trademarks, or other intellectual property rights. If the Software is not accompanied by a license agreement and you do not otherwise have a written agreement with Cypress governing the use of the Software, then Cypress hereby grants you a personal, non-exclusive, nontransferable license (without the right to sublicense) (1) under its copyright rights in the Software (a) for Software provided in source code form, to modify and reproduce the Software solely for use with Cypress hardware products, only internally within your organization, and (b) to distribute the Software in binary code form externally to end users (either directly or indirectly through resellers and distributors), solely for use on Cypress hardware product units, and (2) under those claims of Cypress's patents that are infringed by the Software (as provided by Cypress, unmodified) to make, use, distribute, and import the Software solely for use with Cypress hardware products. Any other use, reproduction, modification, translation, or compilation of the Software is prohibited.

TO THE EXTENT PERMITTED BY APPLICABLE LAW, CYPRESS MAKES NO WARRANTY OF ANY KIND, EXPRESS OR IMPLIED, WITH REGARD TO THIS DOCUMENT OR ANY SOFTWARE OR ACCOMPANYING HARDWARE, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE. To the extent permitted by applicable law, Cypress reserves the right to make changes to this document without further notice. Cypress does not assume any liability arising out of the application or use of any product or circuit described in this document. Any information provided in this document, including any sample design information or programming code, is provided only for reference purposes. It is the responsibility of the user of this document to properly design, program, and test the functionality and safety of any application made of this information and any resulting product. Cypress products are not designed, intended, or authorized for use as critical components in systems designed or intended for the operation of weapons, weapons systems, nuclear installations, life-support devices or systems, other medical devices or systems (including resuscitation equipment and surgical implants), pollution control or hazardous substances management, or other uses where the failure of the device or system (including resuscitation equipment and surgical implants), pollution control or hazardous substances management, or other uses where the failure of the device or system, or to affect its safety or effectiveness. Cypress is not liable, in whole or in part, and you shall and hereby do release Cypress from any claim, damage, or other liability arising from or related to all Unintended Uses of Cypress products. You shall indemnify and hold Cypress harmless from and against all claims, costs, damages, and other liabilities, including claims for personal injury or death, arising from or related to any Unintended Uses of Cypress products.

Cypress, the Cypress logo, Spansion, the Spansion logo, and combinations thereof, WICED, PSoC, CapSense, EZ-USB, F-RAM, and Traveo are trademarks or registered trademarks of Cypress in the United States and other countries. For a more complete list of Cypress trademarks, visit cypress.com. Other names and brands may be claimed as property of their respective owners.



Page 2 of 2 Document Number: 001-50451 Rev. *f