# Cairo university Faculty of Engineering Computer Engineering Department

Fall 2022- CMP3010 Computer Architecture Term Project Document

#### Five-stages pipeline processor

Objective

By the end of this project, you will be able to design, implement and test a **Harvard (separate memories for data and instructions)**, **RISC-like, five-stages pipeline** processor, with the specifications as described in the following sections.

## Memory units and registers description

In this project, we apply a Harvard architecture with two memory units; **Instructions' memory** and **Data memory**.

The processor in this project has a RISC-like instruction set architecture. There are eight 2-bytes general purpose registers [ Ro to R7]. These registers are separate from the program counter and the stack pointer registers.

The program counter (PC) spans the instructions memory address space that has a total size of 2 Megabytes. Each memory address has a 16-bit width (i.e., is word addressable). The instructions memory starts with the interrupts area (the very first address space from [0 down to  $2^5$ -1]), followed by the instructions area (starting from [ $2^5$  and down to  $2^{20}$ ]) as shown in Figure.1. By default, the PC is initialized with a value of ( $2^5$ ) where the program code starts.

The other memory unit is the data memory, which has a total size of 4 Kilobytes for its own, 16-bit in width (i.e., is word addressable). The processor can access both memory units at the same time without having a memory access hazard.

The data memory starts with the data area (the very first address space and down), followed by the stack area (starting from  $[2^{11} - 1 \text{ and up}]$ ) as shown in Figure.1. By default, the stack pointer (SP) pointer points to the top of the stack (the next free address available in the stack), and is initialized by a value of  $(2^{11}-1)$ .

When an interrupt occurs, the processor finishes the currently fetched instructions (instructions that have already entered the pipeline), save the processor state (Flags), then the address of the next instruction (in PC) is saved on top of the stack, and PC is loaded from address 0 of the memory where the interrupt code resides.

For simplicity reasons, we will have only one interrupt program, the one which starts at the top of the instruction's memory, but be aware of possible nested interrupts i.e., an interrupt might be raised while executing an interrupt, and your processor should handle all of them successfully.

To return from an interrupt, an RTI instruction loads the PC from the top of stack, restores the processor state (Flags), and the flow of the program resumes from the instruction that was supposed to be fetched in-order before handling the interrupted instruction. **Take care of corner cases like Branching.** 

0 to 2 <sup>5</sup> -1	Interrupts
$2^5$ and down to $2^{20}$ -1	Instructions

0 and down	Data
2 <sup>11</sup> -1 and up	Stack

(Instructions' memory 2 MB in size)

(Data memory 4 KB in size)

Figure.1 Memory Units

## ISA specifications

### A) Registers

R[0:7]<15:0>: Eight 16-bit general purpose registers

PC<31:0> : 32-bit program counter

SP<31:0> : 32-bit stack pointer

CCR<3:0> : condition code register that can be divided to

Z<0>:=CCR<0>: zero flag, change after arithmetic, logical, or shift operations

N<0>:=CCR<1>: negative flag, change after arithmetic, logical, or shift operations

C<0>:=CCR<2> : carry flag, change after arithmetic or shift operations.

#### B) Input-Output

IN.PORT<15:0> : 16-bit data input port

OUT.PORT<15:0>: 16-bit data output port

INTR.IN<0>: a single, non-maskable interrupt

RESET.IN<0>: reset signal

#### C) Other registers to hold the operands and opcodes of the instructions

Rsrc : 1st operand register

Rdst : 2nd operand register and result register field

Imm : Immediate Value

## D) Instructions (some instructions will occupy more than one memory location)

Table 1: ISA

Mnemonic	Function	
	One Operand	
<del>_NOP</del>	PC ← PC + 1	
SETE	C ←1	Setc xxx xxxx
CLRC	C ←0	
NOT Rast	NOT value stored in register Rdst	Clcr xxx xxx
	R[Rdst] $\leftarrow$ 1's Complement(R[Rdst]);	NOT xxx
	If (1's Complement(R[Rdst]) = 0): $Z \leftarrow 1$ ; else: $Z \leftarrow 0$	
	If (1's Complement(R[Rdst]) < 0): N $\leftarrow$ 1; else: N $\leftarrow$ 0	
INC Rdst	Increment value stored in Rdst	
	$R[Rdst] \leftarrow R[Rdst] + 1;$	Inc xxx -
	If $((R[Rdst] + 1) = 0)$ : $Z \leftarrow 1$ ; else: $Z \leftarrow 0$ ;	
	If $((R[Rdst] + 1) < 0)$ : N $\leftarrow$ 1; else: N $\leftarrow$ 0	
_DEC Rdst	Decrement value stored in Rdst	
	$R[Rdst] \leftarrow R[Rdst] - 1;$	Dec xxx
	If $((R[Rdst]-1)=0): Z \leftarrow 1$ ; else: $Z \leftarrow 0$ ;	200 700
	If $((R[Rdst] - 1) < 0)$ : N $\leftarrow$ 1; else: N $\leftarrow$ 0	
OHT Ract	$OUT.PORT \leftarrow R[Rdst]$	Out Rstc :
IN_Rdst	$R[Rdst] \leftarrow IN.PORT$	In xxx Rds
	Two Operands	
MOV Rsrc, Rdst	Move value from register Rsrc to register Rdst	MOV Rsr Rds
ADD Rsrc, Rdst	Add the values stored in registers Rsrc, Rdst	
	and store the result in Rdst	ADD Davis Delist
	If the result =0 then $Z \leftarrow 1$ ; else: $Z \leftarrow 0$ ;	ADD Rsrc Rdst
	If the result <0 then $N \leftarrow 1$ ; else: $N \leftarrow 0$	
SUB Rsrc, Rdst	Subtract the values stored in registers Rsrc, Rdst	
_	and store the result in Rdst	SUB Rsrc Rdst
	If the result =0 then $Z \leftarrow 1$ ; else: $Z \leftarrow 0$ ;	SOD KSIC Kust
	If the result <0 then $N \leftarrow 1$ ; else: $N \leftarrow 0$	
AND Rsrc, Rdst	AND the values stored in registers Rsrc, Rdst	
	and store the result in Rdst	AND DC 5
	If the result =0 then $Z \leftarrow 1$ ; else: $Z \leftarrow 0$ ;	AND RSrc Rdst
	If the result <0 then $N \leftarrow 1$ ; else: $N \leftarrow 0$	
OR Rsrc, Rdst	OR the values stored in registers Rsrc, Rdst	
	and store the result in Rdst	OR Rsrc Rds
	If the result =0 then $Z \leftarrow 1$ ; else: $Z \leftarrow 0$ ;	
	If the result <0 then $N \leftarrow 1$ ; else: $N \leftarrow 0$	
S <mark>HL Rsrc, Im</mark> m	Shift left Rsrc by #Imm bits and store result in same reg	ister SHL xxx R
	Don't forget to update carry	
SHP Rare, hum	Shift right Rsrc by #Imm bits and store result in same reg	gister SHR xxx
	Don't forget to update carry	2

	Memory Operations	
PUSH Rdst	$X[SP] \leftarrow R[Rdst];$	Push Rsrc xxx
POP Rust	$R[ Rdst ] \leftarrow X[++SP];$	
IDM_Rdst, Imm	Load immediate value (15 bit) to register Rdst	LDM xxx Rdst
	R[ Rdst ] ← Imm<15:0>	
LDD Rsrc, Rdst	Load value from memory address Rdst to register Rdst	t LDD Rsrc Rd
	R[ Rdst ] ← M[Rsrc];	
STD Rsrc, Rdst	Store value in register Rsrc to memory location Rdst	STD Rdst Rsrc
	M[Rdst] ←R[Rsrc];	
	Branch and Change of Control Operations	
JZ Rdst	Jump if zero	
	If (Z=1): PC $\leftarrow$ R[ Rdst ]; (Z=0)	
JN Rdst	Jump if negative	
	If $(N=1)$ : PC $\leftarrow$ R[ Rdst ]; $(N=0)$	
JC Rdst	Jump if negative	
	If (C=1): PC $\leftarrow$ R[ Rdst ]; (C=0)	
J <mark>MP Rdst</mark>	Jump	
	PC ←R[ Rdst ]	
CALL Rdst	$(X[SP] \leftarrow PC + 1; sp-2; PC \leftarrow R[Rdst])$	
RET	$sp+2$ , $PC \leftarrow X[SP]$	
RTI	sp+2; PC ← X[SP]; Flags restored	
	Input Signals	
Reset	PC $\leftarrow$ 2 <sup>5</sup> h //memory location of the first instruction	
Interrupt	$X[Sp] \leftarrow PC$ ; $sp-2$ ; $PC \leftarrow 0$ ; Flags preserved	

## [25%] Phase1: Making a simple sequence (pipeline-like) processor [Sunday of week 9]

This phase aims to introduce you to the basic components that build the 5-stages pipeline, namely (Fetch -Decode-Execute-Memory-Write Back). So, as a starting point, we will simulate a simple pipeline that issues new instruction after 5-time steps. In every time step, the instruction passes through one of the stages. Each instruction should walk through the complete 5 stages even if it doesn't need to do anything in some of the stages. A new instruction enters only after the previous instruction is completed.

This phase implements no hazards, no branches and no concurrent execution of instructions.

This phase has to implement only the following five instructions using their description in Table.1 above:

- 1. LDD Rsrc, Rdst
- 2. STD Rsrc, Rdst
- 3. ADD Rsrc, Rdst
- 4. NOT Rdst
- 5. NOP

Since this is a temporary phase, we will use temporary opcodes of these instructions that can be changed later in phases 2 and 3. The opcodes are as follows:

- LDD [001]
- STD [010]
- ADD [011]
- NOT [100]
- NOP [101]

You are asked to write your own testbench that tests the instruction memory that includes the below instructions **in order**, and get (and show that) your registers, memory, and condition code register are affected accordingly. (use any reasonable values in the memory).

- 1. LDD R1,0h
- 2. LDD R2,2h
- 3. NOP
- 4. ADD R2,R1
- 5. NOT R1
- 6. STD R2,R1

## [25%] Phase2: Designing a complete 5-stages concurrent pipeline processor [Sunday of week 9]

In this phase, you will deliver a **design report** for your concurrent pipelined 5-stages processor.

The processor issues one instruction each cycle, and should be able to handle possible **hazards**, data forwarding, stalling, interrupts and branches with **static branch prediction** for prediction branches.

You should design and deliver a paper report (not software) containing the following:

- Instructions' format of your design
  - Opcode of each instruction.
  - Instruction bits details.
- Schematic diagram of the processor with data flow details
  - ALU / Registers / Memory Blocks.
  - Dataflow Interconnections between Blocks & its sizes.
  - Control Unit detailed design.
- Pipeline stages design
  - Pipeline registers details (Size, Input, Connection, ...).
  - Types of hazards in your design and your solution to them.
  - Data Forwarding.
  - Static Branch Prediction.

## [50%] Phase3: Final delivery of working 5-stages concurrent pipeline processor [Sunday of week 13]

In this phase, you should:

- Implement and integrate your processor containing:
  - Verilog Implementation of each component of the processor.
  - A Verilog file that integrates the different components in a single module.

- A simulation test code that reads a program file and execute it on the processor that.
  - Setups the simulation wave
  - Loads Memory Files & Run the test program
- An assembler code that converts assembly program (Text File) into machine code according to your design (Memory File).
- A report that contains any design changes after phase2
- A report that contains pipeline hazards considered and how your design solves it.

## Common design mistakes in phase 3:

Here are some of the design and implementation mistakes that you should avoid in your projects:

- Intermediate buffers and registers should not operate on the same clock edge, otherwise data will be late one cycle. Same for memory and intermediate buffers.
- Stalling and flushing are not the same thing, make sure to understand the difference.

### Project testing

- You will be given different test programs. You are required to compile and load it onto the memories and **reset** your processor to start executing from memory location 2<sup>5</sup>h. Each program would test some instructions (you should notify the TA if you haven't implemented or have logical errors concerning some of the instruction set).
- You MUST prepare a waveform using do files with the main signals showing that your processor is working correctly (RO-R7, PC, SP, Flags, CLK, Reset, Interrupt, IN. port, Out.port).

### Phase 3 evaluation criteria

In phase3, each project will be evaluated according to:

- The number of instructions that are functioning correctly.
- Pipelining hazards handled in the design.
- Efficient handling of the hazards.
- The branch prediction.
- Failing to implement a working processor will nullify your project grade. No credits will be given to individual modules or a non-working processor.
- Unnecessary latching or very poor understanding of underlying hardware will be penalized.
- Individual Members of the same team can have different grades, you can get a zero grade if you
  didn't work while the rest of the team can get full mark, make sure you balance your work
  distribution.

### Team members

• Each team shall consist of a maximum of four members.

### General advices

- 1. Compile your design on regular bases (after each modification) so that you can figure out new errors early. Accumulated errors are harder to track.
- 2. Use the engineering sense to back trace the error source.

- 3. As much as you can, don't ignore warnings.
- 4. Read the transcript window messages in Modelsim carefully.
- 5. After each major step, and if you have a working processor, save the design before you modify it (use versioning tool if you can as git & svn).
- 6. Always save the ram files to easily export and import them.
- 7. Start early and give yourself enough time for testing.
- 8. Integrate your components incrementally (i.e.: Integrate the memory with the registers, then integrate with them the ALU ...).
- 9. Use coding convention to know each signal functionality easily.
- 10. Try to simulate your control signals sequence for an instruction (i.e.: Add) to know if your timing design is correct.
- 11. There is no problem in changing the design after phase1, but justify your changes.
- 12. Always reset all components at the start of the simulation.
- 13. Don't leave any input signal float "U", set it with 0 or 1.
- 14. Remember that your Verilog code is a HW system (logic gates, Flipflops and wires).
- 15. Use Do files instead of re-forcing all inputs each time

