KIM-1 Quick Reference

For the MOS Technology KIM-1 Microcomputer Module

Jeff Tranter < tranter@pobox.com >

NMI Initialization for Single Step and Stop

17FA 00 17FB 1C

IRQ Initialization for BRK

17FE 00 17FF 1C

Machine context (saved/restored by ST/GO)

00EF PC low 00F0 PC high 00F1 Status Register (flags) 00F2 Stack Pointer 00F3 A 00F4 Y 00F5 X

Cassette Load and Save

Note: 12V power is required when reading tapes.

To save:

- 1. Store \$00 in \$00F1 (to ensure CPU is in decimal mode).
- 2. Save start address (low/high) in \$17F5, \$17F6.
- 3. Save end eddress+1 (low/high) in \$17F7, \$17F8.
- 4. Write tape ID (\$01-\$FE) in \$17F9.
- 5. Start tape in record mode.
- 6. Run address \$1800 (DUMPT) to save.

To load:

- 1. Store \$00 in \$00F1 (to ensure CPU is in decimal mode).
- 2. Write tape ID (\$01-\$FE, \$00 loads any ID, \$FF loads using start address values) to \$17F9.
- 3. Run address \$1873 (LOADT) to load.

Teleprinter Commands

Press < Rubout > or < Delete > after Reset to initialize serial bit rate.

<hex address> <space> Show data at address <hex data> . Write to current address <Return> Advance to next address <Line Feed> Move to previous address <Rub Out> Terminate memory edit L

Load program from paper tape

O Save memory to paper tape (saves from current address to \$17F7, \$17F8)

Go from current address G

2015-02-08 Page 1 of 4

Memory Map

Range	Comments	
\$0000-\$00FF	RAM - page zero (\$00EF, \$00FF are reserved)	
\$0100-\$01FF	RAM - stack	
\$0200-\$03FF	RAM - user programs	
\$0400-\$16FF	Reserved for RAM expansion	
\$1700-\$17FF	RAM/IO/TIMER chips	
\$1700-\$173F	Application I/O and timer	
\$1740-\$177F	KIM I/O and timer	
\$1780-\$17BF	Application RAM	
\$17C0-\$17E6	Application RAM	
\$17E7-\$17FF	KIM RAM	
\$1800-\$1FFF	ROM (2K)	
\$2000-\$FFFF	Reserved for expansion	

Useful ROM Routines

Name	Address	Description
OK	\$1EFE	Check for key depressed. A<>0 No key down. A = 0 Key down.
CRLF	\$1E2F	Send CRLF to TTY.
GETBYT	\$1FD9	Get 2 hex characters from TTY and return them packed in A.
GETCH	\$1E5A	Get one ASCII character from TTY and return in A.
GETKEY	\$1F6A	Return key from keyboard. Value 0-F, 10(AD), 11(DA), 12(+), 13(GO), 14(PC), 15 (no keypress).
OUTCH	\$1EA0	Print ASCII character in A on TTY.
OUTSP	\$1E9E	Print space on TTY.
PRTBYT	\$1E3B	Prints A as 2 hex characters.
PRTPNT	\$1E1E	Prints contents of FB, FA on TTY.
SCANDS	\$1F1F	Output six hex characters on display. Stored in \$00F9, \$00FA, \$00FB.

2015-02-08 Page 2 of 4

Connector Pinouts

Conn	Connector A (lower) Application Connector. Pins A-Z on bottom, 1-22 on top						
Pin	Signal	Pin	Signal				
22	KB Col D	Z	KB Row 1				
21	KB Col A	Y	KB Col C				
20	KB Col E	X	KB Row 2				
19	KB Col B	W	KB Col G				
18	KB Col F	V	KB Row 3				
17	KB Row 0	U	TTY PTR				
16	PB5	Т	TTY KYBD				
15	PB7	S	TTY PTR RTRN(+)				
14	PA0	R	TTY KYBD RTRN(+)				
13	PB4	P	AUDIO OUT HI				
12	PB3	N	+12V				
11	PB2	M	AUDIO OUT LO				
10	PB1	L	AUDIO IN				
9	PB0	K	DECODE ENAB				
8	PA7	J	K7				
7	PA7	Н	K5				
6	PA5	F	K4				
5	PA4	Е	К3				
4	PA1	D	K2				
3	PA2	С	K1				
2	PA3	В	К0				
1	VSS GND	A	VCC +5V				
Connector B (upper) Expansion Connector. Pins A-Z on bottom, 1-22 on top.							
Pin	Signal	Pin	Signal				
22	VSS GND	Z	RAM/R/W				
21	VCC +5V	Y	/Ø2				
20		X	PLL TEST				
19		W	/R/W				
18		V	R/W				
17	SST OUT	U	Ø2				
16	K6	Т	AB15				
15	DB0	S	AB14				
14	DB1	R	AB13				

2015-02-08 Page 3 of 4

KIM-1 Quick Reference

13	DB2	P	AB12
12	DB3	N	AB11
11	DB4	M	AB10
10	DB5	L	AB9
9	DB6	K	AB8
8	DB7	J	AB7
7	RST	Н	AB6
6	NMI	F	AB5
5	R0	E	AB4
4	IRQ	D	AB3
3	Ø1	С	AB2
2	RDY	В	AB1
1	SYNC	A	AB0

2015-02-08 Page 4 of 4