## **Slot Allocation:**

Slot	Function	Slot	Function
0	Language card	1	Printer serial port
2	Modem serial port, 3 <sup>rd</sup> and 4 <sup>th</sup> hard drives	3	80 column card
4	Mouse (//c)	5	"Easter Egg" in early ROMs, external floppy/HDD later ROMs
6	Internal and external floppy drives	7	Mouse (//c Plus)

**Memory Map:** 

riemory wap.						
RAM						
Zero Page						
Stack						
Text/Low Resolution Graphics Video Page 1						
Text/Low Resolution Graphics Video Page 2						
High Resolution Graphics Video Page 1						
000 - \$5FFF High Resolution Graphics Video Page 2						
I/O						
Soft Switches and Status Locations						
Peripheral Card Memory						
Extended Memory for Peripheral Card in Use						
ROM/Bank-Switched RAM						
Bank-Switched RAM (2 Banks RAM, 1 Bank ROM)						
Bank-Switched RAM (1 Bank RAM, 1 Bank ROM)						

# **Common Addresses:**

Hex	Decimal	Function	
\$0020	32	Left margin of text window	
\$0021	33	Text window width	
\$0022	34	Top margin of text window	
\$0023	35	Bottom margin of text window	
\$0024	36	Cursor column	
\$0025	37	Cursor row	
\$004C, 4D	76,77	Integer Basic HIMEM	
\$0069, 6A	105, 106	Applesoft and Integer Basic LOMEM	
\$0073,74	115,116	Applesoft HIMEM	
\$C000	-16384	Read to get keyboard character (>127 means key pressed)	
\$C00E	-16370	Read to set primary character set	
\$C00F	-16369	Read to set secondary character set	

Hex	Decimal	Function
\$C010	-16368	Write to clear keyboard strobe
\$C01A	-16358	Read for mode (<128 graphics, >127 text)
\$C01B	-16357	Read for text window (<128 absent, >127 present)
\$C01C	-16356	Read for screen page (<128 page 1, >127 page 2)
\$C01D	-16355	Read for graphics mode (<128 low-res, >127 hi-res)
\$C01E	-16354	Read for character set status (<128 primary, >127 alternate)
\$C020	-16352	Read to toggle cassette output (not on Apple //c)
\$C030	-16336	Read to toggle speaker
\$C050	-16304	Read to set graphics mode
\$C051	-16303	Read to set text mode
\$C052	-16302	Read to set full screen graphics
\$C053	-16301	Read to set graphics plus text
\$C054	-16300	Read to set graphics page 1
\$C055	-16299	Read to set graphics page 2
\$C056	-16298	Read to set low resolution graphics
\$C057	-16297	Read to set high resolution graphics
\$C058	-16296	Read to set annunciator 0 off
\$C059	-16295	Read to set annunciator 0 on
\$C05A	-16294	Read to set annunciator 1 off
\$C05B	-16293	Read to set annunciator 1 on
\$C05C	-16292	Read to set annunciator 2 off
\$C05D	-16291	Read to set annunciator 2 on
\$C05E	-16290	Read to set annunciator 3 off
\$C05F	-16289	Read to set annunciator 3 on
\$C060	-16288	Read to get cassette tape input level (Not on Apple //c)
\$C061	-16287	Read for pushbutton 0 status (<127 not pressed, >127 pressed)
\$C062	-16286	Read for pushbutton 1 status (<127 not pressed, >127 pressed)
\$C063	-16285	Read for pushbutton 2 status (<127 not pressed, >127 pressed)
\$C064	-16284	Read for pushbutton 3 status (<127 not pressed, >127 pressed)
\$C070	-16272	Read/write to trigger game control connector strobe output once/twice
\$FF69	-151	Enter monitor

#### **Common Keyboard Commands:**

Key	Function		
<control>-<reset></reset></control>	Halt current program		
<control>-<open apple="">-<reset></reset></open></control>	Halt and reboot		
<esc><control>-Q</control></esc>	Leave 80-column mode		
<control>-X</control>	Cancel line		
<esc>E</esc>	Delete to end of line		
<esc>F</esc>	Delete to end of screen		
<esc>@</esc>	Clear screen		

BASIC Keywords: (<sup>1</sup>=Integer BASIC only, <sup>A</sup>=Applesoft only, <sup>D</sup>=DOS, <sup>P</sup>=ProDOS)

Di 1010 Itcy W	or ass ( integer	District Unity, 1	ippicsort only,	DOO, ITODOC	<u>')                                    </u>	
_P	? <sup>A</sup>	APPEND <sup>D,P</sup>	AUTO <sup>I</sup>	BLOAD <sup>D,P</sup>	BRUN <sup>D,P</sup>	BSAVE <sup>D,P</sup>
CALL	CAT <sup>P</sup>	CATALOG <sup>D,P</sup>	CHAIN <sup>D,P</sup>	CLEAR <sup>A</sup>	CLOSE <sup>D,P</sup>	CLR <sup>I</sup>
COLOR	CONI	CONT <sup>A</sup>	CREATE <sup>P</sup>	DATA	DEFFN <sup>A</sup>	DEL
DELETE <sup>D,P</sup>	DIM	DRAW <sup>A</sup>	DSP <sup>I</sup>	END	EXEC <sup>D,P</sup>	FLASH <sup>A</sup>
FLUSH <sup>P</sup>	FOR	FP <sup>I,D</sup>	FREP	GET <sup>A</sup>	GOSUB	GOTO
GR	HCOLOR <sup>A</sup>	HGR <sup>A</sup>	HGR2 <sup>A</sup>	HLIN	нмем:	HOME <sup>A</sup>
HPLOT <sup>A</sup>	HTAB <sup>A</sup>	IF-THEN	IN#	INIT <sup>D</sup>	INPUT	INVERSE <sup>A</sup>
LET	LIST	LOAD <sup>D,P</sup>	LOCK <sup>D,P</sup>	LOMEM:	MAN <sup>I</sup>	MAXFILES <sup>D</sup>
MON <sup>D</sup>	NEW	NEXT	NODSPI	NOTRACE	NOMON <sup>D</sup>	NORMAL <sup>A</sup>
ON <sup>A</sup>	ONERR <sup>A</sup>	OPEN <sup>D,P</sup>	PDL	PEEK	PLOT	POKE
POP <sup>A</sup>	POSITION <sup>D,P</sup>	PR#	PREFIX <sup>P</sup>	PRINT	READ <sup>D,P</sup>	RECALL <sup>A</sup>
REM	RENAME <sup>D,P</sup>	RESTORE <sup>P</sup>	RESUME <sup>A</sup>	RETURN	RT <sup>A</sup>	RUN <sup>D,P</sup>
SAVE <sup>D,P</sup>	SCALE <sup>A</sup>	SHLOAD <sup>A</sup>	SPEED <sup>A</sup>	STOP <sup>A</sup>	STORE <sup>P</sup>	TAB <sup>I</sup>
TEXT	TRACE	UNLOCK <sup>D,P</sup>	USR	VERIFY <sup>D</sup>	VLIN	VTAB
WAIT <sup>A</sup>	WRITE <sup>D,P</sup>	XDRAW <sup>A</sup>				
	1	1	I .	1	1	1

### **BASIC Functions:**

ABS	ASC	ATN <sup>A</sup>	CHR\$ <sup>A</sup>	COS <sup>A</sup>	EXP <sup>A</sup>	$FN^A$
FRE <sup>A</sup>	INT <sup>A</sup>	LEFT\$A	LEN	LOG <sup>A</sup>	MID\$ <sup>A</sup>	PDL
PEEK	POS <sup>A</sup>	RIGHT\$ <sup>A</sup>	RND	SCRN	SGN	SIN <sup>A</sup>
SPC <sup>A</sup>	SQR <sup>A</sup>	STR\$ <sup>A</sup>	TAB <sup>A</sup>	USR <sup>A</sup>	VAL <sup>A</sup>	

## **Monitor Commands:**

	<control>-C Return (e.g. to BASIC)</control>	
<slot><control>-P Send output to/activate device in slot <slot></slot></control></slot>		Send output to/activate device in slot <i><slot></slot></i>
	<slot><control>-K</control></slot>	Accept input from device in slot <slot></slot>

Display contents of address < <i>a</i> >
Display contents of next 8 bytes of memory
Display range of memory from <a> to <b></b></a>
Examine registers. Can then change values using : <i>a x y p s</i>
Modify memory locations starting at address $<$ a $>$ . Omit $<$ a $>$ to use next address. Prefix data with ' and follow by space to enter a character.
Write memory to tape (not on Apple //c)
Read memory from tape (not on Apple //c)
Move (copy) memory
Step one instruction from address <a> and display registers. Omit <a> to step next instruction. (later ROMs only)</a></a>
Trace instructions from address <a> until BRK instruction or Closed-Apple key pressed. Press Open-Apple key to slow down speed of trace. (later ROMs only)</a>
Verify memory
Go to address <a></a>
Disassemble code from address < <i>a</i> >
Set inverse video
Set normal video
Add hex numbers
Subtract hex numbers
Jump to user-defined routine at \$03F8
Enter mini-assembler (later ROMs only)

## **Mini-Assembler Commands:**

\$ <monitor command=""></monitor>	Run monitor command (early ROM only)	
<mnem> <operands></operands></mnem>	Assemble instruction at current address	
<addr>:<mnem> <operands></operands></mnem></addr>	Assemble instruction at specific address	
<return></return>	Empty line returns to monitor	

### **Common 80 Column Card Control Characters:**

7	Beep speaker	8	Cursor left	10	Cursor down
11	Clear screen from cursor	12	Clear screen	14	Set normal video
15	Set inverse video	17	Set active-40 mode	18	Set active-80 mode
21	Leave 80 column mode	22	Scroll down	23	Scroll up
24	Deactivate Mousetext	25	Cursor home	26	Clear line
27	Activate Mousetext	28	Cursor right	29	Clear to end of line

**Prompts:** 

>	Integer BASIC	]	Applesoft	*	Monitor	!	Mini-Assembler			
Lo-I	Lo-Res Graphics Colors:									
0	Black	1	Magenta	2	Dark Blue	3	Purple			
4	Dark Green	5	Grey 1	6	Medium Blue	7	Light Blue			
8	Brown	9	Orange	10	Grey 2	11	Pink			
12	Light Green	13	Yellow	14	Aqua	15	White			

**Hi-Res Graphics Colors:** 

0	Black	1	Green	2	Purple	3	White	
4	Black	5	Orange	6	Blue	7	White	

#### **AppleCommander Command Line Options:**

_i	<imagename></imagename>	[ <imagename>]</imagename>	display	, information	about image(s).
I	\IIIIagciiaiiic/	\limagchanic/	uispia	minominanon	about mage(3).

- -ls <imagename> [<imagename>] list brief directory of image(s).
- -l <imagename> [<imagename>] list directory of image(s).
- -ll <imagename> [<imagename>] list detailed directory of image(s).
- -e <imagename> <filename> [<output>] export file from image to stdout or to an output file.
- -x <imagename> [<directory>] extract all files from image to directory.
- -g <imagename> <filename> [<output>] get raw file from image to stdout or to an output file.
- -p <imagename> <filename> <type> [[\$|0x]<addr>] put stdin in filename on image, using file type and address [0x2000].
- -d <imagename> <filename> delete file from image.
- -k <imagename> <filename> lock file on image.
- -u <imagename> <filename> unlock file on image.
- -n <imagename> <volname> change volume name (ProDOS or Pascal).
- -cc65 <imagename> <filename> <type> put stdin with cc65 header in filename on image
- -geos <imagename> interpret stdin as a GEOS conversion file and place it on image (ProDOS only).
- -dos140 <imagename> create a 140K DOS 3.3 image.
- -pro140 <imagename> <volname> create a 140K ProDOS image.
- -pro800 <imagename> <volname> create an 800K ProDOS image.
- -pas140 <imagename> <volname> create a 140K Pascal image.
- -pas800 <imagename> <volname> create an 800K Pascal image.
- -convert <filename> <imagename> [<sizeblocks>] uncompress a ShrinkIt or Binary II file or convert a DiskCopy 4.2 image into a ProDOS disk image.

#### Using ADT Pro with Apple //c:

Serial speed: 9600bps, 8N1, no h/w or s/w handshaking.

Initialize serial port: IN#2 <Control>A 14 B

Serial file transfer from Linux: ascii-xfr -s -l 50 -c 20 *filename* >/dev/ttyUSB0