			Frequencies				
	Mode number	Number of	Frequency	Frequency	Std Dev	Frequency	
Step		transients	(LMS)	(CWT)	(CWT)	(CWT2)	
		(CWT)	$_{ m Hz}$	$_{ m Hz}$	${ m Hz}$	$_{ m Hz}$	
	1	1	8.35	8.37	/	/	
P_0	2	3	33.94	33.93	0.01	33.93	
	3	2	36.78	36.76	0.06	36.70	
	1	2	11.12	11.05	0.00	/	
P_6	2	1	31.20	31.32	/	/	
	3	2	32.84	32.81	0.03	/	
	4	1	37.37	37.25	/	/	
P_7	1	3	10.99	11.02	0.02	/	
	2	5	28.36	28.23	0.11	28.14	
	3	8	34.20	34.15	0.09	34.18	

			Dampings					
Step	Mode number	Number of	Damping	Damping	Std Dev	Damping		
		transients	(LMS)	(CWT)	(CWT)	(CWT2)		
		(CWT)	%	%	%	%		
P_0	1	1	1.64	1.17	/	/		
	2	3	0.43	0.29	0.15	0.48		
	3	2	0.57	0.56	0.32	0.46		
P_6	1	2	0.64	0.54	0.08	/		
	2	1	0.36	0.51	/	/		
	3	2	0.66	0.27	0.03	/		
	4	1	0.60	0.42	/	/		
P_7	1	3	0.61	0.82	0.25	/		
	2	5	0.67	0.66	0.19	0.87		
	3	8	0.58	0.70	0.16	0.64		

			Modal Shapes						
Step	Mode number	Number of transients (CWT)	MAC (CWT × LMS)	$\begin{array}{c} \text{MAC} \\ (\text{CWT2} \\ \times \text{LMS}) \\ \% \end{array}$	$\begin{array}{c} \text{MAC} \\ (\text{CWT2} \\ \times \text{CWT}) \end{array}$	$\begin{bmatrix} \tilde{I}_{np} \\ (\text{LMS}) \\ \% \end{bmatrix}$	$\begin{array}{c} \tilde{I}_{np} \\ (\text{CWT}) \\ \% \end{array}$	Std Dev (CWT)	$\begin{pmatrix} \tilde{I}_{np} \\ (\text{CWT2}) \\ \% \end{pmatrix}$
P_0	1	1	99.73	/	/	2.46	1.39	/	/
	2	3	99.98	99.94	99.88	7.10	7.90	0.81	7.21
	3	2	98.91	99.11	99.52	5.50	3.93	3.50	4.31
P_6	1	2	100.00	/	/	0.23	0.29	0.26	/
	2	1	99.94	/	/	1.34	1.07	/	/
	3	2	99.92	/	/	1.09	1.43	0.04	/
	4	1	98.96	/	/	5.75	5.51	/	/
P ₇	1	3	99.99	/	/	0.46	0.61	0.39	/
	2	5	99.96	97.65	97.59	0.65	1.56	1.78	3.21
	3	8	91.08	84.49	97.30	31.32	3.86	2.89	2.83